

## COOLING SYSTEM

---

Check the radiator air passages for clogging or damage.

Straighten bent fins, and remove insects, mud or other obstructions with compressed air or low water pressure.

Replace the radiator if the air flow is restricted over more than 20% of the radiating surface.

Inspect the water hoses for cracks or deterioration, and replace them if necessary.

[Check the tightness of all water hose band screws](#).

