

## REMOVAL/INSTALLATION

### Remove the rear carrier.

Remove the following:

- Tapping screws [1]
- Rear center cowl socket bolts [2]
- Rear center cowl [3]
- Well nuts [4]

Installation is in the reverse order of removal.

#### **TORQUE:**

<b>Rear center cowl socket bolt:</b>
--------------------------------------

<b>0.42 N·m (0.04 kgf·m, 0.3 lbf·ft)</b>
--

