

## MECHANICAL SEAL INSPECTION

[Remove the under cover.](#)

Check the water pump bleed pipe [1] for signs of coolant leakage.

**NOTE:**

- A small amount of coolant weeping from the bleed pipe is normal.
- Make sure that there is no continuous coolant leakage from the bleed pipe while operating the engine.

Replace the water pump as an assembly if necessary.

[Install the under cover.](#)

