

## REMOVAL/INSTALLATION

### Remove the oil strainer.

Remove the oil pump mounting bolts [1] and oil pump [2].

Installation is in the reverse order of removal.

#### **TORQUE:**

<b>Oil pump mounting bolt:</b>
--------------------------------

<b>16 N·m (1.6 kgf·m, 12 lbf·ft)</b>
--------------------------------------

#### **NOTE:**

- Align the oil pump driven shaft end with the oil pump drive shaft groove.

