

## REMOVAL

Remove the right crankcase cover:

- [MT model:](#)
- [DCT model:](#)

Remove the coolant drain bolt [1] and sealing washer [2].

Remove the water pump cover bolts [3] and water pump body [4].

