

## BATTERY REMOVAL/INSTALLATION

### Remove the main seat.

Turn the ignition switch OFF.

Remove the bolt [1] and disconnect the battery negative (-) cable [2] first.

Then remove the bolt [3] and disconnect the battery positive (+) cable [4].

Release the band [5].

Remove the battery [6].

Install the battery in the reverse order of removal.

### **NOTE:**

- Connect the battery positive (+) cable first and then the negative (-) cable.

