

REMOVAL/INSTALLATION

Remove the rear side cowl.

Remove the following:

- Rear carrier bolts [1]
- Washers [2]
- Rear carrier [3]

Installation is in the reverse order of removal.

TORQUE:
Rear carrier bolt:
35 N·m (3.6 kgf·m, 26 lbf·ft)

