

FUEL LEVEL SENSOR REMOVAL/INSTALLATION

Remove the fuel tank.

Remove the nuts [1].

Remove the fuel level sensor [2] and O-ring [3].

Installation is in the reverse order of removal.

NOTE:

- Replace the O-ring with a new one.
- Apply engine oil to a new O-ring.
- Align the sensor plate hole [4] with the tank boss.

