

## RELAY INSPECTION

### [Remove the TBW relay.](#)

Connect an ohmmeter to the TBW relay [1] terminals as shown.

Connect a 12 V battery to the TBW relay terminals as shown.

There should be continuity only when 12 V battery is connected.

If there is no continuity when the 12 V battery is connected, replace the TBW relay.

### [Install the TBW relay.](#)

