

REMOVAL/INSTALLATION

Support the motorcycle securely using a hoist or equivalent.

Remove the mainstand return springs [1].

Remove the circlip [2].

Remove the mainstand [3] by its sliding to the right side from the frame [4].

Installation is in the reverse order of removal.

NOTE:

- Apply the molybdenum disulfide grease to the contact area of the spring plate [5], main stand spring plate [6] and frame.
- [Refer to the Cable and Harness Routing for the mainstand return spring installation direction](https://www.ecom.honda-eu.com/gma10/EMM/Contents/rel/sm/KF016394/html/S2MLF000A020041S2MLF000B020067.html).
- Replace the circlip with a new one.

