

FUEL LEVEL SENSOR INSPECTION

[Remove the fuel level sensor.](#)

Connect the ohmmeter to the fuel level sensor 2P (Black) connector [1].

CONNECTION: Red/blue – Green

Measure the resistance with the float [2] at the full and empty positions.

	FULL	EMPTY
Resistance	6 – 10 Ω	434 – 446 Ω

[If it is out of specification, replace the fuel level sensor.](#)

