

REMOVAL/INSTALLATIONRemove the front cowl.

Release the open air temperature connector cover [1] from the headlight unit.

Disconnect the open air temperature sensor 2P (Black) connector [2].

Remove the bolts [3].

Disconnect the headlight 6P (Black) connectors [4].

Remove the headlight unit [5].

Remove the collars [6] and grommets [7] from the headlight unit.

Installation is in the reverse order of removal.

NOTE:

- Route the wires properly.
- Put the open air temperature sensor connector cover to the center groove on the headlight unit when installing.



