


INSTALLATION

Install the side collars [1] to the front wheel.




Apply a thin coat of grease to the front axle sliding surface.
Install the front wheel between the forks.

NOTE:

- Be careful not to damage the pulser ring.

Install the front axle [1] from the right side.




Install and tighten the front axle nut [1] to the specified torque.

TORQUE: 59 N·m (6.0 kgf·m, 44 lbf·ft)

Tighten the left front axle holder pinch bolts [2] to the specified torque.

TORQUE: 27 N·m (2.8 kgf·m, 20 lbf·ft)




Apply locking agent to the front brake caliper mounting bolt [1] threads.

Install the front brake calipers [2] and new front brake caliper mounting bolts.

Tighten the front brake caliper mounting bolts to the specified torque.

TORQUE: 45 N·m (4.6 kgf·m, 33 lbf·ft)

With the front brake applied, pump the forks up and down several times to seat the axle and check brake operation.



Tighten the right front axle holder pinch bolts [1] to the specified torque.

TORQUE: 27 N·m (2.8 kgf·m, 20 lbf·ft)

[Check the clearance gap between the front wheel speed sensor bracket and pulser ring.](#)

