

FUEL PRESSURE NORMALIZATION

1. Connect the fuel pump unit 5P (Black) connector [1].
[Connect the battery negative \(-\) cable.](#)
2. Turn the ignition switch ON.
The fuel pump will run for about 2 seconds and fuel pressure will rise.
NOTE:
 - Do not start the engine.
3. Turn the ignition switch OFF.
4. Repeat previous step 2 or 3 times, and check that there is no leakage in the fuel supply system.
5. [Install the fuel tank.](#)

