

REMOVAL


[Drain the engine oil.](#)

[Drain the coolant.](#)

[Remove the right rear engine cover.](#)

Loosen the lock nut [1] and lower adjusting nut [2].

Disconnect the clutch cable [3] from the clutch lifter lever [4].




Cut off and remove the hose clamp [1].

Disconnect the bypass hose [2].

Loosen the hose band screw [3].


Disconnect the radiator lower hose [4].



Remove the right crankcase cover bolts [1].
Turn the clutch lifter lever [2] counterclockwise to disengage the lifter lever slit from the clutch lifter pin.
Remove the right crankcase cover [3].


NOTE:

- Be careful not to drop the return spring.



Remove the dowel pins [1] and gasket [2].





Remove the O-ring [1].

