

HEADLIGHT AIM

Place the motorcycle on a level surface.

Adjust the headlight aim vertically by turning the vertical beam adjusting screw [1].

Adjust horizontally by turning the horizontal adjusting screws [2].

NOTE:

- Adjust the headlight beam as specified by local laws and regulations.

