

QEMU version 4.2.50 User Documentation

Table of Contents

- [1 Introduction](#)
 - [1.1 Features](#)
- [2 QEMU PC System emulator](#)
 - [2.1 Introduction](#)
 - [2.2 Quick Start](#)
 - [2.3 Invocation](#)
 - [2.3.1 Standard options](#)
 - [2.3.2 Block device options](#)
 - [2.3.3 USB options](#)
 - [2.3.4 Display options](#)
 - [2.3.5 i386 target only](#)
 - [2.3.6 Network options](#)
 - [2.3.7 Character device options](#)
 - [2.3.8 TPM device options](#)
 - [2.3.9 Linux/Multiboot boot specific](#)
 - [2.3.10 Debug/Expert options](#)
 - [2.3.11 Generic object creation](#)
 - [2.3.12 Device URL Syntax](#)
 - [2.4 Keys in the graphical frontends](#)
 - [2.5 Keys in the character backend multiplexer](#)
 - [2.6 QEMU Monitor](#)
 - [2.6.1 Commands](#)
 - [2.6.2 Integer expressions](#)
 - [2.7 CPU models](#)
 - [2.7.1 Recommendations for KVM CPU model configuration on x86 hosts](#)
 - [2.7.1.1 Preferred CPU models for Intel x86 hosts](#)
 - [2.7.1.2 Important CPU features for Intel x86 hosts](#)
 - [2.7.1.3 Preferred CPU models for AMD x86 hosts](#)
 - [2.7.1.4 Important CPU features for AMD x86 hosts](#)
 - [2.7.1.5 Default x86 CPU models](#)
 - [2.7.1.6 Other non-recommended x86 CPUs](#)
 - [2.7.2 Supported CPU model configurations on MIPS hosts](#)
 - [2.7.2.1 Supported CPU models for MIPS32 hosts](#)
 - [2.7.2.2 Supported CPU models for MIPS64 hosts](#)
 - [2.7.2.3 Supported CPU models for nanoMIPS hosts](#)
 - [2.7.2.4 Preferred CPU models for MIPS hosts](#)
 - [2.7.3 Syntax for configuring CPU models](#)
 - [2.7.3.1 QEMU command line](#)
 - [2.7.3.2 Libvirt guest XML](#)
 - [2.8 Disk Images](#)
 - [2.8.1 Quick start for disk image creation](#)
 - [2.8.2 Snapshot mode](#)
 - [2.8.3 VM snapshots](#)
 - [2.9 Network emulation](#)
 - [2.9.1 Using TAP network interfaces](#)
 - [2.9.1.1 Linux host](#)
 - [2.9.1.2 Windows host](#)

- [2.9.2 Using the user mode network stack](#)
 - [2.9.3 Hubs](#)
 - [2.9.4 Connecting emulated networks between QEMU instances](#)
- [2.10 Other Devices](#)
 - [2.10.1 Inter-VM Shared Memory device](#)
 - [2.10.1.1 Migration with ivshmem](#)
 - [2.10.1.2 ivshmem and hugepages](#)
- [2.11 Direct Linux Boot](#)
- [2.12 USB emulation](#)
 - [2.12.1 Connecting USB devices](#)
 - [2.12.2 Using host USB devices on a Linux host](#)
- [2.13 VNC security](#)
 - [2.13.1 Without passwords](#)
 - [2.13.2 With passwords](#)
 - [2.13.3 With x509 certificates](#)
 - [2.13.4 With x509 certificates and client verification](#)
 - [2.13.5 With x509 certificates, client verification and passwords](#)
 - [2.13.6 With SASL authentication](#)
 - [2.13.7 With x509 certificates and SASL authentication](#)
 - [2.13.8 Configuring SASL mechanisms](#)
- [2.14 TLS setup for network services](#)
 - [2.14.1 Setup the Certificate Authority](#)
 - [2.14.2 Issuing server certificates](#)
 - [2.14.3 Issuing client certificates](#)
 - [2.14.4 TLS x509 credential configuration](#)
 - [2.14.5 TLS Pre-Shared Keys \(PSK\)](#)
- [2.15 GDB usage](#)
- [2.16 Target OS specific information](#)
 - [2.16.1 Linux](#)
 - [2.16.2 Windows](#)
 - [2.16.2.1 SVGA graphic modes support](#)
 - [2.16.2.2 CPU usage reduction](#)
 - [2.16.2.3 Windows 2000 disk full problem](#)
 - [2.16.2.4 Windows 2000 shutdown](#)
 - [2.16.2.5 Share a directory between Unix and Windows](#)
 - [2.16.2.6 Windows XP security problem](#)
 - [2.16.3 MS-DOS and FreeDOS](#)
 - [2.16.3.1 CPU usage reduction](#)
- [3 QEMU System emulator for non PC targets](#)
 - [3.1 PowerPC System emulator](#)
 - [3.2 Sparc32 System emulator](#)
 - [3.3 Sparc64 System emulator](#)
 - [3.4 MIPS System emulator](#)
 - [3.4.1 nanoMIPS System emulator](#)
 - [3.5 ARM System emulator](#)
 - [3.6 ColdFire System emulator](#)
 - [3.7 Cris System emulator](#)
 - [3.8 Microblaze System emulator](#)
 - [3.9 SH4 System emulator](#)
 - [3.10 Xtensa System emulator](#)
- [4 QEMU User space emulator](#)
 - [4.1 Supported Operating Systems](#)

- [4.2 Features](#)
- [4.3 Linux User space emulator](#)
 - [4.3.1 Quick Start](#)
 - [4.3.2 Wine launch](#)
 - [4.3.3 Command line options](#)
 - [4.3.4 Other binaries](#)
- [4.4 BSD User space emulator](#)
 - [4.4.1 BSD Status](#)
 - [4.4.2 Quick Start](#)
 - [4.4.3 Command line options](#)
- [5 System requirements](#)
 - [5.1 KVM kernel module](#)
- [6 Security](#)
 - [6.1 Overview](#)
 - [6.2 Security Requirements](#)
 - [6.2.1 Virtualization Use Case](#)
 - [6.2.2 Non-virtualization Use Case](#)
 - [6.3 Architecture](#)
 - [6.3.1 Guest Isolation](#)
 - [6.3.2 Principle of Least Privilege](#)
 - [6.3.3 Isolation mechanisms](#)
 - [6.4 Sensitive configurations](#)
 - [6.4.1 Monitor console \(QMP and HMP\)](#)
- [Appendix A Implementation notes](#)
 - [A.1 CPU emulation](#)
 - [A.1.1 x86 and x86-64 emulation](#)
 - [A.1.2 ARM emulation](#)
 - [A.1.3 MIPS emulation](#)
 - [A.1.4 PowerPC emulation](#)
 - [A.1.5 Sparc32 and Sparc64 emulation](#)
 - [A.1.6 Xtensa emulation](#)
 - [A.2 Managed start up options](#)
- [Appendix B Deprecated features](#)
 - [B.1 System emulator command line arguments](#)
 - [B.1.1 -machine enforce-config-section=on/off \(since 3.1\)](#)
 - [B.1.2 -no-kvm \(since 1.3.0\)](#)
 - [B.1.3 -usbdevice \(since 2.10.0\)](#)
 - [B.1.4 -drive file=json:{...{'driver': 'file'}} \(since 3.0\)](#)
 - [B.1.5 -net ...,name=*name* \(since 3.1\)](#)
 - [B.1.6 -smp \(invalid topologies\) \(since 3.1\)](#)
 - [B.1.7 -vnc acl \(since 4.0.0\)](#)
 - [B.1.8 QEMU_AUDIO_ environment variables and -audio-help \(since 4.0\)](#)
 - [B.1.9 Creating sound card devices and vnc without audiodev= property \(since 4.2\)](#)
 - [B.1.10 -mon ...,control=readline,pretty=on/off \(since 4.1\)](#)
 - [B.1.11 -realtime \(since 4.1\)](#)
 - [B.1.12 -numa node,mem=*size* \(since 4.1\)](#)
 - [B.1.13 -numa node \(without memory specified\) \(since 4.1\)](#)
 - [B.1.14 RISC-V -bios \(since 4.1\)](#)
 - [B.1.15 -tb-size option \(since 5.0\)](#)
 - [B.1.16 -show-cursor option \(since 5.0\)](#)
 - [B.2 QEMU Machine Protocol \(QMP\) commands](#)

- [B.2.1 change \(since 2.5.0\)](#)
 - [B.2.2 migrate_set_downtime and migrate_set_speed \(since 2.8.0\)](#)
 - [B.2.3 migrate-set-cache-size and query-migrate-cache-size \(since 2.11.0\)](#)
 - [B.2.4 query-block result field dirty-bitmaps\[i\].status \(since 4.0\)](#)
 - [B.2.5 query-block result field dirty-bitmaps \(Since 4.2\)](#)
 - [B.2.6 query-cpus \(since 2.12.0\)](#)
 - [B.2.7 query-cpus-fast "arch" output member \(since 3.0.0\)](#)
 - [B.2.8 cpu-add \(since 4.0\)](#)
 - [B.2.9 query-events \(since 4.0\)](#)
 - [B.2.10 chardev client socket with 'wait' option \(since 4.0\)](#)
- [B.3 Human Monitor Protocol \(HMP\) commands](#)
 - [B.3.1 The hub_id parameter of 'hostfwd_add' / 'hostfwd_remove' \(since 3.1\)](#)
 - [B.3.2 cpu-add \(since 4.0\)](#)
 - [B.3.3 acl_show, acl_reset, acl_policy, acl_add, acl_remove \(since 4.0.0\)](#)
- [B.4 Guest Emulator ISAs](#)
 - [B.4.1 RISC-V ISA privilege specification version 1.09.1 \(since 4.1\)](#)
- [B.5 System emulator CPUs](#)
 - [B.5.1 RISC-V ISA CPUs \(since 4.1\)](#)
 - [B.5.2 RISC-V ISA CPUs \(since 4.1\)](#)
- [B.6 System emulator devices](#)
 - [B.6.1 ide-drive \(since 4.2\)](#)
 - [B.6.2 scsi-disk \(since 4.2\)](#)
- [B.7 System emulator machines](#)
 - [B.7.1 mips r4k platform \(since 5.0\)](#)
 - [B.7.2 pc-1.0, pc-1.1, pc-1.2 and pc-1.3 \(since 5.0\)](#)
 - [B.7.3 spike_v1.9.1 and spike_v1.10 \(since 4.1\)](#)
- [B.8 Device options](#)
 - [B.8.1 Emulated device options](#)
 - [B.8.1.1 -device virtio-blk,scsi=on|off \(since 5.0.0\)](#)
 - [B.8.2 Block device options](#)
 - [B.8.2.1 "backing": "" \(since 2.12.0\)](#)
 - [B.8.2.2 rbd keyvalue pair encoded filenames: "" \(since 3.1.0\)](#)
- [B.9 Related binaries](#)
 - [B.9.1 qemu-img convert -n -o \(since 4.2.0\)](#)
- [B.10 Backwards compatibility](#)
 - [B.10.1 Runnability guarantee of CPU models \(since 4.1.0\)](#)
- [Appendix C Recently removed features](#)
 - [C.1 QEMU Machine Protocol \(QMP\) commands](#)
 - [C.1.1 block-dirty-bitmap-add "autoload" parameter \(since 4.2.0\)](#)
 - [C.2 Related binaries](#)
 - [C.2.1 qemu-nbd -partition \(removed in 5.0.0\)](#)
- [Appendix D Supported build platforms](#)
 - [D.1 Linux OS](#)
 - [D.2 Windows](#)
 - [D.3 macOS](#)
 - [D.4 FreeBSD](#)
 - [D.5 NetBSD](#)
 - [D.6 OpenBSD](#)
- [Appendix E License](#)
- [Appendix F Index](#)
 - [F.1 Concept Index](#)

- [F.2 Function Index](#)
 - [F.3 Keystroke Index](#)
 - [F.4 Program Index](#)
 - [F.5 Data Type Index](#)
 - [F.6 Variable Index](#)
-

1 Introduction

1.1 Features

QEMU is a FAST! processor emulator using dynamic translation to achieve good emulation speed.

QEMU has two operating modes:

- Full system emulation. In this mode, QEMU emulates a full system (for example a PC), including one or several processors and various peripherals. It can be used to launch different Operating Systems without rebooting the PC or to debug system code.
- User mode emulation. In this mode, QEMU can launch processes compiled for one CPU on another CPU. It can be used to launch the Wine Windows API emulator (<https://www.winehq.org>) or to ease cross-compilation and cross-debugging.

QEMU has the following features:

- QEMU can run without a host kernel driver and yet gives acceptable performance. It uses dynamic translation to native code for reasonable speed, with support for self-modifying code and precise exceptions.
- It is portable to several operating systems (GNU/Linux, *BSD, Mac OS X, Windows) and architectures.
- It performs accurate software emulation of the FPU.

QEMU user mode emulation has the following features:

- Generic Linux system call converter, including most ioctls.
- clone() emulation using native CPU clone() to use Linux scheduler for threads.
- Accurate signal handling by remapping host signals to target signals.

QEMU full system emulation has the following features:

- QEMU uses a full software MMU for maximum portability.

- QEMU can optionally use an in-kernel accelerator, like kvm. The accelerators execute most of the guest code natively, while continuing to emulate the rest of the machine.
 - Various hardware devices can be emulated and in some cases, host devices (e.g. serial and parallel ports, USB, drives) can be used transparently by the guest Operating System. Host device passthrough can be used for talking to external physical peripherals (e.g. a webcam, modem or tape drive).
 - Symmetric multiprocessing (SMP) support. Currently, an in-kernel accelerator is required to use more than one host CPU for emulation.
-

2 QEMU PC System emulator

2.1 Introduction

The QEMU PC System emulator simulates the following peripherals:

- - i440FX host PCI bridge and PIIX3 PCI to ISA bridge
- - Cirrus CLGD 5446 PCI VGA card or dummy VGA card with Bochs VESA extensions (hardware level, including all non standard modes).
- - PS/2 mouse and keyboard
- - 2 PCI IDE interfaces with hard disk and CD-ROM support
- - Floppy disk
- - PCI and ISA network adapters
- - Serial ports
- - IPMI BMC, either and internal or external one
- - Creative SoundBlaster 16 sound card
- - ENSONIQ AudioPCI ES1370 sound card
- - Intel 82801AA AC97 Audio compatible sound card
- - Intel HD Audio Controller and HDA codec
- - Adlib (OPL2) - Yamaha YM3812 compatible chip
- - Gravis Ultrasound GF1 sound card
- - CS4231A compatible sound card
- - PCI UHCI, OHCI, EHCI or XHCI USB controller and a virtual USB-1.1 hub.

SMP is supported with up to 255 CPUs.

QEMU uses the PC BIOS from the Seabios project and the Plex86/Bochs LGPL VGA BIOS.

QEMU uses YM3812 emulation by Tatsuyuki Satoh.

QEMU uses GUS emulation (GUSEMU32 <http://www.deinmeister.de/gusemu/>) by Tibor "TS" Schütz.

Note that, by default, GUS shares IRQ(7) with parallel ports and so QEMU must be told to not have parallel ports to have working GUS.

```
qemu-system-x86_64 dos.img -soundhw gus -parallel none
```

Alternatively:

```
qemu-system-x86_64 dos.img -device gus,irq=5
```

Or some other unclaimed IRQ.

CS4231A is the chip used in Windows Sound System and GUSMAX products

2.2 Quick Start

Download and uncompress a hard disk image with Linux installed (e.g. `linux.img`) and type:

```
qemu-system-x86_64 linux.img
```

Linux should boot and give you a prompt.

2.3 Invocation

```
qemu-system-x86_64 [options] [disk_image]
```

disk_image is a raw hard disk image for IDE hard disk 0. Some targets do not need a disk image.

2.3.1 Standard options

`-h`

Display help and exit

`-version`

Display version information and exit

`-machine [type=] name [,prop=value [, ...]]`

Select the emulated machine by *name*. Use `-machine help` to list available machines.

For architectures which aim to support live migration compatibility across releases, each release will introduce a new versioned machine type. For

example, the 2.8.0 release introduced machine types “pc-i440fx-2.8” and “pc-q35-2.8” for the x86_64/i686 architectures.

To allow live migration of guests from QEMU version 2.8.0, to QEMU version 2.9.0, the 2.9.0 version must support the “pc-i440fx-2.8” and “pc-q35-2.8” machines too. To allow users live migrating VMs to skip multiple intermediate releases when upgrading, new releases of QEMU will support machine types from many previous versions.

Supported machine properties are:

```
accel=acclsl[:acclsl2[:...]]
```

This is used to enable an accelerator. Depending on the target architecture, kvm, xen, hax, hvf, whpx or tcg can be available. By default, tcg is used. If there is more than one accelerator specified, the next one is used if the previous one fails to initialize.

```
vmport=on|off|auto
```

Enables emulation of VMWare IO port, for vmmouse etc. auto says to select the value based on accel. For accel=xen the default is off otherwise the default is on.

```
dump-guest-core=on|off
```

Include guest memory in a core dump. The default is on.

```
mem-merge=on|off
```

Enables or disables memory merge support. This feature, when supported by the host, de-duplicates identical memory pages among VMs instances (enabled by default).

```
aes-key-wrap=on|off
```

Enables or disables AES key wrapping support on s390-ccw hosts. This feature controls whether AES wrapping keys will be created to allow execution of AES cryptographic functions. The default is on.

```
dea-key-wrap=on|off
```

Enables or disables DEA key wrapping support on s390-ccw hosts. This feature controls whether DEA wrapping keys will be created to allow execution of DEA cryptographic functions. The default is on.

```
nvdimmm=on|off
```


Enables or disables NVDIMM support. The default is off.

`enforce-config-section=on|off`

If `enforce-config-section` is set to *on*, force migration code to send configuration section even if the `machine-type` sets the `migration.send-configuration` property to *off*. NOTE: this parameter is deprecated. Please use `-global migration.send-configuration=on/off` instead.

`memory-encryption=`

Memory encryption object to use. The default is none.

`hmat=on|off`

Enables or disables ACPI Heterogeneous Memory Attribute Table (HMAT) support. The default is off.

`-cpu model`

Select CPU model (`-cpu help` for list and additional feature selection)

`-accel name[,prop=value[,...]]`

This is used to enable an accelerator. Depending on the target architecture, `kvm`, `xen`, `hax`, `hvf`, `whpx` or `tcg` can be available. By default, `tcg` is used. If there is more than one accelerator specified, the next one is used if the previous one fails to initialize.

`igd-passthru=on|off`

When Xen is in use, this option controls whether Intel integrated graphics devices can be passed through to the guest (default=off)

`kernel-irqchip=on|off|split`

Controls KVM in-kernel irqchip support. The default is full acceleration of the interrupt controllers. On x86, `split irqchip` reduces the kernel attack surface, at a performance cost for non-MSI interrupts. Disabling the in-kernel irqchip completely is not recommended except for debugging purposes.

`kvm-shadow-mem=size`

Defines the size of the KVM shadow MMU.

`tb-size=n`

Controls the size (in MiB) of the TCG translation block cache.

thread=single|multi

Controls number of TCG threads. When the TCG is multi-threaded there will be one thread per vCPU therefor taking advantage of additional host cores. The default is to enable multi-threading where both the back-end and front-ends support it and no incompatible TCG features have been enabled (e.g. icount/replay).

-smp
[cpus=*n* [, cores=*cores*] [, threads=*threads*] [, dies=*dies*] [, sockets=*sockets*] [, maxcpus=*maxcpus*]

Simulate an SMP system with *n* CPUs. On the PC target, up to 255 CPUs are supported. On Sparc32 target, Linux limits the number of usable CPUs to 4. For the PC target, the number of *cores* per die, the number of *threads* per cores, the number of *dies* per packages and the total number of *sockets* can be specified. Missing values will be computed. If any on the three values is given, the total number of CPUs *n* can be omitted. *maxcpus* specifies the maximum number of hotpluggable CPUs.

-numa node [, mem=*size*] [, cpus=*firstcpu*[-*lastcpu*]] [, nodeid=*node*] [, initiator=*initiator*]
-numa node [, memdev=*id*] [, cpus=*firstcpu*[-*lastcpu*]] [, nodeid=*node*] [, initiator=*initiator*]
-numa dist, src=*source*, dst=*destination*, val=*distance*
-numa cpu, node-id=*node* [, socket-id=*x*] [, core-id=*y*] [, thread-id=*z*]
-numa hmat-
lb, initiator=*node*, target=*node*, hierarchy=*hierarchy*, data-type=*tpye* [, latency=*lat*] [, bandwidth=*bw*]
-numa hmat-cache, node-id=*node*, size=*size*, level=*level* [, associativity=*str*] [, policy=*str*] [, line=*size*]

Define a NUMA node and assign RAM and VCPUs to it. Set the NUMA distance from a source node to a destination node. Set the ACPI Heterogeneous Memory Attributes for the given nodes.

Legacy VCPU assignment uses ‘cpus’ option where *firstcpu* and *lastcpu* are CPU indexes. Each ‘cpus’ option represent a contiguous range of CPU indexes (or a single VCPU if *lastcpu* is omitted). A non-contiguous set of VCPUs can be represented by providing multiple ‘cpus’ options. If ‘cpus’ is omitted on all nodes, VCPUs are automatically split between them.

For example, the following option assigns VCPUs 0, 1, 2 and 5 to a NUMA node:

-numa node, cpus=0-2, cpus=5

‘cpu’ option is a new alternative to ‘cpus’ option which uses ‘socket-id|core-id|thread-id’ properties to assign CPU objects to a *node* using topology layout properties of CPU. The set of properties is machine specific, and depends on used machine type/‘smp’ options. It could be queried with ‘hotpluggable-cpus’ monitor command. ‘node-id’ property specifies *node* to which CPU object will be assigned, it’s required for *node* to be declared with ‘node’ option before it’s used with ‘cpu’ option.

For example:

```
-M pc \
-smp 1,sockets=2,maxcpus=2 \
-numa node,nodeid=0 -numa node,nodeid=1 \
-numa cpu,node-id=0,socket-id=0 -numa cpu,node-id=1,socket-id=1
```

‘mem’ assigns a given RAM amount to a node. ‘memdev’ assigns RAM from a given memory backend device to a node. If ‘mem’ and ‘memdev’ are omitted in all nodes, RAM is split equally between them.

‘mem’ and ‘memdev’ are mutually exclusive. Furthermore, if one node uses ‘memdev’, all of them have to use it.

‘initiator’ is an additional option that points to an *initiator* NUMA node that has best performance (the lowest latency or largest bandwidth) to this NUMA *node*. Note that this option can be set only when the machine property ‘hmat’ is set to ‘on’.

Following example creates a machine with 2 NUMA nodes, node 0 has CPU, node 1 has only memory, and its initiator is node 0. Note that because node 0 has CPU, by default the initiator of node 0 is itself and must be itself.

```
-machine hmat=on \
-m 2G,slots=2,maxmem=4G \
-object memory-backend-ram,size=1G,id=m0 \
-object memory-backend-ram,size=1G,id=m1 \
-numa node,nodeid=0,memdev=m0 \
-numa node,nodeid=1,memdev=m1,initiator=0 \
-smp 2,sockets=2,maxcpus=2 \
-numa cpu,node-id=0,socket-id=0 \
-numa cpu,node-id=0,socket-id=1
```

source and *destination* are NUMA node IDs. *distance* is the NUMA distance from *source* to *destination*. The distance from a node to itself is always 10. If any pair of nodes is given a distance, then all pairs must be given distances. Although, when distances are only given in one direction for each pair of nodes, then the distances in the opposite directions are assumed to be the same. If, however, an asymmetrical pair of distances is given for even one node pair, then all node pairs must be provided distance values for both directions, even when they are symmetrical. When a node is unreachable from another node, set the pair’s distance to 255.

Note that the `-numa` option doesn't allocate any of the specified resources, it just assigns existing resources to NUMA nodes. This means that one still has to use the `-m`, `-smp` options to allocate RAM and VCPUs respectively.

Use `'hmat-lb'` to set System Locality Latency and Bandwidth Information between initiator and target NUMA nodes in ACPI Heterogeneous Attribute Memory Table (HMAT). Initiator NUMA node can create memory requests, usually it has one or more processors. Target NUMA node contains addressable memory.

In `'hmat-lb'` option, *node* are NUMA node IDs. *hierarchy* is the memory hierarchy of the target NUMA node: if *hierarchy* is 'memory', the structure represents the memory performance; if *hierarchy* is 'first-level|second-level|third-level', this structure represents aggregated performance of memory side caches for each domain. *type* of 'data-type' is type of data represented by this structure instance: if 'hierarchy' is 'memory', 'data-type' is 'access|read|write' latency or 'access|read|write' bandwidth of the target memory; if 'hierarchy' is 'first-level|second-level|third-level', 'data-type' is 'access|read|write' hit latency or 'access|read|write' hit bandwidth of the target memory side cache.

lat is latency value in nanoseconds. *bw* is bandwidth value, the possible value and units are NUM[M|G|T], mean that the bandwidth value are NUM byte per second (or MB/s, GB/s or TB/s depending on used suffix). Note that if latency or bandwidth value is 0, means the corresponding latency or bandwidth information is not provided.

In `'hmat-cache'` option, *node-id* is the NUMA-id of the memory belongs. *size* is the size of memory side cache in bytes. *level* is the cache level described in this structure, note that the cache level 0 should not be used with `'hmat-cache'` option. *associativity* is the cache associativity, the possible value is 'none/direct(direct-mapped)/complex(complex cache indexing)'. *policy* is the write policy. *line* is the cache Line size in bytes.

For example, the following options describe 2 NUMA nodes. Node 0 has 2 cpus and a ram, node 1 has only a ram. The processors in node 0 access memory in node 0 with access-latency 5 nanoseconds, access-bandwidth is 200 MB/s; The processors in NUMA node 0 access memory in NUMA node 1 with access-latency 10 nanoseconds, access-bandwidth is 100 MB/s. And for memory side cache information, NUMA node 0 and 1 both have 1 level memory cache, size is 10KB, policy is write-back, the cache Line size is 8 bytes:

```
-machine hmat=on \  
-m 2G \  
-object memory-backend-ram,size=1G,id=m0 \  
-object memory-backend-ram,size=1G,id=m1 \  
-smp 2 \  

```

```

-numa node,nodeid=0,memdev=m0 \
-numa node,nodeid=1,memdev=m1,initiator=0 \
-numa cpu,node-id=0,socket-id=0 \
-numa cpu,node-id=0,socket-id=1 \
-numa hmat-lb,initiator=0,target=0,hierarchy=memory,data-
type=access-latency,latency=5 \
-numa hmat-lb,initiator=0,target=0,hierarchy=memory,data-
type=access-bandwidth,bandwidth=200M \
-numa hmat-lb,initiator=0,target=1,hierarchy=memory,data-
type=access-latency,latency=10 \
-numa hmat-lb,initiator=0,target=1,hierarchy=memory,data-
type=access-bandwidth,bandwidth=100M \
-numa hmat-cache,node-
id=0,size=10K,level=1,associativity=direct,policy=write-
back,line=8 \
-numa hmat-cache,node-
id=1,size=10K,level=1,associativity=direct,policy=write-
back,line=8
-add-fd fd=fd,set=set[,opaque=opaque]

```

Add a file descriptor to an fd set. Valid options are:

fd=fd

This option defines the file descriptor of which a duplicate is added to fd set. The file descriptor cannot be stdin, stdout, or stderr.

set=set

This option defines the ID of the fd set to add the file descriptor to.

opaque=opaque

This option defines a free-form string that can be used to describe *fd*.

You can open an image using pre-opened file descriptors from an fd set:

```

qemu-system-x86_64 \
-add-fd fd=3,set=2,opaque="rdwr:/path/to/file" \
-add-fd fd=4,set=2,opaque="ronly:/path/to/file" \
-drive file=/dev/fdset/2,index=0,media=disk
-set group.id.arg=value

```

Set parameter *arg* for item *id* of type *group*

```

-global driver.prop=value
-global driver=driver,property=property,value=value

```

Set default value of *driver*'s property *prop* to *value*, e.g.:

```

qemu-system-x86_64 -global ide-hd.physical_block_size=4096 disk-
image.img

```

In particular, you can use this to set driver properties for devices which are created automatically by the machine model. To create a device which is not created automatically and set properties on it, use `-device`.

`-global driver.prop=value` is shorthand for `-global driver=driver,property=prop,value=value`. The longhand syntax works even when *driver* contains a dot.

`-boot`

```
[order=drives] [,once=drives] [,menu=on|off] [,splash=sp_name] [,splash-time=sp_time] [,reboot-timeout=rb_timeout] [,strict=on|off]
```

Specify boot order *drives* as a string of drive letters. Valid drive letters depend on the target architecture. The x86 PC uses: a, b (floppy 1 and 2), c (first hard disk), d (first CD-ROM), n-p (Etherboot from network adapter 1-4), hard disk boot is the default. To apply a particular boot order only on the first startup, specify it via *once*. Note that the *order* or *once* parameter should not be used together with the *bootindex* property of devices, since the firmware implementations normally do not support both at the same time.

Interactive boot menus/prompts can be enabled via *menu=on* as far as firmware/BIOS supports them. The default is non-interactive boot.

A splash picture could be passed to bios, enabling user to show it as logo, when option *splash=sp_name* is given and *menu=on*, If firmware/BIOS supports them. Currently Seabios for X86 system support it. limitation: The splash file could be a jpeg file or a BMP file in 24 BPP format(true color). The resolution should be supported by the SVGA mode, so the recommended is 320x240, 640x480, 800x640.

A timeout could be passed to bios, guest will pause for *rb_timeout* ms when boot failed, then reboot. If *rb_timeout* is '-1', guest will not reboot, qemu passes '-1' to bios by default. Currently Seabios for X86 system support it.

Do strict boot via *strict=on* as far as firmware/BIOS supports it. This only effects when boot priority is changed by *bootindex* options. The default is non-strict boot.

```
# try to boot from network first, then from hard disk
qemu-system-x86_64 -boot order=nc
# boot from CD-ROM first, switch back to default order after
reboot
qemu-system-x86_64 -boot once=d
# boot with a splash picture for 5 seconds.
qemu-system-x86_64 -boot menu=on,splash=/root/boot.bmp,splash-
time=5000
```

Note: The legacy format `'-boot drives'` is still supported but its use is discouraged as it may be removed from future versions.

`-m [size=]megs[, slots=n, maxmem=size]`

Sets guest startup RAM size to *megs* megabytes. Default is 128 MiB. Optionally, a suffix of “M” or “G” can be used to signify a value in megabytes or gigabytes respectively. Optional pair *slots*, *maxmem* could be used to set amount of hotpluggable memory slots and maximum amount of memory. Note that *maxmem* must be aligned to the page size.

For example, the following command-line sets the guest startup RAM size to 1GB, creates 3 slots to hotplug additional memory and sets the maximum memory the guest can reach to 4GB:

```
qemu-system-x86_64 -m 1G,slots=3,maxmem=4G
```

If *slots* and *maxmem* are not specified, memory hotplug won't be enabled and the guest startup RAM will never increase.

`-mem-path path`

Allocate guest RAM from a temporarily created file in *path*.

`-mem-prealloc`

Preallocate memory when using `-mem-path`.

`-k language`

Use keyboard layout *language* (for example `fr` for French). This option is only needed where it is not easy to get raw PC keycodes (e.g. on Macs, with some X11 servers or with a VNC or curses display). You don't normally need to use it on PC/Linux or PC/Windows hosts.

The available layouts are:

ar	de-ch	es	fo	fr-ca	hu	ja	mk	no	pt-br	sv
da	en-gb	et	fr	fr-ch	is	lt	nl	pl	ru	th
de	en-us	fi	fr-be	hr	it	lv	nl-be	pt	sl	tr

The default is `en-us`.

`-audio-help`

Will show the `-audiodev` equivalent of the currently specified (deprecated) environment variables.

`-audiodev [driver=]driver,id=id[, prop [=value] [, ...]]`

Adds a new audio backend *driver* identified by *id*. There are global and driver specific properties. Some values can be set differently for input and output, they're marked with *in|out*.. You can set the input's property with *in.prop* and the output's property with *out.prop*. For example:

```
-audiodev alsa,id=example,in.frequency=44110,out.frequency=8000
-audiodev alsa,id=example,out.channels=1 # leaves in.channels
unspecified
```

NOTE: parameter validation is known to be incomplete, in many cases specifying an invalid option causes QEMU to print an error message and continue emulation without sound.

Valid global options are:

id=identifier

Identifies the audio backend.

timer-period=period

Sets the timer *period* used by the audio subsystem in microseconds. Default is 10000 (10 ms).

in|out.mixing-engine=on|off

Use QEMU's mixing engine to mix all streams inside QEMU and convert audio formats when not supported by the backend. When off, *fixed-settings* must be off too. Note that disabling this option means that the selected backend must support multiple streams and the audio formats used by the virtual cards, otherwise you'll get no sound. It's not recommended to disable this option unless you want to use 5.1 or 7.1 audio, as mixing engine only supports mono and stereo audio. Default is on.

in|out.fixed-settings=on|off

Use fixed settings for host audio. When off, it will change based on how the guest opens the sound card. In this case you must not specify *frequency*, *channels* or *format*. Default is on.

in|out.frequency=frequency

Specify the *frequency* to use when using *fixed-settings*. Default is 44100Hz.

in|out.channels=channels

Specify the number of *channels* to use when using *fixed-settings*. Default is 2 (stereo).

`in|out.format=format`

Specify the sample *format* to use when using *fixed-settings*. Valid values are: `s8`, `s16`, `s32`, `u8`, `u16`, `u32`. Default is `s16`.

`in|out.voices=voices`

Specify the number of *voices* to use. Default is 1.

`in|out.buffer-length=usecs`

Sets the size of the buffer in microseconds.

`-audiodev none, id=id [, prop [= value] [, ...]]`

Creates a dummy backend that discards all outputs. This backend has no backend specific properties.

`-audiodev alsa, id=id [, prop [= value] [, ...]]`

Creates backend using the ALSA. This backend is only available on Linux.

ALSA specific options are:

`in|out.dev=device`

Specify the ALSA *device* to use for input and/or output. Default is `default`.

`in|out.period-length=usecs`

Sets the period length in microseconds.

`in|out.try-poll=on|off`

Attempt to use poll mode with the device. Default is `on`.

`threshold=threshold`

Threshold (in microseconds) when playback starts. Default is 0.

`-audiodev coreaudio, id=id [, prop [= value] [, ...]]`

Creates a backend using Apple's Core Audio. This backend is only available on Mac OS and only supports playback.

Core Audio specific options are:

`in|out.buffer-count=count`

Sets the *count* of the buffers.

```
-audiodev dsound,id=id[,prop[=value][,...]]
```

Creates a backend using Microsoft's DirectSound. This backend is only available on Windows and only supports playback.

DirectSound specific options are:

```
latency=usecs
```

Add extra *usecs* microseconds latency to playback. Default is 10000 (10 ms).

```
-audiodev oss,id=id[,prop[=value][,...]]
```

Creates a backend using OSS. This backend is available on most Unix-like systems.

OSS specific options are:

```
in|out.dev=device
```

Specify the file name of the OSS *device* to use. Default is `/dev/dsp`.

```
in|out.buffer-count=count
```

Sets the *count* of the buffers.

```
in|out.try-poll=on|off
```

Attempt to use poll mode with the device. Default is on.

```
try-mmap=on|off
```

Try using memory mapped device access. Default is off.

```
exclusive=on|off
```

Open the device in exclusive mode (vmix won't work in this case). Default is off.

```
dsp-policy=policy
```

Sets the timing policy (between 0 and 10, where smaller number means smaller latency but higher CPU usage). Use -1 to use buffer sizes specified by `buffer` and `buffer-count`. This option is ignored if you do not have OSS 4. Default is 5.

```
-audiodev pa,id=id[,prop[=value][,...]]
```

Creates a backend using PulseAudio. This backend is available on most systems.

PulseAudio specific options are:

`server=server`

Sets the PulseAudio *server* to connect to.

`in|out.name=sink`

Use the specified source/sink for recording/playback.

`in|out.latency=usecs`

Desired latency in microseconds. The PulseAudio server will try to honor this value but actual latencies may be lower or higher.

`-audiodev sdl,id=id[,prop[=value][,...]]`

Creates a backend using SDL. This backend is available on most systems, but you should use your platform's native backend if possible. This backend has no backend specific properties.

`-audiodev spice,id=id[,prop[=value][,...]]`

Creates a backend that sends audio through SPICE. This backend requires `-spice` and automatically selected in that case, so usually you can ignore this option. This backend has no backend specific properties.

`-audiodev wav,id=id[,prop[=value][,...]]`

Creates a backend that writes audio to a WAV file.

Backend specific options are:

`path=path`

Write recorded audio into the specified file. Default is `qemu.wav`.

`-soundhw card1[,card2,...]` or `-soundhw all`

Enable audio and selected sound hardware. Use 'help' to print all available sound hardware. For example:

```
qemu-system-x86_64 -soundhw sb16,adlib disk.img
qemu-system-x86_64 -soundhw es1370 disk.img
qemu-system-x86_64 -soundhw ac97 disk.img
qemu-system-x86_64 -soundhw hda disk.img
qemu-system-x86_64 -soundhw all disk.img
```

```
qemu-system-x86_64 -soundhw help
```

Note that Linux's i810_audio OSS kernel (for AC97) module might require manually specifying clocking.

```
modprobe i810_audio clocking=48000  
-device driver[,prop[=value][,...]]
```

Add device *driver*. *prop=value* sets driver properties. Valid properties depend on the driver. To get help on possible drivers and properties, use `-device help` and `-device driver,help`.

Some drivers are:

```
-device ipmi-bmc-sim,id=id[,slave_addr=val][,sdrfile=file][,fruareasize=val][,frudatafile=file][,guid=uuid]
```

Add an IPMI BMC. This is a simulation of a hardware management interface processor that normally sits on a system. It provides a watchdog and the ability to reset and power control the system. You need to connect this to an IPMI interface to make it useful

The IPMI slave address to use for the BMC. The default is 0x20. This address is the BMC's address on the I2C network of management controllers. If you don't know what this means, it is safe to ignore it.

```
id=id
```

The BMC id for interfaces to use this device.

```
slave_addr=val
```

Define slave address to use for the BMC. The default is 0x20.

```
sdrfile=file
```

file containing raw Sensor Data Records (SDR) data. The default is none.

```
fruareasize=val
```

size of a Field Replaceable Unit (FRU) area. The default is 1024.

```
frudatafile=file
```

file containing raw Field Replaceable Unit (FRU) inventory data. The default is none.

```
guid=uuid
```

value for the GUID for the BMC, in standard UUID format. If this is set, get "Get GUID" command to the BMC will return it. Otherwise "Get GUID" will return an error.

```
-device ipmi-bmc-extern,id=id,chardev=id[,slave_addr=val]
```

Add a connection to an external IPMI BMC simulator. Instead of locally emulating the BMC like the above item, instead connect to an external entity that provides the IPMI services.

A connection is made to an external BMC simulator. If you do this, it is strongly recommended that you use the "reconnect=" chardev option to reconnect to the simulator if the connection is lost. Note that if this is not used carefully, it can be a security issue, as the interface has the ability to send resets, NMIs, and power off the VM. It's best if QEMU makes a connection to an external simulator running on a secure port on localhost, so neither the simulator nor QEMU is exposed to any outside network.

See the "lanserv/README.vm" file in the OpenIPMI library for more details on the external interface.

```
-device isa-ipmi-kcs,bmc=id[,ioport=val][,irq=val]
```

Add a KCS IPMI interface on the ISA bus. This also adds a corresponding ACPI and SMBIOS entries, if appropriate.

bmc=id

The BMC to connect to, one of ipmi-bmc-sim or ipmi-bmc-extern above.

ioport=val

Define the I/O address of the interface. The default is 0xca0 for KCS.

irq=val

Define the interrupt to use. The default is 5. To disable interrupts, set this to 0.

```
-device isa-ipmi-bt,bmc=id[,ioport=val][,irq=val]
```

Like the KCS interface, but defines a BT interface. The default port is 0xe4 and the default interrupt is 5.

```
-name name
```

Sets the *name* of the guest. This name will be displayed in the SDL window caption. The *name* will also be used for the VNC server. Also optionally set the

top visible process name in Linux. Naming of individual threads can also be enabled on Linux to aid debugging.

`-uuid uuid`

Set system UUID.

2.3.2 Block device options

`-fda file`

`-fdb file`

Use *file* as floppy disk 0/1 image (see [disk images](#)).

`-hda file`

`-hdb file`

`-hdc file`

`-hdd file`

Use *file* as hard disk 0, 1, 2 or 3 image (see [disk images](#)).

`-cdrom file`

Use *file* as CD-ROM image (you cannot use `-hdc` and `-cdrom` at the same time). You can use the host CD-ROM by using `/dev/cdrom` as filename.

`-blockdev option[,option[,option[,...]]]`

Define a new block driver node. Some of the options apply to all block drivers, other options are only accepted for a specific block driver. See below for a list of generic options and options for the most common block drivers.

Options that expect a reference to another node (e.g. *file*) can be given in two ways. Either you specify the node name of an already existing node (`file=node-name`), or you define a new node inline, adding options for the referenced node after a dot (`file.filename=path,file.aio=native`).

A block driver node created with `-blockdev` can be used for a guest device by specifying its node name for the `drive` property in a `-device` argument that defines a block device.

Valid options for any block driver node:
`driver`

Specifies the block driver to use for the given node.

`node-name`

This defines the name of the block driver node by which it will be referenced later. The name must be unique, i.e. it must not match the name of a different block driver node, or (if you use `-drive` as well) the ID of a drive.

If no node name is specified, it is automatically generated. The generated node name is not intended to be predictable and changes between QEMU invocations. For the top level, an explicit node name must be specified.

`read-only`

Open the node read-only. Guest write attempts will fail.

Note that some block drivers support only read-only access, either generally or in certain configurations. In this case, the default value `read-only=off` does not work and the option must be specified explicitly.

`auto-read-only`

If `auto-read-only=on` is set, QEMU may fall back to read-only usage even when `read-only=off` is requested, or even switch between modes as needed, e.g. depending on whether the image file is writable or whether a writing user is attached to the node.

`force-share`

Override the image locking system of QEMU by forcing the node to utilize weaker shared access for permissions where it would normally request exclusive access. When there is the potential for multiple instances to have the same file open (whether this invocation of QEMU is the first or the second instance), both instances must permit shared access for the second instance to succeed at opening the file.

Enabling `force-share=on` requires `read-only=on`.

`cache.direct`

The host page cache can be avoided with `cache.direct=on`. This will attempt to do disk IO directly to the guest's memory. QEMU may still perform an internal copy of the data.

`cache.no-flush`

In case you don't care about data integrity over host failures, you can use `cache.no-flush=on`. This option tells QEMU that it never needs to write any data to the disk but can instead keep things in cache. If anything goes wrong, like your host losing power, the disk storage getting disconnected accidentally, etc. your image will most probably be rendered unusable.

`discard=discard`

discard is one of "ignore" (or "off") or "unmap" (or "on") and controls whether *discard* (also known as *trim* or *unmap*) requests are ignored or passed to the filesystem. Some machine types may not support discard requests.

`detect-zeroes=detect-zeroes`

detect-zeroes is "off", "on" or "unmap" and enables the automatic conversion of plain zero writes by the OS to driver specific optimized zero write commands. You may even choose "unmap" if *discard* is set to "unmap" to allow a zero write to be converted to an *unmap* operation.

Driver-specific options for *file*

This is the protocol-level block driver for accessing regular files.

filename

The path to the image file in the local filesystem

aio

Specifies the AIO backend (threads/native, default: threads)

locking

Specifies whether the image file is protected with Linux OFD / POSIX locks. The default is to use the Linux Open File Descriptor API if available, otherwise no lock is applied. (auto/on/off, default: auto)

Example:

```
-blockdev driver=file,node-name=disk,filename=disk.img
```

Driver-specific options for *raw*

This is the image format block driver for raw images. It is usually stacked on top of a protocol level block driver such as *file*.

file

Reference to or definition of the data source block driver node (e.g. a *file* driver node)

Example 1:

```
-blockdev driver=file,node-name=disk_file,filename=disk.img
-blockdev driver=raw,node-name=disk,file=disk_file
```

Example 2:

```
-blockdev driver=raw,node-
name=disk,file.driver=file,file.filename=disk.img
```


Driver-specific options for qcow2

This is the image format block driver for qcow2 images. It is usually stacked on top of a protocol level block driver such as `file`.

`file`

Reference to or definition of the data source block driver node (e.g. a `file` driver node)

`backing`

Reference to or definition of the backing file block device (default is taken from the image file). It is allowed to pass `null` here in order to disable the default backing file.

`lazy-refcounts`

Whether to enable the lazy refcounts feature (on/off; default is taken from the image file)

`cache-size`

The maximum total size of the L2 table and refcount block caches in bytes (default: the sum of `l2-cache-size` and `refcount-cache-size`)

`l2-cache-size`

The maximum size of the L2 table cache in bytes (default: if `cache-size` is not specified - 32M on Linux platforms, and 8M on non-Linux platforms; otherwise, as large as possible within the `cache-size`, while permitting the requested or the minimal refcount cache size)

`refcount-cache-size`

The maximum size of the refcount block cache in bytes (default: 4 times the cluster size; or if `cache-size` is specified, the part of it which is not used for the L2 cache)

`cache-clean-interval`

Clean unused entries in the L2 and refcount caches. The interval is in seconds. The default value is 600 on supporting platforms, and 0 on other platforms. Setting it to 0 disables this feature.

`pass-discard-request`

Whether discard requests to the qcow2 device should be forwarded to the data source (on/off; default: on if `discard=unmap` is specified, off otherwise)

`pass-discard-snapshot`

Whether discard requests for the data source should be issued when a snapshot operation (e.g. deleting a snapshot) frees clusters in the qcow2 file (on/off; default: on)

`pass-discard-other`

Whether discard requests for the data source should be issued on other occasions where a cluster gets freed (on/off; default: off)

`overlap-check`

Which overlap checks to perform for writes to the image (none/constant/cached/all; default: cached). For details or finer granularity control refer to the QAPI documentation of `blockdev-add`.

Example 1:

```
-blockdev driver=file,node-name=my_file,filename=/tmp/disk.qcow2
-blockdev driver=qcow2,node-name=hda,file=my_file,overlap-
check=none,cache-size=16777216
```

Example 2:

```
-blockdev driver=qcow2,node-
name=disk,file.driver=http,file.filename=http://example.com/image
.qcow2
```

Driver-specific options for other drivers

Please refer to the QAPI documentation of the `blockdev-add` QMP command.

`-drive option[,option[,option[,...]]]`

Define a new drive. This includes creating a block driver node (the backend) as well as a guest device, and is mostly a shortcut for defining the corresponding `-blockdev` and `-device` options.

`-drive` accepts all options that are accepted by `-blockdev`. In addition, it knows the following options:

`file=`*file*

This option defines which disk image (see [disk images](#)) to use with this drive. If the filename contains comma, you must double it (for instance, "file=my,,file" to use file "my,file").

Special files such as iSCSI devices can be specified using protocol specific URLs. See the section for "Device URL Syntax" for more information.

`if=`*interface*

This option defines on which type on interface the drive is connected.
Available types are: ide, scsi, sd, mtd, floppy, pflash, virtio, none.

`bus=bus, unit=unit`

These options define where is connected the drive by defining the bus number and the unit id.

`index=index`

This option defines where is connected the drive by using an index in the list of available connectors of a given interface type.

`media=media`

This option defines the type of the media: disk or cdrom.

`snapshot=snapshot`

snapshot is "on" or "off" and controls snapshot mode for the given drive (see - snapshot).

`cache=cache`

cache is "none", "writeback", "unsafe", "directsync" or "writethrough" and controls how the host cache is used to access block data. This is a shortcut that sets the `cache.direct` and `cache.no-flush` options (as in - blockdev), and additionally `cache.writeback`, which provides a default for the `write-cache` option of block guest devices (as in -device). The modes correspond to the following settings:

	cache.writeback	cache.direct	cache.no-flush
writeback	on	off	off
none	on	on	off
writethrough	off	off	off
directsync	off	on	off
unsafe	on	off	on

The default mode is `cache=writeback`.

`aio=aio`

aio is "threads", or "native" and selects between pthread based disk I/O and native Linux AIO.

`format=format`

Specify which disk *format* will be used rather than detecting the format. Can be used to specify `format=raw` to avoid interpreting an untrusted format header.

`werror=action, rerror=action`

Specify which *action* to take on write and read errors. Valid actions are: "ignore" (ignore the error and try to continue), "stop" (pause QEMU), "report" (report the error to the guest), "enospc" (pause QEMU only if the host disk is full; report the error to the guest otherwise). The default setting is `werror=enospc` and `rerror=report`.

`copy-on-read=copy-on-read`

copy-on-read is "on" or "off" and enables whether to copy read backing file sectors into the image file.

`bps=b, bps_rd=r, bps_wr=w`

Specify bandwidth throttling limits in bytes per second, either for all request types or for reads or writes only. Small values can lead to timeouts or hangs inside the guest. A safe minimum for disks is 2 MB/s.

`bps_max=bm, bps_rd_max=rm, bps_wr_max=wm`

Specify bursts in bytes per second, either for all request types or for reads or writes only. Bursts allow the guest I/O to spike above the limit temporarily.

`iops=i, iops_rd=r, iops_wr=w`

Specify request rate limits in requests per second, either for all request types or for reads or writes only.

`iops_max=bm, iops_rd_max=rm, iops_wr_max=wm`

Specify bursts in requests per second, either for all request types or for reads or writes only. Bursts allow the guest I/O to spike above the limit temporarily.

`iops_size=is`

Let every *is* bytes of a request count as a new request for iops throttling purposes. Use this option to prevent guests from circumventing iops limits by sending fewer but larger requests.

`group=g`

Join a throttling quota group with given name *g*. All drives that are members of the same group are accounted for together. Use this option to prevent guests from circumventing throttling limits by using many small disks instead of a single larger disk.

By default, the `cache.writeback=on` mode is used. It will report data writes as completed as soon as the data is present in the host page cache. This is safe as long as your guest OS makes sure to correctly flush disk caches where needed. If your guest OS does not handle volatile disk write caches correctly and your host crashes or loses power, then the guest may experience data corruption.

For such guests, you should consider using `cache.writeback=off`. This means that the host page cache will be used to read and write data, but write notification will be sent to the guest only after QEMU has made sure to flush each write to the disk. Be aware that this has a major impact on performance.

When using the `-snapshot` option, unsafe caching is always used.

Copy-on-read avoids accessing the same backing file sectors repeatedly and is useful when the backing file is over a slow network. By default copy-on-read is off.

Instead of `-cdrom` you can use:

```
qemu-system-x86_64 -drive file=file,index=2,media=cdrom
```

Instead of `-hda`, `-hdb`, `-hdc`, `-hdd`, you can use:

```
qemu-system-x86_64 -drive file=file,index=0,media=disk
qemu-system-x86_64 -drive file=file,index=1,media=disk
qemu-system-x86_64 -drive file=file,index=2,media=disk
qemu-system-x86_64 -drive file=file,index=3,media=disk
```

You can open an image using pre-opened file descriptors from an fd set:

```
qemu-system-x86_64 \
-add-fd fd=3,set=2,opaque="rdwr:/path/to/file" \
-add-fd fd=4,set=2,opaque="ronly:/path/to/file" \
-drive file=/dev/fdset/2,index=0,media=disk
```

You can connect a CDROM to the slave of `ide0`:

```
qemu-system-x86_64 -drive file=file,if=ide,index=1,media=cdrom
```

If you don't specify the `"file="` argument, you define an empty drive:

```
qemu-system-x86_64 -drive if=ide,index=1,media=cdrom
```

Instead of `-fda`, `-fdb`, you can use:

```
qemu-system-x86_64 -drive file=file,index=0,if=floppy
qemu-system-x86_64 -drive file=file,index=1,if=floppy
```

By default, *interface* is `"ide"` and *index* is automatically incremented:

```
qemu-system-x86_64 -drive file=a -drive file=b"
```

is interpreted like:

```
qemu-system-x86_64 -hda a -hdb b  
-mtdblock file
```

Use *file* as on-board Flash memory image.

```
-sd file
```

Use *file* as SecureDigital card image.

```
-pflash file
```

Use *file* as a parallel flash image.

```
-snapshot
```

Write to temporary files instead of disk image files. In this case, the raw disk image you use is not written back. You can however force the write back by pressing `C-a s` (see [disk_images](#)).

```
-fsdev  
local,id=id,path=path,security_model=security_model [,writeout=writeout][,readonly][,fmode=fmode][,dmode=dmode]  
[,throttling.option=value[,throttling.option=value[,...]]  
]  
-fsdev  
proxy,id=id,socket=socket[,writeout=writeout][,readonly]  
-fsdev  
proxy,id=id,sock_fd=sock_fd[,writeout=writeout][,readonly]  
]  
-fsdev synth,id=id[,readonly]
```

Define a new file system device. Valid options are:

local

Accesses to the filesystem are done by QEMU.

proxy

Accesses to the filesystem are done by virtfs-proxy-helper(1).

synth

Synthetic filesystem, only used by QTests.

`id=id`

Specifies identifier for this device.

`path=path`

Specifies the export path for the file system device. Files under this path will be available to the 9p client on the guest.

`security_model=security_model`

Specifies the security model to be used for this export path. Supported security models are "passthrough", "mapped-xattr", "mapped-file" and "none". In "passthrough" security model, files are stored using the same credentials as they are created on the guest. This requires QEMU to run as root. In "mapped-xattr" security model, some of the file attributes like uid, gid, mode bits and link target are stored as file attributes. For "mapped-file" these attributes are stored in the hidden `.virtfs_metadata` directory. Directories exported by this security model cannot interact with other unix tools. "none" security model is same as passthrough except the sever won't report failures if it fails to set file attributes like ownership. Security model is mandatory only for local fsdriver. Other fsdrivers (like proxy) don't take security model as a parameter.

`writeout=writeout`

This is an optional argument. The only supported value is "immediate". This means that host page cache will be used to read and write data but write notification will be sent to the guest only when the data has been reported as written by the storage subsystem.

`readonly`

Enables exporting 9p share as a readonly mount for guests. By default read-write access is given.

`socket=socket`

Enables proxy filesystem driver to use passed socket file for communicating with `virtfs-proxy-helper(1)`.

`sock_fd=sock_fd`

Enables proxy filesystem driver to use passed socket descriptor for communicating with `virtfs-proxy-helper(1)`. Usually a helper like `libvirt` will create `socketpair` and pass one of the fds as `sock_fd`.

`fmode=fmode`

Specifies the default mode for newly created files on the host. Works only with security models "mapped-xattr" and "mapped-file".

`dmode=dmode`

Specifies the default mode for newly created directories on the host. Works only with security models "mapped-xattr" and "mapped-file".

`throttling.bps-total=b, throttling.bps-read=r, throttling.bps-write=w`

Specify bandwidth throttling limits in bytes per second, either for all request types or for reads or writes only.

`throttling.bps-total-max=bm, bps-read-max=rm, bps-write-max=wm`

Specify bursts in bytes per second, either for all request types or for reads or writes only. Bursts allow the guest I/O to spike above the limit temporarily.

`throttling.iops-total=i, throttling.iops-read=r, throttling.iops-write=w`

Specify request rate limits in requests per second, either for all request types or for reads or writes only.

`throttling.iops-total-max=im, throttling.iops-read-max=irm, throttling.iops-write-max=iwm`

Specify bursts in requests per second, either for all request types or for reads or writes only. Bursts allow the guest I/O to spike above the limit temporarily.

`throttling.iops-size=is`

Let every *is* bytes of a request count as a new request for iops throttling purposes.

-fsdev option is used along with -device driver "virtio-9p-...".

`-device virtio-9p-type, fsdev=id, mount_tag=mount_tag`

Options for virtio-9p-... driver are:

type

Specifies the variant to be used. Supported values are "pci", "ccw" or "device", depending on the machine type.

`fsdev=id`

Specifies the id value specified along with -fsdev option.

`mount_tag=mount_tag`

Specifies the tag name to be used by the guest to mount this export point.

```
-virtfs
local,path=path,mount_tag=mount_tag ,security_model=security_model[,writeout=writeout][,readonly]
[,fmode=fmode][,dmode=dmode][,multidevs=multidevs]
-virtfs
proxy,socket=socket,mount_tag=mount_tag [,writeout=writeout][,readonly]
-virtfs
proxy,sock_fd=sock_fd,mount_tag=mount_tag [,writeout=writeout][,readonly]
-virtfs synth,mount_tag=mount_tag
```

Define a new filesystem device and expose it to the guest using a virtio-9p device. The general form of a Virtual File system pass-through options are:

`local`

Accesses to the filesystem are done by QEMU.

`proxy`

Accesses to the filesystem are done by virtfs-proxy-helper(1).

`synth`

Synthetic filesystem, only used by QTests.

`id=id`

Specifies identifier for the filesystem device

`path=path`

Specifies the export path for the file system device. Files under this path will be available to the 9p client on the guest.

`security_model=security_model`

Specifies the security model to be used for this export path. Supported security models are "passthrough", "mapped-xattr", "mapped-file" and "none". In

"passthrough" security model, files are stored using the same credentials as they are created on the guest. This requires QEMU to run as root. In "mapped-xattr" security model, some of the file attributes like uid, gid, mode bits and link target are stored as file attributes. For "mapped-file" these attributes are stored in the hidden .virtfs_metadata directory. Directories exported by this security model cannot interact with other unix tools. "none" security model is same as passthrough except the sever won't report failures if it fails to set file attributes like ownership. Security model is mandatory only for local fsdriver. Other fsdrivers (like proxy) don't take security model as a parameter.

`writeout=writeout`

This is an optional argument. The only supported value is "immediate". This means that host page cache will be used to read and write data but write notification will be sent to the guest only when the data has been reported as written by the storage subsystem.

`readonly`

Enables exporting 9p share as a readonly mount for guests. By default read-write access is given.

`socket=socket`

Enables proxy filesystem driver to use passed socket file for communicating with virtfs-proxy-helper(1). Usually a helper like libvirt will create socketpair and pass one of the fds as sock_fd.

`sock_fd`

Enables proxy filesystem driver to use passed 'sock_fd' as the socket descriptor for interfacing with virtfs-proxy-helper(1).

`fmode=fmode`

Specifies the default mode for newly created files on the host. Works only with security models "mapped-xattr" and "mapped-file".

`dmode=dmode`

Specifies the default mode for newly created directories on the host. Works only with security models "mapped-xattr" and "mapped-file".

`mount_tag=mount_tag`

Specifies the tag name to be used by the guest to mount this export point.

`multidevs=multidevs`

Specifies how to deal with multiple devices being shared with a 9p export. Supported behaviours are either "remap", "forbid" or "warn". The latter is the default behaviour on which virtfs 9p expects only one device to be shared with the same export, and if more than one device is shared and accessed via the same 9p export then only a warning message is logged (once) by qemu on host side. In order to avoid file ID collisions on guest you should either create a separate virtfs export for each device to be shared with guests (recommended way) or you might use "remap" instead which allows you to share multiple devices with only one export instead, which is achieved by remapping the original inode numbers from host to guest in a way that would prevent such collisions. Remapping inodes in such use cases is required because the original device IDs from host are never passed and exposed on guest. Instead all files of an export shared with virtfs always share the same device id on guest. So two files with identical inode numbers but from actually different devices on host would otherwise cause a file ID collision and hence potential misbehaviours on guest. "forbid" on the other hand assumes like "warn" that only one device is shared by the same export, however it will not only log a warning message but also deny access to additional devices on guest. Note though that "forbid" does currently not block all possible file access operations (e.g. readdir()) would still return entries from other devices).

`-iscsi`

Configure iSCSI session parameters.

2.3.3 USB options

`-usb`

Enable USB emulation on machine types with an on-board USB host controller (if not enabled by default). Note that on-board USB host controllers may not support USB 3.0. In this case `-device qemu-xhci` can be used instead on machines with PCI.

`-usbdevice devname`

Add the USB device *devname*. Note that this option is deprecated, please use `-device usb-...` instead. See [usb devices](#).

`mouse`

Virtual Mouse. This will override the PS/2 mouse emulation when activated.

`tablet`

Pointer device that uses absolute coordinates (like a touchscreen). This means QEMU is able to report the mouse position without having to grab the mouse. Also overrides the PS/2 mouse emulation when activated.

braille

Braille device. This will use BrlAPI to display the braille output on a real or fake device.

2.3.4 Display options

`-display type`

Select type of display to use. This option is a replacement for the old style `-sdl/-curses/...` options. Use `-display help` to list the available display types. Valid values for *type* are

sdl

Display video output via SDL (usually in a separate graphics window; see the SDL documentation for other possibilities).

curses

Display video output via curses. For graphics device models which support a text mode, QEMU can display this output using a curses/ncurses interface. Nothing is displayed when the graphics device is in graphical mode or if the graphics device does not support a text mode. Generally only the VGA device models support text mode. The font charset used by the guest can be specified with the `charset` option, for example `charset=CP850` for IBM CP850 encoding. The default is `CP437`.

none

Do not display video output. The guest will still see an emulated graphics card, but its output will not be displayed to the QEMU user. This option differs from the `-nographic` option in that it only affects what is done with video output; `-nographic` also changes the destination of the serial and parallel port data.

gtk

Display video output in a GTK window. This interface provides drop-down menus and other UI elements to configure and control the VM during runtime.

vnc

Start a VNC server on display `<arg>`

`egl-headless`

Offload all OpenGL operations to a local DRI device. For any graphical display, this display needs to be paired with either VNC or SPICE displays.

`spice-app`

Start QEMU as a Spice server and launch the default Spice client application. The Spice server will redirect the serial consoles and QEMU monitors. (Since 4.0)

`-nographic`

Normally, if QEMU is compiled with graphical window support, it displays output such as guest graphics, guest console, and the QEMU monitor in a window. With this option, you can totally disable graphical output so that QEMU is a simple command line application. The emulated serial port is redirected on the console and muxed with the monitor (unless redirected elsewhere explicitly). Therefore, you can still use QEMU to debug a Linux kernel with a serial console. Use `C-a h` for help on switching between the console and monitor.

`-curses`

Normally, if QEMU is compiled with graphical window support, it displays output such as guest graphics, guest console, and the QEMU monitor in a window. With this option, QEMU can display the VGA output when in text mode using a curses/ncurses interface. Nothing is displayed in graphical mode.

`-alt-grab`

Use Ctrl-Alt-Shift to grab mouse (instead of Ctrl-Alt). Note that this also affects the special keys (for fullscreen, monitor-mode switching, etc).

`-ctrl-grab`

Use Right-Ctrl to grab mouse (instead of Ctrl-Alt). Note that this also affects the special keys (for fullscreen, monitor-mode switching, etc).

`-no-quit`

Disable SDL window close capability.

`-sdl`

Enable SDL.

`-spice option[,option[,...]]`

Enable the spice remote desktop protocol. Valid options are

`port=<nr>`

Set the TCP port spice is listening on for plaintext channels.

`addr=<addr>`

Set the IP address spice is listening on. Default is any address.

`ipv4`

`ipv6`

`unix`

Force using the specified IP version.

`password=<secret>`

Set the password you need to authenticate.

`sasl`

Require that the client use SASL to authenticate with the spice. The exact choice of authentication method used is controlled from the system / user's SASL configuration file for the 'qemu' service. This is typically found in /etc/sasl2/qemu.conf. If running QEMU as an unprivileged user, an environment variable SASL_CONF_PATH can be used to make it search alternate locations for the service config. While some SASL auth methods can also provide data encryption (eg GSSAPI), it is recommended that SASL always be combined with the 'tls' and 'x509' settings to enable use of SSL and server certificates. This ensures a data encryption preventing compromise of authentication credentials.

`disable-ticketing`

Allow client connects without authentication.

`disable-copy-paste`

Disable copy paste between the client and the guest.

`disable-agent-file-xfer`

Disable spice-vdagent based file-xfer between the client and the guest.

`tls-port=<nr>`

Set the TCP port spice is listening on for encrypted channels.

x509-dir=<dir>

Set the x509 file directory. Expects same filenames as -vnc \$display,x509=\$dir

x509-key-file=<file>
x509-key-password=<file>
x509-cert-file=<file>
x509-cacert-file=<file>
x509-dh-key-file=<file>

The x509 file names can also be configured individually.

tls-ciphers=<list>

Specify which ciphers to use.

tls-
channel=[main|display|cursor|inputs|record|playback]
plaintext-
channel=[main|display|cursor|inputs|record|playback]

Force specific channel to be used with or without TLS encryption. The options can be specified multiple times to configure multiple channels. The special name "default" can be used to set the default mode. For channels which are not explicitly forced into one mode the spice client is allowed to pick tls/plaintext as he pleases.

image-compression=[auto_glz|auto_lz|quic|glz|lz|off]

Configure image compression (lossless). Default is auto_glz.

jpeg-wan-compression=[auto|never|always]
zlib-glz-wan-compression=[auto|never|always]

Configure wan image compression (lossy for slow links). Default is auto.

streaming-video=[off|all|filter]

Configure video stream detection. Default is off.

agent-mouse=[on|off]

Enable/disable passing mouse events via vagent. Default is on.

playback-compression=[on|off]

Enable/disable audio stream compression (using celt 0.5.1). Default is on.

`seamless-migration=[on|off]`

Enable/disable spice seamless migration. Default is off.

`gl=[on|off]`

Enable/disable OpenGL context. Default is off.

`rendernode=<file>`

DRM render node for OpenGL rendering. If not specified, it will pick the first available. (Since 2.9)

`-portrait`

Rotate graphical output 90 deg left (only PXA LCD).

`-rotate deg`

Rotate graphical output some deg left (only PXA LCD).

`-vga type`

Select type of VGA card to emulate. Valid values for *type* are

`cirrus`

Cirrus Logic GD5446 Video card. All Windows versions starting from Windows 95 should recognize and use this graphic card. For optimal performances, use 16 bit color depth in the guest and the host OS. (This card was the default before QEMU 2.2)

`std`

Standard VGA card with Bochs VBE extensions. If your guest OS supports the VESA 2.0 VBE extensions (e.g. Windows XP) and if you want to use high resolution modes ($\geq 1280 \times 1024 \times 16$) then you should use this option. (This card is the default since QEMU 2.2)

`vmware`

VMWare SVGA-II compatible adapter. Use it if you have sufficiently recent XFree86/XOrg server or Windows guest with a driver for this card.

`qxl`

QXL paravirtual graphic card. It is VGA compatible (including VESA 2.0 VBE support). Works best with qxl guest drivers installed though. Recommended choice when using the spice protocol.

tcx

(sun4m only) Sun TCX framebuffer. This is the default framebuffer for sun4m machines and offers both 8-bit and 24-bit colour depths at a fixed resolution of 1024x768.

cg3

(sun4m only) Sun cgthree framebuffer. This is a simple 8-bit framebuffer for sun4m machines available in both 1024x768 (OpenBIOS) and 1152x900 (OBP) resolutions aimed at people wishing to run older Solaris versions.

virtio

Virtio VGA card.

none

Disable VGA card.

`-full-screen`

Start in full screen.

`-g widthxheight[xdepth]`

Set the initial graphical resolution and depth (PPC, SPARC only).

`-vnc display[,option[,option[,...]]]`

Normally, if QEMU is compiled with graphical window support, it displays output such as guest graphics, guest console, and the QEMU monitor in a window. With this option, you can have QEMU listen on VNC display *display* and redirect the VGA display over the VNC session. It is very useful to enable the usb tablet device when using this option (option `-device usb-tablet`). When using the VNC display, you must use the `-k` parameter to set the keyboard layout if you are not using `en-us`. Valid syntax for the *display* is

`to=L`

With this option, QEMU will try next available VNC *displays*, until the number *L*, if the originally defined `"-vnc display"` is not available, e.g. port 5900+*display* is already used by another application. By default, `to=0`.

host:d

TCP connections will only be allowed from *host* on display *d*. By convention the TCP port is 5900+*d*. Optionally, *host* can be omitted in which case the server will accept connections from any host.

unix:path

Connections will be allowed over UNIX domain sockets where *path* is the location of a unix socket to listen for connections on.

none

VNC is initialized but not started. The `monitor change` command can be used to later start the VNC server.

Following the *display* value there may be one or more *option* flags separated by commas. Valid options are

reverse

Connect to a listening VNC client via a “reverse” connection. The client is specified by the *display*. For reverse network connections (*host:d,reverse*), the *d* argument is a TCP port number, not a display number.

websocket

Opens an additional TCP listening port dedicated to VNC Websocket connections. If a bare *websocket* option is given, the Websocket port is 5700+*display*. An alternative port can be specified with the syntax `websocket=port`.

If *host* is specified connections will only be allowed from this host. It is possible to control the websocket listen address independently, using the syntax `websocket=host:port`.

If no TLS credentials are provided, the websocket connection runs in unencrypted mode. If TLS credentials are provided, the websocket connection requires encrypted client connections.

password

Require that password based authentication is used for client connections.

The password must be set separately using the `set_password` command in the [pcsys_monitor](#). The syntax to change your password is: `set_password <protocol> <password>` where <protocol> could be either "vnc" or "spice".

If you would like to change <protocol> password expiration, you should use `expire_password <protocol> <expiration-time>` where expiration time could be one of the following options: now, never, +seconds or UNIX time of expiration, e.g. +60 to make password expire in 60 seconds, or 1335196800 to make password expire on "Mon Apr 23 12:00:00 EDT 2012" (UNIX time for this date and time).

You can also use keywords "now" or "never" for the expiration time to allow <protocol> password to expire immediately or never expire.

`tls-creds=ID`

Provides the ID of a set of TLS credentials to use to secure the VNC server. They will apply to both the normal VNC server socket and the websocket socket (if enabled). Setting TLS credentials will cause the VNC server socket to enable the VeNCrypt auth mechanism. The credentials should have been previously created using the `-object tls-creds` argument.

`tls-authz=ID`

Provides the ID of the QAuthZ authorization object against which the client's x509 distinguished name will be validated. This object is only resolved at time of use, so can be deleted and recreated on the fly while the VNC server is active. If missing, it will default to denying access.

`sasl`

Require that the client use SASL to authenticate with the VNC server. The exact choice of authentication method used is controlled from the system / user's SASL configuration file for the 'qemu' service. This is typically found in `/etc/sasl2/qemu.conf`. If running QEMU as an unprivileged user, an environment variable `SASL_CONF_PATH` can be used to make it search alternate locations for the service config. While some SASL auth methods can also provide data encryption (eg GSSAPI), it is recommended that SASL always be combined with the 'tls' and 'x509' settings to enable use of SSL and server certificates. This ensures a data encryption preventing compromise of authentication credentials. See the [vnc_security](#) section for details on using SASL authentication.

`sasl-authz=ID`

Provides the ID of the QAuthZ authorization object against which the client's SASL username will be validated. This object is only resolved at time of use, so can be deleted and recreated on the fly while the VNC server is active. If missing, it will default to denying access.

`acl`

Legacy method for enabling authorization of clients against the x509 distinguished name and SASL username. It results in the creation of two `authz-list` objects with IDs of `vnc.username` and `vnc.x509dnname`. The rules for these objects must be configured with the HMP ACL commands.

This option is deprecated and should no longer be used. The new `sasl-authz` and `tls-authz` options are a replacement.

`lossy`

Enable lossy compression methods (gradient, JPEG, ...). If this option is set, VNC client may receive lossy framebuffer updates depending on its encoding settings. Enabling this option can save a lot of bandwidth at the expense of quality.

`non-adaptive`

Disable adaptive encodings. Adaptive encodings are enabled by default. An adaptive encoding will try to detect frequently updated screen regions, and send updates in these regions using a lossy encoding (like JPEG). This can be really helpful to save bandwidth when playing videos. Disabling adaptive encodings restores the original static behavior of encodings like Tight.

`share=[allow-exclusive|force-shared|ignore]`

Set display sharing policy. 'allow-exclusive' allows clients to ask for exclusive access. As suggested by the rfb spec this is implemented by dropping other connections. Connecting multiple clients in parallel requires all clients asking for a shared session (`vncviewer: -shared` switch). This is the default. 'force-shared' disables exclusive client access. Useful for shared desktop sessions, where you don't want someone forgetting specify `-shared` disconnect everybody else. 'ignore' completely ignores the shared flag and allows everybody connect unconditionally. Doesn't conform to the rfb spec but is traditional QEMU behavior.

`key-delay-ms`

Set keyboard delay, for key down and key up events, in milliseconds. Default is 10. Keyboards are low-bandwidth devices, so this slowdown can help the device and guest to keep up and not lose events in case events are arriving in bulk. Possible causes for the latter are flaky network connections, or scripts for automated testing.

`audiodev=audiodev`

Use the specified *audiodev* when the VNC client requests audio transmission. When not using an *-audiodev* argument, this option must be omitted, otherwise it must be present and specify a valid *audiodev*.

2.3.5 i386 target only

`-win2k-hack`

Use it when installing Windows 2000 to avoid a disk full bug. After Windows 2000 is installed, you no longer need this option (this option slows down the IDE transfers).

`-no-fd-bootchk`

Disable boot signature checking for floppy disks in BIOS. May be needed to boot from old floppy disks.

`-no-acpi`

Disable ACPI (Advanced Configuration and Power Interface) support. Use it if your guest OS complains about ACPI problems (PC target machine only).

`-no-hpet`

Disable HPET support.

`-acpitable`

`[sig=str][,rev=n][,oem_id=str][,oem_table_id=str][,oem_rev=n]
[,asl_compiler_id=str][,asl_compiler_rev=n][,data=file1[:
file2]...]`

Add ACPI table with specified header fields and context from specified files. For *file=*, take whole ACPI table from the specified files, including all ACPI headers (possible overridden by other options). For *data=*, only data portion of the table is used, all header information is specified in the command line. If a SLIC table is supplied to QEMU, then the SLIC's *oem_id* and *oem_table_id* fields will override the same in the RSDT and the FADT (a.k.a. FACP), in order to ensure the field matches required by the Microsoft SLIC spec and the ACPI spec.

`-smbios file=binary`

Load SMBIOS entry from binary file.

`-smbios`

`type=0[,vendor=str][,version=str][,date=str][,release=%d.
%d][,uefi=on|off]`

Specify SMBIOS type 0 fields

```
-smbios  
type=1[,manufacturer=str][,product=str][,version=str][,serial=str][,uuid=uuid][,sku=str][,family=str]
```

Specify SMBIOS type 1 fields

```
-smbios  
type=2[,manufacturer=str][,product=str][,version=str][,serial=str][,asset=str][,location=str]
```

Specify SMBIOS type 2 fields

```
-smbios  
type=3[,manufacturer=str][,version=str][,serial=str][,asset=str][,sku=str]
```

Specify SMBIOS type 3 fields

```
-smbios  
type=4[,sock_pfx=str][,manufacturer=str][,version=str][,serial=str][,asset=str][,part=str]
```

Specify SMBIOS type 4 fields

```
-smbios  
type=17[,loc_pfx=str][,bank=str][,manufacturer=str][,serial=str][,asset=str][,part=str][,speed=%d]
```

Specify SMBIOS type 17 fields

2.3.6 Network options

```
-nic [tap|bridge|user|l2tpv3|vde|netmap|vhost-user|socket][,...][,mac=macaddr][,model=mn]
```

This option is a shortcut for configuring both the on-board (default) guest NIC hardware and the host network backend in one go. The host backend options are the same as with the corresponding `-netdev` options below. The guest NIC model can be set with `model=modelname`. Use `model=help` to list the available device types. The hardware MAC address can be set with `mac=macaddr`.

The following two example do exactly the same, to show how `-nic` can be used to shorten the command line length:

```
qemu-system-x86_64 -netdev user,id=n1,ipv6=off -device
e1000,netdev=n1,mac=52:54:98:76:54:32
qemu-system-x86_64 -nic
user,ipv6=off,model=e1000,mac=52:54:98:76:54:32
-nic none
```

Indicate that no network devices should be configured. It is used to override the default configuration (default NIC with “user” host network backend) which is activated if no other networking options are provided.

```
-netdev user,id=id[,option][,option][,...]
```

Configure user mode host network backend which requires no administrator privilege to run. Valid options are:

`id=id`

Assign symbolic name for use in monitor commands.

`ipv4=on|off` and `ipv6=on|off`

Specify that either IPv4 or IPv6 must be enabled. If neither is specified both protocols are enabled.

`net=addr[/mask]`

Set IP network address the guest will see. Optionally specify the netmask, either in the form a.b.c.d or as number of valid top-most bits. Default is 10.0.2.0/24.

`host=addr`

Specify the guest-visible address of the host. Default is the 2nd IP in the guest network, i.e. x.x.x.2.

`ipv6-net=addr[/int]`

Set IPv6 network address the guest will see (default is fec0::/64). The network prefix is given in the usual hexadecimal IPv6 address notation. The prefix size is optional, and is given as the number of valid top-most bits (default is 64).

`ipv6-host=addr`

Specify the guest-visible IPv6 address of the host. Default is the 2nd IPv6 in the guest network, i.e. xxxx::2.

`restrict=on|off`

If this option is enabled, the guest will be isolated, i.e. it will not be able to contact the host and no guest IP packets will be routed over the host to the outside. This option does not affect any explicitly set forwarding rules.

`hostname=name`

Specifies the client hostname reported by the built-in DHCP server.

`dhcpstart=addr`

Specify the first of the 16 IPs the built-in DHCP server can assign. Default is the 15th to 31st IP in the guest network, i.e. x.x.x.15 to x.x.x.31.

`dns=addr`

Specify the guest-visible address of the virtual nameserver. The address must be different from the host address. Default is the 3rd IP in the guest network, i.e. x.x.x.3.

`ipv6-dns=addr`

Specify the guest-visible address of the IPv6 virtual nameserver. The address must be different from the host address. Default is the 3rd IP in the guest network, i.e. xxxx::3.

`dnssearch=domain`

Provides an entry for the domain-search list sent by the built-in DHCP server. More than one domain suffix can be transmitted by specifying this option multiple times. If supported, this will cause the guest to automatically try to append the given domain suffix(es) in case a domain name can not be resolved.

Example:

```
qemu-system-x86_64 -nic
user,dnssearch=mgmt.example.org,dnssearch=example.org
domainname=domain
```

Specifies the client domain name reported by the built-in DHCP server.

`tftp=dir`

When using the user mode network stack, activate a built-in TFTP server. The files in *dir* will be exposed as the root of a TFTP server. The TFTP client on the guest must be configured in binary mode (use the command `bin` of the Unix TFTP client).

`tftp-server-name=name`

In BOOTP reply, broadcast *name* as the "TFTP server name" (RFC2132 option 66). This can be used to advise the guest to load boot files or configurations from a different server than the host address.

```
bootfile=file
```

When using the user mode network stack, broadcast *file* as the BOOTP filename. In conjunction with `tftp`, this can be used to network boot a guest from a local directory.

Example (using pxelinux):

```
qemu-system-x86_64 -hda linux.img -boot n -device e1000,netdev=n1 \
-netdev user,id=n1,tftp=/path/to/tftp/files,bootfile=/pxelinux.0
smb=dir [,smbserver=addr]
```

When using the user mode network stack, activate a built-in SMB server so that Windows OSes can access to the host files in *dir* transparently. The IP address of the SMB server can be set to *addr*. By default the 4th IP in the guest network is used, i.e. x.x.x.4.

In the guest Windows OS, the line:

```
10.0.2.4 smbserver
```

must be added in the file `C:\WINDOWS\LMHOSTS` (for windows 9x/Me) or `C:\WINNT\SYSTEM32\DRIVERS\ETC\LMHOSTS` (Windows NT/2000).

Then *dir* can be accessed in `\\smbserver\qemu`.

Note that a SAMBA server must be installed on the host OS.

```
hostfwd=[tcp|udp]:[hostaddr]:hostport-[guestaddr]:guestport
```

Redirect incoming TCP or UDP connections to the host port *hostport* to the guest IP address *guestaddr* on guest port *guestport*. If *guestaddr* is not specified, its value is x.x.x.15 (default first address given by the built-in DHCP server). By specifying *hostaddr*, the rule can be bound to a specific host interface. If no connection type is set, TCP is used. This option can be given multiple times.

For example, to redirect host X11 connection from screen 1 to guest screen 0, use the following:

```
# on the host
qemu-system-x86_64 -nic user,hostfwd=tcp:127.0.0.1:6001-:6000
```

```
# this host xterm should open in the guest X11 server
xterm -display :1
```

To redirect telnet connections from host port 5555 to telnet port on the guest, use the following:

```
# on the host
qemu-system-x86_64 -nic user,hostfwd=tcp::5555-:23
telnet localhost 5555
```

Then when you use on the host `telnet localhost 5555`, you connect to the guest telnet server.

```
guestfwd=[tcp]:server:port-dev
guestfwd=[tcp]:server:port-cmd:command
```

Forward guest TCP connections to the IP address *server* on port *port* to the character device *dev* or to a program executed by *cmd:command* which gets spawned for each connection. This option can be given multiple times.

You can either use a chardev directly and have that one used throughout QEMU's lifetime, like in the following example:

```
# open 10.10.1.1:4321 on bootup, connect 10.0.2.100:1234 to it
whenever
# the guest accesses it
qemu-system-x86_64 -nic user,guestfwd=tcp:10.0.2.100:1234-
tcp:10.10.1.1:4321
```

Or you can execute a command on every TCP connection established by the guest, so that QEMU behaves similar to an `inetd` process for that virtual server:

```
# call "netcat 10.10.1.1 4321" on every TCP connection to
10.0.2.100:1234
# and connect the TCP stream to its stdin/stdout
qemu-system-x86_64 -nic
'user,id=n1,guestfwd=tcp:10.0.2.100:1234-cmd:netcat 10.10.1.1
4321'
```

```
-netdev
tap,id=id[,fd=h][,ifname=name][,script=file][,downscript=
dfile][,br=bridge][,helper=helper]
```

Configure a host TAP network backend with ID *id*.

Use the network script *file* to configure it and the network script *dfile* to deconfigure it. If *name* is not provided, the OS automatically provides one. The default network configure script is `/etc/qemu-ifup` and the default network deconfigure script is `/etc/qemu-ifdown`.

Use `script=no` or `downscript=no` to disable script execution.

If running QEMU as an unprivileged user, use the network helper *helper* to configure the TAP interface and attach it to the bridge. The default network

helper executable is `/path/to/qemu-bridge-helper` and the default bridge device is `br0`.

`fd=h` can be used to specify the handle of an already opened host TAP interface.

Examples:

```
#launch a QEMU instance with the default network script
qemu-system-x86_64 linux.img -nic tap
#launch a QEMU instance with two NICs, each one connected
#to a TAP device
qemu-system-x86_64 linux.img \
-netdev tap,id=nd0,ifname=tap0 -device e1000,netdev=nd0 \
-netdev tap,id=nd1,ifname=tap1 -device rtl8139,netdev=nd1
#launch a QEMU instance with the default network helper to
#connect a TAP device to bridge br0
qemu-system-x86_64 linux.img -device virtio-net-pci,netdev=n1 \
-netdev tap,id=n1,"helper=/path/to/qemu-bridge-helper"
-netdev bridge,id=id[,br=bridge][,helper=helper]
```

Connect a host TAP network interface to a host bridge device.

Use the network helper *helper* to configure the TAP interface and attach it to the bridge. The default network helper executable is `/path/to/qemu-bridge-helper` and the default bridge device is `br0`.

Examples:

```
#launch a QEMU instance with the default network helper to
#connect a TAP device to bridge br0
qemu-system-x86_64 linux.img -netdev bridge,id=n1 -device virtio-
net,netdev=n1
#launch a QEMU instance with the default network helper to
#connect a TAP device to bridge qemubr0
qemu-system-x86_64 linux.img -netdev bridge,br=qemubr0,id=n1 -
device virtio-net,netdev=n1
-netdev
socket,id=id[,fd=h][,listen=[host]:port][,connect=host:po
rt]
```

This host network backend can be used to connect the guest's network to another QEMU virtual machine using a TCP socket connection. If `listen` is specified, QEMU waits for incoming connections on *port* (*host* is optional). `connect` is used to connect to another QEMU instance using the `listen` option. `fd=h` specifies an already opened TCP socket.

Example:

```
# launch a first QEMU instance
qemu-system-x86_64 linux.img \
-device e1000,netdev=n1,mac=52:54:00:12:34:56 \
-netdev socket,id=n1,listen=:1234
```

```

# connect the network of this instance to the network of the
first instance
qemu-system-x86_64 linux.img \
-device e1000,netdev=n2,mac=52:54:00:12:34:57 \
-netdev socket,id=n2,connect=127.0.0.1:1234
-netdev
socket,id=id[,fd=h][,mcast=maddr:port[,localaddr=addr]]

```

Configure a socket host network backend to share the guest's network traffic with another QEMU virtual machines using a UDP multicast socket, effectively making a bus for every QEMU with same multicast address *maddr* and *port*.

NOTES:

1. Several QEMU can be running on different hosts and share same bus (assuming correct multicast setup for these hosts).
2. mcast support is compatible with User Mode Linux (argument `ethN=mcast`), see <http://user-mode-linux.sf.net>.
3. Use `fd=h` to specify an already opened UDP multicast socket.

Example:

```

# launch one QEMU instance
qemu-system-x86_64 linux.img \
-device e1000,netdev=n1,mac=52:54:00:12:34:56 \
-netdev socket,id=n1,mcast=230.0.0.1:1234
# launch another QEMU instance on same "bus"
qemu-system-x86_64 linux.img \
-device e1000,netdev=n2,mac=52:54:00:12:34:57 \
-netdev socket,id=n2,mcast=230.0.0.1:1234
# launch yet another QEMU instance on same "bus"
qemu-system-x86_64 linux.img \
-device e1000,netdev=n3,mac=52:54:00:12:34:58 \
-netdev socket,id=n3,mcast=230.0.0.1:1234

```

Example (User Mode Linux compat.):

```

# launch QEMU instance (note mcast address selected is UML's
default)
qemu-system-x86_64 linux.img \
-device e1000,netdev=n1,mac=52:54:00:12:34:56 \
-netdev socket,id=n1,mcast=239.192.168.1:1102
# launch UML
/path/to/linux ubd0=/path/to/root_fs eth0=mcast

```

Example (send packets from host's 1.2.3.4):

```

qemu-system-x86_64 linux.img \
-device e1000,netdev=n1,mac=52:54:00:12:34:56 \
-netdev socket,id=n1,mcast=239.192.168.1:1102,localaddr=1.2.3.4
-netdev
l2tpv3,id=id,src=srcaddr,dst=dstaddr[,srcport=srcport][,dstport=dstport],txsession=txsession[,rxsession=rxsession][,ipv6][,udp][,cookie64][,counter][,pincounter][,txcookie=txcookie][,rxcookie=rxcookie][,offset=offset]

```

Configure a L2TPv3 pseudowire host network backend. L2TPv3 (RFC3391) is a popular protocol to transport Ethernet (and other Layer 2) data frames between two systems. It is present in routers, firewalls and the Linux kernel (from version 3.3 onwards).

This transport allows a VM to communicate to another VM, router or firewall directly.

`src=srcaddr`

source address (mandatory)

`dst=dstaddr`

destination address (mandatory)

`udp`

select udp encapsulation (default is ip).

`srcport=srcport`

source udp port.

`dstport=dstport`

destination udp port.

`ipv6`

force v6, otherwise defaults to v4.

`rxcookie=rxcookie`

`txcookie=txcookie`

Cookies are a weak form of security in the l2tpv3 specification. Their function is mostly to prevent misconfiguration. By default they are 32 bit.

`cookie64`

Set cookie size to 64 bit instead of the default 32

`counter=off`

Force a 'cut-down' L2TPv3 with no counter as in draft-mkonstan-l2tpext-keyed-ipv6-tunnel-00

`pincounter=on`

Work around broken counter handling in peer. This may also help on networks which have packet reorder.

`offset=offset`

Add an extra offset between header and data

For example, to attach a VM running on host 4.3.2.1 via L2TPv3 to the bridge br-lan on the remote Linux host 1.2.3.4:

```
# Setup tunnel on linux host using raw ip as encapsulation
# on 1.2.3.4
ip l2tp add tunnel remote 4.3.2.1 local 1.2.3.4 tunnel_id 1
peer_tunnel_id 1 \
encap udp udp_sport 16384 udp_dport 16384
ip l2tp add session tunnel_id 1 name vmtunnel0 session_id \
0xFFFFFFFF peer_session_id 0xFFFFFFFF
ifconfig vmtunnel0 mtu 1500
ifconfig vmtunnel0 up
brctl addif br-lan vmtunnel0

# on 4.3.2.1
# launch QEMU instance - if your network has reorder or is very
lossy add ,pincounter

qemu-system-x86_64 linux.img -device e1000,netdev=n1 \
-netdev
l2tpv3,id=n1,src=4.2.3.1,dst=1.2.3.4,udp,srcport=16384,dstport=16
384,rxsession=0xffffffff,txsession=0xffffffff,counter
```

```
-netdev
vde,id=id[,sock=socketpath][,port=n][,group=groupname][,m
ode=octalmode]
```

Configure VDE backend to connect to PORT *n* of a vde switch running on host and listening for incoming connections on *socketpath*. Use GROUP *groupname* and MODE *octalmode* to change default ownership and permissions for communication port. This option is only available if QEMU has been compiled with vde support enabled.

Example:

```
# launch vde switch
vde_switch -F -sock /tmp/myswitch
# launch QEMU instance
qemu-system-x86_64 linux.img -nic vde,sock=/tmp/myswitch
-netdev vhost-
user,chardev=id[,vhostforce=on|off][,queues=n]
```

Establish a vhost-user netdev, backed by a chardev *id*. The chardev should be a unix domain socket backed one. The vhost-user uses a specifically defined protocol to pass vhost ioctl replacement messages to an application on the other end of the socket. On non-MSIX guests, the feature can be forced

with *vhostforce*. Use *'queues=n'* to specify the number of queues to be created for multiqueue vhost-user.

Example:

```
qemu -m 512 -object memory-backend-file,id=mem,size=512M,mem-  
path=/hugetlbfs,share=on \  
-numa node,memdev=mem \  
-chardev socket,id=chr0,path=/path/to/socket \  
-netdev type=vhost-user,id=net0,chardev=chr0 \  
-device virtio-net-pci,netdev=net0  
-netdev hubport,id=id,hubid=hubid[,netdev=nd]
```

Create a hub port on the emulated hub with ID *hubid*.

The hubport netdev lets you connect a NIC to a QEMU emulated hub instead of a single netdev. Alternatively, you can also connect the hubport to another netdev with ID *nd* by using the *netdev=nd* option.

```
-net nic[,netdev=nd] [,macaddr=mac] [,model=type]  
[,name=name] [,addr=addr] [,vectors=v]
```

Legacy option to configure or create an on-board (or machine default) Network Interface Card(NIC) and connect it either to the emulated hub with ID 0 (i.e. the default hub), or to the netdev *nd*. If *model* is omitted, then the default NIC model associated with the machine type is used. Note that the default NIC model may change in future QEMU releases, so it is highly recommended to always specify a model. Optionally, the MAC address can be changed to *mac*, the device address set to *addr* (PCI cards only), and a *name* can be assigned for use in monitor commands. Optionally, for PCI cards, you can specify the number *v* of MSI-X vectors that the card should have; this option currently only affects virtio cards; set *v = 0* to disable MSI-X. If no *-net* option is specified, a single NIC is created. QEMU can emulate several different models of network card. Use *-net nic,model=help* for a list of available devices for your target.

```
-net user|tap|bridge|socket|l2tpv3|vde[,...] [,name=name]
```

Configure a host network backend (with the options corresponding to the same *-netdev* option) and connect it to the emulated hub 0 (the default hub). Use *name* to specify the name of the hub port.

2.3.7 Character device options

The general form of a character device option is:

```
-chardev backend,id=id[,mux=on|off] [,options]
```

Backend is one

of: null, socket, udp, msmouse, vc, ringbuf, file, pipe, console, serial, pty, stdio, braille, tty, parallel, parport, spicevmc, spiceport. The specific backend will determine the applicable options.

Use `-chardev help` to print all available chardev backend types.

All devices must have an id, which can be any string up to 127 characters long. It is used to uniquely identify this device in other command line directives.

A character device may be used in multiplexing mode by multiple front-ends. Specify `mux=on` to enable this mode. A multiplexer is a "1:N" device, and here the "1" end is your specified chardev backend, and the "N" end is the various parts of QEMU that can talk to a chardev. If you create a chardev with `id=myid` and `mux=on`, QEMU will create a multiplexer with your specified ID, and you can then configure multiple front ends to use that chardev ID for their input/output. Up to four different front ends can be connected to a single multiplexed chardev. (Without multiplexing enabled, a chardev can only be used by a single front end.) For instance you could use this to allow a single stdio chardev to be used by two serial ports and the QEMU monitor:

```
-chardev stdio,mux=on,id=char0 \  
-mon chardev=char0,mode=readline \  
-serial chardev:char0 \  
-serial chardev:char0
```

You can have more than one multiplexer in a system configuration; for instance you could have a TCP port multiplexed between UART 0 and UART 1, and stdio multiplexed between the QEMU monitor and a parallel port:

```
-chardev stdio,mux=on,id=char0 \  
-mon chardev=char0,mode=readline \  
-parallel chardev:char0 \  
-chardev tcp,...,mux=on,id=char1 \  
-serial chardev:char1 \  
-serial chardev:char1
```

When you're using a multiplexed character device, some escape sequences are interpreted in the input. See [Keys in the character backend multiplexer](#).

Note that some other command line options may implicitly create multiplexed character backends; for instance `-serial mon:stdio` creates a multiplexed stdio backend connected to the serial port and the QEMU monitor, and `-nographic` also multiplexes the console and the monitor to stdio.

There is currently no support for multiplexing in the other direction (where a single QEMU front end takes input and output from multiple chardevs).

Every backend supports the `logfile` option, which supplies the path to a file to record all data transmitted via the backend. The `logappend` option controls whether the log file will be truncated or appended to when opened.

The available backends are:

```
-chardev null,id=id
```

A void device. This device will not emit any data, and will drop any data it receives. The null backend does not take any options.

```
-chardev socket,id=id[,TCP options or unix  
options][,server][,nowait][,telnet][,websocket][,reconnec  
t=seconds][,tls-creds=id][,tls-authz=id]
```

Create a two-way stream socket, which can be either a TCP or a unix socket. A unix socket will be created if `path` is specified. Behaviour is undefined if TCP options are specified for a unix socket.

`server` specifies that the socket shall be a listening socket.

`nowait` specifies that QEMU should not block waiting for a client to connect to a listening socket.

`telnet` specifies that traffic on the socket should interpret telnet escape sequences.

`websocket` specifies that the socket uses WebSocket protocol for communication.

`reconnect` sets the timeout for reconnecting on non-server sockets when the remote end goes away. qemu will delay this many seconds and then attempt to reconnect. Zero disables reconnecting, and is the default.

`tls-creds` requests enablement of the TLS protocol for encryption, and specifies the id of the TLS credentials to use for the handshake. The credentials must be previously created with the `-object tls-creds` argument.

`tls-auth` provides the ID of the QAuthZ authorization object against which the client's x509 distinguished name will be validated. This object is only resolved at time of use, so can be deleted and recreated on the fly while the chardev server is active. If missing, it will default to denying access.

TCP and unix socket options are given below:

TCP options:

```
port=port[,host=host][,to=to][,ipv4][,ipv6][,nodelay]
```

`host` for a listening socket specifies the local address to be bound. For a connecting socket specifies the remote host to connect to. `host` is optional for listening sockets. If not specified it defaults to `0.0.0.0`.

`port` for a listening socket specifies the local port to be bound. For a connecting socket specifies the port on the remote host to connect to. `port` can be given as either a port number or a service name. `port` is required.

`to` is only relevant to listening sockets. If it is specified, and `port` cannot be bound, QEMU will attempt to bind to subsequent ports up to and including `to` until it succeeds. `to` must be specified as a port number.

`ipv4` and `ipv6` specify that either IPv4 or IPv6 must be used. If neither is specified the socket may use either protocol.

`nodelay` disables the Nagle algorithm.

unix options: `path=path`

`path` specifies the local path of the unix socket. `path` is required.

`-chardev`

`udp,id=id[,host=host],port=port[,localaddr=localaddr][,localport=localport][,ipv4][,ipv6]`

Sends all traffic from the guest to a remote host over UDP.

`host` specifies the remote host to connect to. If not specified it defaults to `localhost`.

`port` specifies the port on the remote host to connect to. `port` is required.

`localaddr` specifies the local address to bind to. If not specified it defaults to `0.0.0.0`.

`localport` specifies the local port to bind to. If not specified any available local port will be used.

`ipv4` and `ipv6` specify that either IPv4 or IPv6 must be used. If neither is specified the device may use either protocol.

`-chardev msmouse,id=id`

Forward QEMU's emulated msmouse events to the guest. `msmouse` does not take any options.

```
-chardev  
vc,id=id[,width=width][,height=height][[,cols=cols][,rows=rows]]
```

Connect to a QEMU text console. *vc* may optionally be given a specific size.

width and *height* specify the width and height respectively of the console, in pixels.

cols and *rows* specify that the console be sized to fit a text console with the given dimensions.

```
-chardev ringbuf,id=id[,size=size]
```

Create a ring buffer with fixed size *size*. *size* must be a power of two and defaults to 64K.

```
-chardev file,id=id,path=path
```

Log all traffic received from the guest to a file.

path specifies the path of the file to be opened. This file will be created if it does not already exist, and overwritten if it does. *path* is required.

```
-chardev pipe,id=id,path=path
```

Create a two-way connection to the guest. The behaviour differs slightly between Windows hosts and other hosts:

On Windows, a single duplex pipe will be created at `\\.pipe\\path`.

On other hosts, 2 pipes will be created called `path.in` and `path.out`. Data written to `path.in` will be received by the guest. Data written by the guest can be read from `path.out`. QEMU will not create these fifos, and requires them to be present.

path forms part of the pipe path as described above. *path* is required.

```
-chardev console,id=id
```

Send traffic from the guest to QEMU's standard output. *console* does not take any options.

console is only available on Windows hosts.

```
-chardev serial,id=id,path=path
```

Send traffic from the guest to a serial device on the host.

On Unix hosts serial will actually accept any tty device, not only serial lines.

`path` specifies the name of the serial device to open.

```
-chardev pty,id=id
```

Create a new pseudo-terminal on the host and connect to it. `pty` does not take any options.

`pty` is not available on Windows hosts.

```
-chardev stdio,id=id[,signal=on|off]
```

Connect to standard input and standard output of the QEMU process.

`signal` controls if signals are enabled on the terminal, that includes exiting QEMU with the key sequence `Control-c`. This option is enabled by default, use `signal=off` to disable it.

```
-chardev braille,id=id
```

Connect to a local BrlAPI server. `braille` does not take any options.

```
-chardev tty,id=id,path=path
```

`tty` is only available on Linux, Sun, FreeBSD, NetBSD, OpenBSD and DragonFlyBSD hosts. It is an alias for `serial`.

`path` specifies the path to the tty. `path` is required.

```
-chardev parallel,id=id,path=path
```

```
-chardev parport,id=id,path=path
```

`parallel` is only available on Linux, FreeBSD and DragonFlyBSD hosts.

Connect to a local parallel port.

`path` specifies the path to the parallel port device. `path` is required.

```
-chardev spicevmc,id=id,debug=debug,name=name
```

`spicevmc` is only available when spice support is built in.

`debug` debug level for `spicevmc`

`name` name of spice channel to connect to

Connect to a spice virtual machine channel, such as vdiport.

```
-chardev spiceport, id=id, debug=debug, name=name
```

spiceport is only available when spice support is built in.

debug debug level for spicevmc

name name of spice port to connect to

Connect to a spice port, allowing a Spice client to handle the traffic identified by a name (preferably a fqdn).

2.3.8 TPM device options

The general form of a TPM device option is:

```
-tpmdev backend, id=id[, options]
```

The specific backend type will determine the applicable options. The `-tpmdev` option creates the TPM backend and requires a `-device` option that specifies the TPM frontend interface model.

Use `-tpmdev help` to print all available TPM backend types.

The available backends are:

```
-tpmdev passthrough, id=id, path=path, cancel-path=cancel-path
```

(Linux-host only) Enable access to the host's TPM using the passthrough driver.

path specifies the path to the host's TPM device, i.e., on a Linux host this would be `/dev/tpm0`. *path* is optional and by default `/dev/tpm0` is used.

cancel-path specifies the path to the host TPM device's sysfs entry allowing for cancellation of an ongoing TPM command. *cancel-path* is optional and by default QEMU will search for the sysfs entry to use.

Some notes about using the host's TPM with the passthrough driver:

The TPM device accessed by the passthrough driver must not be used by any other application on the host.

Since the host's firmware (BIOS/UEFI) has already initialized the TPM, the VM's firmware (BIOS/UEFI) will not be able to initialize the TPM again and may therefore not show a TPM-specific menu that would otherwise allow the

user to configure the TPM, e.g., allow the user to enable/disable or activate/deactivate the TPM. Further, if TPM ownership is released from within a VM then the host's TPM will get disabled and deactivated. To enable and activate the TPM again afterwards, the host has to be rebooted and the user is required to enter the firmware's menu to enable and activate the TPM. If the TPM is left disabled and/or deactivated most TPM commands will fail.

To create a passthrough TPM use the following two options:

```
-tpmdev passthrough,id=tpm0 -device tpm-tis,tpmdev=tpm0
```

Note that the `-tpmdev id` is `tpm0` and is referenced by `tpmdev=tpm0` in the device option.

```
-tpmdev emulator,id=id,chardev=dev
```

(Linux-host only) Enable access to a TPM emulator using Unix domain socket based chardev backend.

`chardev` specifies the unique ID of a character device backend that provides connection to the software TPM server.

To create a TPM emulator backend device with chardev socket backend:

```
-chardev socket,id=chrtpm,path=/tmp/swtpm-sock -tpmdev  
emulator,id=tpm0,chardev=chrtpm -device tpm-tis,tpmdev=tpm0
```

2.3.9 Linux/Multiboot boot specific

When using these options, you can use a given Linux or Multiboot kernel without installing it in the disk image. It can be useful for easier testing of various kernels.

```
-kernel bzImage
```

Use *bzImage* as kernel image. The kernel can be either a Linux kernel or in multiboot format.

```
-append cmdline
```

Use *cmdline* as kernel command line

```
-initrd file
```

Use *file* as initial ram disk.

```
-initrd "file1 arg=foo,file2"
```

This syntax is only available with multiboot.

Use *file1* and *file2* as modules and pass `arg=foo` as parameter to the first module.

`-dtb file`

Use *file* as a device tree binary (dtb) image and pass it to the kernel on boot.

2.3.10 Debug/Expert options

`-fw_cfg [name=]name, file=file`

Add named `fw_cfg` entry with contents from file *file*.

`-fw_cfg [name=]name, string=str`

Add named `fw_cfg` entry with contents from string *str*.

The terminating NUL character of the contents of *str* will not be included as part of the `fw_cfg` item data. To insert contents with embedded NUL characters, you have to use the *file* parameter.

The `fw_cfg` entries are passed by QEMU through to the guest.

Example:

```
-fw_cfg name=opt/com.mycompany/blob, file=./my_blob.bin
```

creates an `fw_cfg` entry named `opt/com.mycompany/blob` with contents from `./my_blob.bin`.

`-serial dev`

Redirect the virtual serial port to host character device *dev*. The default device is `vc` in graphical mode and `stdio` in non graphical mode.

This option can be used several times to simulate up to 4 serial ports.

Use `-serial none` to disable all serial ports.

Available character devices are:

`vc [: WxH]`

Virtual console. Optionally, a width and height can be given in pixel with

```
vc:800x600
```

It is also possible to specify width or height in characters:

vc:80Cx24C

pty

[Linux only] Pseudo TTY (a new PTY is automatically allocated)

none

No device is allocated.

null

void device

chardev:*id*

Use a named character device defined with the `-chardev` option.

/dev/XXX

[Linux only] Use host tty, e.g. /dev/ttyS0. The host serial port parameters are set according to the emulated ones.

/dev/parportN

[Linux only, parallel port only] Use host parallel port *N*. Currently SPP and EPP parallel port features can be used.

file:*filename*

Write output to *filename*. No character can be read.

stdio

[Unix only] standard input/output

pipe:*filename*

name pipe *filename*

COM*n*

[Windows only] Use host serial port *n*

udp:[*remote_host*]:*remote_port*[@[*src_ip*]:*src_port*]

This implements UDP Net Console. When *remote_host* or *src_ip* are not specified they default to 0.0.0.0. When not using a specified *src_port* a random port is automatically chosen.

If you just want a simple readonly console you can use `netcat` or `nc`, by starting QEMU with: `-serial udp::4555` and `nc` as: `nc -u -l -p 4555`. Any time QEMU writes something to that port it will appear in the netconsole session.

If you plan to send characters back via netconsole or you want to stop and start QEMU a lot of times, you should have QEMU use the same source port each time by using something like `-serial udp::4555@:4556` to QEMU. Another approach is to use a patched version of netcat which can listen to a TCP port and send and receive characters via udp. If you have a patched version of netcat which activates telnet remote echo and single char transfer, then you can use the following options to set up a netcat redirector to allow telnet on port 5555 to access the QEMU port.

QEMU Options:

`-serial udp::4555@:4556`

netcat options:

`-u -P 4555 -L 0.0.0.0:4556 -t -p 5555 -I -T`

telnet options:

`localhost 5555`

`tcp:[host]:port[,server][,nowait][,nodelay][,reconnect=seconds]`

The TCP Net Console has two modes of operation. It can send the serial I/O to a location or wait for a connection from a location. By default the TCP Net Console is sent to *host* at the *port*. If you use the *server* option QEMU will wait for a client socket application to connect to the port before continuing, unless the *nowait* option was specified. The *nodelay* option disables the Nagle buffering algorithm. The *reconnect* option only applies if *noserver* is set, if the connection goes down it will attempt to reconnect at the given interval. If *host* is omitted, 0.0.0.0 is assumed. Only one TCP connection at a time is accepted. You can use `telnet` to connect to the corresponding character device.

Example to send tcp console to 192.168.0.2 port 4444

`-serial tcp:192.168.0.2:4444`

Example to listen and wait on port 4444 for connection

`-serial tcp::4444,server`

Example to not wait and listen on ip 192.168.0.100 port 4444

`-serial tcp:192.168.0.100:4444,server,nowait`

```
telnet:host:port[,server][,nowait][,nodelay]
```

The telnet protocol is used instead of raw tcp sockets. The options work the same as if you had specified `-serial tcp`. The difference is that the port acts like a telnet server or client using telnet option negotiation. This will also allow you to send the MAGIC_SYSRQ sequence if you use a telnet that supports sending the break sequence. Typically in unix telnet you do it with Control-] and then type "send break" followed by pressing the enter key.

```
websocket:host:port,server[,nowait][,nodelay]
```

The WebSocket protocol is used instead of raw tcp socket. The port acts as a WebSocket server. Client mode is not supported.

```
unix:path[,server][,nowait][,reconnect=seconds]
```

A unix domain socket is used instead of a tcp socket. The option works the same as if you had specified `-serial tcp` except the unix domain socket *path* is used for connections.

```
mon:dev_string
```

This is a special option to allow the monitor to be multiplexed onto another serial port. The monitor is accessed with key sequence of Control-a and then pressing c. *dev_string* should be any one of the serial devices specified above. An example to multiplex the monitor onto a telnet server listening on port 4444 would be:

```
-serial mon:telnet::4444,server,nowait
```

When the monitor is multiplexed to stdio in this way, Ctrl+C will not terminate QEMU any more but will be passed to the guest instead.

```
braille
```

Braille device. This will use BrlAPI to display the braille output on a real or fake device.

```
msmouse
```

Three button serial mouse. Configure the guest to use Microsoft protocol.

```
-parallel dev
```

Redirect the virtual parallel port to host device *dev* (same devices as the serial port). On Linux hosts, `/dev/parportN` can be used to use hardware devices connected on the corresponding host parallel port.

This option can be used several times to simulate up to 3 parallel ports.

Use `-parallel none` to disable all parallel ports.

`-monitor dev`

Redirect the monitor to host device *dev* (same devices as the serial port). The default device is `vc` in graphical mode and `stdio` in non graphical mode. Use `-monitor none` to disable the default monitor.

`-qmp dev`

Like `-monitor` but opens in 'control' mode.

`-qmp-pretty dev`

Like `-qmp` but uses pretty JSON formatting.

`-mon`

`[chardev=]name[,mode=readline|control][,pretty[=on|off]]`

Setup monitor on chardev *name*. `pretty` turns on JSON pretty printing easing human reading and debugging.

`-debugcon dev`

Redirect the debug console to host device *dev* (same devices as the serial port). The debug console is an I/O port which is typically port 0xe9; writing to that I/O port sends output to this device. The default device is `vc` in graphical mode and `stdio` in non graphical mode.

`-pidfile file`

Store the QEMU process PID in *file*. It is useful if you launch QEMU from a script.

`-singlestep`

Run the emulation in single step mode.

`--preconfig`

Pause QEMU for interactive configuration before the machine is created, which allows querying and configuring properties that will affect machine initialization. Use QMP command 'x-exit-preconfig' to exit the preconfig state and move to the next state (i.e. run guest if `-S` isn't used or pause the second time if `-S` is used). This option is experimental.

-S

Do not start CPU at startup (you must type 'c' in the monitor).

-realtime mlock=on|off

Run qemu with realtime features. mlocking qemu and guest memory can be enabled via mlock=on (enabled by default).

-overcommit mem-lock=on|off

-overcommit cpu-pm=on|off

Run qemu with hints about host resource overcommit. The default is to assume that host overcommits all resources.

Locking qemu and guest memory can be enabled via mem-lock=on (disabled by default). This works when host memory is not overcommitted and reduces the worst-case latency for guest. This is equivalent to `realtime`.

Guest ability to manage power state of host cpus (increasing latency for other processes on the same host cpu, but decreasing latency for guest) can be enabled via `cpu-pm=on` (disabled by default). This works best when host CPU is not overcommitted. When used, host estimates of CPU cycle and power utilization will be incorrect, not taking into account guest idle time.

-gdb dev

Wait for gdb connection on device *dev* (see [gdb_usage](#)). Typical connections will likely be TCP-based, but also UDP, pseudo TTY, or even stdio are reasonable use case. The latter is allowing to start QEMU from within gdb and establish the connection via a pipe:

```
(gdb) target remote | exec qemu-system-x86_64 -gdb stdio ...
```

-S

Shorthand for `-gdb tcp::1234`, i.e. open a gdbserver on TCP port 1234 (see [gdb_usage](#)).

-d item1[,...]

Enable logging of specified items. Use '`-d help`' for a list of log items.

-D logfile

Output log in *logfile* instead of to stderr

-dfilter range1[,...]

Filter debug output to that relevant to a range of target addresses. The filter spec can be either *start+size*, *start-size* or *start..end* where *start* *end* and *size* are the addresses and sizes required. For example:

```
-dfilter  
0x8000..0x8fff,0xffffffffc000080000+0x200,0xffffffffc000060000-0x1000
```

Will dump output for any code in the 0x1000 sized block starting at 0x8000 and the 0x200 sized block starting at 0xffffffffc000080000 and another 0x1000 sized block starting at 0xffffffffc00005f000.

`-seed number`

Force the guest to use a deterministic pseudo-random number generator, seeded with *number*. This does not affect crypto routines within the host.

`-L path`

Set the directory for the BIOS, VGA BIOS and keymaps.

To list all the data directories, use `-L help`.

`-bios file`

Set the filename for the BIOS.

`-enable-kvm`

Enable KVM full virtualization support. This option is only available if KVM support is enabled when compiling.

`-xen-domid id`

Specify xen guest domain *id* (XEN only).

`-xen-attach`

Attach to existing xen domain. libxl will use this when starting QEMU (XEN only). Restrict set of available xen operations to specified domain id (XEN only).

`-no-reboot`

Exit instead of rebooting.

`-no-shutdown`

Don't exit QEMU on guest shutdown, but instead only stop the emulation. This allows for instance switching to monitor to commit changes to the disk image.

`-loadvm file`

Start right away with a saved state (`loadvm` in monitor)

`-daemonize`

Daemonize the QEMU process after initialization. QEMU will not detach from standard IO until it is ready to receive connections on any of its devices. This option is a useful way for external programs to launch QEMU without having to cope with initialization race conditions.

`-option-rom file`

Load the contents of *file* as an option ROM. This option is useful to load things like EtherBoot.

`-rtc`

`[base=utc|localtime|datetime] [,clock=host|rt|vm] [,driftfix=none|slew]`

Specify `base` as `utc` or `localtime` to let the RTC start at the current UTC or local time, respectively. `localtime` is required for correct date in MS-DOS or Windows. To start at a specific point in time, provide *datetime* in the format `2006-06-17T16:01:21` or `2006-06-17`. The default base is UTC.

By default the RTC is driven by the host system time. This allows using of the RTC as accurate reference clock inside the guest, specifically if the host time is smoothly following an accurate external reference clock, e.g. via NTP. If you want to isolate the guest time from the host, you can set `clock` to `rt` instead, which provides a host monotonic clock if host support it. To even prevent the RTC from progressing during suspension, you can set `clock` to `vm` (virtual clock). ‘`clock=vm`’ is recommended especially in `icount` mode in order to preserve determinism; however, note that in `icount` mode the speed of the virtual clock is variable and can in general differ from the host clock.

Enable `driftfix` (i386 targets only) if you experience time drift problems, specifically with Windows’ ACPI HAL. This option will try to figure out how many timer interrupts were not processed by the Windows guest and will re-inject them.

`-icount`

`[shift=N|auto] [,rr=record|replay,rrfile=filename,rrsnapshot=snapshot]`

Enable virtual instruction counter. The virtual cpu will execute one instruction every 2^N ns of virtual time. If `auto` is specified then the virtual cpu speed will

be automatically adjusted to keep virtual time within a few seconds of real time.

When the virtual cpu is sleeping, the virtual time will advance at default speed unless `sleep=on|off` is specified. With `sleep=on|off`, the virtual time will jump to the next timer deadline instantly whenever the virtual cpu goes to sleep mode and will not advance if no timer is enabled. This behavior give deterministic execution times from the guest point of view.

Note that while this option can give deterministic behavior, it does not provide cycle accurate emulation. Modern CPUs contain superscalar out of order cores with complex cache hierarchies. The number of instructions executed often has little or no correlation with actual performance.

`align=on` will activate the delay algorithm which will try to synchronise the host clock and the virtual clock. The goal is to have a guest running at the real frequency imposed by the shift option. Whenever the guest clock is behind the host clock and if `align=on` is specified then we print a message to the user to inform about the delay. Currently this option does not work when `shift` is `auto`. Note: The sync algorithm will work for those shift values for which the guest clock runs ahead of the host clock. Typically this happens when the shift value is high (how high depends on the host machine).

When `rr` option is specified deterministic record/replay is enabled. Replay log is written into *filename* file in record mode and read from this file in replay mode.

Option `rrsnapshot` is used to create new vm snapshot named *snapshot* at the start of execution recording. In replay mode this option is used to load the initial VM state.

`-watchdog model`

Create a virtual hardware watchdog device. Once enabled (by a guest action), the watchdog must be periodically polled by an agent inside the guest or else the guest will be restarted. Choose a model for which your guest has drivers.

The *model* is the model of hardware watchdog to emulate. Use `-watchdog help` to list available hardware models. Only one watchdog can be enabled for a guest.

The following models may be available:

`ib700`

iBASE 700 is a very simple ISA watchdog with a single timer.

i6300esb

Intel 6300ESB I/O controller hub is a much more featureful PCI-based dual-timer watchdog.

diag288

A virtual watchdog for s390x backed by the diagnose 288 hypercall (currently KVM only).

`-watchdog-action action`

The *action* controls what QEMU will do when the watchdog timer expires. The default is `reset` (forcefully reset the guest). Other possible actions are: `shutdown` (attempt to gracefully shutdown the guest), `poweroff` (forcefully poweroff the guest), `inject-nmi` (inject a NMI into the guest), `pause` (pause the guest), `debug` (print a debug message and continue), or `none` (do nothing).

Note that the `shutdown` action requires that the guest responds to ACPI signals, which it may not be able to do in the sort of situations where the watchdog would have expired, and thus `-watchdog-action shutdown` is not recommended for production use.

Examples:

```
-watchdog i6300esb -watchdog-action pause
-watchdog ib700
```

`-echr numeric_ascii_value`

Change the escape character used for switching to the monitor when using monitor and serial sharing. The default is `0x01` when using the `-nographic` option. `0x01` is equal to pressing Control-a. You can select a different character from the ascii control keys where 1 through 26 map to Control-a through Control-z. For instance you could use the either of the following to change the escape character to Control-t.

```
-echr 0x14
-echr 20
```

`-show-cursor`

Show cursor.

`-tb-size n`

Set TCG translation block cache size. Deprecated, use `'-accel tcg,tb-size=n'` instead.

```
-incoming tcp:[host]:port[,to=maxport][,ipv4][,ipv6]
-incoming rdma:host:port[,ipv4][,ipv6]
```


Prepare for incoming migration, listen on a given tcp port.

`-incoming unix:socketpath`

Prepare for incoming migration, listen on a given unix socket.

`-incoming fd:fd`

Accept incoming migration from a given filedescriptor.

`-incoming exec:cmdline`

Accept incoming migration as an output from specified external command.

`-incoming defer`

Wait for the URI to be specified via `migrate_incoming`. The monitor can be used to change settings (such as migration parameters) prior to issuing the `migrate_incoming` to allow the migration to begin.

`-only-migratable`

Only allow migratable devices. Devices will not be allowed to enter an unmigratable state.

`-nodefaults`

Don't create default devices. Normally, QEMU sets the default devices like serial port, parallel port, virtual console, monitor device, VGA adapter, floppy and CD-ROM drive and others. The `-nodefaults` option will disable all those default devices.

`-chroot dir`

Immediately before starting guest execution, chroot to the specified directory. Especially useful in combination with `-runas`.

`-runas user`

Immediately before starting guest execution, drop root privileges, switching to the specified user.

`-prom-env variable=value`

Set OpenBIOS nvram *variable* to given *value* (PPC, SPARC only).

`-semihosting`

Enable semihosting mode (ARM, M68K, Xtensa, MIPS, Nios II only).

```
-semlisting-config  
[enable=on|off] [,target=native|gdb|auto] [,chardev=id] [,arg=string[,...]]
```

Enable and configure semlisting (ARM, M68K, Xtensa, MIPS, Nios II only).

`target=native|gdb|auto`

Defines where the semlisting calls will be addressed, to QEMU (`native`) or to GDB (`gdb`). The default is `auto`, which means `gdb` during debug sessions and `native` otherwise.

`chardev=string`

Send the output to a chardev backend output for native or auto output when not in `gdb`

`arg=string1,arg=string2,...`

Allows the user to pass input arguments, and can be used multiple times to build up a list. The old-style `-kernel/-append` method of passing a command line is still supported for backward compatibility. If both the `--semlisting-config arg` and the `-kernel/-append` are specified, the former is passed to semlisting as it always takes precedence.

```
-old-param
```

Old param mode (ARM only).

```
-
```

```
sandbox arg[,obsolete=string] [,elevateprivileges=string] [  
,spawn=string] [,resourcecontrol=string]
```

Enable Secomp mode 2 system call filter. 'on' will enable syscall filtering and 'off' will disable it. The default is 'off'.

`obsolete=string`

Enable Obsolete system calls

`elevateprivileges=string`

Disable set*uid|gid system calls

`spawn=string`

Disable *fork and execve

resourcecontrol=*string*

Disable process affinity and scheduler priority

-readconfig *file*

Read device configuration from *file*. This approach is useful when you want to spawn QEMU process with many command line options but you don't want to exceed the command line character limit.

-writeconfig *file*

Write device configuration to *file*. The *file* can be either filename to save command line and device configuration into file or dash -) character to print the output to stdout. This can be later used as input file for -readconfig option.

-no-user-config

The -no-user-config option makes QEMU not load any of the user-provided config files on *sysconfdir*.

-trace [[enable=]*pattern*][,events=*file*][,file=*file*]

Specify tracing options.

[enable=]*pattern*

Immediately enable events matching *pattern* (either event name or a globbing pattern). This option is only available if QEMU has been compiled with the *simple*, *log* or *ftrace* tracing backend. To specify multiple events or patterns, specify the -trace option multiple times.

Use -trace help to print a list of names of trace points.

events=*file*

Immediately enable events listed in *file*. The file must contain one event name (as listed in the trace-events-all file) per line; globbing patterns are accepted too. This option is only available if QEMU has been compiled with the *simple*, *log* or *ftrace* tracing backend.

file=*file*

Log output traces to *file*. This option is only available if QEMU has been compiled with the *simple* tracing backend.

-plugin file=*file*[,arg=*string*]

Load a plugin.

`file=`*file*

Load the given plugin from a shared library file.

`arg=`*string*

Argument string passed to the plugin. (Can be given multiple times.)

`-enable-fips`

Enable FIPS 140-2 compliance mode.

`-msg timestamp [=on|off]`

Control error message format.

`timestamp=on|off`

Prefix messages with a timestamp. Default is off.

`-dump-vmstate` *file*

Dump json-encoded vmstate information for current machine type to file in *file*

`-enable-sync-profile`

Enable synchronization profiling.

2.3.11 Generic object creation

`-object` *typename* [*,prop1=value1,...*]

Create a new object of type *typename* setting properties in the order they are specified. Note that the 'id' property must be set. These objects are placed in the '/objects' path.

`-object memory-backend-file,id=id,size=size,mem-path=dir,share=on|off,discard-data=on|off,merge=on|off,dump=on|off,prealloc=on|off,host-nodes=host-nodes,policy=default|preferred|bind|interleave,align=align`

Creates a memory file backend object, which can be used to back the guest RAM with huge pages.

The `id` parameter is a unique ID that will be used to reference this memory region when configuring the `-numa` argument.

The `size` option provides the size of the memory region, and accepts common suffixes, eg 500M.

The `mem-path` provides the path to either a shared memory or huge page filesystem mount.

The `share` boolean option determines whether the memory region is marked as private to QEMU, or shared. The latter allows a co-operating external process to access the QEMU memory region.

The `share` is also required for pvr dma devices due to limitations in the RDMA API provided by Linux.

Setting `share=on` might affect the ability to configure NUMA bindings for the memory backend under some circumstances, see [Documentation/vm/numa_memory_policy.txt](#) on the Linux kernel source tree for additional details.

Setting the `discard-data` boolean option to *on* indicates that file contents can be destroyed when QEMU exits, to avoid unnecessarily flushing data to the backing file. Note that `discard-data` is only an optimization, and QEMU might not discard file contents if it aborts unexpectedly or is terminated using SIGKILL.

The `merge` boolean option enables memory merge, also known as `MADV_MERGEABLE`, so that Kernel Samepage Merging will consider the pages for memory deduplication.

Setting the `dump` boolean option to *off* excludes the memory from core dumps. This feature is also known as `MADV_DONTDUMP`.

The `prealloc` boolean option enables memory preallocation.

The `host-nodes` option binds the memory range to a list of NUMA host nodes.

The `policy` option sets the NUMA policy to one of the following values:

default

default host policy

preferred

prefer the given host node list for allocation

bind

restrict memory allocation to the given host node list

interleave

interleave memory allocations across the given host node list

The `align` option specifies the base address alignment when QEMU `mmap(2)` `mem-path`, and accepts common suffixes, eg 2M. Some backend store specified by `mem-path` requires an alignment different than the default one used by QEMU, eg the device DAX `/dev/dax0.0` requires 2M alignment rather than 4K. In such cases, users can specify the required alignment via this option.

The `pmem` option specifies whether the backing file specified by `mem-path` is in host persistent memory that can be accessed using the SNIA NVM programming model (e.g. Intel NVDIMM). If `pmem` is set to 'on', QEMU will take necessary operations to guarantee the persistence of its own writes to `mem-path` (e.g. in vNVDIMM label emulation and live migration). Also, we will map the backend-file with `MAP_SYNC` flag, which ensures the file metadata is in sync for `mem-path` in case of host crash or a power failure. `MAP_SYNC` requires support from both the host kernel (since Linux kernel 4.15) and the filesystem of `mem-path` mounted with DAX option.

```
-object memory-backend-  
ram,id=id,merge=on|off,dump=on|off,share=on|off,preal-  
loc=on|off,size=size,host-nodes=host-  
nodes,policy=default|preferred|bind|interleave
```

Creates a memory backend object, which can be used to back the guest RAM. Memory backend objects offer more control than the `-m` option that is traditionally used to define guest RAM. Please refer to `memory-backend-file` for a description of the options.

```
-object memory-backend-  
memfd,id=id,merge=on|off,dump=on|off,share=on|off,pre-  
alloc=on|off,size=size,host-nodes=host-  
nodes,policy=default|preferred|bind|interleave,seal=o-  
n|off,hugetlb=on|off,hugetlbsize=size
```

Creates an anonymous memory file backend object, which allows QEMU to share the memory with an external process (e.g. when using `vhost-user`). The memory is allocated with `memfd` and optional sealing. (Linux only)

The `seal` option creates a sealed-file, that will block further resizing the memory ('on' by default).

The `hugetlb` option specify the file to be created resides in the `hugetlbfs` filesystem (since Linux 4.14). Used in conjunction with the `hugetlb` option, the `hugetlbsize` option specify the `hugetlb` page size on systems that support multiple `hugetlb` page sizes (it must be a power of 2 value supported by the system).

In some versions of Linux, the `hugetlb` option is incompatible with the `seal` option (requires at least Linux 4.16).

Please refer to `memory-backend-file` for a description of the other options.

The `share` boolean option is *on* by default with `memfd`.

```
-object rng-builtin,id=id
```

Creates a random number generator backend which obtains entropy from QEMU builtin functions. The `id` parameter is a unique ID that will be used to reference this entropy backend from the `virtio-rng` device. By default, the `virtio-rng` device uses this RNG backend.

```
-object rng-random,id=id,filename=/dev/random
```

Creates a random number generator backend which obtains entropy from a device on the host. The `id` parameter is a unique ID that will be used to reference this entropy backend from the `virtio-rng` device.

The `filename` parameter specifies which file to obtain entropy from and if omitted defaults to `/dev/urandom`.

```
-object rng-egd,id=id,chardev=chardev
```

Creates a random number generator backend which obtains entropy from an external daemon running on the host. The `id` parameter is a unique ID that will be used to reference this entropy backend from the `virtio-rng` device.

The `chardev` parameter is the unique ID of a character device backend that provides the connection to the RNG daemon.

```
-object tls-creds-  
anon,id=id,endpoint=endpoint,dir=/path/to/cred/dir,ve  
rify-peer=on|off
```

Creates a TLS anonymous credentials object, which can be used to provide TLS support on network backends. The `id` parameter is a unique ID which

network backends will use to access the credentials. The `endpoint` is either `server` or `client` depending on whether the QEMU network backend that uses the credentials will be acting as a client or as a server. If `verify-peer` is enabled (the default) then once the handshake is completed, the peer credentials will be verified, though this is a no-op for anonymous credentials.

The `dir` parameter tells QEMU where to find the credential files. For server endpoints, this directory may contain a file `dh-params.pem` providing diffie-hellman parameters to use for the TLS server. If the file is missing, QEMU will generate a set of DH parameters at startup. This is a computationally expensive operation that consumes random pool entropy, so it is recommended that a persistent set of parameters be generated upfront and saved.

```
-object tls-creds-  
psk,id=id,endpoint=endpoint,dir=/path/to/keys/dir[,us  
ername=username]
```

Creates a TLS Pre-Shared Keys (PSK) credentials object, which can be used to provide TLS support on network backends. The `id` parameter is a unique ID which network backends will use to access the credentials. The `endpoint` is either `server` or `client` depending on whether the QEMU network backend that uses the credentials will be acting as a client or as a server. For clients only, `username` is the username which will be sent to the server. If omitted it defaults to “qemu”.

The `dir` parameter tells QEMU where to find the keys file. It is called “`dir/keys.psk`” and contains “username:key” pairs. This file can most easily be created using the GnuTLS `psktool` program.

For server endpoints, `dir` may also contain a file `dh-params.pem` providing diffie-hellman parameters to use for the TLS server. If the file is missing, QEMU will generate a set of DH parameters at startup. This is a computationally expensive operation that consumes random pool entropy, so it is recommended that a persistent set of parameters be generated up front and saved.

```
-object tls-creds-  
x509,id=id,endpoint=endpoint,dir=/path/to/cred/dir,pri  
ority=priority,verify-peer=on|off,passwordid=id
```

Creates a TLS anonymous credentials object, which can be used to provide TLS support on network backends. The `id` parameter is a unique ID which network backends will use to access the credentials. The `endpoint` is either `server` or `client` depending on whether the QEMU network backend that uses the credentials will be acting as a client or as a server. If `verify-peer` is enabled (the default) then once the handshake is completed, the peer

credentials will be verified. With x509 certificates, this implies that the clients must be provided with valid client certificates too.

The *dir* parameter tells QEMU where to find the credential files. For server endpoints, this directory may contain a file *dh-params.pem* providing diffie-hellman parameters to use for the TLS server. If the file is missing, QEMU will generate a set of DH parameters at startup. This is a computationally expensive operation that consumes random pool entropy, so it is recommended that a persistent set of parameters be generated upfront and saved.

For x509 certificate credentials the directory will contain further files providing the x509 certificates. The certificates must be stored in PEM format, in filenames *ca-cert.pem*, *ca-crl.pem* (optional), *server-cert.pem* (only servers), *server-key.pem* (only servers), *client-cert.pem* (only clients), and *client-key.pem* (only clients).

For the *server-key.pem* and *client-key.pem* files which contain sensitive private keys, it is possible to use an encrypted version by providing the *passwordid* parameter. This provides the ID of a previously created `secret` object containing the password for decryption.

The *priority* parameter allows to override the global default priority used by gnutls. This can be useful if the system administrator needs to use a weaker set of crypto priorities for QEMU without potentially forcing the weakness onto all applications. Or conversely if one wants a stronger default for QEMU than for all other applications, they can do this through this parameter. Its format is a gnutls priority string as described at https://gnutls.org/manual/html_node/Priority-Strings.html.

```
-object filter-  
buffer,id=id,netdev=netdevid,interval=t[,queue=all|rx  
|tx][,status=on|off]
```

Interval *t* can't be 0, this filter batches the packet delivery: all packets arriving in a given interval on netdev *netdevid* are delayed until the end of the interval. Interval is in microseconds. *status* is optional that indicate whether the netfilter is on (enabled) or off (disabled), the default status for netfilter will be 'on'.

queue *all/rx/tx* is an option that can be applied to any netfilter.

all: the filter is attached both to the receive and the transmit queue of the netdev (default).

rx: the filter is attached to the receive queue of the netdev, where it will receive packets sent to the netdev.

tx: the filter is attached to the transmit queue of the netdev, where it will receive packets sent by the netdev.

```
-object filter-  
mirror,id=id,netdev=netdevid,outdev=chardevid,queue=all|rx|tx[,vnet_hdr_support]
```

filter-mirror on netdev *netdevid*, mirror net packet to chardev *chardevid*, if it has the *vnet_hdr_support* flag, filter-mirror will mirror packet with *vnet_hdr_len*.

```
-object filter-  
redirector,id=id,netdev=netdevid,indev=chardevid,outdev=chardevid,queue=all|rx|tx[,vnet_hdr_support]
```

filter-redirector on netdev *netdevid*, redirect filter's net packet to chardev *chardevid*, and redirect *indev*'s packet to filter. if it has the *vnet_hdr_support* flag, filter-redirector will redirect packet with *vnet_hdr_len*. Create a filter-redirector we need to differ outdev id from *indev* id, id can not be the same. we can just use *indev* or *outdev*, but at least one of *indev* or *outdev* need to be specified.

```
-object filter-  
rewriter,id=id,netdev=netdevid,queue=all|rx|tx[,vnet_hdr_support]
```

Filter-rewriter is a part of COLO project. It will rewrite tcp packet to secondary from primary to keep secondary tcp connection, and rewrite tcp packet to primary from secondary make tcp packet can be handled by client. if it has the *vnet_hdr_support* flag, we can parse packet with vnet header.

usage: colo secondary: -object filter-
redirector,id=f1,netdev=hn0,queue=tx,indev=red0 -object filter-
redirector,id=f2,netdev=hn0,queue=rx,outdev=red1 -object filter-
rewriter,id=rew0,netdev=hn0,queue=all

```
-object filter-  
dump,id=id,netdev=dev[,file=filename][,maxlen=len]
```

Dump the network traffic on netdev *dev* to the file specified by *filename*. At most *len* bytes (64k by default) per packet are stored. The file format is libpcap, so it can be analyzed with tools such as tcpdump or Wireshark.

```
-object colo-  
compare,id=id,primary_in=chardevid,secondary_in=chardevid,outdev=chardevid,iothread=id[,vnet_hdr_support][  
,notify_dev=id]
```

Colo-compare gets packet from *primary_inchardev* and *secondary_inchardev*, than compare primary packet with secondary packet. If the packets are same, we will output primary packet to *outdevchardev*, else we will notify colo-frame do checkpoint and send primary packet to *outdevchardev*. In order to improve efficiency, we need to put the task of comparison in another thread. If it has the *vnet_hdr_support* flag, colo compare will send/recv packet with *vnet_hdr_len*. If you want to use Xen COLO, will need the *notify_dev* to notify Xen colo-frame to do checkpoint.

we must use it with the help of filter-mirror and filter-redirector.

KVM COLO

```
primary:
-netdev tap,id=hn0,vhost=off,script=/etc/qemu-
ifup,downscript=/etc/qemu-ifdown
-device e1000,id=e0,netdev=hn0,mac=52:a4:00:12:78:66
-chardev socket,id=mirror0,host=3.3.3.3,port=9003,server,nowait
-chardev socket,id=compare1,host=3.3.3.3,port=9004,server,nowait
-chardev socket,id=compare0,host=3.3.3.3,port=9001,server,nowait
-chardev socket,id=compare0-0,host=3.3.3.3,port=9001
-chardev
socket,id=compare_out,host=3.3.3.3,port=9005,server,nowait
-chardev socket,id=compare_out0,host=3.3.3.3,port=9005
-object iothread,id=iothread1
-object filter-mirror,id=m0,netdev=hn0,queue=tx,outdev=mirror0
-object filter-
redirector,netdev=hn0,id=redire0,queue=rx,indev=compare_out
-object filter-
redirector,netdev=hn0,id=redire1,queue=rx,outdev=compare0
-object colo-compare,id=comp0,primary_in=compare0-
0,secondary_in=compare1,outdev=compare_out0,iothread=iothread1

secondary:
-netdev tap,id=hn0,vhost=off,script=/etc/qemu-ifup,down
script=/etc/qemu-ifdown
-device e1000,netdev=hn0,mac=52:a4:00:12:78:66
-chardev socket,id=red0,host=3.3.3.3,port=9003
-chardev socket,id=red1,host=3.3.3.3,port=9004
-object filter-redirector,id=f1,netdev=hn0,queue=tx,indev=red0
-object filter-redirector,id=f2,netdev=hn0,queue=rx,outdev=red1
```

Xen COLO

```
primary:
-netdev tap,id=hn0,vhost=off,script=/etc/qemu-
ifup,downscript=/etc/qemu-ifdown
-device e1000,id=e0,netdev=hn0,mac=52:a4:00:12:78:66
-chardev socket,id=mirror0,host=3.3.3.3,port=9003,server,nowait
-chardev socket,id=compare1,host=3.3.3.3,port=9004,server,nowait
-chardev socket,id=compare0,host=3.3.3.3,port=9001,server,nowait
-chardev socket,id=compare0-0,host=3.3.3.3,port=9001
-chardev
socket,id=compare_out,host=3.3.3.3,port=9005,server,nowait
-chardev socket,id=compare_out0,host=3.3.3.3,port=9005
-chardev
socket,id=notify_way,host=3.3.3.3,port=9009,server,nowait
-object filter-mirror,id=m0,netdev=hn0,queue=tx,outdev=mirror0
```

```

-object filter-
redirector,netdev=hn0,id=redire0,queue=rx,indev=compare_out
-object filter-
redirector,netdev=hn0,id=redire1,queue=rx,outdev=compare0
-object iothread,id=iothread1
-object colo-compare,id=comp0,primary_in=compare0-
0,secondary_in=compare1,outdev=compare_out0,notify_dev=nofity_way
,iothread=iothread1

secondary:
-netdev tap,id=hn0,vhost=off,script=/etc/qemu-ifup,down
script=/etc/qemu-ifdown
-device e1000,netdev=hn0,mac=52:a4:00:12:78:66
-chardev socket,id=red0,host=3.3.3.3,port=9003
-chardev socket,id=red1,host=3.3.3.3,port=9004
-object filter-redirector,id=f1,netdev=hn0,queue=tx,indev=red0
-object filter-redirector,id=f2,netdev=hn0,queue=rx,outdev=red1

```

If you want to know the detail of above command line, you can read the colo-compare git log.

```

-object cryptodev-backend-
builtin,id=id[,queues=queues]

```

Creates a cryptodev backend which executes crypto operation from the QEMU cipher APIS. The *id* parameter is a unique ID that will be used to reference this cryptodev backend from the `virtio-crypto` device. The *queues* parameter is optional, which specify the queue number of cryptodev backend, the default of *queues* is 1.

```

# qemu-system-x86_64 \
[...] \
-object cryptodev-backend-builtin,id=cryptodev0 \
-device virtio-crypto-pci,id=crypto0,cryptodev=cryptodev0 \
[...]
-object cryptodev-vhost-
user,id=id,chardev=chardev[id[,queues=queues]

```

Creates a vhost-user cryptodev backend, backed by a chardev *chardev[id]*. The *id* parameter is a unique ID that will be used to reference this cryptodev backend from the `virtio-crypto` device. The chardev should be a unix domain socket backed one. The vhost-user uses a specifically defined protocol to pass vhost ioctl replacement messages to an application on the other end of the socket. The *queues* parameter is optional, which specify the queue number of cryptodev backend for multiqueue vhost-user, the default of *queues* is 1.

```

# qemu-system-x86_64 \
[...] \
-chardev socket,id=chardev0,path=/path/to/socket \
-object cryptodev-vhost-user,id=cryptodev0,chardev=chardev0 \
-device virtio-crypto-pci,id=crypto0,cryptodev=cryptodev0 \
[...]

```

```
-object
secret,id=id,data=string,format=raw|base64[,keyid=secretid,iv=string]
-object
secret,id=id,file=filename,format=raw|base64[,keyid=secretid,iv=string]
```

Defines a secret to store a password, encryption key, or some other sensitive data. The sensitive data can either be passed directly via the *data* parameter, or indirectly via the *file* parameter. Using the *data* parameter is insecure unless the sensitive data is encrypted.

The sensitive data can be provided in raw format (the default), or base64. When encoded as JSON, the raw format only supports valid UTF-8 characters, so base64 is recommended for sending binary data. QEMU will convert from whichever format is provided to the format it needs internally. eg, an RBD password can be provided in raw format, even though it will be base64 encoded when passed onto the RBD server.

For added protection, it is possible to encrypt the data associated with a secret using the AES-256-CBC cipher. Use of encryption is indicated by providing the *keyid* and *iv* parameters. The *keyid* parameter provides the ID of a previously defined secret that contains the AES-256 decryption key. This key should be 32-bytes long and be base64 encoded. The *iv* parameter provides the random initialization vector used for encryption of this particular secret and should be a base64 encrypted string of the 16-byte IV.

The simplest (insecure) usage is to provide the secret inline

```
# qemu-system-x86_64 -object
secret,id=sec0,data=letmein,format=raw
```

The simplest secure usage is to provide the secret via a file

```
# printf "letmein" > mypasswd.txt # qemu-system-x86_64 -object
secret,id=sec0,file=myspasswd.txt,format=raw
```

For greater security, AES-256-CBC should be used. To illustrate usage, consider the openssl command line tool which can encrypt the data. Note that when encrypting, the plaintext must be padded to the cipher block size (32 bytes) using the standard PKCS#5/6 compatible padding algorithm.

First a master key needs to be created in base64 encoding:

```
# openssl rand -base64 32 > key.b64
# KEY=$(base64 -d key.b64 | hexdump -v -e '/1 "%02X"')
```

Each secret to be encrypted needs to have a random initialization vector generated. These do not need to be kept secret

```
# openssl rand -base64 16 > iv.b64
# IV=$(base64 -d iv.b64 | hexdump -v -e '/1 "%02X"')
```

The secret to be defined can now be encrypted, in this case we're telling openssl to base64 encode the result, but it could be left as raw bytes if desired.

```
# SECRET=$(printf "letmein" |
openssl enc -aes-256-cbc -a -K $KEY -iv $IV)
```

When launching QEMU, create a master secret pointing to `key.b64` and specify that to be used to decrypt the user password. Pass the contents of `iv.b64` to the second secret

```
# qemu-system-x86_64 \
-object secret,id=secmaster0,format=base64,file=key.b64 \
-object secret,id=sec0,keyid=secmaster0,format=base64,\
data=$SECRET,iv=$(<iv.b64)
-object sev-guest,id=id,cbitpos=cbitpos,reduced-phys-
bits=val,[sev-
device=string,policy=policy,handle=handle,dh-cert-
file=file,session-file=file]
```

Create a Secure Encrypted Virtualization (SEV) guest object, which can be used to provide the guest memory encryption support on AMD processors.

When memory encryption is enabled, one of the physical address bit (aka the C-bit) is utilized to mark if a memory page is protected. The `cbitpos` is used to provide the C-bit position. The C-bit position is Host family dependent hence user must provide this value. On EPYC, the value should be 47.

When memory encryption is enabled, we loose certain bits in physical address space. The `reduced-phys-bits` is used to provide the number of bits we loose in physical address space. Similar to C-bit, the value is Host family dependent. On EPYC, the value should be 5.

The `sev-device` provides the device file to use for communicating with the SEV firmware running inside AMD Secure Processor. The default device is `'/dev/sev'`. If hardware supports memory encryption then `/dev/sev` devices are created by CCP driver.

The `policy` provides the guest policy to be enforced by the SEV firmware and restrict what configuration and operational commands can be performed on this guest by the hypervisor. The policy should be provided by the guest owner and is bound to the guest and cannot be changed throughout the lifetime of the guest. The default is 0.

If guest policy allows sharing the key with another SEV guest then handle can be used to provide handle of the guest from which to share the key.

The `dh-cert-file` and `session-file` provides the guest owner's Public Diffie-Hellman key defined in SEV spec. The PDH and session parameters are used for establishing a cryptographic session with the guest owner to negotiate keys used for attestation. The file must be encoded in base64.

e.g to launch a SEV guest

```
# qemu-system-x86_64 \
.....
-object sev-guest,id=sev0,cbitpos=47,reduced-phys-bits=5 \
-machine ...,memory-encryption=sev0
.....
```

```
-object authz-simple,id=id,identity=string
```

Create an authorization object that will control access to network services.

The `identity` parameter identifies the user and its format depends on the network service that authorization object is associated with. For authorizing based on TLS x509 certificates, the identity must be the x509 distinguished name. Note that care must be taken to escape any commas in the distinguished name.

An example authorization object to validate a x509 distinguished name would look like:

```
# qemu-system-x86_64 \
...
-object 'authz-
simple,id=auth0,identity=CN=laptop.example.com,,O=Example
Org,,L=London,,ST=London,,C=GB' \
...
```

Note the use of quotes due to the x509 distinguished name containing whitespace, and escaping of `,`.

```
-object authz-
listfile,id=id,filename=path,refresh=yes|no
```

Create an authorization object that will control access to network services.

The `filename` parameter is the fully qualified path to a file containing the access control list rules in JSON format.

An example set of rules that match against SASL usernames might look like:

```
{
```

```

"rules": [
{ "match": "fred", "policy": "allow", "format": "exact" },
{ "match": "bob", "policy": "allow", "format": "exact" },
{ "match": "danb", "policy": "deny", "format": "glob" },
{ "match": "dan*", "policy": "allow", "format": "exact" },
],
"policy": "deny"
}

```

When checking access the object will iterate over all the rules and the first rule to match will have its `policy` value returned as the result. If no rules match, then the default `policy` value is returned.

The rules can either be an exact string match, or they can use the simple UNIX glob pattern matching to allow wildcards to be used.

If `refresh` is set to true the file will be monitored and automatically reloaded whenever its content changes.

As with the `authz-simple` object, the format of the identity strings being matched depends on the network service, but is usually a TLS x509 distinguished name, or a SASL username.

An example authorization object to validate a SASL username would look like:

```

# qemu-system-x86_64 \
...
-object authz-simple,id=auth0,filename=/etc/qemu/vnc-
sas1.acl,refresh=yes
...
-object authz-pam,id=id,service=string

```

Create an authorization object that will control access to network services.

The `service` parameter provides the name of a PAM service to use for authorization. It requires that a file `/etc/pam.d/service` exist to provide the configuration for the `account` subsystem.

An example authorization object to validate a TLS x509 distinguished name would look like:

```

# qemu-system-x86_64 \
...
-object authz-pam,id=auth0,service=qemu-vnc
...

```

There would then be a corresponding config file for PAM at `/etc/pam.d/qemu-vnc` that contains:

```

account requisite pam_listfile.so item=user sense=allow \
file=/etc/qemu/vnc.allow

```


Finally the `/etc/qemu/vnc.allow` file would contain the list of x509 distinguished names that are permitted access

```
CN=laptop.example.com,O=Example Home,L=London,ST=London,C=GB
-object iothread,id=id,poll-max-ns=poll-max-ns,poll-grow=poll-grow,poll-shrink=poll-shrink
```

Creates a dedicated event loop thread that devices can be assigned to. This is known as an IOThread. By default device emulation happens in vCPU threads or the main event loop thread. This can become a scalability bottleneck. IOThreads allow device emulation and I/O to run on other host CPUs.

The `id` parameter is a unique ID that will be used to reference this IOThread from `-device ... ,iothread=id`. Multiple devices can be assigned to an IOThread. Note that not all devices support an `iothread` parameter.

The `query-iothreads` QMP command lists IOThreads and reports their thread IDs so that the user can configure host CPU pinning/affinity.

IOThreads use an adaptive polling algorithm to reduce event loop latency. Instead of entering a blocking system call to monitor file descriptors and then pay the cost of being woken up when an event occurs, the polling algorithm spins waiting for events for a short time. The algorithm's default parameters are suitable for many cases but can be adjusted based on knowledge of the workload and/or host device latency.

The `poll-max-ns` parameter is the maximum number of nanoseconds to busy wait for events. Polling can be disabled by setting this value to 0.

The `poll-grow` parameter is the multiplier used to increase the polling time when the algorithm detects it is missing events due to not polling long enough.

The `poll-shrink` parameter is the divisor used to decrease the polling time when the algorithm detects it is spending too long polling without encountering events.

The polling parameters can be modified at run-time using the `qom-set` command (where `iothread1` is the IOThread's `id`):

```
(qemu) qom-set /objects/iothread1 poll-max-ns 100000
```

2.3.12 Device URL Syntax

In addition to using normal file images for the emulated storage devices, QEMU can also use networked resources such as iSCSI devices. These are specified using a special URL syntax.

iSCSI

iSCSI support allows QEMU to access iSCSI resources directly and use as images for the guest storage. Both disk and cdrom images are supported.

Syntax for specifying iSCSI LUNs is “iscsi://<target-ip>[:<port>]/<target-iqn>/<lun>”

By default qemu will use the iSCSI initiator-name 'iqn.2008-11.org.linux-kvm[:<name>]' but this can also be set from the command line or a configuration file.

Since version Qemu 2.4 it is possible to specify a iSCSI request timeout to detect stalled requests and force a reestablishment of the session. The timeout is specified in seconds. The default is 0 which means no timeout. Libiscsi 1.15.0 or greater is required for this feature.

Example (without authentication):

```
qemu-system-x86_64 -iscsi initiator-name=iqn.2001-04.com.example:my-initiator \
                    -cdrom iscsi://192.0.2.1/iqn.2001-04.com.example/2 \
                    -drive file=iscsi://192.0.2.1/iqn.2001-04.com.example/1
```

Example (CHAP username/password via URL):

```
qemu-system-x86_64 -drive
file=iscsi://user%password@192.0.2.1/iqn.2001-04.com.example/1
```

Example (CHAP username/password via environment variables):

```
LIBISCSI_CHAP_USERNAME="user" \
LIBISCSI_CHAP_PASSWORD="password" \
qemu-system-x86_64 -drive file=iscsi://192.0.2.1/iqn.2001-04.com.example/1
```

NBD

QEMU supports NBD (Network Block Devices) both using TCP protocol as well as Unix Domain Sockets. With TCP, the default port is 10809.

Syntax for specifying a NBD device using TCP, in preferred URI form: “nbd://<server-ip>[:<port>]/[<export>]”

Syntax for specifying a NBD device using Unix Domain Sockets; remember that '?' is a shell glob character and may need quoting: “nbd+unix:///[:<export>]?socket=<domain-socket>”

Older syntax that is also recognized: “nbd:<server-ip>:<port>[:exportname=<export>]”

Syntax for specifying a NBD device using Unix Domain Sockets
“nbd:unix:<domain-socket>[:exportname=<export>]”

Example for TCP

```
qemu-system-x86_64 --drive file=nbd:192.0.2.1:30000
```

Example for Unix Domain Sockets

```
qemu-system-x86_64 --drive file=nbd:unix:/tmp/nbd-socket
```

SSH

QEMU supports SSH (Secure Shell) access to remote disks.

Examples:

```
qemu-system-x86_64 -drive file=ssh://user@host/path/to/disk.img  
qemu-system-x86_64 -drive  
file.driver=ssh,file.user=user,file.host=host,file.port=22,file.p  
ath=/path/to/disk.img
```

Currently authentication must be done using ssh-agent. Other authentication methods may be supported in future.

Sheepdog

Sheepdog is a distributed storage system for QEMU. QEMU supports using either local sheepdog devices or remote networked devices.

Syntax for specifying a sheepdog device

```
sheepdog[+tcp|+unix]://[host:port]/vdiname[?socket=path][#snapid|  
#tag]
```

Example

```
qemu-system-x86_64 --drive  
file=sheepdog://192.0.2.1:30000/MyVirtualMachine
```

See also <https://sheepdog.github.io/sheepdog/>.

GlusterFS

GlusterFS is a user space distributed file system. QEMU supports the use of GlusterFS volumes for hosting VM disk images using TCP, Unix Domain Sockets and RDMA transport protocols.

Syntax for specifying a VM disk image on GlusterFS volume is

URI:

```
gluster[+type]://[host[:port]]/volume/path[?socket=...][,debug=N]
[,logfile=...]

JSON:
'json:{"driver":"qcow2","file":{"driver":"gluster","volume":"test
vol","path":"a.img","debug":N,"logfile":"..."},

"server":[{"type":"tcp","host":"...","port":"..."},

{"type":"unix","socket":"..."}]}'
```

Example

```
URI:
qemu-system-x86_64 --drive
file=gluster://192.0.2.1/testvol/a.img,

file.debug=9,file.logfile=/var/log/qemu-gluster.log

JSON:
qemu-system-x86_64 'json:{"driver":"qcow2",
                        "file":{"driver":"gluster",

"volume":"testvol","path":"a.img",

"debug":9,"logfile":"/var/log/qemu-gluster.log",

"server":[{"type":"tcp","host":"1.2.3.4","port":24007},

{"type":"unix","socket":"/var/run/glusterd.socket"}]}'
qemu-system-x86_64 -drive
driver=qcow2,file.driver=gluster,file.volume=testvol,file.path=/p
ath/a.img,

file.debug=9,file.logfile=/var/log/qemu-gluster.log,

file.server.0.type=tcp,file.server.0.host=1.2.3.4,file.server.0.p
ort=24007,

file.server.1.type=unix,file.server.1.socket=/var/run/glusterd.so
cket
```

See also <http://www.gluster.org>.

HTTP/HTTPS/FTP/FTPS

QEMU supports read-only access to files accessed over http(s) and ftp(s).

Syntax using a single filename:

```
<protocol>://[<username>[:<password>]@]<host>/<path>
```

where:

protocol

'http', 'https', 'ftp', or 'ftps'.

`username`

Optional username for authentication to the remote server.

`password`

Optional password for authentication to the remote server.

`host`

Address of the remote server.

`path`

Path on the remote server, including any query string.

The following options are also supported:

`url`

The full URL when passing options to the driver explicitly.

`readahead`

The amount of data to read ahead with each range request to the remote server. This value may optionally have the suffix 'T', 'G', 'M', 'K', 'k' or 'b'. If it does not have a suffix, it will be assumed to be in bytes. The value must be a multiple of 512 bytes. It defaults to 256k.

`sslverify`

Whether to verify the remote server's certificate when connecting over SSL. It can have the value 'on' or 'off'. It defaults to 'on'.

`cookie`

Send this cookie (it can also be a list of cookies separated by ';') with each outgoing request. Only supported when using protocols such as HTTP which support cookies, otherwise ignored.

`timeout`

Set the timeout in seconds of the CURL connection. This timeout is the time that CURL waits for a response from the remote server to get the size of the image to be downloaded. If not set, the default timeout of 5 seconds is used.

Note that when passing options to qemu explicitly, `driver` is the value of `<protocol>`.

Example: boot from a remote Fedora 20 live ISO image

```
qemu-system-x86_64 --drive
media=cdrom,file=https://archives.fedoraproject.org/pub/archive/f
edora/linux/releases/20/Live/x86_64/Fedora-Live-Desktop-x86_64-
20-1.iso,readonly

qemu-system-x86_64 --drive
media=cdrom,file.driver=http,file.url=http://archives.fedoraproje
ct.org/pub/fedora/linux/releases/20/Live/x86_64/Fedora-Live-
Desktop-x86_64-20-1.iso,readonly
```

Example: boot from a remote Fedora 20 cloud image using a local overlay for writes, copy-on-read, and a readahead of 64k

```
qemu-img create -f qcow2 -o
backing_file='json:{"file.driver":"http",,
"file.url":"http://archives.fedoraproject.org/pub/archive/fedora/
linux/releases/20/Images/x86_64/Fedora-x86_64-20-20131211.1-
sda.qcow2",, "file.readahead":"64k"}' /tmp/Fedora-x86_64-20-
20131211.1-sda.qcow2

qemu-system-x86_64 -drive file=/tmp/Fedora-x86_64-20-20131211.1-
sda.qcow2,copy-on-read=on
```

Example: boot from an image stored on a VMware vSphere server with a self-signed certificate using a local overlay for writes, a readahead of 64k and a timeout of 10 seconds.

```
qemu-img create -f qcow2 -o
backing_file='json:{"file.driver":"https",,
"file.url":"https://user:password@vsphere.example.com/folder/test
/test-flat.vmdk?dcPath=Datacenter&dsName=datastore1",,
"file.sslverify":"off",, "file.readahead":"64k",,
"file.timeout":10}' /tmp/test.qcow2

qemu-system-x86_64 -drive file=/tmp/test.qcow2
```

2.4 Keys in the graphical frontends

During the graphical emulation, you can use special key combinations to change modes. The default key mappings are shown below, but if you use `-alt-grab` then the modifier is Ctrl-Alt-Shift (instead of Ctrl-Alt) and if you use `-ctrl-grab` then the modifier is the right Ctrl key (instead of Ctrl-Alt):

Ctrl-Alt-f

Toggle full screen

Ctrl-Alt++

Enlarge the screen

Ctrl-Alt--

Shrink the screen

`Ctrl-Alt-u`

Restore the screen's un-scaled dimensions

`Ctrl-Alt-n`

Switch to virtual console 'n'. Standard console mappings are:

1

Target system display

2

Monitor

3

Serial port

`Ctrl-Alt`

Toggle mouse and keyboard grab.

In the virtual consoles, you can use `Ctrl-Up`, `Ctrl-Down`, `Ctrl-PageUp` and `Ctrl-PageDown` to move in the back log.

2.5 Keys in the character backend multiplexer

During emulation, if you are using a character backend multiplexer (which is the default if you are using `-nographic`) then several commands are available via an escape sequence. These key sequences all start with an escape character, which is `Ctrl-a` by default, but can be changed with `-echr`. The list below assumes you're using the default.

`Ctrl-a h`

Print this help

`Ctrl-a x`

Exit emulator

`Ctrl-a s`

Save disk data back to file (if `-snapshot`)

Ctrl-a t

Toggle console timestamps

Ctrl-a b

Send break (magic sysrq in Linux)

Ctrl-a c

Rotate between the frontends connected to the multiplexer (usually this switches between the monitor and the console)

Ctrl-a Ctrl-a

Send the escape character to the frontend

2.6 QEMU Monitor

The QEMU monitor is used to give complex commands to the QEMU emulator. You can use it to:

- - Remove or insert removable media images (such as CD-ROM or floppies).
- - Freeze/unfreeze the Virtual Machine (VM) and save or restore its state from a disk file.
- - Inspect the VM state without an external debugger.

2.6.1 Commands

The following commands are available:

help or ? [*cmd*]

Show the help for all commands or just for command *cmd*.

commit

Commit changes to the disk images (if -snapshot is used) or backing files. If the backing file is smaller than the snapshot, then the backing file will be resized to be the same size as the snapshot. If the snapshot is smaller than the backing file, the backing file will not be truncated. If you want the backing file to match the size of the smaller snapshot, you can safely truncate it yourself once the commit operation successfully completes.

q or quit

Quit the emulator.

`exit_preconfig`

This command makes QEMU exit the preconfig state and proceed with VM initialization using configuration data provided on the command line and via the QMP monitor during the preconfig state. The command is only available during the preconfig state (i.e. when the `-preconfig` command line option was in use).

`block_resize`

Resize a block image while a guest is running. Usually requires guest action to see the updated size. Resize to a lower size is supported, but should be used with extreme caution. Note that this command only resizes image files, it can not resize block devices like LVM volumes.

`block_stream`

Copy data from a backing file into a block device.

`block_job_set_speed`

Set maximum speed for a background block operation.

`block_job_cancel`

Stop an active background block operation (streaming, mirroring).

`block_job_complete`

Manually trigger completion of an active background block operation. For mirroring, this will switch the device to the destination path.

`block_job_pause`

Pause an active block streaming operation.

`block_job_resume`

Resume a paused block streaming operation.

`eject [-f] device`

Eject a removable medium (use `-f` to force it).

`drive_del device`

Remove host block device. The result is that guest generated IO is no longer submitted against the host device underlying the disk. Once a drive has been

deleted, the QEMU Block layer returns -EIO which results in IO errors in the guest for applications that are reading/writing to the device. These errors are always reported to the guest, regardless of the drive's error actions (drive options `error`, `werror`).

change device setting

Change the configuration of a device.

change diskdevice filename [format [read-only-mode]]

Change the medium for a removable disk device to point to *filename*. eg

```
(qemu) change ide1-cd0 /path/to/some.iso
```

format is optional.

read-only-mode may be used to change the read-only status of the device. It accepts the following values:

retain

Retains the current status; this is the default.

read-only

Makes the device read-only.

read-write

Makes the device writable.

change vnc display,options

Change the configuration of the VNC server. The valid syntax for *display* and *options* are described at [sec invocation](#). eg

```
(qemu) change vnc localhost:1
change vnc password [password]
```

Change the password associated with the VNC server. If the new password is not supplied, the monitor will prompt for it to be entered. VNC passwords are only significant up to 8 letters. eg

```
(qemu) change vnc password
Password: ****
```

screendump filename

Save screen into PPM image *filename*.

`logfile filename`

Output logs to *filename*.

`trace-event`

changes status of a trace event

`trace-file on|off|flush`

Open, close, or flush the trace file. If no argument is given, the status of the trace file is displayed.

`log item1[, ...]`

Activate logging of the specified items.

`savevm tag`

Create a snapshot of the whole virtual machine. If *tag* is provided, it is used as human readable identifier. If there is already a snapshot with the same tag, it is replaced. More info at [vm snapshots](#).

Since 4.0, savevm stopped allowing the snapshot id to be set, accepting only *tag* as parameter.

`loadvm tag`

Set the whole virtual machine to the snapshot identified by the tag *tag*.

Since 4.0, loadvm stopped accepting snapshot id as parameter.

`delvm tag`

Delete the snapshot identified by *tag*.

Since 4.0, delvm stopped deleting snapshots by snapshot id, accepting only *tag* as parameter.

`singlestep [off]`

Run the emulation in single step mode. If called with option off, the emulation returns to normal mode.

`stop`

Stop emulation.

`c or cont`

Resume emulation.

`system_wakeup`

Wakeup guest from suspend.

`gdbserver [port]`

Start gdbserver session (default *port*=1234)

`x/fmt addr`

Virtual memory dump starting at *addr*.

`xp /fmt addr`

Physical memory dump starting at *addr*.

fmt is a format which tells the command how to format the data. Its syntax is: `/ {count} {format} {size}`

count

is the number of items to be dumped.

format

can be x (hex), d (signed decimal), u (unsigned decimal), o (octal), c (char) or i (asm instruction).

size

can be b (8 bits), h (16 bits), w (32 bits) or g (64 bits). On x86, *h* or *w* can be specified with the *i* format to respectively select 16 or 32 bit code instruction size.

Examples:

- Dump 10 instructions at the current instruction pointer:
 - `(qemu) x/10i $eip`
 - `0x90107063: ret`
 - `0x90107064: sti`
 - `0x90107065: lea 0x0(%esi,1),%esi`
 - `0x90107069: lea 0x0(%edi,1),%edi`
 - `0x90107070: ret`
 - `0x90107071: jmp 0x90107080`
 - `0x90107073: nop`
 - `0x90107074: nop`
 - `0x90107075: nop`
 - `0x90107076: nop`

- Dump 80 16 bit values at the start of the video memory.
 - (qemu) xp/80hx 0xb8000
 - 0x000b8000: 0x0b50 0x0b6c 0x0b65 0x0b78 0x0b38 0x0b36 0x0b2f 0x0b42
 - 0x000b8010: 0x0b6f 0x0b63 0x0b68 0x0b73 0x0b20 0x0b56 0x0b47 0x0b41
 - 0x000b8020: 0x0b42 0x0b69 0x0b6f 0x0b73 0x0b20 0x0b63 0x0b75 0x0b72
 - 0x000b8030: 0x0b72 0x0b65 0x0b6e 0x0b74 0x0b2d 0x0b63 0x0b76 0x0b73
 - 0x000b8040: 0x0b20 0x0b30 0x0b35 0x0b20 0x0b4e 0x0b6f 0x0b76 0x0b20
 - 0x000b8050: 0x0b32 0x0b30 0x0b30 0x0b33 0x0720 0x0720 0x0720 0x0720
 - 0x000b8060: 0x0720 0x0720 0x0720 0x0720 0x0720 0x0720 0x0720 0x0720
 - 0x000b8070: 0x0720 0x0720 0x0720 0x0720 0x0720 0x0720 0x0720 0x0720
 - 0x000b8080: 0x0720 0x0720 0x0720 0x0720 0x0720 0x0720 0x0720 0x0720
 - 0x000b8090: 0x0720 0x0720 0x0720 0x0720 0x0720 0x0720 0x0720 0x0720

`gpa2hva addr`

Print the host virtual address at which the guest's physical address *addr* is mapped.

`gpa2hpa addr`

Print the host physical address at which the guest's physical address *addr* is mapped.

`gva2gpa addr`

Print the guest physical address at which the guest's virtual address *addr* is mapped based on the mapping for the current CPU.

`p or print/fmt expr`

Print expression value. Only the *format* part of *fmt* is used.

`i/fmt addr [.index]`

Read I/O port.

`o/fmt addr val`

Write to I/O port.

`sendkey keys`

Send *keys* to the guest. *keys* could be the name of the key or the raw value in hexadecimal format. Use - to press several keys simultaneously. Example:

```
sendkey ctrl-alt-f1
```

This command is useful to send keys that your graphical user interface intercepts at low level, such as `ctrl-alt-f1` in X Window.

```
sync-profile [on|off|reset]
```

Enable, disable or reset synchronization profiling. With no arguments, prints whether profiling is on or off.

```
system_reset
```

Reset the system.

```
system_powerdown
```

Power down the system (if supported).

```
sum addr size
```

Compute the checksum of a memory region.

```
device_add config
```

Add device.

```
device_del id
```

Remove device *id*. *id* may be a short ID or a QOM object path.

```
cpu index
```

Set the default CPU.

```
mouse_move dx dy [dz]
```

Move the active mouse to the specified coordinates *dx dy* with optional scroll axis *dz*.

```
mouse_button val
```

Change the active mouse button state *val* (1=L, 2=M, 4=R).

```
mouse_set index
```

Set which mouse device receives events at given *index*, index can be obtained with

```
info mice
wavcapture filename audiodev [frequency [bits [channels]]
]
```

Capture audio into *filename* from *audiodev*, using sample rate *frequency* bits per sample *bits* and number of channels *channels*.

Defaults:

- - Sample rate = 44100 Hz - CD quality
- - Bits = 16
- - Number of channels = 2 - Stereo

```
stopcapture index
```

Stop capture with a given *index*, index can be obtained with

```
info capture
memsave addr size file
```

save to disk virtual memory dump starting at *addr* of size *size*.

```
pmemsave addr size file
```

save to disk physical memory dump starting at *addr* of size *size*.

```
boot_set bootdevicelist
```

Define new values for the boot device list. Those values will override the values specified on the command line through the `-boot` option.

The values that can be specified here depend on the machine type, but are the same that can be specified in the `-boot` command line option.

```
nmi cpu
```

Inject an NMI on the default CPU (x86/s390) or all CPUs (ppc64).

```
ringbuf_write device data
```

Write *data* to ring buffer character device *device*. *data* must be a UTF-8 string.

```
ringbuf_read device
```

Read and print up to *size* bytes from ring buffer character device *device*. Certain non-printable characters are printed `\uXXXX`, where `XXXX` is the

character code in hexadecimal. Character \ is printed \\. Bug: can screw up when the buffer contains invalid UTF-8 sequences, NUL characters, after the ring buffer lost data, and when reading stops because the size limit is reached.

`announce_self`

Trigger a round of GARP/RARP broadcasts; this is useful for explicitly updating the network infrastructure after a reconfiguration or some forms of migration. The timings of the round are set by the migration announce parameters. An optional comma separated *interfaces* list restricts the announce to the named set of interfaces. An optional *id* can be used to start a separate announce timer and to change the parameters of it later.

`migrate [-d] [-b] [-i] uri`

Migrate to *uri* (using -d to not wait for completion). -b for migration with full copy of disk -i for migration with incremental copy of disk (base image is shared)

`migrate_cancel`

Cancel the current VM migration.

`migrate_continue state`

Continue migration from the paused state *state*

`migrate_incoming uri`

Continue an incoming migration using the *uri* (that has the same syntax as the -incoming option).

`migrate_recover uri`

Continue a paused incoming postcopy migration using the *uri*.

`migrate_pause`

Pause an ongoing migration. Currently it only supports postcopy.

`migrate_set_cache_size value`

Set cache size to *value* (in bytes) for xbzrle migrations.

`migrate_set_speed value`

Set maximum speed to *value* (in bytes) for migrations.

`migrate_set_downtime second`

Set maximum tolerated downtime (in seconds) for migration.

`migrate_set_capability capability state`

Enable/Disable the usage of a capability *capability* for migration.

`migrate_set_parameter parameter value`

Set the parameter *parameter* for migration.

`migrate_start_postcopy`

Switch in-progress migration to postcopy mode. Ignored after the end of migration (or once already in postcopy).

`x_colo_lost_heartbeat`

Tell COLO that heartbeat is lost, a failover or takeover is needed.

`client_migrate_info protocol hostname port tls-port cert-subject`

Set migration information for remote display. This makes the server ask the client to automatically reconnect using the new parameters once migration finished successfully. Only implemented for SPICE.

`dump-guest-memory [-p] filename begin length`
`dump-guest-memory [-z|-l|-s|-w] filename`

Dump guest memory to *protocol*. The file can be processed with crash or gdb. Without -z|-l|-s|-w, the dump format is ELF. -p: do paging to get guest's memory mapping. -z: dump in kdump-compressed format, with zlib compression. -l: dump in kdump-compressed format, with lzo compression. -s: dump in kdump-compressed format, with snappy compression. -w: dump in Windows crashdump format (can be used instead of ELF-dump converting), for Windows x64 guests with vmcoreinfo driver only filename: dump file name. begin: the starting physical address. It's optional, and should be specified together with length. length: the memory size, in bytes. It's optional, and should be specified together with begin.

`dump-keys filename`

Save guest storage keys to a file.

`migration_mode mode`

Enables or disables migration mode.

snapshot_blkdev

Snapshot device, using snapshot file as target if provided

snapshot_blkdev_internal

Take an internal snapshot on device if it support

snapshot_delete_blkdev_internal

Delete an internal snapshot on device if it support

drive_mirror

Start mirroring a block device's writes to a new destination, using the specified target.

drive_backup

Start a point-in-time copy of a block device to a specified target.

drive_add

Add drive to PCI storage controller.

pcie_aer_inject_error

Inject PCIe AER error

netdev_add

Add host network device.

netdev_del

Remove host network device.

object_add

Create QOM object.

object_del

Destroy QOM object.

hostfwd_add

Redirect TCP or UDP connections from host to guest (requires -net user).

`hostfwd_remove`

Remove host-to-guest TCP or UDP redirection.

`balloon value`

Request VM to change its memory allocation to *value* (in MB).

`set_link name [on|off]`

Switch link *name* on (i.e. up) or off (i.e. down).

`watchdog_action`

Change watchdog action.

`acl_show aclname`

List all the matching rules in the access control list, and the default policy. There are currently two named access control lists, *vnc.x509dname* and *vnc.username* matching on the x509 client certificate distinguished name, and SASL username respectively.

`acl_policy aclname allow|deny`

Set the default access control list policy, used in the event that none of the explicit rules match. The default policy at startup is always *deny*.

`acl_add aclname match allow|deny [index]`

Add a match rule to the access control list, allowing or denying access. The match will normally be an exact username or x509 distinguished name, but can optionally include wildcard globs. eg **@EXAMPLE.COM* to allow all users in the *EXAMPLE.COM* kerberos realm. The match will normally be appended to the end of the ACL, but can be inserted earlier in the list if the optional *index* parameter is supplied.

`acl_remove aclname match`

Remove the specified match rule from the access control list.

`acl_reset aclname`

Remove all matches from the access control list, and set the default policy back to *deny*.

`nbd_server_start host:port`

Start an NBD server on the given host and/or port. If the `-a` option is included, all of the virtual machine's block devices that have an inserted media on them are automatically exported; in this case, the `-w` option makes the devices writable too.

`nbd_server_add device [name]`

Export a block device through QEMU's NBD server, which must be started beforehand with `nbd_server_start`. The `-w` option makes the exported device writable too. The export name is controlled by *name*, defaulting to *device*.

`nbd_server_remove [-f] name`

Stop exporting a block device through QEMU's NBD server, which was previously started with `nbd_server_add`. The `-f` option forces the server to drop the export immediately even if clients are connected; otherwise the command fails unless there are no clients.

`nbd_server_stop`

Stop the QEMU embedded NBD server.

`mce cpu bank status mcgstatus addr misc`

Inject an MCE on the given CPU (x86 only).

`getfd fdname`

If a file descriptor is passed alongside this command using the SCM_RIGHTS mechanism on unix sockets, it is stored using the name *fdname* for later use by other monitor commands.

`closefd fdname`

Close the file descriptor previously assigned to *fdname* using the `getfd` command. This is only needed if the file descriptor was never used by another monitor command.

`block_passwd device password`

Set the encrypted device *device* password to *password*

This command is now obsolete and will always return an error since 2.10

`block_set_io_throttle device bps bps_rd bps_wr iops iops_rd iops_wr`

Change I/O throttle limits for a block drive
to *bps bps_rd bps_wr iops iops_rd iops_wr*. *device* can be a block device name,
a qdev ID or a QOM path.

```
set_password [ vnc | spice ] password [ action-if-  
connected ]
```

Change spice/vnc password. Use zero to make the password stay valid
forever. *action-if-connected* specifies what should happen in case a connection
is established: *fail* makes the password change fail. *disconnect* changes the
password and disconnects the client. *keep* changes the password and keeps the
connection up. *keep* is the default.

```
expire_password [ vnc | spice ] expire-time
```

Specify when a password for spice/vnc becomes invalid. *expire-time* accepts:

now

Invalidate password instantly.

never

Password stays valid forever.

+nsec

Password stays valid for *nsec* seconds starting now.

nsec

Password is invalidated at the given time. *nsec* are the seconds passed since
1970, i.e. unix epoch.

```
chardev-add args
```

chardev-add accepts the same parameters as the *-chardev* command line switch.

```
chardev-change args
```

chardev-change accepts existing chardev *id* and then the same arguments as the
-chardev command line switch (except for "id").

```
chardev-remove id
```

Removes the chardev *id*.

```
chardev-send-break id
```

Send a break on the chardev *id*.

`qemu-io device command`

Executes a qemu-io command on the given block device.

`cpu-add id`

Add CPU with id *id*. This command is deprecated, please
+use `device_add` instead. For details, refer to 'docs/cpu-hotplug.rst'.

`qom-list [path]`

Print QOM properties of object at location *path*

`qom-set path property value`

Set QOM property *property* of object at location *path* to value *value*

`info subcommand`

Show various information about the system state.

`info version`

Show the version of QEMU.

`info network`

Show the network state.

`info chardev`

Show the character devices.

`info block`

Show info of one block device or all block devices.

`info blockstats`

Show block device statistics.

`info block-jobs`

Show progress of ongoing block device operations.

`info registers`

Show the cpu registers.

```
info lapic
```

Show local APIC state

```
info ioapic
```

Show io APIC state

```
info cpus
```

Show infos for each CPU.

```
info history
```

Show the command line history.

```
info irq
```

Show the interrupts statistics (if available).

```
info pic
```

Show PIC state.

```
info rdma
```

Show RDMA state.

```
info pci
```

Show PCI information.

```
info tlb
```

Show virtual to physical memory mappings.

```
info mem
```

Show the active virtual memory mappings.

```
info mtree
```

Show memory tree.

```
info jit
```

Show dynamic compiler info.

```
info opcount
```

Show dynamic compiler opcode counters

```
info sync-profile [-m|-n] [max]
```

Show synchronization profiling info, up to *max* entries (default: 10), sorted by total wait time. -m: sort by mean wait time -n: do not coalesce objects with the same call site When different objects that share the same call site are coalesced, the "Object" field shows—enclosed in brackets—the number of objects being coalesced.

```
info kvm
```

Show KVM information.

```
info numa
```

Show NUMA information.

```
info usb
```

Show guest USB devices.

```
info usbhost
```

Show host USB devices.

```
info profile
```

Show profiling information.

```
info capture
```

Show capture information.

```
info snapshots
```

Show the currently saved VM snapshots.

```
info status
```

Show the current VM status (running/paused).

```
info mice
```

Show which guest mouse is receiving events.

```
info vnc
```


Show the vnc server status.

```
info spice
```

Show the spice server status.

```
info name
```

Show the current VM name.

```
info uuid
```

Show the current VM UUID.

```
info cpustats
```

Show CPU statistics.

```
info usernet
```

Show user network stack connection states.

```
info migrate
```

Show migration status.

```
info migrate_capabilities
```

Show current migration capabilities.

```
info migrate_parameters
```

Show current migration parameters.

```
info migrate_cache_size
```

Show current migration xbzrle cache size.

```
info balloon
```

Show balloon information.

```
info qtree
```

Show device tree.

```
info qdm
```

Show qdev device model list.

```
info qom-tree
```

Show QOM composition tree.

```
info roms
```

Show roms.

```
info trace-events
```

Show available trace-events & their state.

```
info tpm
```

Show the TPM device.

```
info memdev
```

Show memory backends

```
info memory-devices
```

Show memory devices.

```
info iothreads
```

Show iothread's identifiers.

```
info rocker name
```

Show rocker switch.

```
info rocker-ports name-ports
```

Show rocker ports.

```
info rocker-of-dpa-flows name [tbl_id]
```

Show rocker OF-DPA flow tables.

```
info rocker-of-dpa-groups name [type]
```

Show rocker OF-DPA groups.

```
info skeys address
```

Display the value of a storage key (s390 only)

```
info cmma address
```

Display the values of the CMMA storage attributes for a range of pages (s390 only)

```
info dump
```

Display the latest dump status.

```
info ramblock
```

Dump all the ramblocks of the system.

```
info hotpluggable-cpus
```

Show information about hotpluggable CPUs

```
info vm-generation-id
```

Show Virtual Machine Generation ID

```
info memory_size_summary
```

Display the amount of initially allocated and present hotpluggable (if enabled) memory in bytes.

```
info sev
```

Show SEV information.

2.6.2 Integer expressions

The monitor understands integers expressions for every integer argument. You can use register names to get the value of specifics CPU registers by prefixing them with \$.

2.7 CPU models

QEMU / KVM CPU model configuration

QEMU / KVM virtualization supports two ways to configure CPU models

Host passthrough

This passes the host CPU model features, model, stepping, exactly to the guest. Note that KVM may filter out some host CPU model features if they cannot be supported with virtualization. Live migration is unsafe when this mode is used as libvirt / QEMU cannot guarantee a stable CPU is exposed to the guest across

hosts. This is the recommended CPU to use, provided live migration is not required.

Named model

QEMU comes with a number of predefined named CPU models, that typically refer to specific generations of hardware released by Intel and AMD. These allow the guest VMs to have a degree of isolation from the host CPU, allowing greater flexibility in live migrating between hosts with differing hardware.

In both cases, it is possible to optionally add or remove individual CPU features, to alter what is presented to the guest by default.

Libvirt supports a third way to configure CPU models known as "Host model". This uses the QEMU "Named model" feature, automatically picking a CPU model that is similar the host CPU, and then adding extra features to approximate the host model as closely as possible. This does not guarantee the CPU family, stepping, etc will precisely match the host CPU, as they would with "Host passthrough", but gives much of the benefit of passthrough, while making live migration safe.

2.7.1 Recommendations for KVM CPU model configuration on x86 hosts

The information that follows provides recommendations for configuring CPU models on x86 hosts. The goals are to maximise performance, while protecting guest OS against various CPU hardware flaws, and optionally enabling live migration between hosts with heterogeneous CPU models.

2.7.1.1 Preferred CPU models for Intel x86 hosts

The following CPU models are preferred for use on Intel hosts. Administrators / applications are recommended to use the CPU model that matches the generation of the host CPUs in use. In a deployment with a mixture of host CPU models between machines, if live migration compatibility is required, use the newest CPU model that is compatible across all desired hosts.

Skylake-Server
Skylake-Server-IBRS

Intel Xeon Processor (Skylake, 2016)

Skylake-Client
Skylake-Client-IBRS

Intel Core Processor (Skylake, 2015)

Broadwell
Broadwell-IBRS
Broadwell-noTSX
Broadwell-noTSX-IBRS

Intel Core Processor (Broadwell, 2014)

Haswell
Haswell-IBRS
Haswell-noTSX
Haswell-noTSX-IBRS

Intel Core Processor (Haswell, 2013)

IvyBridge
IvyBridge-IBRS

Intel Xeon E3-12xx v2 (Ivy Bridge, 2012)

SandyBridge
SandyBridge-IBRS

Intel Xeon E312xx (Sandy Bridge, 2011)

Westmere
Westmere-IBRS

Westmere E56xx/L56xx/X56xx (Nehalem-C, 2010)

Nehalem
Nehalem-IBRS

Intel Core i7 9xx (Nehalem Class Core i7, 2008)

Penryn

Intel Core 2 Duo P9xxx (Penryn Class Core 2, 2007)

Conroe

Intel Celeron_4x0 (Conroe/Merom Class Core 2, 2006)

2.7.1.2 Important CPU features for Intel x86 hosts

The following are important CPU features that should be used on Intel x86 hosts, when available in the host CPU. Some of them require explicit configuration to enable, as they are not included by default in some, or all, of the named CPU models listed above. In general all of these features are included if using "Host passthrough" or "Host model".

pcid

Recommended to mitigate the cost of the Meltdown (CVE-2017-5754) fix

Included by default in Haswell, Broadwell & Skylake Intel CPU models.

Should be explicitly turned on for Westmere, SandyBridge, and IvyBridge Intel CPU models. Note that some desktop/mobile Westmere CPUs cannot support this feature.

`spec-ctrl`

Required to enable the Spectre v2 (CVE-2017-5715) fix.

Included by default in Intel CPU models with -IBRS suffix.

Must be explicitly turned on for Intel CPU models without -IBRS suffix.

Requires the host CPU microcode to support this feature before it can be used for guest CPUs.

`stibp`

Required to enable stronger Spectre v2 (CVE-2017-5715) fixes in some operating systems.

Must be explicitly turned on for all Intel CPU models.

Requires the host CPU microcode to support this feature before it can be used for guest CPUs.

`ssbd`

Required to enable the CVE-2018-3639 fix

Not included by default in any Intel CPU model.

Must be explicitly turned on for all Intel CPU models.

Requires the host CPU microcode to support this feature before it can be used for guest CPUs.

`pdpe1gb`

Recommended to allow guest OS to use 1GB size pages

Not included by default in any Intel CPU model.

Should be explicitly turned on for all Intel CPU models.

Note that not all CPU hardware will support this feature.

md-clear

Required to confirm the MDS (CVE-2018-12126, CVE-2018-12127, CVE-2018-12130, CVE-2019-11091) fixes.

Not included by default in any Intel CPU model.

Must be explicitly turned on for all Intel CPU models.

Requires the host CPU microcode to support this feature before it can be used for guest CPUs.

2.7.1.3 Preferred CPU models for AMD x86 hosts

The following CPU models are preferred for use on Intel hosts. Administrators / applications are recommended to use the CPU model that matches the generation of the host CPUs in use. In a deployment with a mixture of host CPU models between machines, if live migration compatibility is required, use the newest CPU model that is compatible across all desired hosts.

EPYC
EPYC-IBPB

AMD EPYC Processor (2017)

Opteron_G5

AMD Opteron 63xx class CPU (2012)

Opteron_G4

AMD Opteron 62xx class CPU (2011)

Opteron_G3

AMD Opteron 23xx (Gen 3 Class Opteron, 2009)

Opteron_G2

AMD Opteron 22xx (Gen 2 Class Opteron, 2006)

Opteron_G1

AMD Opteron 240 (Gen 1 Class Opteron, 2004)

2.7.1.4 Important CPU features for AMD x86 hosts

The following are important CPU features that should be used on AMD x86 hosts, when available in the host CPU. Some of them require explicit configuration to enable, as they are not included by default in some, or all, of the named CPU models listed above. In general all of these features are included if using "Host passthrough" or "Host model".

`ibpb`

Required to enable the Spectre v2 (CVE-2017-5715) fix.

Included by default in AMD CPU models with -IBPB suffix.

Must be explicitly turned on for AMD CPU models without -IBPB suffix.

Requires the host CPU microcode to support this feature before it can be used for guest CPUs.

`stibp`

Required to enable stronger Spectre v2 (CVE-2017-5715) fixes in some operating systems.

Must be explicitly turned on for all AMD CPU models.

Requires the host CPU microcode to support this feature before it can be used for guest CPUs.

`virt-ssbd`

Required to enable the CVE-2018-3639 fix

Not included by default in any AMD CPU model.

Must be explicitly turned on for all AMD CPU models.

This should be provided to guests, even if amd-ssbd is also provided, for maximum guest compatibility.

Note for some QEMU / libvirt versions, this must be force enabled when using "Host model", because this is a virtual feature that doesn't exist in the physical host CPUs.

`amd-ssbd`

Required to enable the CVE-2018-3639 fix

Not included by default in any AMD CPU model.

Must be explicitly turned on for all AMD CPU models.

This provides higher performance than virt-ssbd so should be exposed to guests whenever available in the host. virt-ssbd should none the less also be exposed for maximum guest compatibility as some kernels only know about virt-ssbd.

amd-no-ssb

Recommended to indicate the host is not vulnerable CVE-2018-3639

Not included by default in any AMD CPU model.

Future hardware generations of CPU will not be vulnerable to CVE-2018-3639, and thus the guest should be told not to enable its mitigations, by exposing amd-no-ssb. This is mutually exclusive with virt-ssbd and amd-ssbd.

pdpe1gb

Recommended to allow guest OS to use 1GB size pages

Not included by default in any AMD CPU model.

Should be explicitly turned on for all AMD CPU models.

Note that not all CPU hardware will support this feature.

2.7.1.5 Default x86 CPU models

The default QEMU CPU models are designed such that they can run on all hosts. If an application does not wish to do perform any host compatibility checks before launching guests, the default is guaranteed to work.

The default CPU models will, however, leave the guest OS vulnerable to various CPU hardware flaws, so their use is strongly discouraged. Applications should follow the earlier guidance to setup a better CPU configuration, with host passthrough recommended if live migration is not needed.

qemu32
qemu64

QEMU Virtual CPU version 2.5+ (32 & 64 bit variants)

qemu64 is used for x86_64 guests and qemu32 is used for i686 guests, when no -cpu argument is given to QEMU, or no <cpu> is provided in libvirt XML.

2.7.1.6 Other non-recommended x86 CPUs

The following CPUs models are compatible with most AMD and Intel x86 hosts, but their usage is discouraged, as they expose a very limited featureset, which prevents guests having optimal performance.

kvm32
kvm64

Common KVM processor (32 & 64 bit variants)

Legacy models just for historical compatibility with ancient QEMU versions.

486
athlon
phenom
coreduo
core2duo
n270
pentium
pentium2
pentium3

Various very old x86 CPU models, mostly predating the introduction of hardware assisted virtualization, that should thus not be required for running virtual machines.

2.7.2 Supported CPU model configurations on MIPS hosts

QEMU supports variety of MIPS CPU models:

2.7.2.1 Supported CPU models for MIPS32 hosts

The following CPU models are supported for use on MIPS32 hosts. Administrators / applications are recommended to use the CPU model that matches the generation of the host CPUs in use. In a deployment with a mixture of host CPU models between machines, if live migration compatibility is required, use the newest CPU model that is compatible across all desired hosts.

mips32r6-generic

MIPS32 Processor (Release 6, 2015)

P5600

MIPS32 Processor (P5600, 2014)

M14K
M14Kc

MIPS32 Processor (M14K, 2009)

74Kf

MIPS32 Processor (74K, 2007)

34Kf

MIPS32 Processor (34K, 2006)

24Kc
24KEc
24Kf

MIPS32 Processor (24K, 2003)

4Kc
4Km
4KEcR1
4KEmR1
4KEc
4KEm

MIPS32 Processor (4K, 1999)

2.7.2.2 Supported CPU models for MIPS64 hosts

The following CPU models are supported for use on MIPS64 hosts. Administrators / applications are recommended to use the CPU model that matches the generation of the host CPUs in use. In a deployment with a mixture of host CPU models between machines, if live migration compatibility is required, use the newest CPU model that is compatible across all desired hosts.

I6400

MIPS64 Processor (Release 6, 2014)

Loongson-2F

MIPS64 Processor (Loongson 2, 2008)

Loongson-2E

MIPS64 Processor (Loongson 2, 2006)

mips64dspr2

MIPS64 Processor (Release 2, 2006)

MIPS64R2-generic
5KEc

5KEf

MIPS64 Processor (Release 2, 2002)

20Kc

MIPS64 Processor (20K, 2000)

5Kc

5Kf

MIPS64 Processor (5K, 1999)

VR5432

MIPS64 Processor (VR, 1998)

R4000

MIPS64 Processor (MIPS III, 1991)

2.7.2.3 Supported CPU models for nanoMIPS hosts

The following CPU models are supported for use on nanoMIPS hosts. Administrators / applications are recommended to use the CPU model that matches the generation of the host CPUs in use. In a deployment with a mixture of host CPU models between machines, if live migration compatibility is required, use the newest CPU model that is compatible across all desired hosts.

I7200

MIPS I7200 (nanoMIPS, 2018)

2.7.2.4 Preferred CPU models for MIPS hosts

The following CPU models are preferred for use on different MIPS hosts:

MIPS III

R4000

MIPS32R2

34Kf

MIPS64R6

I6400

2.7.3 Syntax for configuring CPU models

The example below illustrate the approach to configuring the various CPU models / features in QEMU and libvirt

2.7.3.1 QEMU command line

Host passthrough

```
$ qemu-system-x86_64 -cpu host
```

With feature customization:

```
$ qemu-system-x86_64 -cpu host,-vmx,...
```

Named CPU models

```
$ qemu-system-x86_64 -cpu Westmere
```

With feature customization:

```
$ qemu-system-x86_64 -cpu Westmere,+pcid,...
```

2.7.3.2 Libvirt guest XML

Host passthrough

```
<cpu mode='host-passthrough'/>
```

With feature customization:

```
<cpu mode='host-passthrough'>
  <feature name="vmx" policy="disable"/>
  ...
</cpu>
```

Host model

```
<cpu mode='host-model'/>
```

With feature customization:

```
<cpu mode='host-model'>
  <feature name="vmx" policy="disable"/>
  ...
</cpu>
```

Named model

```
<cpu mode='custom'>
  <model name="Westmere"/>
</cpu>
```

With feature customization:

```
<cpu mode='custom'>
  <model name="Westmere"/>
  <feature name="pcid" policy="require"/>
  ...
</cpu>
```

2.8 Disk Images

QEMU supports many disk image formats, including growable disk images (their size increase as non empty sectors are written), compressed and encrypted disk images.

2.8.1 Quick start for disk image creation

You can create a disk image with the command:

```
qemu-img create myimage.img mysize
```

where *myimage.img* is the disk image filename and *mysize* is its size in kilobytes. You can add an `M` suffix to give the size in megabytes and a `G` suffix for gigabytes.

See the `qemu-img` invocation documentation for more information.

2.8.2 Snapshot mode

If you use the option `-snapshot`, all disk images are considered as read only. When sectors are written, they are written in a temporary file created in `/tmp`. You can however force the write back to the raw disk images by using the `commit` monitor command (or `C-a s` in the serial console).

2.8.3 VM snapshots

VM snapshots are snapshots of the complete virtual machine including CPU state, RAM, device state and the content of all the writable disks. In order to use VM snapshots, you must have at least one non removable and writable block device using the `qcow2` disk image format. Normally this device is the first virtual hard drive.

Use the monitor command `savevm` to create a new VM snapshot or replace an existing one. A human readable name can be assigned to each snapshot in addition to its numerical ID.

Use `loadvm` to restore a VM snapshot and `delvm` to remove a VM snapshot. `info snapshots` lists the available snapshots with their associated information:

```
(qemu) info snapshots
Snapshot devices: hda
Snapshot list (from hda):
```

ID	TAG	VM SIZE	DATE	VM CLOCK
1	start	41M	2006-08-06 12:38:02	00:00:14.954
2		40M	2006-08-06 12:43:29	00:00:18.633
3	msys	40M	2006-08-06 12:44:04	00:00:23.514

A VM snapshot is made of a VM state info (its size is shown in `info snapshots`) and a snapshot of every writable disk image. The VM state info is stored in the first `qcow2` non removable and writable block device. The disk image snapshots are stored in every disk image. The size of a snapshot in a disk image is difficult to evaluate and is not shown by `info snapshots` because the associated disk sectors are shared among all the snapshots to save disk space (otherwise each snapshot would need a full copy of all the disk images).

When using the (unrelated) `-snapshot` option ([disk images snapshot mode](#)), you can always make VM snapshots, but they are deleted as soon as you exit QEMU.

VM snapshots currently have the following known limitations:

- They cannot cope with removable devices if they are removed or inserted after a snapshot is done.
- A few device drivers still have incomplete snapshot support so their state is not saved or restored properly (in particular USB).

2.9 Network emulation

QEMU can simulate several network cards (e.g. PCI or ISA cards on the PC target) and can connect them to a network backend on the host or an emulated hub. The various host network backends can either be used to connect the NIC of the guest to a real network (e.g. by using a TAP devices or the non-privileged user mode network stack), or to other guest instances running in another QEMU process (e.g. by using the socket host network backend).

2.9.1 Using TAP network interfaces

This is the standard way to connect QEMU to a real network. QEMU adds a virtual network device on your host (called `tapN`), and you can then configure it as if it was a real ethernet card.

2.9.1.1 Linux host

As an example, you can download the `linux-test-xxx.tar.gz` archive and copy the script `qemu-ifup` in `/etc` and configure properly `sudo` so that the command `ifconfig` contained in `qemu-ifup` can be executed as root. You must verify that your host kernel supports the TAP network interfaces: the device `/dev/net/tun` must be present.

See [sec invocation](#) to have examples of command lines using the TAP network interfaces.

2.9.1.2 Windows host

There is a virtual ethernet driver for Windows 2000/XP systems, called TAP-Win32. But it is not included in standard QEMU for Windows, so you will need to get it separately. It is part of OpenVPN package, so download OpenVPN from : <https://openvpn.net/>.

2.9.2 Using the user mode network stack

By using the option `-net user` (default configuration if no `-net` option is specified), QEMU uses a completely user mode network stack (you don't need root privilege to use the virtual network). The virtual network configuration is the following:

```

guest (10.0.2.15) <-----> Firewall/DHCP server <-----> Internet
                        |
                        | (10.0.2.2)
                        |
                        ----> DNS server (10.0.2.3)
                        |
                        ----> SMB server (10.0.2.4)
```

The QEMU VM behaves as if it was behind a firewall which blocks all incoming connections. You can use a DHCP client to automatically configure the network in the QEMU VM. The DHCP server assign addresses to the hosts starting from 10.0.2.15.

In order to check that the user mode network is working, you can ping the address 10.0.2.2 and verify that you got an address in the range 10.0.2.x from the QEMU virtual DHCP server.

Note that ICMP traffic in general does not work with user mode networking. `ping`, aka. ICMP echo, to the local router (10.0.2.2) shall work, however. If you're using QEMU on Linux `>= 3.0`, it can use unprivileged ICMP ping sockets to allow `ping` to the Internet. The host admin has to set the `ping_group_range` in order to grant access to those sockets. To allow ping for GID 100 (usually users group):

```
echo 100 100 > /proc/sys/net/ipv4/ping_group_range
```

When using the built-in TFTP server, the router is also the TFTP server.

When using the `'-netdev user,hostfwd=...'` option, TCP or UDP connections can be redirected from the host to the guest. It allows for example to redirect X11, telnet or SSH connections.

2.9.3 Hubs

QEMU can simulate several hubs. A hub can be thought of as a virtual connection between several network devices. These devices can be for example QEMU virtual ethernet cards or virtual Host ethernet devices (TAP devices). You can connect guest NICs or host network backends to such a hub using the `-netdev hubport` or `-nic hubport` options. The legacy `-net` option also connects the given device to the emulated hub with ID 0 (i.e. the default hub) unless you specify a netdev with `-net nic,netdev=xxx` here.

2.9.4 Connecting emulated networks between QEMU instances

Using the `-netdev socket` (or `-nic socket` or `-net socket`) option, it is possible to create emulated networks that span several QEMU instances. See the description of the `-netdev socket` option in the [Invocation chapter](#) to have a basic example.

2.10 Other Devices

2.10.1 Inter-VM Shared Memory device

On Linux hosts, a shared memory device is available. The basic syntax is:

```
qemu-system-x86_64 -device ivshmem-plain,memdev=hostmem
```

where *hostmem* names a host memory backend. For a POSIX shared memory backend, use something like

```
-object memory-backend-file,size=1M,share,mem-  
path=/dev/shm/ivshmem,id=hostmem
```

If desired, interrupts can be sent between guest VMs accessing the same shared memory region. Interrupt support requires using a shared memory server and using a chardev socket to connect to it. The code for the shared memory server is [qemu.git/contrib/ivshmem-server](https://github.com/qemu/qemu/blob/master/contrib/ivshmem-server). An example syntax when using the shared memory server is:

```
# First start the ivshmem server once and for all  
ivshmem-server -p pidfile -S path -m shm-name -l shm-size -n vectors  
  
# Then start your qemu instances with matching arguments  
qemu-system-x86_64 -device ivshmem-doorbell,vectors=vectors,chardev=id  
                  -chardev socket,path=path,id=id
```

When using the server, the guest will be assigned a VM ID (≥ 0) that allows guests using the same server to communicate via interrupts. Guests can read their VM ID from a device register (see `ivshmem-spec.txt`).

2.10.1.1 Migration with `ivshmem`

With device property `master=on`, the guest will copy the shared memory on migration to the destination host. With `master=off`, the guest will not be able to migrate with the device attached. In the latter case, the device should be detached and then reattached after migration using the PCI hotplug support.

At most one of the devices sharing the same memory can be master. The master must complete migration before you plug back the other devices.

2.10.1.2 `ivshmem` and hugepages

Instead of specifying the `<shm size>` using POSIX `shm`, you may specify a memory backend that has hugepage support:

```
qemu-system-x86_64 -object memory-backend-file,size=1G,mem-  
path=/dev/hugepages/my-shmem-file,share,id=mb1  
-device ivshmem-plain,memdev=mb1
```

`ivshmem-server` also supports hugepages mount points with the `-m` memory path argument.

2.11 Direct Linux Boot

This section explains how to launch a Linux kernel inside QEMU without having to make a full bootable image. It is very useful for fast Linux kernel testing.

The syntax is:

```
qemu-system-x86_64 -kernel bzImage -hda rootdisk.img -append "root=/dev/hda"
```

Use `-kernel` to provide the Linux kernel image and `-append` to give the kernel command line arguments. The `-initrd` option can be used to provide an INITRD image.

If you do not need graphical output, you can disable it and redirect the virtual serial port and the QEMU monitor to the console with the `-nographic` option. The typical command line is:

```
qemu-system-x86_64 -kernel bzImage -hda rootdisk.img \  
-append "root=/dev/hda console=ttyS0" -nographic
```

Use `Ctrl-a c` to switch between the serial console and the monitor (see [pcsys_keys](#)).

2.12 USB emulation

QEMU can emulate a PCI UHCI, OHCI, EHCI or XHCI USB controller. You can plug virtual USB devices or real host USB devices (only works with certain host operating systems). QEMU will automatically create and connect virtual USB hubs as necessary to connect multiple USB devices.

2.12.1 Connecting USB devices

USB devices can be connected with the `-device usb-...` command line option or the `device_add` monitor command. Available devices are:

`usb-mouse`

Virtual Mouse. This will override the PS/2 mouse emulation when activated.

`usb-tablet`

Pointer device that uses absolute coordinates (like a touchscreen). This means QEMU is able to report the mouse position without having to grab the mouse. Also overrides the PS/2 mouse emulation when activated.

`usb-storage, drive=drive_id`

Mass storage device backed by *drive_id* (see [disk_images](#))

`usb-uas`

USB attached SCSI device, see [usb-storage.txt](#) for details

`usb-bot`

Bulk-only transport storage device, see [usb-storage.txt](#) for details here, too

`usb-mtp, rootdir=dir`

Media transfer protocol device, using *dir* as root of the file tree that is presented to the guest.

`usb-host, hostbus=bus, hostaddr=addr`

Pass through the host device identified by *bus* and *addr*

`usb-host, vendorid=vendor, productid=product`

Pass through the host device identified by *vendor* and *product* ID

`usb-wacom-tablet`

Virtual Wacom PenPartner tablet. This device is similar to the `tablet` above but it can be used with the `tslib` library because in addition to touch coordinates it reports touch pressure.

`usb-kbd`

Standard USB keyboard. Will override the PS/2 keyboard (if present).

`usb-serial,chardev=id`

Serial converter. This emulates an FTDI FT232BM chip connected to host character device *id*.

`usb-braille,chardev=id`

Braille device. This will use BrlAPI to display the braille output on a real or fake device referenced by *id*.

`usb-net[,netdev=id]`

Network adapter that supports CDC ethernet and RNDIS protocols. *id* specifies a netdev defined with `-netdev ...,id=id`. For instance, user-mode networking can be used with

```
qemu-system-x86_64 [...] -netdev user,id=net0 -device usb-net,netdev=net0
```

`usb-ccid`

Smartcard reader device

`usb-audio`

USB audio device

2.12.2 Using host USB devices on a Linux host

WARNING: this is an experimental feature. QEMU will slow down when using it. USB devices requiring real time streaming (i.e. USB Video Cameras) are not supported yet.

1. If you use an early Linux 2.4 kernel, verify that no Linux driver is actually using the USB device. A simple way to do that is simply to disable the corresponding kernel module by renaming it from `mydriver.o` to `mydriver.o.disabled`.
2. Verify that `/proc/bus/usb` is working (most Linux distributions should enable it by default). You should see something like that:
 3. `ls /proc/bus/usb`

4. `001 devices drivers`
5. Since only root can access to the USB devices directly, you can either launch QEMU as root or change the permissions of the USB devices you want to use. For testing, the following suffices:
 6. `chown -R myuid /proc/bus/usb`
7. Launch QEMU and do in the monitor:
 8. `info usbhost`
 9. `Device 1.2, speed 480 Mb/s`
 10. `Class 00: USB device 1234:5678, USB DISK`

You should see the list of the devices you can use (Never try to use hubs, it won't work).

11. Add the device in QEMU by using:

12. `device_add usb-host,vendorid=0x1234,productid=0x5678`

Normally the guest OS should report that a new USB device is plugged. You can use the option `-device usb-host, . . .` to do the same.

13. Now you can try to use the host USB device in QEMU.

When relaunching QEMU, you may have to unplug and plug again the USB device to make it work again (this is a bug).

2.13 VNC security

The VNC server capability provides access to the graphical console of the guest VM across the network. This has a number of security considerations depending on the deployment scenarios.

2.13.1 Without passwords

The simplest VNC server setup does not include any form of authentication. For this setup it is recommended to restrict it to listen on a UNIX domain socket only. For example

```
qemu-system-x86_64 [...OPTIONS...] -vnc unix:/home/joebloggs/.qemu-myvm-vnc
```

This ensures that only users on local box with read/write access to that path can access the VNC server. To securely access the VNC server from a remote machine, a combination of netcat+ssh can be used to provide a secure tunnel.

2.13.2 With passwords

The VNC protocol has limited support for password based authentication. Since the protocol limits passwords to 8 characters it should not be considered to provide high security. The password can be fairly easily brute-forced by a client making repeat connections. For this reason, a VNC server using password authentication should be restricted to only listen on the loopback interface or UNIX domain sockets. Password authentication is not supported when operating in FIPS 140-2 compliance mode as it requires the use of the DES cipher. Password authentication is requested with the `password` option, and then once QEMU is running the password is set with the monitor. Until the monitor is used to set the password all clients will be rejected.

```
qemu-system-x86_64 [...OPTIONS...] -vnc :1,password -monitor stdio
(qemu) change vnc password
Password: *****
(qemu)
```

2.13.3 With x509 certificates

The QEMU VNC server also implements the VeNCrypt extension allowing use of TLS for encryption of the session, and x509 certificates for authentication. The use of x509 certificates is strongly recommended, because TLS on its own is susceptible to man-in-the-middle attacks. Basic x509 certificate support provides a secure session, but no authentication. This allows any client to connect, and provides an encrypted session.

```
qemu-system-x86_64 [...OPTIONS...] \
-object tls-creds-x509,id=tls0,dir=/etc/pki/qemu,endpoint=server,verify-
peer=no \
-vnc :1,tls-creds=tls0 -monitor stdio
```

In the above example `/etc/pki/qemu` should contain at least three files, `ca-cert.pem`, `server-cert.pem` and `server-key.pem`. Unprivileged users will want to use a private directory, for example `$HOME/.pki/qemu`. NB the `server-key.pem` file should be protected with file mode 0600 to only be readable by the user owning it.

2.13.4 With x509 certificates and client verification

Certificates can also provide a means to authenticate the client connecting. The server will request that the client provide a certificate, which it will then validate against the CA certificate. This is a good choice if deploying in an environment with a private internal certificate authority. It uses the same syntax as previously, but with `verify-peer` set to `yes` instead.

```
qemu-system-x86_64 [...OPTIONS...] \
-object tls-creds-x509,id=tls0,dir=/etc/pki/qemu,endpoint=server,verify-
peer=yes \
-vnc :1,tls-creds=tls0 -monitor stdio
```

2.13.5 With x509 certificates, client verification and passwords

Finally, the previous method can be combined with VNC password authentication to provide two layers of authentication for clients.

```
qemu-system-x86_64 [...OPTIONS...] \  
-object tls-creds-x509,id=tls0,dir=/etc/pki/qemu,endpoint=server,verify-  
peer=yes \  
-vnc :1,tls-creds=tls0,password -monitor stdio  
(qemu) change vnc password  
Password: *****  
(qemu)
```

2.13.6 With SASL authentication

The SASL authentication method is a VNC extension, that provides an easily extendable, pluggable authentication method. This allows for integration with a wide range of authentication mechanisms, such as PAM, GSSAPI/Kerberos, LDAP, SQL databases, one-time keys and more. The strength of the authentication depends on the exact mechanism configured. If the chosen mechanism also provides a SSF layer, then it will encrypt the datastream as well.

Refer to the later docs on how to choose the exact SASL mechanism used for authentication, but assuming use of one supporting SSF, then QEMU can be launched with:

```
qemu-system-x86_64 [...OPTIONS...] -vnc :1,sasl -monitor stdio
```

2.13.7 With x509 certificates and SASL authentication

If the desired SASL authentication mechanism does not supported SSF layers, then it is strongly advised to run it in combination with TLS and x509 certificates. This provides securely encrypted data stream, avoiding risk of compromising of the security credentials. This can be enabled, by combining the 'sasl' option with the aforementioned TLS + x509 options:

```
qemu-system-x86_64 [...OPTIONS...] \  
-object tls-creds-x509,id=tls0,dir=/etc/pki/qemu,endpoint=server,verify-  
peer=yes \  
-vnc :1,tls-creds=tls0,sasl -monitor stdio
```

2.13.8 Configuring SASL mechanisms

The following documentation assumes use of the Cyrus SASL implementation on a Linux host, but the principles should apply to any other SASL implementation or host. When SASL is enabled, the mechanism configuration will be loaded from system default SASL service config /etc/sasl2/qemu.conf. If running QEMU as an

unprivileged user, an environment variable `SASL_CONF_PATH` can be used to make it search alternate locations for the service config file.

If the TLS option is enabled for VNC, then it will provide session encryption, otherwise the SASL mechanism will have to provide encryption. In the latter case the list of possible plugins that can be used is drastically reduced. In fact only the GSSAPI SASL mechanism provides an acceptable level of security by modern standards. Previous versions of QEMU referred to the DIGEST-MD5 mechanism, however, it has multiple serious flaws described in detail in RFC 6331 and thus should never be used any more. The SCRAM-SHA-1 mechanism provides a simple username/password auth facility similar to DIGEST-MD5, but does not support session encryption, so can only be used in combination with TLS.

When not using TLS the recommended configuration is

```
mech_list: gssapi
keytab: /etc/qemu/krb5.tab
```

This says to use the 'GSSAPI' mechanism with the Kerberos v5 protocol, with the server principal stored in `/etc/qemu/krb5.tab`. For this to work the administrator of your KDC must generate a Kerberos principal for the server, with a name of 'qemu/somehost.example.com@EXAMPLE.COM' replacing 'somehost.example.com' with the fully qualified host name of the machine running QEMU, and 'EXAMPLE.COM' with the Kerberos Realm.

When using TLS, if username+password authentication is desired, then a reasonable configuration is

```
mech_list: scram-sha-1
sasldb_path: /etc/qemu/passwd.db
```

The `saslpasswd2` program can be used to populate the `passwd.db` file with accounts.

Other SASL configurations will be left as an exercise for the reader. Note that all mechanisms, except GSSAPI, should be combined with use of TLS to ensure a secure data channel.

2.14 TLS setup for network services

Almost all network services in QEMU have the ability to use TLS for session data encryption, along with x509 certificates for simple client authentication. What follows is a description of how to generate certificates suitable for usage with QEMU, and applies to the VNC server, character devices with the TCP backend, NBD server and client, and migration server and client.

At a high level, QEMU requires certificates and private keys to be provided in PEM format. Aside from the core fields, the certificates should include various extension

data sets, including v3 basic constraints data, key purpose, key usage and subject alt name.

The GnuTLS package includes a command called `certtool` which can be used to easily generate certificates and keys in the required format with expected data present. Alternatively a certificate management service may be used.

At a minimum it is necessary to setup a certificate authority, and issue certificates to each server. If using x509 certificates for authentication, then each client will also need to be issued a certificate.

Assuming that the QEMU network services will only ever be exposed to clients on a private intranet, there is no need to use a commercial certificate authority to create certificates. A self-signed CA is sufficient, and in fact likely to be more secure since it removes the ability of malicious 3rd parties to trick the CA into mis-issuing certs for impersonating your services. The only likely exception where a commercial CA might be desirable is if enabling the VNC websockets server and exposing it directly to remote browser clients. In such a case it might be useful to use a commercial CA to avoid needing to install custom CA certs in the web browsers.

The recommendation is for the server to keep its certificates in either `/etc/pki/qemu` or for unprivileged users in `$HOME/.pki/qemu`.

2.14.1 Setup the Certificate Authority

This step only needs to be performed once per organization / organizational unit. First the CA needs a private key. This key must be kept VERY secret and secure. If this key is compromised the entire trust chain of the certificates issued with it is lost.

```
# certtool --generate-privkey > ca-key.pem
```

To generate a self-signed certificate requires one core piece of information, the name of the organization. A template file `ca.info` should be populated with the desired data to avoid having to deal with interactive prompts from `certtool`:

```
# cat > ca.info <<EOF
cn = Name of your organization
ca
cert_signing_key
EOF
# certtool --generate-self-signed \
  --load-privkey ca-key.pem
  --template ca.info \
  --outfile ca-cert.pem
```

The `ca` keyword in the template sets the v3 basic constraints extension to indicate this certificate is for a CA, while `cert_signing_key` sets the key usage extension to indicate this will be used for signing other keys. The generated `ca-cert.pem` file

should be copied to all servers and clients wishing to utilize TLS support in the VNC server. The `ca-key.pem` must not be disclosed/copied anywhere except the host responsible for issuing certificates.

2.14.2 Issuing server certificates

Each server (or host) needs to be issued with a key and certificate. When connecting the certificate is sent to the client which validates it against the CA certificate. The core pieces of information for a server certificate are the hostnames and/or IP addresses that will be used by clients when connecting. The hostname / IP address that the client specifies when connecting will be validated against the hostname(s) and IP address(es) recorded in the server certificate, and if no match is found the client will close the connection.

Thus it is recommended that the server certificate include both the fully qualified and unqualified hostnames. If the server will have permanently assigned IP address(es), and clients are likely to use them when connecting, they may also be included in the certificate. Both IPv4 and IPv6 addresses are supported. Historically certificates only included 1 hostname in the `CN` field, however, usage of this field for validation is now deprecated. Instead modern TLS clients will validate against the Subject Alt Name extension data, which allows for multiple entries. In the future usage of the `CN` field may be discontinued entirely, so providing SAN extension data is strongly recommended.

On the host holding the CA, create template files containing the information for each server, and use it to issue server certificates.

```
# cat > server-hostNNN.info <<EOF
organization = Name of your organization
cn = hostNNN.foo.example.com
dns_name = hostNNN
dns_name = hostNNN.foo.example.com
ip_address = 10.0.1.87
ip_address = 192.8.0.92
ip_address = 2620:0:cafe::87
ip_address = 2001:24::92
tls_www_server
encryption_key
signing_key
EOF
# certtool --generate-privkey > server-hostNNN-key.pem
# certtool --generate-certificate \
    --load-ca-certificate ca-cert.pem \
    --load-ca-privkey ca-key.pem \
    --load-privkey server-hostNNN-key.pem \
    --template server-hostNNN.info \
    --outfile server-hostNNN-cert.pem
```

The `dns_name` and `ip_address` fields in the template are setting the subject alt name extension data. The `tls_www_server` keyword is the key purpose extension to indicate this certificate is intended for usage in a web server. Although QEMU network

services are not in fact HTTP servers (except for VNC websockets), setting this key purpose is still recommended. The `encryption_key` and `signing_key` keyword is the key usage extension to indicate this certificate is intended for usage in the data session.

The `server-hostNNN-key.pem` and `server-hostNNN-cert.pem` files should now be securely copied to the server for which they were generated, and renamed to `server-key.pem` and `server-cert.pem` when added to the `/etc/pki/qemu` directory on the target host. The `server-key.pem` file is security sensitive and should be kept protected with file mode 0600 to prevent disclosure.

2.14.3 Issuing client certificates

The QEMU x509 TLS credential setup defaults to enabling client verification using certificates, providing a simple authentication mechanism. If this default is used, each client also needs to be issued a certificate. The client certificate contains enough metadata to uniquely identify the client with the scope of the certificate authority. The client certificate would typically include fields for organization, state, city, building, etc.

Once again on the host holding the CA, create template files containing the information for each client, and use it to issue client certificates.

```
# cat > client-hostNNN.info <<EOF
country = GB
state = London
locality = City Of London
organization = Name of your organization
cn = hostNNN.foo.example.com
tls_www_client
encryption_key
signing_key
EOF
# certtool --generate-privkey > client-hostNNN-key.pem
# certtool --generate-certificate \
    --load-ca-certificate ca-cert.pem \
    --load-ca-privkey ca-key.pem \
    --load-privkey client-hostNNN-key.pem \
    --template client-hostNNN.info \
    --outfile client-hostNNN-cert.pem
```

The subject alt name extension data is not required for clients, so the `dns_name` and `ip_address` fields are not included. The `tls_www_client` keyword is the key purpose extension to indicate this certificate is intended for usage in a web client. Although QEMU network clients are not in fact HTTP clients, setting this key purpose is still recommended. The `encryption_key` and `signing_key` keyword is the key usage extension to indicate this certificate is intended for usage in the data session.

The `client-hostNNN-key.pem` and `client-hostNNN-cert.pem` files should now be securely copied to the client for which they were generated, and renamed to `client-key.pem` and `client-cert.pem` when added to the `/etc/pki/qemu` directory on the target host. The `client-key.pem` file is security sensitive and should be kept protected with file mode `0600` to prevent disclosure.

If a single host is going to be using TLS in both a client and server role, it is possible to create a single certificate to cover both roles. This would be quite common for the migration and NBD services, where a QEMU process will be started by accepting a TLS protected incoming migration, and later itself be migrated out to another host. To generate a single certificate, simply include the template data from both the client and server instructions in one.

```
# cat > both-hostNNN.info <<EOF
country = GB
state = London
locality = City Of London
organization = Name of your organization
cn = hostNNN.foo.example.com
dns_name = hostNNN
dns_name = hostNNN.foo.example.com
ip_address = 10.0.1.87
ip_address = 192.8.0.92
ip_address = 2620:0:cafe::87
ip_address = 2001:24::92
tls_www_server
tls_www_client
encryption_key
signing_key
EOF
# certtool --generate-privkey > both-hostNNN-key.pem
# certtool --generate-certificate \
    --load-ca-certificate ca-cert.pem \
    --load-ca-privkey ca-key.pem \
    --load-privkey both-hostNNN-key.pem \
    --template both-hostNNN.info \
    --outfile both-hostNNN-cert.pem
```

When copying the PEM files to the target host, save them twice, once as `server-cert.pem` and `server-key.pem`, and again as `client-cert.pem` and `client-key.pem`.

2.14.4 TLS x509 credential configuration

QEMU has a standard mechanism for loading x509 credentials that will be used for network services and clients. It requires specifying the `tls-creds-x509` class name to the `--object` command line argument for the system emulators. Each set of credentials loaded should be given a unique string identifier via the `id` parameter. A single set of TLS credentials can be used for multiple network backends, so VNC, migration, NBD, character devices can all share the same credentials. Note, however, that credentials for use in a client endpoint must be loaded separately from those used in a server endpoint.

When specifying the object, the `dir` parameter specifies which directory contains the credential files. This directory is expected to contain files with the names mentioned previously, `ca-cert.pem`, `server-key.pem`, `server-cert.pem`, `client-key.pem` and `client-cert.pem` as appropriate. It is also possible to include a set of pre-generated Diffie-Hellman (DH) parameters in a file `dh-params.pem`, which can be created using the `certtool --generate-dh-params` command. If omitted, QEMU will dynamically generate DH parameters when loading the credentials.

The `endpoint` parameter indicates whether the credentials will be used for a network client or server, and determines which PEM files are loaded.

The `verify` parameter determines whether x509 certificate validation should be performed. This defaults to enabled, meaning clients will always validate the server hostname against the certificate subject alt name fields and/or CN field. It also means that servers will request that clients provide a certificate and validate them. Verification should never be turned off for client endpoints, however, it may be turned off for server endpoints if an alternative mechanism is used to authenticate clients. For example, the VNC server can use SASL to authenticate clients instead.

To load server credentials with client certificate validation enabled

```
qemu-system-x86_64 -object tls-creds-  
x509,id=tls0,dir=/etc/pki/qemu,endpoint=server
```

while to load client credentials use

```
qemu-system-x86_64 -object tls-creds-  
x509,id=tls0,dir=/etc/pki/qemu,endpoint=client
```

Network services which support TLS will all have a `tls-creds` parameter which expects the ID of the TLS credentials object. For example with VNC:

```
qemu-system-x86_64 -vnc 0.0.0.0:0,tls-creds=tls0
```

2.14.5 TLS Pre-Shared Keys (PSK)

Instead of using certificates, you may also use TLS Pre-Shared Keys (TLS-PSK). This can be simpler to set up than certificates but is less scalable.

Use the GnuTLS `psktool` program to generate a `keys.psk` file containing one or more usernames and random keys:

```
mkdir -m 0700 /tmp/keys  
psktool -u rich -p /tmp/keys/keys.psk
```

TLS-enabled servers such as `qemu-nbd` can use this directory like so:

```
qemu-nbd \  
-t -x / \  
--object tls-creds-psk,id=tls0,endpoint=server,dir=/tmp/keys \  

```

```
--tls-creds tls0 \  
image.qcow2
```

When connecting from a qemu-based client you must specify the directory containing `keys.psk` and an optional *username* (defaults to “qemu”):

```
qemu-img info \  
--object tls-creds-psk,id=tls0,dir=/tmp/keys,username=rich,endpoint=client \  
\  
--image-opts \  
file.driver=nbd,file.host=localhost,file.port=10809,file.tls-creds=tls0,file.export=/  

```

2.15 GDB usage

QEMU has a primitive support to work with gdb, so that you can do 'Ctrl-C' while the virtual machine is running and inspect its state.

In order to use gdb, launch QEMU with the '-s' option. It will wait for a gdb connection:

```
qemu-system-x86_64 -s -kernel bzImage -hda rootdisk.img -append  
"root=/dev/hda"  
Connected to host network interface: tun0  
Waiting gdb connection on port 1234
```

Then launch gdb on the 'vmlinux' executable:

```
> gdb vmlinux
```

In gdb, connect to QEMU:

```
(gdb) target remote localhost:1234
```

Then you can use gdb normally. For example, type 'c' to launch the kernel:

```
(gdb) c
```

Here are some useful tips in order to use gdb on system code:

1. Use `info reg` to display all the CPU registers.
2. Use `x/10i $eip` to display the code at the PC position.
3. Use `set architecture i8086` to dump 16 bit code. Then use `x/10i $cs*16+$eip` to dump the code at the PC position.

Advanced debugging options:

The default single stepping behavior is step with the IRQs and timer service routines off. It is set this way because when gdb executes a single step it expects to advance beyond the current instruction. With the IRQs and timer service routines on, a single step might jump into the one of the interrupt or exception vectors instead of executing

the current instruction. This means you may hit the same breakpoint a number of times before executing the instruction gdb wants to have executed. Because there are rare circumstances where you want to single step into an interrupt vector the behavior can be controlled from GDB. There are three commands you can query and set the single step behavior:

```
maintenance packet qqemu.sstepbits
```

This will display the MASK bits used to control the single stepping IE:

```
(gdb) maintenance packet qqemu.sstepbits
sending: "qqemu.sstepbits"
received: "ENABLE=1,NOIRQ=2,NOTIMER=4"
maintenance packet qqemu.sstep
```

This will display the current value of the mask used when single stepping IE:

```
(gdb) maintenance packet qqemu.sstep
sending: "qqemu.sstep"
received: "0x7"
maintenance packet Qqemu.sstep=HEX_VALUE
```

This will change the single step mask, so if wanted to enable IRQs on the single step, but not timers, you would use:

```
(gdb) maintenance packet Qqemu.sstep=0x5
sending: "qemu.sstep=0x5"
received: "OK"
```

2.16 Target OS specific information

2.16.1 Linux

To have access to SVGA graphic modes under X11, use the `vesa` or the `cirrus` X11 driver. For optimal performances, use 16 bit color depth in the guest and the host OS.

When using a 2.6 guest Linux kernel, you should add the option `clock=pit` on the kernel command line because the 2.6 Linux kernels make very strict real time clock checks by default that QEMU cannot simulate exactly.

When using a 2.6 guest Linux kernel, verify that the 4G/4G patch is not activated because QEMU is slower with this patch. The QEMU Accelerator Module is also much slower in this case. Earlier Fedora Core 3 Linux kernel (< 2.6.9-1.724_FC3) were known to incorporate this patch by default. Newer kernels don't have it.

2.16.2 Windows

If you have a slow host, using Windows 95 is better as it gives the best speed. Windows 2000 is also a good choice.

2.16.2.1 SVGA graphic modes support

QEMU emulates a Cirrus Logic GD5446 Video card. All Windows versions starting from Windows 95 should recognize and use this graphic card. For optimal performances, use 16 bit color depth in the guest and the host OS.

If you are using Windows XP as guest OS and if you want to use high resolution modes which the Cirrus Logic BIOS does not support (i.e. $\geq 1280 \times 1024 \times 16$), then you should use the VESA VBE virtual graphic card (option `-std-vga`).

2.16.2.2 CPU usage reduction

Windows 9x does not correctly use the CPU HLT instruction. The result is that it takes host CPU cycles even when idle. You can install the utility from <https://web.archive.org/web/20060212132151/http://www.user.cityline.ru/~maxamn/amnhltm.zip> to solve this problem. Note that no such tool is needed for NT, 2000 or XP.

2.16.2.3 Windows 2000 disk full problem

Windows 2000 has a bug which gives a disk full problem during its installation. When installing it, use the `-win2k-hack` QEMU option to enable a specific workaround. After Windows 2000 is installed, you no longer need this option (this option slows down the IDE transfers).

2.16.2.4 Windows 2000 shutdown

Windows 2000 cannot automatically shutdown in QEMU although Windows 98 can. It comes from the fact that Windows 2000 does not automatically use the APM driver provided by the BIOS.

In order to correct that, do the following (thanks to Struan Bartlett): go to the Control Panel => Add/Remove Hardware & Next => Add/Troubleshoot a device => Add a new device & Next => No, select the hardware from a list & Next => NT Apm/Legacy Support & Next => Next (again) a few times. Now the driver is installed and Windows 2000 now correctly instructs QEMU to shutdown at the appropriate moment.

2.16.2.5 Share a directory between Unix and Windows

See [sec invocation](#) about the help of the option `'-netdev user,smb=...'`.

2.16.2.6 Windows XP security problem

Some releases of Windows XP install correctly but give a security error when booting:

```
A problem is preventing Windows from accurately checking the
license for this computer. Error code: 0x800703e6.
```


The workaround is to install a service pack for XP after a boot in safe mode. Then reboot, and the problem should go away. Since there is no network while in safe mode, its recommended to download the full installation of SP1 or SP2 and transfer that via an ISO or using the vvfat block device ("-hdb fat:directory_which_holds_the_SP").

2.16.3 MS-DOS and FreeDOS

2.16.3.1 CPU usage reduction

DOS does not correctly use the CPU HLT instruction. The result is that it takes host CPU cycles even when idle. You can install the utility from <https://web.archive.org/web/20051222085335/http://www.vmware.com/software/dosidle210.zip> to solve this problem.

3 QEMU System emulator for non PC targets

QEMU is a generic emulator and it emulates many non PC machines. Most of the options are similar to the PC emulator. The differences are mentioned in the following sections.

3.1 PowerPC System emulator

Use the executable `qemu-system-ppc` to simulate a complete 40P (PREP) or PowerMac PowerPC system.

QEMU emulates the following PowerMac peripherals:

- - UniNorth or Grackle PCI Bridge
- - PCI VGA compatible card with VESA Bochs Extensions
- - 2 PMAC IDE interfaces with hard disk and CD-ROM support
- - NE2000 PCI adapters
- - Non Volatile RAM
- - VIA-CUDA with ADB keyboard and mouse.

QEMU emulates the following 40P (PREP) peripherals:

- - PCI Bridge
- - PCI VGA compatible card with VESA Bochs Extensions
- - 2 IDE interfaces with hard disk and CD-ROM support
- - Floppy disk
- - PCnet network adapters
- - Serial port
- - PREP Non Volatile RAM

- - PC compatible keyboard and mouse.

Since version 0.9.1, QEMU uses OpenBIOS <https://www.openbios.org/> for the g3beige and mac99 PowerMac and the 40p machines. OpenBIOS is a free (GPL v2) portable firmware implementation. The goal is to implement a 100% IEEE 1275-1994 (referred to as Open Firmware) compliant firmware.

The following options are specific to the PowerPC emulation:

`-g WxH[xDEPTH]`

Set the initial VGA graphic mode. The default is 800x600x32.

`-prom-env string`

Set OpenBIOS variables in NVRAM, for example:

```
qemu-system-ppc -prom-env 'auto-boot?=false' \
  -prom-env 'boot-device=hd:2,\yaboot' \
  -prom-env 'boot-args=conf=hd:2,\yaboot.conf'
```

More information is available at http://perso.magic.fr/l_indien/qemu-ppc/.

3.2 Sparc32 System emulator

Use the executable `qemu-system-sparc` to simulate the following Sun4m architecture machines:

- - SPARCstation 4
- - SPARCstation 5
- - SPARCstation 10
- - SPARCstation 20
- - SPARCserver 600MP
- - SPARCstation LX
- - SPARCstation Voyager
- - SPARCclassic
- - SPARCbook

The emulation is somewhat complete. SMP up to 16 CPUs is supported, but Linux limits the number of usable CPUs to 4.

QEMU emulates the following sun4m peripherals:

- - IOMMU
- - TCX or cgthree Frame buffer
- - Lance (Am7990) Ethernet
- - Non Volatile RAM M48T02/M48T08

- - Slave I/O: timers, interrupt controllers, Zilog serial ports, keyboard and power/reset logic
- - ESP SCSI controller with hard disk and CD-ROM support
- - Floppy drive (not on SS-600MP)
- - CS4231 sound device (only on SS-5, not working yet)

The number of peripherals is fixed in the architecture. Maximum memory size depends on the machine type, for SS-5 it is 256MB and for others 2047MB.

Since version 0.8.2, QEMU uses OpenBIOS <https://www.openbios.org/>. OpenBIOS is a free (GPL v2) portable firmware implementation. The goal is to implement a 100% IEEE 1275-1994 (referred to as Open Firmware) compliant firmware.

A sample Linux 2.6 series kernel and ram disk image are available on the QEMU web site. There are still issues with NetBSD and OpenBSD, but most kernel versions work. Please note that currently older Solaris kernels don't work probably due to interface issues between OpenBIOS and Solaris.

The following options are specific to the Sparc32 emulation:

`-g WxHx[xDEPTH]`

Set the initial graphics mode. For TCX, the default is 1024x768x8 with the option of 1024x768x24. For cgthree, the default is 1024x768x8 with the option of 1152x900x8 for people who wish to use OBP.

`-prom-env string`

Set OpenBIOS variables in NVRAM, for example:

```
qemu-system-sparc -prom-env 'auto-boot?=false' \
  -prom-env 'boot-device=sd(0,2,0):d' -prom-env 'boot-args=linux
single'
```

`-M [SS-4|SS-5|SS-10|SS-20|SS-600MP|LX|Voyager|SPARCClassic] [|SPARCbook]`

Set the emulated machine type. Default is SS-5.

3.3 Sparc64 System emulator

Use the executable `qemu-system-sparc64` to simulate a Sun4u (UltraSPARC PC-like machine), Sun4v (T1 PC-like machine), or generic Niagara (T1) machine. The Sun4u emulator is mostly complete, being able to run Linux, NetBSD and OpenBSD in headless (`-nographic`) mode. The Sun4v emulator is still a work in progress.

The Niagara T1 emulator makes use of firmware and OS binaries supplied in the S10image/ directory of the OpenSPARC T1 project http://download.oracle.com/technetwork/systems/opensparc/OpenSPARCT1_Arch.1.5.tar.bz2 and is able to boot the disk.s10hw2 Solaris image.

```
qemu-system-sparc64 -M niagara -L /path-to/S10image/ \
-nographic -m 256 \
-drive if=pflash,readonly=on,file=/S10image/disk.s10hw2
```

QEMU emulates the following peripherals:

- - UltraSparc IIi APB PCI Bridge
- - PCI VGA compatible card with VESA Bochs Extensions
- - PS/2 mouse and keyboard
- - Non Volatile RAM M48T59
- - PC-compatible serial ports
- - 2 PCI IDE interfaces with hard disk and CD-ROM support
- - Floppy disk

The following options are specific to the Sparc64 emulation:

`-prom-env string`

Set OpenBIOS variables in NVRAM, for example:

```
qemu-system-sparc64 -prom-env 'auto-boot?=false'
-M [sun4u|sun4v|niagara]
```

Set the emulated machine type. The default is sun4u.

3.4 MIPS System emulator

Four executables cover simulation of 32 and 64-bit MIPS systems in both endian options, `qemu-system-mips`, `qemu-system-mipsel`, `qemu-system-mips64` and `qemu-system-mips64el`. Five different machine types are emulated:

- - A generic ISA PC-like machine "mips"
- - The MIPS Malta prototype board "malta"
- - An ACER Pica "pica61". This machine needs the 64-bit emulator.
- - MIPS emulator pseudo board "mipssim"
- - A MIPS Magnum R4000 machine "magnum". This machine needs the 64-bit emulator.

The generic emulation is supported by Debian 'Etch' and is able to install Debian into a virtual disk image. The following devices are emulated:

- - A range of MIPS CPUs, default is the 24Kf
- - PC style serial port
- - PC style IDE disk
- - NE2000 network card

The Malta emulation supports the following devices:

- - Core board with MIPS 24Kf CPU and Galileo system controller
- - PIIX4 PCI/USB/SMBus controller
- - The Multi-I/O chip's serial device
- - PCI network cards (PCnet32 and others)
- - Malta FPGA serial device
- - Cirrus (default) or any other PCI VGA graphics card

The Boston board emulation supports the following devices:

- - Xilinx FPGA, which includes a PCIe root port and an UART
- - Intel EG20T PCH connects the I/O peripherals, but only the SATA bus is emulated

The ACER Pica emulation supports:

- - MIPS R4000 CPU
- - PC-style IRQ and DMA controllers
- - PC Keyboard
- - IDE controller

The MIPS Magnum R4000 emulation supports:

- - MIPS R4000 CPU
- - PC-style IRQ controller
- - PC Keyboard
- - SCSI controller
- - G364 framebuffer

The Fulong 2E emulation supports:

- - Loongson 2E CPU
- - Bonito64 system controller as North Bridge
- - VT82C686 chipset as South Bridge
- - RTL8139D as a network card chipset

The mipssim pseudo board emulation provides an environment similar to what the proprietary MIPS emulator uses for running Linux. It supports:

- - A range of MIPS CPUs, default is the 24Kf
- - PC style serial port
- - MIPSnet network emulation

3.4.1 nanoMIPS System emulator

Executable `qemu-system-mipsel` also covers simulation of 32-bit nanoMIPS system in little endian mode:

- - nanoMIPS I7200 CPU

Example of `qemu-system-mipsel` usage for nanoMIPS is shown below:

Download <disk_image_file> from <https://mipsdistros.mips.com/LinuxDistro/nanomips/buildroot/index.html>.

Download <kernel_image_file> from <https://mipsdistros.mips.com/LinuxDistro/nanomips/kernels/v4.15.18-432-gb2eb9a8b07a1-20180627102142/index.html>.

Start system emulation of Malta board with nanoMIPS I7200 CPU:

```
qemu-system-mipsel -cpu I7200 -kernel <kernel_image_file> \
    -M malta -serial stdio -m <memory_size> -hda <disk_image_file> \
    -append "mem=256m@0x0 rw console=ttyS0 vga=cirrus vesa=0x111
root=/dev/sda"
```

3.5 ARM System emulator

Use the executable `qemu-system-arm` to simulate a ARM machine. The ARM Integrator/CP board is emulated with the following devices:

- - ARM926E, ARM1026E, ARM946E, ARM1136 or Cortex-A8 CPU
- - Two PL011 UARTs
- - SMC 91c111 Ethernet adapter
- - PL110 LCD controller
- - PL050 KMI with PS/2 keyboard and mouse.
- - PL181 MultiMedia Card Interface with SD card.

The ARM Versatile baseboard is emulated with the following devices:

- - ARM926E, ARM1136 or Cortex-A8 CPU
- - PL190 Vectored Interrupt Controller
- - Four PL011 UARTs
- - SMC 91c111 Ethernet adapter
- - PL110 LCD controller
- - PL050 KMI with PS/2 keyboard and mouse.
- - PCI host bridge. Note the emulated PCI bridge only provides access to PCI memory space. It does not provide access to PCI IO space. This means some devices (eg. ne2k_pci NIC) are not usable, and others (eg. rtl8139 NIC) are only usable when the guest drivers use the memory mapped control registers.

- - PCI OHCI USB controller.
- - LSI53C895A PCI SCSI Host Bus Adapter with hard disk and CD-ROM devices.
- - PL181 MultiMedia Card Interface with SD card.

Several variants of the ARM RealView baseboard are emulated, including the EB, PB-A8 and PBX-A9. Due to interactions with the bootloader, only certain Linux kernel configurations work out of the box on these boards.

Kernels for the PB-A8 board should have CONFIG_REALVIEW_HIGH_PHYS_OFFSET enabled in the kernel, and expect 512M RAM. Kernels for The PBX-A9 board should have CONFIG_SPARSEMEM enabled, CONFIG_REALVIEW_HIGH_PHYS_OFFSET disabled and expect 1024M RAM.

The following devices are emulated:

- - ARM926E, ARM1136, ARM11MPCore, Cortex-A8 or Cortex-A9 MPCore CPU
- - ARM AMBA Generic/Distributed Interrupt Controller
- - Four PL011 UARTs
- - SMC 91c111 or SMSC LAN9118 Ethernet adapter
- - PL110 LCD controller
- - PL050 KMI with PS/2 keyboard and mouse
- - PCI host bridge
- - PCI OHCI USB controller
- - LSI53C895A PCI SCSI Host Bus Adapter with hard disk and CD-ROM devices
- - PL181 MultiMedia Card Interface with SD card.

The XScale-based clamshell PDA models ("Spitz", "Akita", "Borzo" and "Terrier") emulation includes the following peripherals:

- - Intel PXA270 System-on-chip (ARM V5TE core)
- - NAND Flash memory
- - IBM/Hitachi DSCM microdrive in a PXA PCMCIA slot - not in "Akita"
- - On-chip OHCI USB controller
- - On-chip LCD controller
- - On-chip Real Time Clock
- - TI ADS7846 touchscreen controller on SSP bus
- - Maxim MAX1111 analog-digital converter on I²C bus
- - GPIO-connected keyboard controller and LEDs
- - Secure Digital card connected to PXA MMC/SD host
- - Three on-chip UARTs
- - WM8750 audio CODEC on I²C and I²S busses

The Palm Tungsten|E PDA (codename "Cheetah") emulation includes the following elements:

- - Texas Instruments OMAP310 System-on-chip (ARM 925T core)
- - ROM and RAM memories (ROM firmware image can be loaded with - option-rom)
- - On-chip LCD controller
- - On-chip Real Time Clock
- - TI TSC2102i touchscreen controller / analog-digital converter / Audio CODEC, connected through MicroWire and I²S busses
- - GPIO-connected matrix keypad
- - Secure Digital card connected to OMAP MMC/SD host
- - Three on-chip UARTs

Nokia N800 and N810 internet tablets (known also as RX-34 and RX-44 / 48) emulation supports the following elements:

- - Texas Instruments OMAP2420 System-on-chip (ARM 1136 core)
- - RAM and non-volatile OneNAND Flash memories
- - Display connected to EPSON remote framebuffer chip and OMAP on-chip display controller and a LS041y3 MIPI DBI-C controller
- - TI TSC2301 (in N800) and TI TSC2005 (in N810) touchscreen controllers driven through SPI bus
- - National Semiconductor LM8323-controlled qwerty keyboard driven through I²C bus
- - Secure Digital card connected to OMAP MMC/SD host
- - Three OMAP on-chip UARTs and on-chip STI debugging console
- - Mentor Graphics "Inventra" dual-role USB controller embedded in a TI TUSB6010 chip - only USB host mode is supported
- - TI TMP105 temperature sensor driven through I²C bus
- - TI TWL92230C power management companion with an RTC on I²C bus
- - Nokia RETU and TAHVO multi-purpose chips with an RTC, connected through CBUS

The Luminary Micro Stellaris LM3S811EVB emulation includes the following devices:

- - Cortex-M3 CPU core.
- - 64k Flash and 8k SRAM.
- - Timers, UARTs, ADC and I²C interface.
- - OSRAM Pictiva 96x16 OLED with SSD0303 controller on I²C bus.

The Luminary Micro Stellaris LM3S6965EVB emulation includes the following devices:

- - Cortex-M3 CPU core.
- - 256k Flash and 64k SRAM.

- - Timers, UARTs, ADC, I²C and SSI interfaces.
- - OSRAM Pictiva 128x64 OLED with SSD0323 controller connected via SSI.

The Freecom MusicPal internet radio emulation includes the following elements:

- - Marvell MV88W8618 ARM core.
- - 32 MB RAM, 256 KB SRAM, 8 MB flash.
- - Up to 2 16550 UARTs
- - MV88W8xx8 Ethernet controller
- - MV88W8618 audio controller, WM8750 CODEC and mixer
- - 128x64 display with brightness control
- - 2 buttons, 2 navigation wheels with button function

The Siemens SX1 models v1 and v2 (default) basic emulation. The emulation includes the following elements:

- - Texas Instruments OMAP310 System-on-chip (ARM 925T core)
- - ROM and RAM memories (ROM firmware image can be loaded with -pflash)
V1 1 Flash of 16MB and 1 Flash of 8MB V2 1 Flash of 32MB
- - On-chip LCD controller
- - On-chip Real Time Clock
- - Secure Digital card connected to OMAP MMC/SD host
- - Three on-chip UARTs

A Linux 2.6 test image is available on the QEMU web site. More information is available in the QEMU mailing-list archive.

The following options are specific to the ARM emulation:

`-semihosting`

Enable semihosting syscall emulation.

On ARM this implements the "Angel" interface.

Note that this allows guest direct access to the host filesystem, so should only be used with trusted guest OS.

3.6 ColdFire System emulator

Use the executable `qemu-system-m68k` to simulate a ColdFire machine. The emulator is able to boot a uClinux kernel.

The M5208EVB emulation includes the following devices:

- - MCF5208 ColdFire V2 Microprocessor (ISA A+ with EMAC).

- - Three Two on-chip UARTs.
- - Fast Ethernet Controller (FEC)

The AN5206 emulation includes the following devices:

- - MCF5206 ColdFire V2 Microprocessor.
- - Two on-chip UARTs.

The following options are specific to the ColdFire emulation:

`-semihosting`

Enable semihosting syscall emulation.

On M68K this implements the "ColdFire GDB" interface used by libgloss.

Note that this allows guest direct access to the host filesystem, so should only be used with trusted guest OS.

3.7 Cris System emulator

TODO

3.8 Microblaze System emulator

TODO

3.9 SH4 System emulator

TODO

3.10 Xtensa System emulator

Two executables cover simulation of both Xtensa endian options, `qemu-system-xtensa` and `qemu-system-xtensaeb`. Two different machine types are emulated:

- - Xtensa emulator pseudo board "sim"
- - Avnet LX60/LX110/LX200 board

The sim pseudo board emulation provides an environment similar to one provided by the proprietary Tensilica ISS. It supports:

- - A range of Xtensa CPUs, default is the DC232B
- - Console and filesystem access via semihosting calls

The Avnet LX60/LX110/LX200 emulation supports:

- - A range of Xtensa CPUs, default is the DC232B
- - 16550 UART
- - OpenCores 10/100 Mbps Ethernet MAC

The following options are specific to the Xtensa emulation:

`-semihosting`

Enable semihosting syscall emulation.

Xtensa semihosting provides basic file IO calls, such as open/read/write/seek/select. Tensilica baremetal libc for ISS and linux platform "sim" use this interface.

Note that this allows guest direct access to the host filesystem, so should only be used with trusted guest OS.

4 QEMU User space emulator

4.1 Supported Operating Systems

The following OS are supported in user space emulation:

- - Linux (referred as qemu-linux-user)
- - BSD (referred as qemu-bsd-user)

4.2 Features

QEMU user space emulation has the following notable features:

System call translation:

QEMU includes a generic system call translator. This means that the parameters of the system calls can be converted to fix endianness and 32/64-bit mismatches between hosts and targets. IOCTLs can be converted too.

POSIX signal handling:

QEMU can redirect to the running program all signals coming from the host (such as `SIGALRM`), as well as synthesize signals from virtual CPU exceptions (for example `SIGFPE` when the program executes a division by zero).

QEMU relies on the host kernel to emulate most signal system calls, for example to emulate the signal mask. On Linux, QEMU supports both normal and real-time signals.

Threading:

On Linux, QEMU can emulate the `clone` syscall and create a real host thread (with a separate virtual CPU) for each emulated thread. Note that not all targets currently emulate atomic operations correctly. x86 and ARM use a global lock in order to preserve their semantics.

QEMU was conceived so that ultimately it can emulate itself. Although it is not very useful, it is an important test to show the power of the emulator.

4.3 Linux User space emulator

4.3.1 Quick Start

In order to launch a Linux process, QEMU needs the process executable itself and all the target (x86) dynamic libraries used by it.

- On x86, you can just try to launch any process by using the native libraries:

- `qemu-i386 -L / /bin/ls`

`-L /` tells that the x86 dynamic linker must be searched with a `/` prefix.

- Since QEMU is also a linux process, you can launch QEMU with QEMU (NOTE: you can only do that if you compiled QEMU from the sources):

- `qemu-i386 -L / qemu-i386 -L / /bin/ls`

- On non x86 CPUs, you need first to download at least an x86 glibc (`qemu-runtime-i386-XXX-.tar.gz` on the QEMU web page). Ensure that `LD_LIBRARY_PATH` is not set:

- `unset LD_LIBRARY_PATH`

Then you can launch the precompiled `ls x86` executable:

```
qemu-i386 tests/i386/ls
```

You can look at `scripts/qemu-binfmt-conf.sh` so that QEMU is automatically launched by the Linux kernel when you try to launch x86 executables. It requires the `binfmt_misc` module in the Linux kernel.

- The x86 version of QEMU is also included. You can try weird things such as:
 - `qemu-i386 /usr/local/qemu-i386/bin/qemu-i386 \`
 - `/usr/local/qemu-i386/bin/ls-i386`
-

4.3.2 Wine launch

- Ensure that you have a working QEMU with the x86 glibc distribution (see previous section). In order to verify it, you must be able to do:
 - `qemu-i386 /usr/local/qemu-i386/bin/ls-i386`
 - Download the binary x86 Wine install (`qemu-XXX-i386-wine.tar.gz` on the QEMU web page).
 - Configure Wine on your account. Look at the provided script `/usr/local/qemu-i386/bin/wine-conf.sh`. Your previous `${HOME}/.wine` directory is saved to `${HOME}/.wine.org`.
 - Then you can try the example `putty.exe`:
 - `qemu-i386 /usr/local/qemu-i386/wine/bin/wine \`
 - `/usr/local/qemu-i386/wine/c/Program\ Files/putty.exe`
-

4.3.3 Command line options

```
qemu-i386 [-h] [-d] [-L path] [-s size] [-cpu model] [-g port] [-B offset] [-R size] program [arguments...]
-h
```

Print the help

`-L path`

Set the x86 elf interpreter prefix (default=`/usr/local/qemu-i386`)

`-s size`

Set the x86 stack size in bytes (default=`524288`)

`-cpu model`

Select CPU model (`-cpu help` for list and additional feature selection)

`-E var=value`

Set environment *var* to *value*.

`-U var`

Remove *var* from the environment.

`-B offset`

Offset guest address by the specified number of bytes. This is useful when the address region required by guest applications is reserved on the host. This option is currently only supported on some hosts.

`-R size`

Pre-allocate a guest virtual address space of the given size (in bytes). "G", "M", and "k" suffixes may be used when specifying the size.

Debug options:

`-d item1,...`

Activate logging of the specified items (use '`-d help`' for a list of log items)

`-p pagesize`

Act as if the host page size was '`pagesize`' bytes

`-g port`

Wait gdb connection to port

`-singlestep`

Run the emulation in single step mode.

Environment variables:

`QEMU_STRACE`

Print system calls and arguments similar to the '`strace`' program (NOTE: the actual '`strace`' program will not work because the user space emulator hasn't implemented `ptrace`). At the moment this is incomplete. All system calls that don't have a specific argument format are printed with information for six arguments. Many flag-style arguments don't have decoders and will show up as numbers.

4.3.4 Other binaries

qemu-alpha TODO.

qemu-armeb TODO.

qemu-arm is also capable of running ARM "Angel" semihosted ELF binaries (as implemented by the arm-elf and arm-eabi Newlib/GDB configurations), and arm-uclinux bFLT format binaries.

qemu-m68k is capable of running semihosted binaries using the BDM (m5xxx-ram-hosted.ld) or m68k-sim (sim.ld) syscall interfaces, and coldfire uClinux bFLT format binaries.

The binary format is detected automatically.

qemu-cris TODO.

qemu-i386 TODO. qemu-x86_64 TODO.

qemu-microblaze TODO.

qemu-mips executes 32-bit big endian MIPS binaries (MIPS O32 ABI).

qemu-mipsel executes 32-bit little endian MIPS binaries (MIPS O32 ABI).

qemu-mips64 executes 64-bit big endian MIPS binaries (MIPS N64 ABI).

qemu-mips64el executes 64-bit little endian MIPS binaries (MIPS N64 ABI).

qemu-mipsn32 executes 32-bit big endian MIPS binaries (MIPS N32 ABI).

qemu-mipsn32el executes 32-bit little endian MIPS binaries (MIPS N32 ABI).

qemu-nios2 TODO.

qemu-ppc64abi32 TODO. qemu-ppc64 TODO. qemu-ppc TODO.

qemu-sh4eb TODO. qemu-sh4 TODO.

qemu-sparc can execute Sparc32 binaries (Sparc32 CPU, 32 bit ABI).

qemu-sparc32plus can execute Sparc32 and SPARC32PLUS binaries (Sparc64 CPU, 32 bit ABI).

qemu-sparc64 can execute some Sparc64 (Sparc64 CPU, 64 bit ABI) and SPARC32PLUS binaries (Sparc64 CPU, 32 bit ABI).

4.4 BSD User space emulator

4.4.1 BSD Status

- - target Sparc64 on Sparc64: Some trivial programs work.
-

4.4.2 Quick Start

In order to launch a BSD process, QEMU needs the process executable itself and all the target dynamic libraries used by it.

- On Sparc64, you can just try to launch any process by using the native libraries:
 - `qemu-sparc64 /bin/ls`
-

4.4.3 Command line options

```
qemu-sparc64 [-h] [-d] [-L path] [-s size] [-bsd type] program [arguments...]
-h
```

Print the help

`-L path`

Set the library root path (default=/`)`

`-s size`

Set the stack size in bytes (default=524288)

`-ignore-environment`

Start with an empty environment. Without this option, the initial environment is a copy of the caller's environment.

`-E var=value`

Set environment *var* to *value*.

`-U var`

Remove *var* from the environment.

`-bsd type`

Set the type of the emulated BSD Operating system. Valid values are FreeBSD, NetBSD and OpenBSD (default).

Debug options:

`-d item1,...`

Activate logging of the specified items (use `'-d help'` for a list of log items)

`-p pagesize`

Act as if the host page size was `'pagesize'` bytes

`-singlestep`

Run the emulation in single step mode.

5 System requirements

5.1 KVM kernel module

On x86_64 hosts, the default set of CPU features enabled by the KVM accelerator require the host to be running Linux v4.5 or newer.

The OpteronG[345] CPU models require KVM support for RDTSCP, which was added with Linux 4.5 which is supported by the major distros. And even if RHEL7 has kernel 3.10, KVM there has the required functionality there to make it close to a 4.5 or newer kernel.

6 Security

6.1 Overview

This chapter explains the security requirements that QEMU is designed to meet and principles for securely deploying QEMU.

6.2 Security Requirements

QEMU supports many different use cases, some of which have stricter security requirements than others. The community has agreed on the overall security requirements that users may depend on. These requirements define what is considered supported from a security perspective.

6.2.1 Virtualization Use Case

The virtualization use case covers cloud and virtual private server (VPS) hosting, as well as traditional data center and desktop virtualization. These use cases rely on hardware virtualization extensions to execute guest code safely on the physical CPU at close-to-native speed.

The following entities are untrusted, meaning that they may be buggy or malicious:

- Guest
- User-facing interfaces (e.g. VNC, SPICE, WebSocket)
- Network protocols (e.g. NBD, live migration)
- User-supplied files (e.g. disk images, kernels, device trees)
- Passthrough devices (e.g. PCI, USB)

Bugs affecting these entities are evaluated on whether they can cause damage in real-world use cases and treated as security bugs if this is the case.

6.2.2 Non-virtualization Use Case

The non-virtualization use case covers emulation using the Tiny Code Generator (TCG). In principle the TCG and device emulation code used in conjunction with the non-virtualization use case should meet the same security requirements as the virtualization use case. However, for historical reasons much of the non-virtualization use case code was not written with these security requirements in mind.

Bugs affecting the non-virtualization use case are not considered security bugs at this time. Users with non-virtualization use cases must not rely on QEMU to provide guest isolation or any security guarantees.

6.3 Architecture

This section describes the design principles that ensure the security requirements are met.

6.3.1 Guest Isolation

Guest isolation is the confinement of guest code to the virtual machine. When guest code gains control of execution on the host this is called escaping the virtual machine. Isolation also includes resource limits such as throttling of CPU, memory, disk, or network. Guests must be unable to exceed their resource limits.

QEMU presents an attack surface to the guest in the form of emulated devices. The guest must not be able to gain control of QEMU. Bugs in emulated devices could allow malicious guests to gain code execution in QEMU. At this point the guest has escaped the virtual machine and is able to act in the context of the QEMU process on the host.

Guests often interact with other guests and share resources with them. A malicious guest must not gain control of other guests or access their data. Disk image files and

network traffic must be protected from other guests unless explicitly shared between them by the user.

6.3.2 Principle of Least Privilege

The principle of least privilege states that each component only has access to the privileges necessary for its function. In the case of QEMU this means that each process only has access to resources belonging to the guest.

The QEMU process should not have access to any resources that are inaccessible to the guest. This way the guest does not gain anything by escaping into the QEMU process since it already has access to those same resources from within the guest.

Following the principle of least privilege immediately fulfills guest isolation requirements. For example, guest A only has access to its own disk image file `a.img` and not guest B's disk image file `b.img`.

In reality certain resources are inaccessible to the guest but must be available to QEMU to perform its function. For example, host system calls are necessary for QEMU but are not exposed to guests. A guest that escapes into the QEMU process can then begin invoking host system calls.

New features must be designed to follow the principle of least privilege. Should this not be possible for technical reasons, the security risk must be clearly documented so users are aware of the trade-off of enabling the feature.

6.3.3 Isolation mechanisms

Several isolation mechanisms are available to realize this architecture of guest isolation and the principle of least privilege. With the exception of Linux seccomp, these mechanisms are all deployed by management tools that launch QEMU, such as libvirt. They are also platform-specific so they are only described briefly for Linux here.

The fundamental isolation mechanism is that QEMU processes must run as unprivileged users. Sometimes it seems more convenient to launch QEMU as root to give it access to host devices (e.g. `/dev/net/tun`) but this poses a huge security risk. File descriptor passing can be used to give an otherwise unprivileged QEMU process access to host devices without running QEMU as root. It is also possible to launch QEMU as a non-root user and configure UNIX groups for access to `/dev/kvm`, `/dev/net/tun`, and other device nodes. Some Linux distros already ship with UNIX groups for these devices by default.

- SELinux and AppArmor make it possible to confine processes beyond the traditional UNIX process and file permissions model. They restrict the QEMU process from accessing processes and files on the host system that are not needed by QEMU.

- Resource limits and cgroup controllers provide throughput and utilization limits on key resources such as CPU time, memory, and I/O bandwidth.
- Linux namespaces can be used to make process, file system, and other system resources unavailable to QEMU. A namespaced QEMU process is restricted to only those resources that were granted to it.
- Linux seccomp is available via the QEMU `--sandbox` option. It disables system calls that are not needed by QEMU, thereby reducing the host kernel attack surface.

6.4 Sensitive configurations

There are aspects of QEMU that can have security implications which users & management applications must be aware of.

6.4.1 Monitor console (QMP and HMP)

The monitor console (whether used with QMP or HMP) provides an interface to dynamically control many aspects of QEMU's runtime operation. Many of the commands exposed will instruct QEMU to access content on the host file system and/or trigger spawning of external processes.

For example, the `migrate` command allows for the spawning of arbitrary processes for the purpose of tunnelling the migration data stream. The `blockdev-add` command instructs QEMU to open arbitrary files, exposing their content to the guest as a virtual disk.

Unless QEMU is otherwise confined using technologies such as SELinux, AppArmor, or Linux namespaces, the monitor console should be considered to have privileges equivalent to those of the user account QEMU is running under.

It is further important to consider the security of the character device backend over which the monitor console is exposed. It needs to have protection against malicious third parties which might try to make unauthorized connections, or perform man-in-the-middle attacks. Many of the character device backends do not satisfy this requirement and so must not be used for the monitor console.

The general recommendation is that the monitor console should be exposed over a UNIX domain socket backend to the local host only. Use of the TCP based character device backend is inappropriate unless configured to use both TLS encryption and authorization control policy on client connections.

In summary, the monitor console is considered a privileged control interface to QEMU and as such should only be made accessible to a trusted management application or user.

Appendix A Implementation notes

A.1 CPU emulation

A.1.1 x86 and x86-64 emulation

QEMU x86 target features:

- The virtual x86 CPU supports 16 bit and 32 bit addressing with segmentation. LDT/GDT and IDT are emulated. VM86 mode is also supported to run DOSEMU. There is some support for MMX/3DNow!, SSE, SSE2, SSE3, SSSE3, and SSE4 as well as x86-64 SVM.
- Support of host page sizes bigger than 4KB in user mode emulation.
- QEMU can emulate itself on x86.
- An extensive Linux x86 CPU test program is included `tests/test-i386`. It can be used to test other x86 virtual CPUs.

Current QEMU limitations:

- Limited x86-64 support.
 - IPC syscalls are missing.
 - The x86 segment limits and access rights are not tested at every memory access (yet). Hopefully, very few OSes seem to rely on that for normal use.
-

A.1.2 ARM emulation

- Full ARM 7 user emulation.
 - NWFPE FPU support included in user Linux emulation.
 - Can run most ARM Linux binaries.
-

A.1.3 MIPS emulation

- The system emulation allows full MIPS32/MIPS64 Release 2 emulation, including privileged instructions, FPU and MMU, in both little and big endian modes.
- The Linux userland emulation can run many 32 bit MIPS Linux binaries.

Current QEMU limitations:

- Self-modifying code is not always handled correctly.

- 64 bit userland emulation is not implemented.
 - The system emulation is not complete enough to run real firmware.
 - The watchpoint debug facility is not implemented.
-

A.1.4 PowerPC emulation

- Full PowerPC 32 bit emulation, including privileged instructions, FPU and MMU.
 - Can run most PowerPC Linux binaries.
-

A.1.5 Sparc32 and Sparc64 emulation

- Full SPARC V8 emulation, including privileged instructions, FPU and MMU. SPARC V9 emulation includes most privileged and VIS instructions, FPU and I/D MMU. Alignment is fully enforced.
- Can run most 32-bit SPARC Linux binaries, SPARC32PLUS Linux binaries and some 64-bit SPARC Linux binaries.

Current QEMU limitations:

- IPC syscalls are missing.
 - Floating point exception support is buggy.
 - Atomic instructions are not correctly implemented.
 - There are still some problems with Sparc64 emulators.
-

A.1.6 Xtensa emulation

- Core Xtensa ISA emulation, including most options: code density, loop, extended L32R, 16- and 32-bit multiplication, 32-bit division, MAC16, miscellaneous operations, boolean, FP coprocessor, coprocessor context, debug, multiprocessor synchronization, conditional store, exceptions, relocatable vectors, unaligned exception, interrupts (including high priority and timer), hardware alignment, region protection, region translation, MMU, windowed registers, thread pointer, processor ID.
 - Not implemented options: data/instruction cache (including cache prefetch and locking), XLMI, processor interface. Also options not covered by the core ISA (e.g. FLIX, wide branches) are not implemented.
 - Can run most Xtensa Linux binaries.
 - New core configuration that requires no additional instructions may be created from overlay with minimal amount of hand-written code.
-

A.2 Managed start up options

In system mode emulation, it's possible to create a VM in a paused state using the `-S` command line option. In this state the machine is completely initialized according to command line options and ready to execute VM code but VCPU threads are not executing any code. The VM state in this paused state depends on the way QEMU was started. It could be in:

initial state (after reset/power on state)

with direct kernel loading, the initial state could be amended to execute

code loaded by QEMU in the VM's RAM and with incoming migration

with incoming migration, initial state will be amended with the migrated

machine state after migration completes.

This paused state is typically used by users to query machine state and/or additionally configure the machine (by hotplugging devices) in runtime before allowing VM code to run.

However, at the `-S` pause point, it's impossible to configure options that affect initial VM creation (like: `-smp/-m/-numa ...`) or cold plug devices. The experimental `--preconfig` command line option allows pausing QEMU before the initial VM creation, in a "preconfig" state, where additional queries and configuration can be performed via QMP before moving on to the resulting configuration startup. In the preconfig state, QEMU only allows a limited set of commands over the QMP monitor, where the commands do not depend on an initialized machine, including but not limited to:

qmp_capabilities
query-qmp-schema
query-commands
query-status
x-exit-preconfig

Appendix B Deprecated features

In general features are intended to be supported indefinitely once introduced into QEMU. In the event that a feature needs to be removed, it will be listed in this appendix. The feature will remain functional for 2 releases prior to actual removal. Deprecated features may also generate warnings on the console when QEMU starts up, or if activated via a monitor command, however, this is not a mandatory requirement.

Prior to the 2.10.0 release there was no official policy on how long features would be deprecated prior to their removal, nor any documented list of which features were

deprecated. Thus any features deprecated prior to 2.10.0 will be treated as if they were first deprecated in the 2.10.0 release.

What follows is a list of all features currently marked as deprecated.

B.1 System emulator command line arguments

B.1.1 -machine enforce-config-section=on|off (since 3.1)

The `enforce-config-section` parameter is replaced by the `-global migration.send-configuration=on|off` option.

B.1.2 -no-kvm (since 1.3.0)

The “-no-kvm” argument is now a synonym for setting “-accel tcg”.

B.1.3 -usbdevice (since 2.10.0)

The “-usbdevice DEV” argument is now a synonym for setting the “-device usb-DEV” argument instead. The deprecated syntax would automatically enable USB support on the machine type. If using the new syntax, USB support must be explicitly enabled via the “-machine usb=on” argument.

B.1.4 -drive file=json:{...{'driver':'file'}} (since 3.0)

The 'file' driver for drives is no longer appropriate for character or host devices and will only accept regular files (S_IFREG). The correct driver for these file types is 'host_cdrom' or 'host_device' as appropriate.

B.1.5 -net ...,name=*name* (since 3.1)

The `name` parameter of the `-net` option is a synonym for the `id` parameter, which should now be used instead.

B.1.6 -smp (invalid topologies) (since 3.1)

CPU topology properties should describe whole machine topology including possible CPUs.

However, historically it was possible to start QEMU with an incorrect topology where $n \leq sockets * cores * threads < maxcpus$, which could lead to an incorrect topology enumeration by the guest. Support for invalid topologies will be removed, the user must ensure topologies described with `-smp` include all possible cpus, i.e. $sockets * cores * threads = maxcpus$.

B.1.7 -vnc acl (since 4.0.0)

The `acl` option to the `-vnc` argument has been replaced by the `tls-authz` and `sasl-authz` options.

B.1.8 QEMU_AUDIO_ environment variables and -audio-help (since 4.0)

The “-audiodev” argument is now the preferred way to specify audio backend settings instead of environment variables. To ease migration to the new format, the “-audiodev-help” option can be used to convert the current values of the environment variables to “-audiodev” options.

B.1.9 Creating sound card devices and vnc without audiodev= property (since 4.2)

When not using the deprecated legacy audio config, each sound card should specify an `audiodev=` property. Additionally, when using `vnc`, you should specify an `audiodev=` property if you plan to transmit audio through the VNC protocol.

B.1.10 -mon ...,control=readline,pretty=on|off (since 4.1)

The `pretty=on|off` switch has no effect for HMP monitors, but is silently ignored. Using the switch with HMP monitors will become an error in the future.

B.1.11 -realtime (since 4.1)

The `-realtime mlock=on|off` argument has been replaced by the `-overcommit memlock=on|off` argument.

B.1.12 -numa node,mem=*size* (since 4.1)

The parameter `mem` of `-numa node` is used to assign a part of guest RAM to a NUMA node. But when using it, it's impossible to manage specified RAM chunk on the host side (like bind it to a host node, setting bind policy, ...), so guest ends up with the fake NUMA configuration with suboptimal performance. However since 2014 there is an alternative way to assign RAM to a NUMA node using parameter `memdev`, which does the same as `mem` and adds means to actually manage node RAM on the host side. Use parameter `memdev` with *memory-backend-ram* backend as a replacement for parameter `mem` to achieve the same fake NUMA effect or a properly configured *memory-backend-file* backend to actually benefit from NUMA configuration. In future new machine versions will not accept the option but it will still work with old machine types. User can check QAPI schema to see if the legacy option is supported by looking at `MachineInfo::numa-mem-supported` property.

B.1.13 -numa node (without memory specified) (since 4.1)

Splitting RAM by default between NUMA nodes has the same issues as `mem` parameter described above with the difference that the role of the user plays

QEMU using implicit generic or board specific splitting rule.

Use `memdev` with *memory-backend-ram* backend or `mem` (if it's supported by used machine type) to define mapping explicitly instead.

B.1.14 RISC-V -bios (since 4.1)

QEMU 4.1 introduced support for the `-bios` option in QEMU for RISC-V for the RISC-V virt machine and sifive_u machine.

QEMU 4.1 has no changes to the default behaviour to avoid breakages. This default will change in a future QEMU release, so please prepare now. All users of the virt or sifive_u machine must change their command line usage.

QEMU 4.1 has three options, please migrate to one of these three: 1. “`-bios none`” - This is the current default behavior if no `-bios` option is included. QEMU will not automatically load any firmware. It is up to the user to load all the images they need. 2. “`-bios default`” - In a future QEMU release this will become the default behaviour if no `-bios` option is specified. This option will load the default OpenSBI firmware automatically. The firmware is included with the QEMU release and no user interaction is required. All a user needs to do is specify the kernel they want to boot with the `-kernel` option 3. “`-bios <file>`” - Tells QEMU to load the specified file as the firmwrae.

B.1.15 -tb-size option (since 5.0)

QEMU 5.0 introduced an alternative syntax to specify the size of the translation block cache, `-accel tcg,tb-size=`. The new syntax deprecates the previously available `-tb-size` option.

B.1.16 -show-cursor option (since 5.0)

Use `-display sdl,show-cursor=on` or `-display gtk,show-cursor=on` instead.

B.2 QEMU Machine Protocol (QMP) commands

B.2.1 change (since 2.5.0)

Use “`blockdev-change-medium`” or “`change-vnc-password`” instead.

B.2.2 migrate_set_downtime and migrate_set_speed (since 2.8.0)

Use “`migrate-set-parameters`” instead.

B.2.3 migrate-set-cache-size and query-migrate-cache-size (since 2.11.0)

Use “`migrate-set-parameters`” and “`query-migrate-parameters`” instead.

B.2.4 query-block result field dirty-bitmaps[i].status (since 4.0)

The “status” field of the “BlockDirtyInfo” structure, returned by the query-block command is deprecated. Two new boolean fields, “recording” and “busy” effectively replace it.

B.2.5 query-block result field dirty-bitmaps (Since 4.2)

The “dirty-bitmaps” field of the “BlockInfo” structure, returned by the query-block command is itself now deprecated. The “dirty-bitmaps” field of the “BlockDeviceInfo” struct should be used instead, which is the type of the “inserted” field in query-block replies, as well as the type of array items in query-named-block-nodes.

Since the “dirty-bitmaps” field is optionally present in both the old and new locations, clients must use introspection to learn where to anticipate the field if/when it does appear in command output.

B.2.6 query-cpus (since 2.12.0)

The “query-cpus” command is replaced by the “query-cpus-fast” command.

B.2.7 query-cpus-fast "arch" output member (since 3.0.0)

The “arch” output member of the “query-cpus-fast” command is replaced by the “target” output member.

B.2.8 cpu-add (since 4.0)

Use “device_add” for hotplugging vCPUs instead of “cpu-add”. See documentation of “query-hotpluggable-cpus” for additional details.

B.2.9 query-events (since 4.0)

The “query-events” command has been superseded by the more powerful and accurate “query-qmp-schema” command.

B.2.10 chardev client socket with 'wait' option (since 4.0)

Character devices creating sockets in client mode should not specify the 'wait' field, which is only applicable to sockets in server mode

B.3 Human Monitor Protocol (HMP) commands

B.3.1 The hub_id parameter of 'hostfwd_add' / 'hostfwd_remove' (since 3.1)

The [hub_id name] parameter tuple of the 'hostfwd_add' and 'hostfwd_remove' HMP commands has been replaced by netdev_id.

B.3.2 cpu-add (since 4.0)

Use “device_add” for hotplugging vCPUs instead of “cpu-add”. See documentation of “query-hotpluggable-cpus” for additional details.

B.3.3 acl_show, acl_reset, acl_policy, acl_add, acl_remove (since 4.0.0)

The “acl_show”, “acl_reset”, “acl_policy”, “acl_add”, and “acl_remove” commands are deprecated with no replacement. Authorization for VNC should be performed using the pluggable QAuthZ objects.

B.4 Guest Emulator ISAs

B.4.1 RISC-V ISA privledge specification version 1.09.1 (since 4.1)

The RISC-V ISA privledge specification version 1.09.1 has been deprecated. QEMU supports both the newer version 1.10.0 and the ratified version 1.11.0, these should be used instead of the 1.09.1 version.

B.5 System emulator CPUS

B.5.1 RISC-V ISA CPUs (since 4.1)

The RISC-V cpus with the ISA version in the CPU name have been deprecated. The four CPUs are: “rv32gcsu-v1.9.1“, “rv32gcsu-v1.10.0“, “rv64gcsu-v1.9.1“ and “rv64gcsu-v1.10.0“. Instead the version can be specified via the CPU “priv_spec“ option when using the “rv32“ or “rv64“ CPUs.

B.5.2 RISC-V ISA CPUs (since 4.1)

The RISC-V no MMU cpus have been deprecated. The two CPUs: “rv32imacu-nommu“ and “rv64imacu-nommu“ should no longer be used. Instead the MMU status can be specified via the CPU “mmu“ option when using the “rv32“ or “rv64“ CPUs.

B.6 System emulator devices

B.6.1 ide-drive (since 4.2)

The ‘ide-drive’ device is deprecated. Users should use ‘ide-hd’ or ‘ide-cd’ as appropriate to get an IDE hard disk or CD-ROM as needed.

B.6.2 scsi-disk (since 4.2)

The ‘scsi-disk’ device is deprecated. Users should use ‘scsi-hd’ or ‘scsi-cd’ as appropriate to get a SCSI hard disk or CD-ROM as needed.

B.7 System emulator machines

B.7.1 mips r4k platform (since 5.0)

This machine type is very old and unmaintained. Users should use the 'malta' machine type instead.

B.7.2 pc-1.0, pc-1.1, pc-1.2 and pc-1.3 (since 5.0)

These machine types are very old and likely can not be used for live migration from old QEMU versions anymore. A newer machine type should be used instead.

B.7.3 spike_v1.9.1 and spike_v1.10 (since 4.1)

The version specific Spike machines have been deprecated in favour of the generic "spike" machine. If you need to specify an older version of the RISC-V spec you can use the "-cpu rv64gcsu,priv_spec=v1.9.1" command line argument.

B.8 Device options

B.8.1 Emulated device options

B.8.1.1 -device virtio-blk,scsi=on|off (since 5.0.0)

The virtio-blk SCSI passthrough feature is a legacy VIRTIO feature. VIRTIO 1.0 and later do not support it because the virtio-scsi device was introduced for full SCSI support. Use virtio-scsi instead when SCSI passthrough is required.

Note this also applies to "-device virtio-blk-pci,scsi=on|off", which is an alias.

B.8.2 Block device options

B.8.2.1 "backing": "" (since 2.12.0)

In order to prevent QEMU from automatically opening an image's backing chain, use ""backing": null" instead.

B.8.2.2 rbd keyvalue pair encoded filenames: "" (since 3.1.0)

Options for "rbd" should be specified according to its runtime options, like other block drivers. Legacy parsing of keyvalue pair encoded filenames is useful to open images with the old format for backing files; These image files should be updated to use the current format.

Example of legacy encoding:

```
json:{"file.driver":"rbd", "file.filename":"rbd:rbd/name"}
```

The above, converted to the current supported format:

```
json:{"file.driver":"rbd", "file.pool":"rbd", "file.image":"name"}
```

B.9 Related binaries

B.9.1 qemu-img convert -n -o (since 4.2.0)

All options specified in `-o` are image creation options, so they have no effect when used with `-n` to skip image creation. Silently ignored options can be confusing, so this combination of options will be made an error in future versions.

B.10 Backwards compatibility

B.10.1 Runnability guarantee of CPU models (since 4.1.0)

Previous versions of QEMU never changed existing CPU models in ways that introduced additional host software or hardware requirements to the VM. This allowed management software to safely change the machine type of an existing VM without introducing new requirements ("runnability guarantee"). This prevented CPU models from being updated to include CPU vulnerability mitigations, leaving guests vulnerable in the default configuration.

The CPU model runnability guarantee won't apply anymore to existing CPU models. Management software that needs runnability guarantees must resolve the CPU model aliases using the "alias-of" field returned by the "query-cpu-definitions" QMP command.

While those guarantees are kept, the return value of "query-cpu-definitions" will have existing CPU model aliases point to a version that doesn't break runnability guarantees (specifically, version 1 of those CPU models). In future QEMU versions, aliases will point to newer CPU model versions depending on the machine type, so management software must resolve CPU model aliases before starting a virtual machine.

Appendix C Recently removed features

What follows is a record of recently removed, formerly deprecated features that serves as a record for users who have encountered trouble after a recent upgrade.

C.1 QEMU Machine Protocol (QMP) commands

C.1.1 block-dirty-bitmap-add "autoload" parameter (since 4.2.0)

The "autoload" parameter has been ignored since 2.12.0. All bitmaps are automatically loaded from qcow2 images.

C.2 Related binaries

C.2.1 qemu-nbd --partition (removed in 5.0.0)

The “`qemu-nbd -partition $digit`” code (also spelled `-P`) could only handle MBR partitions, and never correctly handled logical partitions beyond partition 5. Exporting a partition can still be done by utilizing the `--image-opts` option with a raw blockdev using the `offset` and `size` parameters layered on top of any other existing blockdev. For example, if partition 1 is 100MiB long starting at 1MiB, the old command:

```
qemu-nbd -t -P 1 -f qcow2 file.qcow2
```

can be rewritten as:

```
qemu-nbd -t --image-opts  
driver=raw,offset=1M,size=100M,file.driver=qcow2,file.file.driver=file,file.f  
ile.filename=file.qcow2
```

Appendix D Supported build platforms

QEMU aims to support building and executing on multiple host OS platforms. This appendix outlines which platforms are the major build targets. These platforms are used as the basis for deciding upon the minimum required versions of 3rd party software QEMU depends on. The supported platforms are the targets for automated testing performed by the project when patches are submitted for review, and tested before and after merge.

If a platform is not listed here, it does not imply that QEMU won't work. If an unlisted platform has comparable software versions to a listed platform, there is every expectation that it will work. Bug reports are welcome for problems encountered on unlisted platforms unless they are clearly older vintage than what is described here.

Note that when considering software versions shipped in distros as support targets, QEMU considers only the version number, and assumes the features in that distro match the upstream release with the same version. In other words, if a distro backports extra features to the software in their distro, QEMU upstream code will not add explicit support for those backports, unless the feature is auto-detectable in a manner that works for the upstream releases too.

The Repology site <https://repology.org> is a useful resource to identify currently shipped versions of software in various operating systems, though it does not cover all distros listed below.

D.1 Linux OS

For distributions with frequent, short-lifetime releases, the project will aim to support all versions that are not end of life by their respective vendors. For the purposes of identifying supported software versions, the project will look at Fedora, Ubuntu, and

openSUSE distros. Other short- lifetime distros will be assumed to ship similar software versions.

For distributions with long-lifetime releases, the project will aim to support the most recent major version at all times. Support for the previous major version will be dropped 2 years after the new major version is released, or when it reaches “end of life”. For the purposes of identifying supported software versions, the project will look at RHEL, Debian, Ubuntu LTS, and SLES distros. Other long-lifetime distros will be assumed to ship similar software versions.

D.2 Windows

The project supports building with current versions of the MinGW toolchain, hosted on Linux.

D.3 macOS

The project supports building with the two most recent versions of macOS, with the current homebrew package set available.

D.4 FreeBSD

The project aims to support the all the versions which are not end of life.

D.5 NetBSD

The project aims to support the most recent major version at all times. Support for the previous major version will be dropped 2 years after the new major version is released.

D.6 OpenBSD

The project aims to support the all the versions which are not end of life.

Appendix E License

QEMU is a trademark of Fabrice Bellard.

QEMU is released under the [GNU General Public License](#), version 2. Parts of QEMU have specific licenses, see file [LICENSE](#).

Appendix F Index

F.1 Concept Index

This is the main index. Should we combine all keywords in one index? TODO

Jump to: [O](#) [Q](#) [S](#) [U](#)

Index Entry	Section
O	
operating modes:	intro_features
Q	
QEMU monitor:	pcsys_monitor
quick start:	pcsys_quickstart
S	
system emulation:	intro_features
system emulation (ARM):	ARM System emulator
system emulation (ColdFire):	ColdFire System emulator
system emulation (Cris):	Cris System emulator
system emulation (M68K):	ColdFire System emulator
system emulation (Microblaze):	Microblaze System emulator
system emulation (MIPS):	MIPS System emulator
system emulation (nanoMIPS):	nanoMIPS System emulator
system emulation (PC):	QEMU PC System emulator
system emulation (PowerPC):	PowerPC System emulator
system emulation (SH4):	SH4 System emulator
system emulation (Sparc32):	Sparc32 System emulator
system emulation (Sparc64):	Sparc64 System emulator
system emulation (Xtensa):	Xtensa System emulator
U	
user mode (Alpha):	Other binaries
user mode (ARM):	Other binaries
user mode (ARM):	Other binaries
user mode (ColdFire):	Other binaries
user mode (Cris):	Other binaries
user mode (i386):	Other binaries
user mode (M68K):	Other binaries
user mode (Microblaze):	Other binaries
user mode (MIPS):	Other binaries
user mode (NiosII):	Other binaries

user mode (PowerPC):	Other binaries
user mode (SH4):	Other binaries
user mode (SPARC):	Other binaries
user mode emulation:	intro_features

Jump to: [O](#) [Q](#) [S](#) [U](#)

F.2 Function Index

This index could be used for command line options and monitor functions.

Jump to: [-](#)
[A](#) [B](#) [C](#) [D](#) [E](#) [G](#) [H](#) [I](#) [L](#) [M](#) [N](#) [O](#) [P](#) [Q](#) [R](#) [S](#) [T](#) [W](#) [X](#)

Index Entry

Section

-

--preconfig:	sec_invocation
-accel:	sec_invocation
-acpitable:	sec_invocation
-add-fd:	sec_invocation
-alt-grab:	sec_invocation
-append:	sec_invocation
-audio-help:	sec_invocation
-audiodev:	sec_invocation
-bios:	sec_invocation
-blockdev:	sec_invocation
-boot:	sec_invocation
-cdrom:	sec_invocation
-chardev:	sec_invocation
-chroot:	sec_invocation
-cpu:	sec_invocation
-ctrl-grab:	sec_invocation
-curses:	sec_invocation
-d:	sec_invocation
-D:	sec_invocation
-daemonize:	sec_invocation
-debugcon:	sec_invocation
-device:	sec_invocation
-dfilter:	sec_invocation
-display:	sec_invocation

<u>-drive:</u>	<u>sec_invocation</u>
<u>-dtb:</u>	<u>sec_invocation</u>
<u>-dump-vmstate:</u>	<u>sec_invocation</u>
<u>-echr:</u>	<u>sec_invocation</u>
<u>-enable-fips:</u>	<u>sec_invocation</u>
<u>-enable-kvm:</u>	<u>sec_invocation</u>
<u>-enable-sync-profile:</u>	<u>sec_invocation</u>
<u>-fda:</u>	<u>sec_invocation</u>
<u>-fdb:</u>	<u>sec_invocation</u>
<u>-fsdev:</u>	<u>sec_invocation</u>
<u>-full-screen:</u>	<u>sec_invocation</u>
<u>-fw cfg:</u>	<u>sec_invocation</u>
<u>-g:</u>	<u>sec_invocation</u>
<u>-gdb:</u>	<u>sec_invocation</u>
<u>-global:</u>	<u>sec_invocation</u>
<u>-h:</u>	<u>sec_invocation</u>
<u>-hda:</u>	<u>sec_invocation</u>
<u>-hdb:</u>	<u>sec_invocation</u>
<u>-hdc:</u>	<u>sec_invocation</u>
<u>-hdd:</u>	<u>sec_invocation</u>
<u>-icount:</u>	<u>sec_invocation</u>
<u>-incoming:</u>	<u>sec_invocation</u>
<u>-initrd:</u>	<u>sec_invocation</u>
<u>-iscsi:</u>	<u>sec_invocation</u>
<u>-k:</u>	<u>sec_invocation</u>
<u>-kernel:</u>	<u>sec_invocation</u>
<u>-L:</u>	<u>sec_invocation</u>
<u>-loadvm:</u>	<u>sec_invocation</u>
<u>-m:</u>	<u>sec_invocation</u>
<u>-machine:</u>	<u>sec_invocation</u>
<u>-mem-path:</u>	<u>sec_invocation</u>
<u>-mem-prealloc:</u>	<u>sec_invocation</u>
<u>-mon:</u>	<u>sec_invocation</u>
<u>-monitor:</u>	<u>sec_invocation</u>
<u>-msg:</u>	<u>sec_invocation</u>
<u>-mtdblock:</u>	<u>sec_invocation</u>
<u>-name:</u>	<u>sec_invocation</u>
<u>-net:</u>	<u>sec_invocation</u>
<u>-netdev:</u>	<u>sec_invocation</u>

<u>-nic:</u>	<u>sec_invocation</u>
<u>-no-acpi:</u>	<u>sec_invocation</u>
<u>-no-fd-bootchk:</u>	<u>sec_invocation</u>
<u>-no-hpet:</u>	<u>sec_invocation</u>
<u>-no-quit:</u>	<u>sec_invocation</u>
<u>-no-reboot:</u>	<u>sec_invocation</u>
<u>-no-shutdown:</u>	<u>sec_invocation</u>
<u>-no-user-config:</u>	<u>sec_invocation</u>
<u>-nodefaults:</u>	<u>sec_invocation</u>
<u>-nographic:</u>	<u>sec_invocation</u>
<u>-numa:</u>	<u>sec_invocation</u>
<u>-object:</u>	<u>sec_invocation</u>
<u>-old-param (ARM):</u>	<u>sec_invocation</u>
<u>-only-migratable:</u>	<u>sec_invocation</u>
<u>-option-rom:</u>	<u>sec_invocation</u>
<u>-overcommit:</u>	<u>sec_invocation</u>
<u>-parallel:</u>	<u>sec_invocation</u>
<u>-pflash:</u>	<u>sec_invocation</u>
<u>-pidfile:</u>	<u>sec_invocation</u>
<u>-plugin:</u>	<u>sec_invocation</u>
<u>-portrait:</u>	<u>sec_invocation</u>
<u>-prom-env:</u>	<u>sec_invocation</u>
<u>-qmp:</u>	<u>sec_invocation</u>
<u>-qmp-pretty:</u>	<u>sec_invocation</u>
<u>-readconfig:</u>	<u>sec_invocation</u>
<u>-realtime:</u>	<u>sec_invocation</u>
<u>-rotate:</u>	<u>sec_invocation</u>
<u>-rtc:</u>	<u>sec_invocation</u>
<u>-runas:</u>	<u>sec_invocation</u>
<u>-S:</u>	<u>sec_invocation</u>
<u>-s:</u>	<u>sec_invocation</u>
<u>-sandbox:</u>	<u>sec_invocation</u>
<u>-sd:</u>	<u>sec_invocation</u>
<u>-sdl:</u>	<u>sec_invocation</u>
<u>-seed:</u>	<u>sec_invocation</u>
<u>-semihosting:</u>	<u>sec_invocation</u>
<u>-semihosting-config:</u>	<u>sec_invocation</u>
<u>-serial:</u>	<u>sec_invocation</u>
<u>-set:</u>	<u>sec_invocation</u>

<u>-show-cursor:</u>	<u>sec_invocation</u>
<u>-singlestep:</u>	<u>sec_invocation</u>
<u>-smbios:</u>	<u>sec_invocation</u>
<u>-smp:</u>	<u>sec_invocation</u>
<u>-snapshot:</u>	<u>sec_invocation</u>
<u>-soundhw:</u>	<u>sec_invocation</u>
<u>-spice:</u>	<u>sec_invocation</u>
<u>-tb-size:</u>	<u>sec_invocation</u>
<u>-tpmdev:</u>	<u>sec_invocation</u>
<u>-trace:</u>	<u>sec_invocation</u>
<u>-usb:</u>	<u>sec_invocation</u>
<u>-usbdevice:</u>	<u>sec_invocation</u>
<u>-uuid:</u>	<u>sec_invocation</u>
<u>-version:</u>	<u>sec_invocation</u>
<u>-vga:</u>	<u>sec_invocation</u>
<u>-virtfs:</u>	<u>sec_invocation</u>
<u>-vnc:</u>	<u>sec_invocation</u>
<u>-watchdog:</u>	<u>sec_invocation</u>
<u>-watchdog-action:</u>	<u>sec_invocation</u>
<u>-win2k-hack:</u>	<u>sec_invocation</u>
<u>-writeconfig:</u>	<u>sec_invocation</u>
<u>-xen-attach:</u>	<u>sec_invocation</u>
<u>-xen-domid:</u>	<u>sec_invocation</u>
<u>-xen-domid-restrict:</u>	<u>sec_invocation</u>

A

<u>acl add:</u>	<u>pcsys_monitor</u>
<u>acl policy:</u>	<u>pcsys_monitor</u>
<u>acl remove:</u>	<u>pcsys_monitor</u>
<u>acl reset:</u>	<u>pcsys_monitor</u>
<u>acl show:</u>	<u>pcsys_monitor</u>
<u>announce self:</u>	<u>pcsys_monitor</u>

B

<u>balloon:</u>	<u>pcsys_monitor</u>
<u>block job cancel:</u>	<u>pcsys_monitor</u>
<u>block job complete:</u>	<u>pcsys_monitor</u>
<u>block job pause:</u>	<u>pcsys_monitor</u>
<u>block job resume:</u>	<u>pcsys_monitor</u>
<u>block job set speed:</u>	<u>pcsys_monitor</u>

<u>block passwd:</u>	<u>pcsys_monitor</u>
<u>block resize:</u>	<u>pcsys_monitor</u>
<u>block set io throttle:</u>	<u>pcsys_monitor</u>
<u>block stream:</u>	<u>pcsys_monitor</u>
<u>boot set:</u>	<u>pcsys_monitor</u>

C

<u>change:</u>	<u>pcsys_monitor</u>
<u>chardev-add:</u>	<u>pcsys_monitor</u>
<u>chardev-change:</u>	<u>pcsys_monitor</u>
<u>chardev-remove:</u>	<u>pcsys_monitor</u>
<u>chardev-send-break:</u>	<u>pcsys_monitor</u>
<u>client migrate info:</u>	<u>pcsys_monitor</u>
<u>closefd:</u>	<u>pcsys_monitor</u>
<u>commit:</u>	<u>pcsys_monitor</u>
<u>cont:</u>	<u>pcsys_monitor</u>
<u>cpu:</u>	<u>pcsys_monitor</u>
<u>cpu-add:</u>	<u>pcsys_monitor</u>

D

<u>delvm:</u>	<u>pcsys_monitor</u>
<u>device add:</u>	<u>pcsys_monitor</u>
<u>device del:</u>	<u>pcsys_monitor</u>
<u>drive add:</u>	<u>pcsys_monitor</u>
<u>drive backup:</u>	<u>pcsys_monitor</u>
<u>drive del:</u>	<u>pcsys_monitor</u>
<u>drive mirror:</u>	<u>pcsys_monitor</u>
<u>dump-guest-memory:</u>	<u>pcsys_monitor</u>
<u>dump-skeys:</u>	<u>pcsys_monitor</u>

E

<u>eject:</u>	<u>pcsys_monitor</u>
<u>exit preconfig:</u>	<u>pcsys_monitor</u>
<u>expire password:</u>	<u>pcsys_monitor</u>

G

<u>gdbserver:</u>	<u>pcsys_monitor</u>
<u>getfd:</u>	<u>pcsys_monitor</u>
<u>gpa2hpa:</u>	<u>pcsys_monitor</u>
<u>gpa2hva:</u>	<u>pcsys_monitor</u>
<u>gva2gpa:</u>	<u>pcsys_monitor</u>

H

<u>help:</u>	<u>pcsys_monitor</u>
<u>hostfwd add:</u>	<u>pcsys_monitor</u>
<u>hostfwd remove:</u>	<u>pcsys_monitor</u>

I

<u>i:</u>	<u>pcsys_monitor</u>
<u>info:</u>	<u>pcsys_monitor</u>
<u>info balloon:</u>	<u>pcsys_monitor</u>
<u>info block:</u>	<u>pcsys_monitor</u>
<u>info block-jobs:</u>	<u>pcsys_monitor</u>
<u>info blockstats:</u>	<u>pcsys_monitor</u>
<u>info capture:</u>	<u>pcsys_monitor</u>
<u>info chardev:</u>	<u>pcsys_monitor</u>
<u>info cmma:</u>	<u>pcsys_monitor</u>
<u>info cpus:</u>	<u>pcsys_monitor</u>
<u>info cpustats:</u>	<u>pcsys_monitor</u>
<u>info dump:</u>	<u>pcsys_monitor</u>
<u>info history:</u>	<u>pcsys_monitor</u>
<u>info hotpluggable-cpus:</u>	<u>pcsys_monitor</u>
<u>info ioapic:</u>	<u>pcsys_monitor</u>
<u>info iothreads:</u>	<u>pcsys_monitor</u>
<u>info irq:</u>	<u>pcsys_monitor</u>
<u>info jit:</u>	<u>pcsys_monitor</u>
<u>info kvm:</u>	<u>pcsys_monitor</u>
<u>info lapic:</u>	<u>pcsys_monitor</u>
<u>info mem:</u>	<u>pcsys_monitor</u>
<u>info memdev:</u>	<u>pcsys_monitor</u>
<u>info memory-devices:</u>	<u>pcsys_monitor</u>
<u>info memory size summary:</u>	<u>pcsys_monitor</u>
<u>info mice:</u>	<u>pcsys_monitor</u>
<u>info migrate:</u>	<u>pcsys_monitor</u>
<u>info migrate cache size:</u>	<u>pcsys_monitor</u>
<u>info migrate capabilities:</u>	<u>pcsys_monitor</u>
<u>info migrate parameters:</u>	<u>pcsys_monitor</u>
<u>info mtree:</u>	<u>pcsys_monitor</u>
<u>info name:</u>	<u>pcsys_monitor</u>
<u>info network:</u>	<u>pcsys_monitor</u>
<u>info numa:</u>	<u>pcsys_monitor</u>

<u>info opcount:</u>	<u>pcsys_monitor</u>
<u>info pci:</u>	<u>pcsys_monitor</u>
<u>info pic:</u>	<u>pcsys_monitor</u>
<u>info profile:</u>	<u>pcsys_monitor</u>
<u>info qdm:</u>	<u>pcsys_monitor</u>
<u>info qom-tree:</u>	<u>pcsys_monitor</u>
<u>info qtree:</u>	<u>pcsys_monitor</u>
<u>info ramblock:</u>	<u>pcsys_monitor</u>
<u>info rdma:</u>	<u>pcsys_monitor</u>
<u>info registers:</u>	<u>pcsys_monitor</u>
<u>info rocker:</u>	<u>pcsys_monitor</u>
<u>info rocker-of-dpa-flows:</u>	<u>pcsys_monitor</u>
<u>info rocker-of-dpa-groups:</u>	<u>pcsys_monitor</u>
<u>info rocker-ports:</u>	<u>pcsys_monitor</u>
<u>info roms:</u>	<u>pcsys_monitor</u>
<u>info sev:</u>	<u>pcsys_monitor</u>
<u>info skeys:</u>	<u>pcsys_monitor</u>
<u>info snapshots:</u>	<u>pcsys_monitor</u>
<u>info spice:</u>	<u>pcsys_monitor</u>
<u>info status:</u>	<u>pcsys_monitor</u>
<u>info sync-profile:</u>	<u>pcsys_monitor</u>
<u>info tlb:</u>	<u>pcsys_monitor</u>
<u>info tpm:</u>	<u>pcsys_monitor</u>
<u>info trace-events:</u>	<u>pcsys_monitor</u>
<u>info usb:</u>	<u>pcsys_monitor</u>
<u>info usbhost:</u>	<u>pcsys_monitor</u>
<u>info usernet:</u>	<u>pcsys_monitor</u>
<u>info uuid:</u>	<u>pcsys_monitor</u>
<u>info version:</u>	<u>pcsys_monitor</u>
<u>info vm-generation-id:</u>	<u>pcsys_monitor</u>
<u>info vnc:</u>	<u>pcsys_monitor</u>

L

<u>loadvm:</u>	<u>pcsys_monitor</u>
<u>log:</u>	<u>pcsys_monitor</u>
<u>logfile:</u>	<u>pcsys_monitor</u>

M

<u>mce (x86):</u>	<u>pcsys_monitor</u>
<u>memsave:</u>	<u>pcsys_monitor</u>

<u>migrate:</u>	<u>pcsys_monitor</u>
<u>migrate cancel:</u>	<u>pcsys_monitor</u>
<u>migrate continue:</u>	<u>pcsys_monitor</u>
<u>migrate incoming:</u>	<u>pcsys_monitor</u>
<u>migrate pause:</u>	<u>pcsys_monitor</u>
<u>migrate recover:</u>	<u>pcsys_monitor</u>
<u>migrate set cache size:</u>	<u>pcsys_monitor</u>
<u>migrate set capability:</u>	<u>pcsys_monitor</u>
<u>migrate set downtime:</u>	<u>pcsys_monitor</u>
<u>migrate set parameter:</u>	<u>pcsys_monitor</u>
<u>migrate set speed:</u>	<u>pcsys_monitor</u>
<u>migrate start postcopy:</u>	<u>pcsys_monitor</u>
<u>migration mode:</u>	<u>pcsys_monitor</u>
<u>mouse button:</u>	<u>pcsys_monitor</u>
<u>mouse move:</u>	<u>pcsys_monitor</u>
<u>mouse set:</u>	<u>pcsys_monitor</u>

N

<u>nbd server add:</u>	<u>pcsys_monitor</u>
<u>nbd server remove:</u>	<u>pcsys_monitor</u>
<u>nbd server start:</u>	<u>pcsys_monitor</u>
<u>nbd server stop:</u>	<u>pcsys_monitor</u>
<u>netdev add:</u>	<u>pcsys_monitor</u>
<u>netdev del:</u>	<u>pcsys_monitor</u>
<u>nmi:</u>	<u>pcsys_monitor</u>

O

<u>o:</u>	<u>pcsys_monitor</u>
<u>object add:</u>	<u>pcsys_monitor</u>
<u>object del:</u>	<u>pcsys_monitor</u>

P

<u>pcie aer inject error:</u>	<u>pcsys_monitor</u>
<u>pmemsave:</u>	<u>pcsys_monitor</u>
<u>print:</u>	<u>pcsys_monitor</u>

Q

<u>gemu-io:</u>	<u>pcsys_monitor</u>
<u>quit:</u>	<u>pcsys_monitor</u>

R

<u>ringbuf read:</u>	<u>pcsys_monitor</u>
<u>ringbuf write:</u>	<u>pcsys_monitor</u>

S

<u>savevm:</u>	<u>pcsys_monitor</u>
<u>screendump:</u>	<u>pcsys_monitor</u>
<u>sendkey:</u>	<u>pcsys_monitor</u>
<u>set link:</u>	<u>pcsys_monitor</u>
<u>set password:</u>	<u>pcsys_monitor</u>
<u>singlestep:</u>	<u>pcsys_monitor</u>
<u>snapshot blkdev:</u>	<u>pcsys_monitor</u>
<u>snapshot blkdev internal:</u>	<u>pcsys_monitor</u>
<u>snapshot delete blkdev internal:</u>	<u>pcsys_monitor</u>
<u>stop:</u>	<u>pcsys_monitor</u>
<u>stopcapture:</u>	<u>pcsys_monitor</u>
<u>sum:</u>	<u>pcsys_monitor</u>
<u>sync-profile:</u>	<u>pcsys_monitor</u>
<u>system powerdown:</u>	<u>pcsys_monitor</u>
<u>system reset:</u>	<u>pcsys_monitor</u>
<u>system wakeup:</u>	<u>pcsys_monitor</u>

T

<u>trace-event:</u>	<u>pcsys_monitor</u>
<u>trace-file:</u>	<u>pcsys_monitor</u>

W

<u>watchdog action:</u>	<u>pcsys_monitor</u>
<u>wavcapture:</u>	<u>pcsys_monitor</u>

X

<u>x:</u>	<u>pcsys_monitor</u>
<u>xp:</u>	<u>pcsys_monitor</u>
<u>x colo lost heartbeat:</u>	<u>pcsys_monitor</u>

Jump to: [:](#) [A](#) [B](#) [C](#) [D](#) [E](#) [G](#) [H](#) [I](#) [L](#) [M](#) [N](#) [O](#) [P](#) [Q](#) [R](#) [S](#) [T](#) [W](#) [X](#)

F.3 Keystroke Index

This is a list of all keystrokes which have a special function in system emulation.

Jump to: [C](#)

Index Entry	Section
C	
Ctrl-a b:	mux_keys
Ctrl-a c:	mux_keys
Ctrl-a Ctrl-a:	mux_keys
Ctrl-a h:	mux_keys
Ctrl-a s:	mux_keys
Ctrl-a t:	mux_keys
Ctrl-a x:	mux_keys
Ctrl-Alt:	pcsys_keys
Ctrl-Alt-+:	pcsys_keys
Ctrl-Alt--:	pcsys_keys
Ctrl-Alt-f:	pcsys_keys
Ctrl-Alt-n:	pcsys_keys
Ctrl-Alt-u:	pcsys_keys
Ctrl-Down:	pcsys_keys
Ctrl-PageDown:	pcsys_keys
Ctrl-PageUp:	pcsys_keys
Ctrl-Up:	pcsys_keys

Jump to: [C](#)

F.4 Program Index

F.5 Data Type Index

This index could be used for qdev device names and options.

F.6 Variable Index
