

DISPLAY CONNECTIONS

Vdd	
GND	
scl	
sda	

PROGRAMMING CONNECTIONS

Vdd	
test	
reset	
GND	

Decrement button

Increment button