


**Operation Manual**

**Thorlabs Instrumentation**

**Optical Power and Energy Meter**

# PM100USB



**2009**

Version: 19570-D02 REV B  
Date: 27.05.2009

<b>Contents</b>	<b>page</b>
<b>1 General Information</b>	<b>4</b>
1.1 Safety	5
1.2 Ordering Codes and Accessories	7
<b>2 Getting Started</b>	<b>9</b>
<b>3 Unpacking</b>	<b>9</b>
3.1 Installation and Preparation	10
3.2 Physical Overview	13
<b>4 Operating the PM100USB</b>	<b>14</b>
4.1 Connecting a Power or Energy Sensor	14
4.2 Controlling the PM100USB	15
4.2.1 PM100 Utility Software	15
4.2.2 Description of the PM100 Utility Front Panel Elements:	16
4.2.3 Power and Energy Measurement	19
4.2.3.1 Range Control	19
4.2.3.2 Wavelength Correction	19
4.2.3.3 Readout Configuration	20
4.2.3.4 Measurement Configuration	20
4.2.3.5 Sensor Temperature Measurements	23
4.2.3.6 Frequency Measurements	23
4.2.3.7 Analyzing Functions	23
4.2.4 Sensor Dependent Functions	24
4.2.4.1 Photodiode Sensors	24
4.2.4.2 Thermal Power Sensors	25
4.2.4.3 Pyroelectric Energy Sensors	27
<b>5 Measurement Considerations</b>	<b>29</b>
5.1 Choosing the right Sensor	29
5.2 Reducing Noise for High Accuracy Measurements	29
5.3 Power Measurement of Pulsed Signals	30
5.4 Line width of Light Sources	30
5.5 Temperature Effects on Thermal Sensors	30
5.6 Ambient and Stray Light	31
5.7 Back Reflection	31
5.8 Beam Diameter vs. Active Sensor Area	31
5.9 Fiber Based Measurements	32
<b>6 Computer Interface</b>	<b>33</b>
6.1 Firmware Update	33
6.2 Using the Instrument Drivers	34

---

6.2.1	Instrument Driver Installation	34
6.2.2	Instrument Driver Example	34
<b>6.3</b>	<b>PM100USB SCPI Commands</b>	<b>35</b>
6.3.1	An Introduction to the SCPI language	35
6.3.2	IEEE488.2 Common Commands	38
6.3.2.1	Command summary	38
6.3.2.2	Command reference	39
6.3.2.3	PM100USB specific SCPI Command Reference	40
6.3.3	Simple LabVIEW Example using SCPI Commands	50
	<b>Maintenance and Repair</b>	<b>54</b>
<b>6.4</b>	<b>Maintenance</b>	<b>54</b>
<b>6.5</b>	<b>Troubleshooting</b>	<b>55</b>
<b>7</b>	<b>Appendix</b>	<b>56</b>
7.1	Warranty	56
7.2	Certifications and compliances	57
7.3	Technical data	58
7.4	Pin Assignment of the Sensor Connector	61
7.5	Thorlabs 'End of Life' policy (WEEE)	62
7.5.1	Waste treatment on your own responsibility	62
7.5.2	Ecological background	63
7.6	List of figures	64
7.7	Addresses	65

We aim to develop and produce the best solution for your application in the field of optical measurement technique. To help us to live up to your expectations and develop our products permanently we need your ideas and suggestions. Therefore, please let us know about possible criticism or ideas. We and our international partners are looking forward to hearing from you.

*Thorlabs*

This part of the instruction manual contains every specific information on the PM100USB handheld optical power and energy meter. A general description is followed by explanations of how to operate the unit manually. You will also find information about a simple remote control of the unit.

## **Attention**

**This manual contains ‘WARNINGS’ and ‘ATTENTION’ labels in this form, to indicate danger for persons or possible damage to equipment.**

**Please read these advises carefully!**

## **NOTE**

**This manual also contains ‘NOTES’ and ‘HINTS’ written in this form.**

## 1 General Information

The PM100USB Optical Power and Energy Meter is designed to measure the optical power of laser light or other monochromatic or near monochromatic light sources and the energy of pulsed light sources.

The compact USB controlled and powered design and compatibility to all Thorlabs “C-Type” Photodiode, Thermal, Pyroelectric sensors, and custom Photodiode, Thermal and Pyroelectric detectors, makes the PM100USB an ideal choice for automated setups and further opens a wide range of applications in Manufacturing, Quality Control, Quality Assurance, and R&D.

The provided software, including drivers and applications for LabVIEW and C makes it easy to integrate the instrument in test and measurement systems. All software and commands are compatible and interchangeable with the PM100D handheld power and energy meter and with the PM100A handheld optical power meter.

## 1.1 Safety

### **Attention**

All statements regarding safety of operation and technical data in this instruction manual will only apply when the unit is operated correctly.

The power meter PM100USB must not be operated in explosion endangered environments!

Sensor, photodiode and control inputs and outputs must only be connected with duly shielded connection cables.

Only with written consent from Thorlabs may changes to single components be carried out or components not supplied by Thorlabs be used.

Do not remove covers!

Refer servicing to qualified personal!

### **Attention**

Mobile telephones, cellular phones or other radio transmitters are not to be used within the range of three meters of this unit since the electromagnetic field intensity may then exceed the maximum allowed disturbance values according to IEC 61326-1.

This product has been tested and found to comply with the limits according to IEC 61326-1 for using connection cables shorter than 3 meters (9.8 feet).

## **Attention**

The following statement applies to the products covered in this manual, unless otherwise specified herein. The statement for other products will appear in the accompanying documentation.

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules and meets all requirements of the Canadian Interference-Causing Equipment Standard ICES-003 for digital apparatus. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/T.V. technician for help.

Thorlabs GmbH is not responsible for any radio television interference caused by modifications of this equipment or the substitution or attachment of connecting cables and equipment other than those specified by Thorlabs GmbH. The correction of interference caused by such unauthorized modification, substitution or attachment will be the responsibility of the user.

The use of shielded I/O cables is required when connecting this equipment to any and all optional peripheral or host devices. Failure to do so may violate FCC and ICES rules.



## 1.2 Ordering Codes and Accessories

Order Code	Description
PM100USB	USB power and energy meter interface

### Photodiode Power Sensors:

Order Code	Type	Detector	Aperture mm	Wavelength nm	Power W
S120C	Compact Sensor	Si	Ø 9.5	400 - 1100	50n - 50m
S120VC	Compact Sensor	UV-Si	Ø 9.5	200 - 1100	50n - 50m
S121C	Compact Sensor	Si	Ø 9.5	400 - 1100	500n - 500m
S122C	Compact Sensor	Ge	Ø 9.5	700 - 1800	50n - 40m
S130C	Slim Sensor Dual Range	Si	Ø 9.5	400 - 1100	5n - 5m 500n - 500m
S130VC	Slim Sensor Dual Range	UV-Si	Ø 9.5	200 - 1100	5n - 5m 50n - 50m
S132C	Slim Sensor Dual Range	Ge	Ø 9.5	700 - 1800 1200 - 1800	5n - 5m 500n - 500m
S140C	Integr. Sphere (1")	Si	Ø 5.0	350 - 1100	1µ - 500m
S144C	Integr. Sphere (1")	InGaAs	Ø 5.0	800 - 1700	1µ - 500m
S142C	Integr. Sphere (2")	Si	Ø 12	350 - 1100	10µ - 20
S145C	Integr. Sphere (2")	InGaAs	Ø 12	800 - 1700	1µ - 3
S145C	Integr. Sphere (2")	InGaAs	Ø 12	800 - 1700	10µ - 20
S150C	Fiber Head	Si	3.6 x 3.6	350 - 1100	100p - 5m
S151C	Fiber Head	Si	3.6 x 3.6	400 - 1100	1n - 20m
S154C	Fiber Head	InGaAs	Ø 2.0	700 - 1700	100p - 5m
S155C	Fiber Head	InGaAs	Ø 2.0	700 - 1700	1n - 20m

### Thermal Power Sensors:

Order Code	Type	Aperture mm	Wavelength nm	Power W
S302C	Thermally Stabilized Thermal Absorber	Ø 12	190 - 25000	100µ - 2
S310C	Thermal Surface Absorber	Ø 20	190 - 25000	10m - 10
S314C	Thermal Surface Absorber	Ø 25	190 - 10600	10m - 60
S322C	Thermal Surface Absorber	Ø 25	190 - 10600	100m - 250
S350C	Thermal Surface Absorber Excimer Coating	Ø 40	190 - 1100 and 10600	10m - 60
S370C	Thermal Volume Absorber for high peak power lasers	Ø 25	400 - 5200	10m - 15

**Pyroelectric Energy Sensors:**

Order Code	Type	Aperture mm	Wavelength nm	Energy J
ES111C	Pyroelectric Sensor with broadband coating	Ø 11	185 - 25000	3μ - 150m
ES120C	Pyroelectric Sensor with broadband coating	Ø 20	185 - 25000	5μ - 500m
ES145C	Pyroelectric Sensor with broadband coating	Ø 45	185 - 25000	30μ - 2
ES220C	Pyroelectric Sensor with ceramic coating	Ø 20	185 - 25000	500μ - 3
ES245C	Pyroelectric Sensor with ceramic coating	Ø 45	185 - 25000	1m - 15

Please visit our homepage <http://www.thorlabs.com> for various accessories like fiber adapters, posts and post-holders, data sheets and further information.

## 2 Getting Started

### 3 Unpacking

Inspect the shipping container for damage.


If the shipping container seems to be damaged, keep it until you have inspected the contents and you have inspected the PM100USB mechanically and electrically.

Verify that you have received the following items.


1. PM100USB power/energy meter
2. USB cable, type 'A' to 'mini-B'
3. Quick-start guide
4. USB memory stick with instrument drivers, user application and operation manual
5. Certificate of Calibration

### 3.1 Installation and Preparation

1. For proper installing the PM100USB it requires a NI-VISA runtime version on the PC (available on the National Instruments website [www.ni.com](http://www.ni.com) or from the data carrier that comes with the instrument. Allow installing and follow the dialog instructions.
2. Install the PM100 Utility software from the data carrier.  
Therefore proceed the Auto-run function by browsing the folder to “Autorun” and executing “Autorun.exe”.



Install the utility software by proceeding the following steps:



3. Interlink the USB cable with its male type 'A' connector at the PC side and the 'Mini B' type connector on the instrument side. The PM100USB gets its operation power from the PC via the USB cable. When connecting the PM100USB first time to a PC, sequent a new hardware 'PM100USB test and measurement device' and a 'DFU device' will be found; please allow installing.  
Installing the 'DFU device' is important for later firmware upgrades, for upgrading the firmware see chapter 6.1. During the 'DFU device' installation a dialog screen with 3 entries for selecting a hardware type will appear, please keep the default setting of the first item (thordfu.inf)  
After successful installation the 'USB LINK' LED in the rear panel lights up and the unit is ready to operate.
4. Connect a suitable power or energy sensor. The sensors are 'hot swappable' and have a self-fixing mechanism. To plug or unplug a sensor slightly press from both sides on the pins in the connector housing. After recognizing a valid sensor and downloading its information and calibration data the 'SENSOR' LED in the rear panel lights up.
5. Run the PM100 Utility software and confirm the connected PM100USB.

3.2 Physical Overview




Figure 1 Front View




Figure 2 Rear View


## 4 Operating the PM100USB

### 4.1 Connecting a Power or Energy Sensor

The PM100USB supports all Thorlabs 'C-Series' photodiode, thermal and pyroelectric sensors. These can easily be identified against older versions of Thorlabs power or energy sensors by their red connector housing. The console will not recognize sensors from the 'A' and 'B' series. Please contact Thorlabs for upgrading of old sensors with 'C-Series' connectors.

To plug or remove a sensor slightly press the two bolts in the connector housing. Sensors can be 'hot-swapped' to the console, after recognizing a new valid sensor the type and calibration data will be downloaded to the console in less than 2 seconds and the unit is ready to operate with the new sensor.

The PM100USB also supports custom detectors, please refer to chapters 4.2.4.1.2 and 4.2.4.2.2 for the measurement settings and chapter 7.4 for the connector pin-out.



**Figure 3     Sensor Connector**



## 4.2 Controlling the PM100USB

### 4.2.1 PM100 Utility Software

The PM100USB comes with an utility software that easily enables remotely operating the PM100USB and visualizing and logging measurement data. The software is written in LabVIEW 8.5.1 and can either be installed from the data carrier as executable where LabVIEW isn't required on the PC; or can be run with LabVIEW 8.5.1 or higher.

The source code of the application is included on the data carrier and can be used to build own applications or to modify the utility program to specific requirements.

The PM100 utility software does **not** require the installation of the instrument drivers that are described under 6.2.

After launching the PM100 utility program it will automatically screen for connected PM100 series devices. Select the desired device and press o.k. In case that the connected PM100USB is not yet recognized, press Rescan to perform a new search for connected PM100 devices.



**Figure 4** Scan Device Dialog

The identification string contains the following items:

- USB Port number

- Thorlabs Vendor ID = 0x1313

- Product ID = 0x8072 = PM100USB

- Instrument serial number

- Measurement instrument device

## 4.2.2 Description of the PM100 Utility Front Panel Elements:




Figure 5 PM100 Utility Front Panel

### Header (1)

This indicator shows the device setup:

- console type (PM100USB)
- serial number of the console
- sensor type
- sensor serial number

### Main Display (2)

The display has a configurable display resolution. Independent from the measurement range the display always has the full number of the selected digits.

To achieve best AD converter resolution it is necessary to set the measurement range according to the signal to measure.

A trigger indicator shows whether the unit is sampling data 'A' indicator or a new measurement value gets displayed 'T' indicator and green light.

### **Left Sub Display (3)**

The display has the following configurable items:

- no display
  - maximum value - sampling until reset
  - ratio max/min value - sampling until reset
  - power or energy density
  - alternate unit depending on connected sensor
- the possible choices depend on the connected sensor

### **Right Sub Display (4)**

The display has the following configurable items, the possible choices depend on the connected sensor::

- no display
- minimum value - sampling until reset
- frequency or repetition rate
- temperature
- resistance of temperature sensor

### **Bargraph indicator (5)**

The bargraph indicator shows the incidence or the used measurement range.

### **Operation and Configuration Buttons (6)**

- Description see chapter 4.2.3
- **Quit button** Shortcut: [Shift + F8]
  - o stops the PM100 application
  - o to restart press the white arrow in the tool bar
- **Save / Recall button** Shortcuts: [Shift + F8] [Shift + F9]  
Saves / recalls the instrument settings like power/energy range index, wavelength, time constant, auto-ranging etc.  
It is possible to have different configuration files for different sensor setups.

### **Statistics screen (7)**

Statistical values in linear and logarithmic representation

### **Data logging screen (8)**

Shows the logging history data. These data can be edit to delete data or to add notes.

### **Histogram (9)**

Power / Energy histogram

- displays histogram data
- the band size can be adjusted between 1 and 9999.

### **Chart display (10)**

Power/Energy Chart with 10.000 point history length

### **Axis configuration for the chart display (11)**

Allows to set the Y (power / energy) axis between fixed and auto-scaling mode and linear and logarithmic representation. The X (sample) axis can be set between fixed and auto-scaling mode.

To adjust the scales it is also possible to edit the values on the axis. Further there is a control palette to zoom to a specific section in the graph or to scroll through the graph versus the X axis.

### **Export button (10)**

Exports the sampling data as shown in the logging screen (8) to a text file.

### 4.2.3 Power and Energy Measurement

#### 4.2.3.1 Range Control

The PM100USB provides six decades of power corresponding current and four decades of power corresponding voltage ranges. The ranges are displayed in the respectively applicable unit, depending on sensor and chosen unit. (Exception: When displaying the power in dBm, the ranges will still display in Watts) Combined with a 16 bit linear A/D converter and a 4 digit numeric display the meter allows very precise measurements with a dynamic range of over 100 dB with one photodiode power sensor. For laser energy measurements four decades energy corresponding voltage ranges are available.

Each current or voltage range measures precisely from -10% up to 110% of the nominal range limits. At the low end this is helpful to identify badly zeroed detectors by a negative power display; at the high end it adds more dynamic when switching to a less sensitive range.

For power measurements an auto-ranging function is available. This is very convenient for measuring an unknown steady CW power level, or when using the logarithmic representation of the power reading ('dBm' units). For tasks like laser tuning or measuring pulsed laser sources manual ranging is often the better choice.

In the energy measurement mode only manual ranging is available.

**Range button** Shortcut: [Shift + F1]

Press to open a dialog box for setting the measurement range

The indicator in the button shows the currently used measurement range in the chosen unit.

A green light indicates 'auto-ranging'

#### 4.2.3.2 Wavelength Correction

Most power and energy sensors show a dependent behaviour in their spectral response. For accurate measurements it is important to set the PM100USB to the wavelength of the light to measure.

**Wavelength / Response button** Shortcut: [Shift + F2]

Press this button to open a dialog box for setting the correction wavelength, or in adapter mode to enter the response in A/W or V/W.

The currently used parameter is indicated in the button label.

#### 4.2.3.3 Readout Configuration

The numeric display can be configured in terms of units of measure and also by selecting additional functions for the two small sub displays.

The min-max monitor and manual range setting automatically switches to the same unit that is selected for the main display; exception is the average power measurement for energy sensors, the ranges will stay in Joules.

**Units / Display button** Shortcut: [Shift + F4]

A dialog box with the following items appears:

- configure unit of measure, depending on the connected sensor in W, J, dBm, V and A
- configure the left sub display to minimum value, frequency or sensor temperature
- configure the right sub display to maximum value, ratio max/min, area calculation or displaying an alternate unit.

#### 4.2.3.4 Measurement Configuration

**Measurement configuration button** Shortcut: [Shift + F3]

Depending on the connected sensor the following parameters can be set in the dialog box:

- display resolution - set number of digits
- averaging rate, a rate of 3000 averages the incoming measurement values for approx. 1 second
- photodiode bandwidth HI and LO → see chapter 4.2.4.1.1
- acceleration circuit for thermal sensors ON/AUTO/OFF → see chapter 4.2.4.2.1
- trigger level for pyroelectric sensors → see chapter 0
- Zeroing for photodiode and thermal sensors
- Beam setup for light intensity measurements

##### 4.2.3.4.1 Averaging

An averaging rate can be set to apply a 'digital filter' on the measurement. A rate of 3000 averages the incoming measurement values for approximately 1 second.

##### 4.2.3.4.2 Zeroing

When measuring very small power levels dark current of photodiode sensors or zero voltage on thermal sensors will have an influence on the measurement result and must be compensated by the zero adjustment. An indicator that a sensor needs to be zeroed is when with covered sensor either a negative power reading or a reading much greater than zero is displayed. At negative power readings additionally a 'ZERO!' warning appears in the status display.

Do not hold a sensor in the hand, especially a thermal sensor, when performing a zero adjustment. Temperature effects will influence the quality of the zeroing result!

After performing a zero adjustment, the detected zero value will be included in all power readings in Watts or dBm. The basic units (A, V) will still measure the absolute values without zero correction. The detected zero value may influence the wavelength corrected calculated full scale power range values in the lower power ranges; there will also be a zero shift in the bar graph representation.

In logarithmic (dBm) representation the unit cannot display negative values. In this case the display will '---'.

Photodiode sensors emit small current levels, even when no photons hit the active area – the so called dark current, that is temperature dependent and in the region of some nA for silicon and InGaAs sensors and up to some  $\mu$ A for germanium sensors. Thermopile sensors need to be zeroed when thermal differences between active area (thermal disk) and the sensor heat sink appear when no light hits the active area or when the heat sink gets hot under light exposure. The zero value will be negative when the heat sink is hotter than the active area and positive, when the active area is hotter than the heat sink. When both heat sink and active area are at room temperature a zero voltage of some  $\mu$ V is normal.

#### 4.2.3.4.3 Light Intensity Measurements

To display the power or energy density or the light intensity value in  $W/cm^2$  or  $J/cm^2$  in the right sub display it is necessary to enter the diameter of the incident beam or at an overfilled sensor the diameter of the sensor aperture.

The utility software allows to configure the beam shape and automatically calculates the beam diameter value.

Round beam shapes:	$1/e^2$ beam diameter
Square beams with the edge length (a):	beam diameter value calculates to $1.128 \times a$ .

Rectangular beams with edge lengths $(a, b)$ : beam diameter calculates to $1.128 \times \sqrt{(a \times b)}$ .
---



#### 4.2.3.5 Sensor Temperature Measurements

Most Thorlabs photodiode and thermal sensors are equipped with a NTC Thermistor to control the temperature of the sensor head.

#### 4.2.3.6 Frequency Measurements

The PM100USB can measure and display frequencies of pulsed, modulated or chopped light sources up to 10kHz. The maximum measurable frequency is depending on the sensor type and instrument settings.

#### 4.2.3.7 Analyzing Functions

The utility software offers various possibilities to view, analyze or export the power and energy measurement data.

The following buttons allow to configure and control these functions.

<b>Logging configuration button</b>
Open dialog box to: <ul style="list-style-type: none"><li>- set averaging rate for logging</li><li>- set interval between samples</li><li>- set number of samples</li><li>- configure logging into data file</li></ul> Shortcut: [Shift + F5]
<b>Start/Stop log button</b> Shortcut: [Shift + F6] <ul style="list-style-type: none"><li>- start and stop data logging</li><li>- a "LED-indicator" shows when logging is active</li></ul>
<b>Reset / Clear button</b> Shortcut: [Shift + F7] <ul style="list-style-type: none"><li>- reset min/max monitor</li><li>- clear power / energy graph</li><li>- clear power / energy histogram</li><li>- clear power / energy statistics</li><li>- clear log screen</li></ul>

## 4.2.4 Sensor Dependent Functions

### 4.2.4.1 Photodiode Sensors

The PM100USB works with all Thorlabs S100C series photodiode power sensors. The sensor is ready to operate few seconds after plugging to the DB9 connector.

### **Attention**

**Refer to the sensor data sheet and pay attention to the optical damage threshold!**

**Exceeding these values will permanently destroy the sensor!**

For the measurement of power levels from nano-watts up to 20 W Thorlabs offers photodiode sensors that show big advantages in sensitivity, stability and drift against thermal sensors. The sensors are built up in a combination of a photodiode and a neutral density filter or a photodiode in combination with an integrating sphere. They provide linearity over several decades and show a very good sensitivity at smallest power levels down to the pW range. Handling fairly small power levels the sensor size can be held small, further the response time of such sensors is very fast down to the sub-microsecond range.

Photodiodes, neutral density filters and also integrating sphere materials show a wavelength dependent behaviour and therefore each sensor is individually calibrated over the whole spectral working range in 5 or 10nm steps. Thereby the sensors spectral response data gets stored in a non-volatile memory inside the DB-9 sensor connector and downloaded to the PM100USB when plugged to the unit. To perform an accurate measurement it is necessary to enter the operating wavelength of the light to measure so that the PM100USB can calculate the laser power from the measured photo current and the right response value from the wavelength calibration table.

#### 4.2.4.1.1 Bandwidth Setting (Signal Filtering)

The analogue bandwidth setting influences the power reading and the analogue output. The bandwidth can be selected either to 'HI' (range dependent bandwidth up to 100kHz) or to 'LO' (15 Hz bandwidth).

For measuring CW or average power from pulsed sources the bandwidth should be set to 'LO'. When using the analogue output to control external equipment or measuring peak power levels the 'HI' setting is required so that the meter can follow the signal.

#### 4.2.4.1.2 Power Measurements with Photodiodes

Common photodiodes can be used for power measurements with the PM100USB. Therefore the PM100USB needs to be set to the 'Photodiode' custom sensor input adapter type. A photodiode and an interlock must be connected to the sensor input (see chapter 7.4 for the connector pin out); it is important to attend to the right polarity (the cathode needs to be connected to ground).

The operation is similar to photodiode power sensors with the exception that at the soft button position of the wavelength menu a response value in A/W for one wavelength can be set.

#### 4.2.4.2 Thermal Power Sensors

The PM100USB is compatible to the Thorlabs S300C series thermal power sensors. The sensor will be ready to operate few seconds after plugging to the DB9 connector.

### **Attention**

**Refer to the sensor data sheet and pay attention to the optical damage threshold!**

**Exceeding these values will permanently destroy the sensor!**

Thermal sensors absorb the incident laser power, whereby the developing heat gets turned into a small voltage caused by heat flow through thermocouple elements between absorbing area and sensor heat sink. Thorlabs offers with its S3xxC series thermal sensors that cover a wide range of applications. The sensors are available with different coatings. Black broad band coating as absorber does not need a wavelength correction because the response is nearly flat from the UV to the mid-IR. Special hard coatings can withstand high power levels and show also a good spectral flatness. Further Thorlabs offers special heads for Excimer lasers with large beam diameters and short pulse lasers with coatings for very high peak power levels.

The output voltage of a thermal sensor is linear to the incident laser power, as long the thermal system is properly zeroed. The main application area for thermal sensors is the measurement of high power levels from 100mW. Thorlabs offers also a special thermally isolated thermal head with flat response and on power levels starting in the  $\mu$ W range.

#### 4.2.4.2.1 Readout acceleration

Thermal sensors show a fairly slow response. When laser power hits the active area it takes, depending on the sensor type, from some 1 up to 20 seconds until the system has settled and the power reading shows the right value.

Through special circuitry this time can be shortened to approximately 1-3 seconds by 'predicting' the final power value. The PM100USB automatically uses the right adjustment of the electronics to the time constant of the thermal sensor. Nevertheless this circuitry has the disadvantage of inducing some noise to the measurement value. Therefore the acceleration circuit can be and disabled / enabled in the measurement configuration.

In 'AUTO' mode the accelerator will switch on when a power change larger than 5% of the measurement range is detected and switch off after 5 times of the time constant of the sensor. This feature provides a fast response and keeps the noise level to a minimum on constant power levels.

### 4.2.4.2.2 Custom Thermal Elements

Custom thermal elements can be used for power measurements with the PM100USB. Therefore the PM100USB needs to be set to the 'Thermopile' custom sensor input adapter type. A thermal element and an interlock must be connected to the sensor input (see chapter 7.4 for the connector pin out). The operation is similar to thermal power sensors with two exceptions:

- The wavelength setting is replaced by a button to enter a response value for one wavelength in V/W.
- In the measurement configuration menu a thermal time constant can be set. This time constant adjusts the acceleration circuit for the measurement prediction.

#### 4.2.4.3 Pyroelectric Energy Sensors

With pyroelectric sensors the PM100USB measures laser pulse energy of single and continuously repeating laser pulses (short pulse). Pyroelectric sensors of the Thorlabs ES100C and ES200C series can work with the PM100USB interface box. The sensor will be ready to operate few seconds after plugging.

### **Attention**

**Refer to the sensor data sheet and pay attention to the optical damage threshold!**

**Exceeding these values will permanently destroy the sensor!**

A pyroelectric sensor permits widely independent of the incident radiation wavelength, the direct transformation of a radiation energy pulse into a voltage pulse. The height of this voltage pulse that is proportional to the laser pulse energy is measured by a peak detector circuit.

When a pyroelectric sensor is connected the PM100USB cannot be switched in auto-range mode. The measurement value will be updated with each incoming pulse. When no pulses appear the measurement display will be held on the last measured value.

##### 4.2.4.3.1 Trigger Level

The trigger level in % can be set in the measurement configuration.

When an incoming pulse exceeds the set trigger level, the peak detector circuit gets armed and is waiting until the pulse peak is reached. After finding the maximum voltage the level is kept and the microprocessor reads the AD converted voltage for displaying the pulse energy. Finally the peak detector circuit gets a reset and is ready for the next pulse.

The trigger level can be adjusted between 1% and 100% of each selected energy range. Only pulses that are higher than the adjusted trigger level are recognized by the PM100USB. The trigger level should be set between the noise level and the expected pulse height.

#### **4.2.4.3.2 Average Power Measurement**

With continuously repeating pulses the PM100USB calculates the average power from the pulse energy and the repetition rate.

#### **4.2.4.3.3 Repetition Rate**

The pulse repetition rate in Hz can be displayed in the left sub display.

#### **4.2.4.3.4 Area Calculation**

When the right beam diameter of the incident beam is entered, this function returns either the average power density in  $\text{W}/\text{cm}^2$  or the energy density in  $\text{J}/\text{cm}^2$ .

#### **4.2.4.3.5 Custom Pyroelectric Sensors**

Custom pyro detectors can be used for energy measurements with the PM100USB. Therefore the PM100USB needs to be set to the 'Pyro Electric' custom sensor input adapter type. A pyro detector and an interlock must be connected to the sensor input (see chapter 7.4 for the connector pin out). The pyro detector must provide a positive signal. The operation is similar to pyro-electric energy sensors with exception that at the soft button position of the wavelength menu a response value in  $\text{V}/\text{J}$  for one wavelength can be set.

## 5 Measurement Considerations

### 5.1 Choosing the right Sensor

The question of the right sensor depends on many factors starting with the light source to measure and the application. No sensor can cover all applications; the following table shows the main pros and contras of the different power sensor types. Of course this can only be a rough guide because within each sensor group there are special models best suitable for specific applications.

#### Power Sensors:

	Photodiode			Thermal		
Light Source	Si	Ge	InGaAs	BB	HTC	Volume
Diode UV - NIR	+++	+	-	++	-	-
Diode NIR	-	+	+++	++	-	-
High Power Fiber Lasers	-	-	++	++	++	-
ASE sources	-	-	++	++	-	-
fs Laser	-	+	++	++	+	-
Gas Laser	++	-	-	++	+	-
Excimer	-	-	-	-	+++	+
YAG	-	-	-	-	+	+++
LED	+	-	-	+++	+	-

### 5.2 Reducing Noise for High Accuracy Measurements

Main disturbing influence on each measurement is noise from grounding, the cable capacitance, temperature effects, stray and ambient light and detector noise.

- The housing of power sensors are connected to the digital ground of the meter and should be linked to earth ground (e.g. via a post); energy sensors should be mounted isolated, because the housing is connected to the meter analog ground.
- The sensor cable must handle very small current or voltage signals. Moving the cable will induce disturbances given through the cable capacitance. For measuring small power or energy levels the cable should be fixed in position.
- With photodiode sensors the bandwidth should be set to 'LOW' setting; with thermal sensors the acceleration circuit should be shut off or set to 'AUTO'.

- The detector noise is lowest with silicon or InGaAs sensors.
- For long term measurements in free space applications it is necessary to provide constant ambient light conditions, or shielding the beam.
- The temperature should be stable over the time of the measurement.

## 5.3 Power Measurement of Pulsed Signals

The PM100USB will read the average value of a pulsed signal when the following conditions apply: For a thermal sensor pulse length, repetition rate and peak power is uncritical as long as the peak power is lower than the damage threshold of the sensor. A thermal sensor reacts very slow and will integrate the power incident on the active area of the sensor.

With a photodiode sensor that can follow short pulses in the ns range it is important that the pulse peak power is within the maximum power range of the sensor. It is also important that the power range is set that accordingly the peak power is within this range, otherwise the reading will clip at the range end and lead to a wrong average value. Further it is important to use a power range in manual mode that can measure the peak value, therefore the Min-Max function is very helpful. Depending on the pulse length and repetition rate the bandwidth setting will influence the power reading. It is recommended to use the low bandwidth setting for a stable display; when the pulse should be monitored via the analog output, the bandwidth should be set to 'HI'.

## 5.4 Line width of Light Sources

The line width of light sources can be neglected only when using a broadband thermal or pyro-electric sensor. Photodiode sensors show a strong dependency of the operating wavelength so if the line width of light sources is greater than 10nm (e.g. LED) there may be an influence on the displayed power. To achieve the best result for broadband light sources with a photodiode sensor it is necessary that the response curve is nearly linear over the line width. When entering the center wavelength of the light source as operation wavelength the PM100USB will nearly show the right optical power for a symmetrical spectral response shape.

## 5.5 Temperature Effects on Thermal Sensors

Thermal sensors react on any temperature differences that occur between thermal disc and heat sink. Influence to the measurement result can be caused by airflow



disturbances or by heating up the heat sink through long enough exposure of the laser beam to the thermal disc.

To avoid disturbances it is recommended to shield the sensor as good as possible from airflow and to zero it properly in the operating condition. That means for short term measurements zero the cold sensor, for long term measurements zero the sensor when it is in a state of thermal stability (e.g. after 10 minutes light exposure).

## **5.6 Ambient and Stray Light**

Ambient or stray light can strongly affect the measurement accuracy in free-space applications. A permanent background light level can be subtracted by conducting a zero adjustment. More complicated is varying ambient light like daylight or turning on/off room light. In such cases the only solution is a proper light shielding of the sensor.

## **5.7 Back Reflection**

Photodiodes, ND filters and even black coatings of thermal sensors show a certain kind of back reflection of the incoming light. Back reflection for example to a diode or HeNe laser can distort the power stability of the laser, therefore it is recommended to slightly tilt the power meter sensor in the laser beam.

When back reflection must be avoided it is advised to use an integrating sphere based S14xC series sensor where the incoming light gets nearly completely absorbed in the sensor.

## **5.8 Beam Diameter vs. Active Sensor Area**

Most sensors are not completely uniform in their response over the active area; except are sensors that are using an integrating sphere as filter and diffuser.

To overcome uniformity issues the incident beam should have a diameter larger than 10% sensor area.

A second topic to follow are the maximum allowed power and energy densities of the sensor. The maximum ratings are given in the sensor spec-sheet. The PM100USB can display the actual power or energy density for a known beam diameter. For high power or high energy beams a good efficiency can be reached to chose a detector that is about 20% - 30% larger than the beam diameter.

## 5.9 Fiber Based Measurements

Laser light emits from an optical fiber in a conical shape, with an angle twice the acceptance angle of the fiber. The acceptance angle is calculated by the numerical aperture of the fiber and is defined as the inverse sine of the numerical aperture.

For typical single mode fibers the total angle of the emitted light is between 15° and 25°, for an angled connector (APC) the cone shifts by approximately 4° from the fiber axis.

This expansion of the beam has to be considered to avoid overfilling the detector and getting wrong results. On the other hand for measurements with high power fiber lasers a certain gap between fiber tip and detector surface has to be kept to decrease the power density.

Thorlabs offers fiber adapters with the most common connectors that are verified with the S12xC series optical sensors and with most thermal sensors.

For large divergence angles or fiber measurements that are critical to back-reflections it is recommended to use an integrating sphere based sensor from the S14xC series.

Another good choice for fiber based measurements are the new 'Fiber-Heads' of the S15xC series. They plug directly to the meter and go without a disturbing cable between sensor and console.

## 6 Computer Interface


### 6.1 Firmware Update

Firmware upgrades can be done by the user via the USB interface. Therefore install the DFU (device firmware upgrade) wizard from the distribution data carrier.

(This setting will be reset to 'Disabled' when the unit was shut off.)

Connect the PM100USB to an USB port of your PC, the PC will find a DFU device; when proceeding the DFU wizard the first time a new DFU device will be recognized, please allow installing.

After then launch the DFU wizard from the start bar. Follow the wizard instructions.



**Figure 6      Firmware Update – DFU Wizard**

Please refer to [www.thorlabs.com](http://www.thorlabs.com) for the latest PM100USB firmware version that can be downloaded as a \*.dfu file.

**Do not disconnect the USB cable while the firmware is downloading!**

## 6.2 Using the Instrument Drivers

### 6.2.1 Instrument Driver Installation

The PM100USB software package contains a set of instrument drivers that allow conveniently remote controlling the instrument in most common programming languages. The instrument drivers must be installed, please follow the setup dialog instructions.


**To successfully complete the install of the PM100USB driver you must have Administrator privileges on the PC which you are performing the install.**

Prior to connecting the PM100USB with a PC, please check if NI-VISA is installed on the PC, otherwise install NI-VISA that is available for free from the National Instruments website [www.ni.com](http://www.ni.com) or from the data carrier that came with the instrument.

After successfully installing the drivers connect the PM100USB to a USB port of your PC. The PC will find a PM100USB test and measurement device. Please follow the instructions of the dialog screens and allow the installing.

### 6.2.2 Instrument Driver Example

The following LabVIEW example demonstrates how to use the instrument drivers for measurement tasks. The example is included on the data carrier that came with the instrument.



**Figure 7 Instrument Driver Example**

## 6.3 PM100USB SCPI Commands

### 6.3.1 An Introduction to the SCPI language

The PM100USB interface commands use the SCPI (*Standard Commands for Programmable Instruments*), ASCII-based command language that was designed for test and measurement instruments.

SCPI commands are based on a hierarchical structure, also known as a *tree system*. In this system, associated commands are grouped together under a common node or root, thus forming *subsystems*. A portion of the `SENSE` subsystem is shown below to illustrate the tree system.

```
[SENSe:]
CORRection
  :COLLect
    :ZERO
      [:INITiate]
      :ABORT
      :STATe?
      :MAGNitude?
    :BEAMdiameter {MINimum|MAXimum|DEFault|<numeric_value>[mm]}
    :BEAMdiameter? [{MINimum|MAXimum|DEFault}]
    :WAVelength {MINimum|MAXimum|<numeric_value>[nm]}
    :WAVelength? [{MINimum|MAXimum}]
    :POWer
      [:PDIode]
        [:RESPonse] MINimum|MAXimum|DEFault|<numeric_value>[A]}
        [:RESPonse]? [{MINimum|MAXimum|DEFault}]
      :THERmopile
        [:RESPonse] {MINimum|MAXimum|DEFault|<numeric_value>[V]}
        [:RESPonse]? [{MINimum|MAXimum|DEFault}]
```

`SENSe` is the root keyword of the command, `CORRection` is the second-level keyword, and `COLLect` and `BEAMdiameter` are third-level keywords, and so on. A *colon* ( : ) separates a command keyword from a lower-level keyword.

#### Command Format

The format used to show commands in this manual is shown below:

```
CURRent[:DC]:RANGe {MINimum|MAXimum|<numeric_value>[A]}
CORRection:BEAMdiameter {MINi-
mum|MAXimum|DEFault|<numeric_value>[mm]}
```

The command syntax shows most commands (and some parameters) as a mixture of upper- and lower-case letters. The upper-case letters indicate the abbreviated spelling for the command. For shorter program lines, send the abbreviated form. For better program readability, send the long form.

For example, in the above syntax statement, `CURR` and `CURRENT` are both acceptable forms. You can use upper- or lower-case letters. Therefore, `CURRENT`, `current`, and `Current` are all acceptable. Other forms, such as `CUR` and `CURREN`, will generate an error.

*Braces* ( { } ) enclose the parameter choices for a given command string. The braces are not sent with the command string. A *vertical bar* ( | ) separates multiple parameter choices for a given command string.

*Triangle brackets* ( < > ) indicate that you must specify a value for the enclosed parameter. For example, the above syntax statement shows the *range* parameter enclosed in triangle brackets. The brackets are not sent with the command string. You must specify a value for the parameter (such as "CURR:DC:RANG 50E-6").

Some parameters are enclosed in *square brackets* ( [ ] ). The brackets indicate that the parameter is optional and can be omitted. The brackets are not sent with the command string. In this example [:DC] can be omitted, so the command string can be shortened to "CURR:RANG 50E-6". If you do not specify a value for an optional parameter, the power/energy meter chooses a default value.

### Command Separators

A *colon* ( : ) is used to separate a command keyword from a lower-level keyword. You must insert a *blank space* to separate a parameter from a command keyword. If a command requires more than one parameter, you must separate adjacent parameters using a *comma* as shown below:

```
"SYST:TIME 10, 34, 48"
```

A *semicolon* ( ; ) is used to separate commands within the *same* subsystem, and can also minimize typing. For example, sending the following command string:

```
"CORR:BEAM 1; WAVE 1310"
```

... is the same as sending the following two commands:

```
"CORR:BEAM 1"
```

```
"CORR:WAVE 10"
```

Use a colon *and* a semicolon to link commands from *different* subsystems. For example, in the following command string, an error is generated if you do not use both the colon *and* semicolon:

```
"CORR:BEAM 1; :AVER 300"
```

### Using the MIN and MAX Parameters

You can substitute MINimum or MAXimum in place of a parameter for many commands. For example, consider the following command:

```
CURRent[:DC]:RANGe {MINimum|MAXimum|<numeric_value>[A]}
```

Instead of selecting a specific current range, you can substitute MIN to set the range to its minimum value or MAX to set the range to its maximum value.

### Querying Parameter Settings

You can query the current value of most parameters by adding a *question mark* ( ? ) to the command. For example, the following command sets the operating wavelength to 1550 nm: "CORR:WAVE 1550"

You can query the operating wavelength by executing: "CORR:WAVE?"

You can also query the minimum or maximum operating wavelength allowed as follows:

```
"CORR:WAVE? MIN"
```

```
"CORR:WAVE? MAX"
```

**Caution** If you send two query commands without reading the response from the first, and then attempt to read the second response, you may receive some data from

the first response followed by the complete second response. To avoid this, do not send a query command without reading the response. When you cannot avoid this situation, send a device clear before sending the second query command.

### SCPI Command Terminators

A command string sent to the power/energy meter *must* terminate with a <new line> character. The IEEE-488 EOI (end-or-identify) message is interpreted as a <new line> character and can be used to terminate a command string in place of a <new line> character. A <carriage return>

followed by a <new line> is also accepted. Command string termination will *always* reset the current SCPI command path to the root level.

### IEEE-488.2 Common Commands

The IEEE-488.2 standard defines a set of *common commands* that perform functions like reset, self-test, and status operations. Common commands always begin with an asterisk ( \* ), are four to five characters in length, and may include one or more parameters. The command keyword is separated from the first parameter by a *blank space*. Use a *semicolon* ( ; ) to separate multiple commands as shown below:

```
"*RST; *CLS; *ESE 32; *OPC?"
```

### SCPI Parameter Types

The SCPI language defines several different data formats to be used in program messages and response messages.

**Numeric Parameters** Commands that require numeric parameters will accept all commonly used decimal representations of numbers including optional signs, decimal points, and scientific notation.

Special values for numeric parameters like MINimum, MAXimum, and DEFault are also accepted. You can also send engineering unit suffixes with numeric parameters (e.g., M, K, or u). If only specific numeric values are accepted, the power/energy meter will automatically round the input numeric parameters. The following command uses a numeric parameter:

```
POWer:REFeRence {MINimum|MAXimum|DEFault|<numeric_value>[W]}
```

**Discrete Parameters** Discrete parameters are used to program settings that have a limited number of values (like W, DBM). They can have a short form and a long form just like command keywords. You can mix upper- and lower-case letters. Query responses will *always* return the short form in all upper-case letters. The following command uses discrete parameters:

```
POW:UNIT {W|DBM}
```

**Boolean Parameters** Boolean parameters represent a single binary condition that is either true or false. For a false condition, the power/energy meter will accept "OFF" or "0". For a true condition, the meter will accept "ON" or "1". When you query a boolean setting, the instrument will *always* return "0" or "1". The following command uses a boolean parameter:

```
CURRent:RANGe:AUTO {OFF|0|ON|1}
```

**String Parameters** String parameters can contain virtually any set of ASCII characters. A string *must* begin and end with matching quotes; either with a single quote or with a double quote. You can include the quote delimiter as part of the string by typing it twice without any characters in between. The following command uses a string parameter:

```
DIAG:CALString <quoted string>
```

## 6.3.2 IEEE488.2 Common Commands

Common commands are device commands that are common to all devices according to the IEEE488.2 standard. These commands are designed and defined by this standard. Most of the commands are described in detail in this section. The following common commands associated with the status structure are covered in the “Status Structure” section: \*CLS, \*ESE, \*ESE?, \*ESR?, \*SRE, \*SRE?, \*STB?

### 6.3.2.1 Command summary

Mnemonic	Name	Description
*CLS	Clear status	Clears all event registers and Error Queue
*ESE <NRf>	Event enable command	Program the Standard Event Enable Register
*ESE?	Event enable query	Read the Standard Event Enable Register
*ESR?	Event status register query	Read and clear the Standard Event Register
*IDN?	Identification query	Read the unit's identification string
*OPC	Operation complete command	Set the Operation Complete bit in the Standard Event Register
*OPC?	Operation complete query	Places a “1” into the output queue when all device operations have been completed
*RST	Reset command	Returns the unit to the *RST default condition
*SRE <NRf>	Service request enable command	Programs the Service Request Enable Register
*SRE?	Service request enable query	Reads the Service Request Enable Register
*STB?	Status byte query	Reads the Status Byte Register
*TST?	Self-test query	Performs the unit's self-test and returns the result.
*WAI	Wait-to-continue command	Wait until all previous commands are executed



### 6.3.2.2 Command reference

#### 6.3.2.2.1 \*IDN? – identification query - read identification code

The identification code includes the manufacturer, model code, serial number, and firmware revision levels and is sent in the following format:  
THORLABS,MMM,SSS,X.X.X

Where:       MMM is the model code  
              SSS is the serial number  
              X.X.X is the instrument firmware revision level

#### 6.3.2.2.2 \*OPC – operation complete - set OPC bit

#### 6.3.2.2.3 \*OPC? – operation complete query – places a “1” in output queue

When \*OPC is sent, the OPC bit in the Standard Event Register will set after all pending command operations are complete. When \*OPC? is sent, an ASCII “1” is placed in the Output Queue after all pending command operations are complete.

Typically, either one of these commands is sent after the INITiate command. The INITiate command is used to take the instrument out of idle in order to perform measurements. While operating within the trigger model layers, many sent commands will not execute. After all programmed operations are completed, the instrument returns to the idle state at which time all pending commands (including \*OPC and/or \*OPC?) are executed. After the last pending command is executed, the OPC bit and/or an ASCII “1” is placed in the Output Queue.

When \*OPC is sent, the OPC bit in the Standard Event Register will set after all pending command operations are complete. When \*OPC? is sent, an ASCII “1” is placed in the Output Queue after all pending command operations are complete.

#### 6.3.2.2.4 \*RST – reset – return instrument to defaults

When the \*RST command is sent, the instrument performs the following operations:

- Returns the instrument to the default conditions
- Cancels all pending commands.
- Cancels response to any previously received \*OPC and \*OPC? commands.

#### 6.3.2.2.5 \*TST? – self-test query – run self test and read result

Use this query command to perform the instrument self-test routine. The command places the coded result in the Output Queue. A returned value of zero (0) indicates that the test passed, other values indicate that the test failed.

#### 6.3.2.2.6 \*WAI – wait-to-continue – wait until previous commands are completed

The \*WAI command is a no operation command for the instrument and thus, does not need to be used. It is there for conformance to IEEE488.2.

### 6.3.2.3 PM100USB specific SCPI Command Reference

See also SCPI Specification, Version 1999.0, May, 1999, <http://www.scpiconsortium.org> . All commands with a 'SCPI' checkmark are described in the SCPI specification.

All described commands work also with the PM100A and PM100USB instruments. (With some limitations due to the hardware capabilities)

#### 6.3.2.3.1 SYSTem subsystem commands

Command	Description
<b>SYSTem</b>	Path to SYSTem subsystem. (SCPI Vol.2 §21)
<b>:BEEPer</b>	
[:IMMediate]	Issue an audible signal. (SCPI Vol.2 §21.2.2)
:STATe {ON 1 OFF 0}	Activate/deactivate the beeper. (SCPI Vol.2 §21.2.3)
:STATe?	Return the state of the the beeper (SCPI Vol.2 §21.2.3)
<b>:ERRor</b>	
[:NEXT]?	Returns the latest <error code, "message">. (SCPI Vol.2 §21.8.8)
<b>:VERSion?</b>	Query level of SCPI standard (1999.0) . (SCPI Vol.2 §21.21)
<b>:DATE &lt;year&gt;,&lt;month&gt;,&lt;day&gt;</b>	Sets the instrument's calendar. (SCPI Vol.2 §21.7)
<b>:DATE?</b>	Query the instrument's calendar. (SCPI Vol.2 §21.7)
<b>:TIME &lt;hour&gt;,&lt;min&gt;,&lt;sec&gt;</b>	Sets the instrument's clock. (SCPI Vol.2 §21.19)
<b>:TIME?</b>	Query the instrument's clock. (SCPI Vol.2 §21.19)
<b>:LFRequency &lt;numeric value&gt;</b>	Sets the instrument's line frequency setting to 50 or 60Hz. (SCPI Vol.2 §21.13)
<b>:LFRequency?</b>	Query the instrument's line frequency setting. (SCPI Vol.2 §21.13)

Commands for PM100D / PM100A only

:SENsOr															
:IDN?	<p>Query information about the connected sensor. This is a query only command. The response consists of the following fields:</p> <p>&lt;name&gt;, &lt;sn&gt;, &lt;cal_msg&gt;, &lt;type&gt;, &lt;subtype&gt;, &lt;flags&gt;</p> <p>&lt;name&gt;:      Sensor name in string response format</p> <p>&lt;sn&gt;:        Sensor serial number in string response format</p> <p>&lt;cal_msg&gt;: calibration message in string response format</p> <p>&lt;type&gt;:      Sensor type in NR1 format</p> <p>&lt;subtype&gt;: Sensor subtype in NR1 format</p> <p>&lt;flags&gt;:     Sensor flags as bitmap in NR1 format.</p> <table> <thead> <tr> <th><u>Flag:</u></th><th><u>Dec.value:</u></th></tr> </thead> <tbody> <tr> <td>Is power sensor</td><td>1</td></tr> <tr> <td>Is energy sensor</td><td>2</td></tr> <tr> <td>Response settable</td><td>16</td></tr> <tr> <td>Wavelength settable</td><td>32</td></tr> <tr> <td>Tau settable</td><td>64</td></tr> <tr> <td>Has temperature sensor</td><td>256</td></tr> </tbody> </table>	<u>Flag:</u>	<u>Dec.value:</u>	Is power sensor	1	Is energy sensor	2	Response settable	16	Wavelength settable	32	Tau settable	64	Has temperature sensor	256
<u>Flag:</u>	<u>Dec.value:</u>														
Is power sensor	1														
Is energy sensor	2														
Response settable	16														
Wavelength settable	32														
Tau settable	64														
Has temperature sensor	256														

**6.3.2.3.2 STATus subsystem commands**

Command	Description
<b>STATus</b>	Path to STATus subsystem. (SCPI Vol.2 §20)
<b>:MEASurement</b>	Path to control measurement event registers
[ :EVENTt ]?	Read the event register
:CONDition?	Read the condition register
:PTRansition <value>	Program the positive transition filter
:PTRansition?	Read the positive transition filter
:NTRansition <value>	Program the negative transition filter
:NTRansition?	Read the negative transition filter
:ENABle <value>	Program the enable register
:ENABle?	Read the enable register
<b>:AUXillary</b>	Path to control measurement event registers
[ :EVENTt ]?	Read the event register
:CONDition?	Read the condition register
:PTRansition <value>	Program the positive transition filter
:PTRansition?	Read the positive transition filter
:NTRansition <value>	Program the negative transition filter
:NTRansition?	Read the negative transition filter
:ENABle <value>	Program the enable register
:ENABle?	Read the enable register
<b>:OPERation</b>	Path to control operation event registers
[ :EVENTt ]?	Read the event register
:CONDition?	Read the condition register
:PTRansition <value>	Program the positive transition filter
:PTRansition?	Read the positive transition filter
:NTRansition <value>	Program the negative transition filter
:NTRansition?	Read the negative transition filter
:ENABle <value>	Program the enable register
:ENABle?	Read the enable register

<b>:QUESTionable</b>	Path to control questionable event registers
<b>[ :EVENT ]?</b>	Read the event register
<b>:CONDition?</b>	Read the condition register
<b>:PTRansition &lt;value&gt;</b>	Program the positive transition filter
<b>:PTRansition?</b>	Read the positive transition filter
<b>:NTRansition &lt;value&gt;</b>	Program the negative transition filter
<b>:NTRansition?</b>	Read the negative transition filter
<b>:ENABle &lt;value&gt;</b>	Program the enable register
<b>:ENABle?</b>	Read the enable register
<b>:PRESet</b>	Return status registers to default states.

#### 6.3.2.3.3 DISPlay subsystem commands

Command	Description
<b>DISPlay</b>	Path to DISPlay subsystem. (SCPI Vol.2 §8)
<b>:BRIGHtness &lt;value&gt;</b>	Set the display birghtness. (SCPI Vol.2 §8.2)
<b>:BRIGHtness?</b>	Return the display birghtness value. (SCPI Vol.2 §8.2)
<b>:CONTRast &lt;value&gt;</b>	Set the display contrast. (SCPI Vol.2 §8.4)
<b>:CONTRast?</b>	Return the display conrast value. (SCPI Vol.2 §8.4)

Commands for PM100D / PM100A only

#### 6.3.2.3.4 CALibration subsystem commands

Command	Description
<b>CALibration</b>	Path to CALibration subsystem. (SCPI Vol.2 §5)
<b>:STRing?</b>	Returns a human readable calibration string. This is a query only command. The response is formatted as string response data.

## 6.3.2.3.5 SENSE subsystem commands

Command	Description
[SENSe]	Path to SENSE subsystem. (SCPI Vol.2 §18)
AVERage	
[ :COUNT] <value>	Sets the averaging rate (1 sample takes approx. 3ms)
[ :COUNT]?	Queries the averaging rate
CORRection	
[ :LOSS[ :INPut[ :MAGNitude]]]	Sets a user attenuation factor in dB
{MINimum MAXimum DEFault  <numeric_value>}	
[ :LOSS[ :INPut[ :MAGNitude]]]?	Queries the user attenuation factor
[ {MINimum MAXimum DEFault}]	
COLLect	
ZERO	
[ :INITiate]	Performs zero adjustment routine
ABORt	Aborts zero adjustment routine
STATe?	Queries the zero adjustment routine state
MAGNitude?	Queries the zero value
BEAMdiameter {MINimum  MAXimum DEFault  <numeric_value>[mm]}	Sets the beam diameter in mm
BEAMdiameter? [ {MINimum  MAXimum DEFault}]	Queries the beam diameter
WAVelength {MINimum  MAXimum  <numeric_value>[nm]}	Sets the operation wavelength in nm
WAVelength? [ {MINimum  MAXimum}]	Queries the operation wavelength

<p>POWER</p> <p>[ :PDIOde]</p> <p>[ :RESPonse] {MINimum MAXimum DEFAULT &lt;numeric_value&gt;[A]}</p> <p>[ :RESPonse]?</p> <p>[ {MINimum MAXimum DEFAULT}]</p> <p>:THERmopile</p> <p>[ :RESPonse] {MINimum MAXimum DEFAULT &lt;numeric_value&gt;[V]}</p> <p>[ :RESPonse]?</p> <p>[ {MINimum MAXimum DEFAULT}]</p> <p>ENERgy</p> <p>[ :PYRO]</p> <p>[ :RESPonse] {MINimum MAXimum DEFAULT &lt;numeric_value&gt;[V]}</p> <p>[ :RESPonse]?</p> <p>[ {MINimum MAXimum DEFAULT}]</p>	<p>Sets the photodiode response value in A/W</p> <p>Queries the photodiode response value</p> <p>Sets the thermopile response value in V/W</p> <p>Queries the thermopile response value</p> <p>Sets the pyro-detector response value in V/J</p> <p>Queries the pyro-detector response value</p>
<p>CURRENT[:DC]</p> <p>RANGE</p> <p>AUTO {OFF 0 ON 1}</p> <p>AUTO?</p> <p>[ :UPPer] {MINimum MAXimum &lt;numeric_value&gt;[A]}</p> <p>[ :UPPer]? [{MINimum MAXimum}]</p> <p>REFERENCE {MINimum MAXimum DEFAULT &lt;numeric_value&gt;[A]}</p>	<p>Switches the auto-ranging function on and off</p> <p>Queries the auto-ranging function state</p> <p>Sets the current range in A</p> <p>Queries the current range</p> <p>Sets a delta reference value in A</p>

REFeRence? [{MINimum  MAXimum DEFault}]  STATe {OFF 0 ON 1}  STATe?	Queries the delta reference value  Switches to delta mode  Queries the delta mode state
ENERgy  RANGe  [:UPPer] {MINmum MAXimum  <numeric_valu>[J]}  [:UPPer]? [{MINimum  MAXimum}]  REFeRence {MINimum  MAXimum DEFault  <numeric_value>[J]}  REFeRence? [{MINimum  MAXimum DEFault}]  STATe {OFF 0 ON 1}  STATe?	Sets the energy range in J  Queries the energy range  Sets a delta reference value in J  Queries the delta reference value  Switches to delta mode  Queries the delta mode state
FREQuency  Range  [UPPer]?  LOWer?	Queries the frequency range
POWER[:DC]  RANGe  AUTO {OFF 0 ON 1}  AUTO?  [:UPPer] {MINmum MAXimum  <numeric_valu>[W]}  [:UPPer]? [{MINimum  MAXimum}]  REFeRence {MINimum  MAXimum DEFault  <numeric_value>[W]}  REFeRence? [{MINimum  MAXimum DEFault}]  STATe {OFF 0 ON 1}	Switches the auto-ranging function on and off  Queries the auto-ranging function state  Sets the current range in W  Queries the current range  Sets a delta reference value in W  Queries the delta reference value  Switches to delta mode



STATE? UNIT {W DBM} UNIT?	Queries the delta mode state Sets the power unit W or dBm Queries the power unit
VOLTage[:DC] RANGe AUTO {OFF 0 ON 1} AUTO? [:UPPer] {MINmum MAXimum  <numeric_valu>[V]} [:UPPer]? [{MINimum  MAXimum}] REFerence {MINimum  MAXimum DEFault  <numeric_value>[V]} REFerence? [{MINimum  MAXimum DEFault}] STATE {OFF 0 ON 1} STATE?	 Switches the auto-ranging function on and off Queries the auto-ranging function state Sets the current range in V  Queries the current range  Sets a delta reference value in V  Queries the delta reference value  Switches to delta mode Queries the delta mode state
PEAKdetector [:THReshold] {MINimum  MAXimum DEFault  <numeric_value> [:THReshold]? [{MINimum  MAXimum DEFault}	 Sets the trigger level in % for the energy mode  Queries the trigger level setting

## 6.3.2.3.6 INPut subsystem commands

Command	Description
<b>INPut</b> [:PDIode] :FILTER [:LPASs] [STATE] {OFF 0 ON 1} [STATE]?	Sets the bandwidth of the photodiode input stage Queries the bandwidth of the photodiode input stage
:THERmopile :ACCElerator [STATE] {OFF 0 ON 1} [STATE]? :AUTO {OFF 0 ON 1} ? :TAU {MINimum  MAXimum DEFAULT  <numeric_value>[s]} :TAU? [{MINimum  MAXimum DEFAULT}]	Sets the thermopile accelerator state Queries the thermopile accelerator state Sets the thermopile accelerator to auto mode Queries thermopile accelerator auto mode Sets thermopile time constant 0-63% in s Queries the thermopile time constant in s
:ADAPter [:TYPE] {PHOTodiode  THERmal PYRo} [:TYPE]?	Sets custom sensor input adapter type Queries custom sensor input adapter type

## 6.3.2.3.7 Measurement commands

Command	Description
INITiate[:IMMEDIATE]	Start measurement
ABORT	Abort measurement
CONFigure[:SCALar]	
[:POWER]	Configure for power measurement
:CURRent[:DC]	Configure for current measurement
:VOLTage[:DC]	Configure for voltage measurement
:ENERgy	Configure for energy measurement
:FREQuency	Configure for frequency measurement
:PDENsity	Configure for power density measurement
:EDENsity	Configure for energy density measurement
:RESistance	Configure for sensor presence resistance measurement
:TEMPerature	Configure for sensor temperature measurement
MEASure[:SCALar]	
[:POWER]	Performs a power measurement
:CURRent[:DC]	Performs a current measurement
:VOLTage[:DC]	Performs a voltage measurement
:ENERgy	Performs a energy measurement
:FREQuency	Performs a frequency measurement
:PDENsity	Performs a power density measurement
:EDENsity	Performs a energy density measurement
:RESistance	Performs a sensor presence resistance measurement
:TEMPerature	Performs a sensor temperature measurement
FETCh?	Read last measurement data (SCPI Vol.2 §3.2)
READ?	Start new measurement and read data (SCPI Vol.2 §3.3)
CONFigure?	Query the current measurement configuration.

### 6.3.3 Simple LabVIEW Example using SCPI Commands



#### PM100D Simple Example.vi

This VI shows how to communicate with a PM100USB, PM100D or PM100A optical power and/or energy meter with SCPI commands. The following steps are demonstrated within this application:

- Initializing the instrument
- Getting system info
- Setting parameters
- Measurement configuration
- Measuring queue
- Fetching and displaying a measurement value
- Closing the application




Figure 8 Simple LabVIEW Example Front Panel



#### Averaging Rate

Sets the averaging rate - 3000 averages take approximately 1s for performing a new measurement value



#### Readout Config

Selects the measurement parameter

- POW power measurement in W
- CURR current measurement in A
- VOLT voltage measurement in V
- ENER energy measurement in J
- FREQ frequency / repetition rate measurement in Hz
- PDEN power density measurement in W/cm<sup>2</sup>

- EDEN energy density measurement in J/cm<sup>2</sup>
- RES thermistor resistance measurement in Ohm
- TEMP temperature measurement in °C

**Stop**

Stops application

**Timeout [ms]**

Sets a timeout value in ms that allows the instrument to sample.  
The timeout must be longer than it takes to perform a new measurement.  
This has especially to be considered when performing single shot energy measurements.

**Error log**

Error indicator, 'no error' is suppressed

**Readout string**

Formatted measurement value

- limitation to 4 significant digits
- SI notation
- '.' decimal separator
- appended unit according readout configuration

**New**

Indicator lights up, when a new measurement value is processed

**Sensor Flags**

Sensor flag bitmap:

- 1 Is power sensor
- 2 Is energy sensor
- 16 Response settable
- 32 Wavelength settable
- 64 Tau settable
- 256 Has temperature sensor

**Sensor Name**

Name of connected power/energy sensor

**Sensor SN**

Serial number of connected power/energy sensor

**IDN String**

Answer from instrument on \*idn? command:

- manufacturer
- model number
- serial number
- firmware version

**Readout value**

Plain readout value in full resolution

## Block diagram




Figure 9 Simple LabVIEW Example Block Diagram

**PM100D\_Initialize.vi**

This VI scans for connected devices, that can be selected in a dialog box.

Next steps

- setting timeout
- performing identification query
- configuring the operation register to '512'; flag gets to HI when a new measurement value is ready to fetch
- clear operation register

**PM100D\_Write.vi**

Writes a SCPI command to the connected instrument

**PM100D\_Read.vi**

Reads data from the connected instrument. All query commands according the SCPI command table are terminated by a question mark (?)

**PM100D\_SensorFlag.vi**

This VI queries all relevant sensor info with SYST:SENS:IDN?

- sensor name
- sensor serial number
- calibration message
- sensor type
- sensor sub-type
- sensor flags

**PM100D\_ConfMeas.vi**

- CONFIGure measurement; CONF:<parameter> (POW, ENER, etc.)
- ABORt measurement
- Clear operation register with STAT:OPER?
- INITiate measurement

**PM100D\_SYST-ERR.vi**

This VI lists all errors coming from the instrument with the command SYST:ERR?

'no error' is suppressed

**PM100D\_Close.vi**

Closes the VISA session

Sets the connected instrument in local mode (default option)

## Maintenance and Repair

### 6.4 Maintenance

Protect the PM100USB from adverse weather conditions. The PM100USB is not water resistant.

#### **Attention**

**To avoid damage to the PM100USB, do not expose it to spray, liquids or solvents!**

The unit does not need a regular maintenance by the user.

If necessary the unit and the display can be cleaned with a cloth dampened with water.

The PM100USB does not contain any modules that could be repaired by the user himself. If a malfunction occurs, the whole unit has to be sent back to *Thorlabs*. Do not remove covers!

To guarantee the specifications given in chapter 7.3 over a long period it is recommended to have the unit calibrated by *Thorlabs* every year.



## 6.5 Troubleshooting

In case that your PM100USB shows malfunction please check the following items:

- ◆ Unit does not work at all (all LEDs off):
  - PM100USB connected to a running PC via USB?
    - Check that test and measurement device is initialized
    - Check connection or try a different USB port
- ◆ Power or Energy reading is negative
  - A photodiode or thermal sensor is connected
    - Check if the unit is in relative measurement mode
    - Conduct the dark current adjustment procedure
  - A photodiode is connected
    - Check the polarity of the connected photodiode
  - A thermal element is connected
    - Check the polarity of the connected thermal element
  - A pyro-electric element is connected
    - Check the polarity of the connected pyro element
- ◆ Pulse energy measurement cannot be measured or is measured wrongly
  - Check for the right trigger level between noise level and expected pulse height
  - Check if energy sensor can handle the laser pulse repetition rate

If you don't find the error source by means of the trouble shooting list please first contact the [Thorlabs-Hotline \( europa@thorlabs.com\)](mailto:europa@thorlabs.com) before sending the PM100USB for checkup and repair to **Thorlabs** - Germany.

➔ (refer to section 7.7, 'Addresses" on page 65)

## 7 Appendix

### 7.1 Warranty

**Thorlabs** warrants material and production of the PM100USB for a period of 24 months starting with the date of shipment. During this warranty period **Thorlabs** will see to defaults by repair or by exchange if these are entitled to warranty.

For warranty repairs or service the unit must be sent back to **Thorlabs** or to a place determined by **Thorlabs**. The customer will carry the shipping costs to **Thorlabs**, in case of warranty repairs **Thorlabs** will carry the shipping costs back to the customer. If no warranty repair is applicable the customer also has to carry the costs for back shipment.

In case of shipment from outside EU duties, taxes etc. which should arise have to be carried by the customer.

**Thorlabs** warrants the hard- and software determined by **Thorlabs** for this unit to operate fault-free provided that they are handled according to our requirements. However, **Thorlabs** does not warrant a fault free and uninterrupted operation of the unit, of the soft- or firmware for special applications nor this instruction manual to be error free. **Thorlabs** is not liable for consequential damages.

#### **Restriction of warranty**

The warranty mentioned before does not cover errors and defects being the result of improper treatment, software or interface not supplied by us, modification, misuse or operation outside the defined ambient stated by us or unauthorized maintenance.

Further claims will not be consented to and will not be acknowledged. **Thorlabs** does explicitly not warrant the usability or the economical use for certain cases of application.

**Thorlabs** reserves the right to change this instruction manual or the technical data of the described unit without notice.

## 7.2 Certifications and compliances

### Certifications and compliances

Category	Standards or description	
EC Declaration of Conformity – EMC	Meets intent of Directive 89/336/EEC for Electromagnetic Compatibility. Compliance was demonstrated to the following specifications as listed in the Official Journal of the European Communities:	
	EN 61326:1997 +A1:1998 +A2:2001 +A3:2003	Electrical equipment for measurement, control and laboratory use – EMC requirements: Immunity: complies with immunity test requirements for equipment intended for use in industrial locations <sup>1</sup> . Emission: complies with EN 55011 Class B Limits <sup>1,3</sup> , IEC 610003-2 and IEC 61000-3-3.
	IEC 61000-4-2	Electrostatic Discharge Immunity (Performance criterion C)
	IEC 61000-4-3	Radiated RF Electromagnetic Field Immunity (Performance Criterion A) <sup>5</sup>
	IEC 61000-4-4	Electrical Fast Transient / Burst Immunity (Perf. Criterion C)
	IEC 61000-4-5	Power Line Surge Immunity (Performance Criterion A)
	IEC 61000-4-6	Conducted RF Immunity (Performance Criterion A)
	IEC 61000-4-8	Power Frequency Magnetic Field Immunity (Perf. Criterion A)
	IEC 61000-4-11	Voltage Dips, Short Interruptions and Voltage Variations Immunity (Performance Criterion A / C <sup>6</sup> )
FCC EMC Compliance	IEC 61000-3-2	AC Power Line Harmonic Emissions
	IEC 61000-3-3	Voltage Fluctuations and Flicker
FCC EMC Compliance	Emissions comply with the Class B Limits of FCC Code of Federal Regulations 47, Part 15, Subpart B <sup>1,3</sup> .	
EC Declaration of Conformity - Low Voltage	Compliance was demonstrated to the following specification as listed in the Official Journal of the European Communities: Low Voltage Directive 73/23/EEC, amended by 93/68/EEC	
	EN 61010-1:2001	Safety requirements for electrical equipment for measurement, control and laboratory use.
U.S. Nationally Recognized Testing Laboratory Listing	UL 61010-1 2 <sup>nd</sup> ed.	Safety requirements for electrical equipment for measurement, control, and laboratory use.
	ISA-82:02.01	Safety requirements for electrical equipment for measurement, control, and laboratory use.
Canadian Certification	CAN/CSA C22.2 No. 61010-1-04	Safety requirements for electrical equipment for measurement, control, and laboratory use.
Additional Compliance	IEC 61010-1:2001	Safety requirements for electrical equipment for measurement, control, and laboratory use.
Equipment Type	Test and measuring	
Safety Class	Class I equipment (as defined in IEC 60950-1:2001)	

<sup>1</sup> Compliance demonstrated using high-quality shielded interface cables shorter than 3 meters.

<sup>3</sup> Emissions, which exceed the levels required by these standards, may occur when this equipment is connected to a test object.

<sup>5</sup> MOD IN port capped at IEC 61000-4-3 test.

<sup>6</sup> Performance Criterion C was reached at additional test levels according to EN 61326-1:2006 table 2

## 7.3 Technical data

General Data	
Detector Compatibility	Photodiode Sensors S100C Series Thermal Sensors S300C Series Pyroelectric Sensors ES100C/ES200C Series Photodiodes (max. 5.5mA) Thermopiles (max. 1.1V) Pyros (max. 110V)
Display Type	External PC – Windows application
Display Update Rate (max)	Up to 500 Hz depending on PC and settings
Display Format	Numerical, Bargraph, Trendgraph, Statistics, Histogram with utility software
Dimensions (H x W x D) Overall	95 x 63.5 x 32.5 mm <sup>3</sup>
Weight	< 0.2 kg
Operating Temperature	0°C - +40°C
Storage Temperature	-40°C - +70°C
Relative Humidity	Max. 80% up to 31 °C, decreasing to 50% at 40 °C
Operation Altitude	< 3000 m
Current Input (Photodiode Sensors)	
Connector	DB9F, left side
Units	W, dBm, W/cm <sup>2</sup> , A
Measurement Ranges	6 decades; 50 nA ... 5 mA Ranges selectable in W or A, sensor depending
Display Resolution	1 pA / responsivity value (A/W)
AD Converter	16 bit
Accuracy	+/- 0.2% f.s. (5 µA – 5 mA) +/- 0.5% f.s. (50nA)
Bandwidth	DC – 100 kHz, depending on sensor and settings
Photodiode Polarity	Cathode ground
Max. Photodiode Impedance	10 nF
Input Resistance	0 Ω (virtual ground)
Wavelength Correction	nm (A/W)
Beam Diameter Setting	1/e <sup>2</sup>
Voltage Input (Thermopile Sensors)	
Connector	DB9F, left side
Units	W, dBm, W/cm <sup>2</sup> , V
Measurement Ranges	4 decades; 1 mV ... 1V Ranges selectable in W or V, sensor depending
Display Resolution	1 µV / responsivity value (V/W)
AD Converter	16 bit
Accuracy	+/- 0.5% f.s.
Bandwidth	DC - 10Hz, depending on sensor and settings
Input Impedance	1 MΩ
Time Constant Correction Range	1 s – 30 s
Wavelength Correction	Sensor depending; nm, (V/W)
Beam Diameter Setting	1/e <sup>2</sup>

<b>Voltage Input (Pyro Sensors)</b>	
Connector	DB9F, left side
Units	J, J/cm <sup>2</sup> , W, W/cm <sup>2</sup> , V
Measurement Ranges	4 decades; 100mV ... 100V Ranges selectable in J or V, sensor depending
Display Resolution	100µV / responsivity value (V/J)
AD Converter	16 bit
Accuracy	+/- 0.5% f.s.
Trigger Threshold	0.1% - 99.9% f.s.
max. Repetition Rate	3 kHz
Input Impedance	1 MΩ
Wavelength Correction	Sensor depending; nm, (V/J)
Beam Diameter Setting	1/e <sup>2</sup>
<b>Sensor Temperature Control</b>	
Supported temperature sensor	Thermistor
Temperature measurement range	-10 °C .. +80 °C
<b>Interface</b>	
Type	USB2.0
Connector	Mini USB
<b>Power Management</b>	
External power supply DC Input	5 VDC via USB
<b>Accessories</b>	
USB cable (2m)	✓
Instrument Drivers on USB Stick	✓
Application Software on USB Stick	✓
User Manual on USB Stick	✓

### Current Input Photodiode Sensors

Current Range	Display Resolution	Measurement Accuracy
5 mA	1 $\mu$ A	+/- 0.2% f.s.
500 $\mu$ A	100 nA	+/- 0.2% f.s.
50 $\mu$ A	10 nA	+/- 0.2% f.s.
5 $\mu$ A	1 nA	+/- 0.2% f.s.
500 nA	100 pA	+/- 0.2% f.s.
50 nA	10 pA	+/- 0.5% f.s.

### Voltage Input Thermal Sensors


Voltage Range	Display Resolution	Measurement Accuracy
1 V	100 $\mu$ V	+/- 0.5% f.s.
100 mV	10 $\mu$ V	+/- 0.5% f.s.
10 mV	1 $\mu$ V	+/- 0.5% f.s.
1 mV	0.1 $\mu$ V	+/- 1.0% f.s.

### Voltage Input Pyroelectrical Sensors

Voltage Range	Display Resolution	Measurement Accuracy
100 V	100 mV	+/- 0.5% f.s.
10 V	10 mV	+/- 0.5% f.s.
1 V	1 mV	+/- 0.5% f.s.
0.1V	100 $\mu$ V	+/- 0.5% f.s.

## 7.4 Pin Assignment of the Sensor Connector

The PM100USB is capable to support custom made detectors. Please read carefully the following instruction prior to connecting a self made sensor.



**Figure 10 Pin assignment of the sensor connector jack(s) (female)**

### pin   connection

- |          |  |
|----------|--|
| <b>3</b> | photodiode ground (anode), thermal and pyro sensor ground, analog ground |
| <b>4</b> | photodiode cathode   |
| <b>5</b> | pyro-electric sensor +   |
| <b>8</b> | thermal sensor +   |
| <b>7</b> | PRESENTconnect this pin via a 1kΩ – 10kΩ resistor to Pin 3 (AGND)        |
| <b>1</b> | +5V                    drive max. 50mA from this pin                     |
| <b>6</b> | DGND   |
| <b>9</b> | n.c.   |

The following described pin is uniquely used for the memory in the sensor head and may not be used. Connecting this pin may cause malfunction of the PM100USB.

- |          |                    |
|----------|--------------------|
| <b>2</b> | EEPROM Digital I/O |
|----------|--------------------|

## **7.5 Thorlabs 'End of Life' policy (WEEE)**

As required by the WEEE (Waste Electrical and Electronic Equipment Directive) of the European Community and the corresponding national laws, Thorlabs offers all end users in the EC the possibility to return 'end of life' units without incurring disposal charges.

This offer is valid for Thorlabs electrical and electronic equipment

- sold after August 13<sup>th</sup> 2005
- marked correspondingly with the crossed out 'wheelie bin' logo (see Figure 11)
- sold to a company or institute within the EC
- currently owned by a company or institute within the EC
- still complete, not disassembled and not contaminated

As the WEEE directive applies to self contained operational electrical and electronic products, this 'end of life' take back service does not refer to other Thorlabs products, such as

- pure OEM products, that means assemblies to be built into a unit by the user (e. g. OEM laser driver cards)
- components
- mechanics and optics
- left over parts of units disassembled by the user (PCB's, housings etc.).

If you wish to return a Thorlabs unit for waste recovery, please contact Thorlabs or your nearest dealer for further information.

### **7.5.1 Waste treatment on your own responsibility**

If you do not return an 'end of life' unit to Thorlabs, you must hand it to a company specialized in waste recovery. Do not dispose of the unit in a litter bin or at a public waste disposal site.



### 7.5.2 Ecological background

It is well known that WEEE pollutes the environment by releasing toxic products during decomposition. The aim of the European RoHS directive is to reduce the content of toxic substances in electronic products in the future.

The intent of the WEEE directive is to enforce the recycling of WEEE. A controlled recycling of end of life products will thereby avoid negative impacts on the environment.



**Figure 11**    **Crossed out 'wheelie bin' symbol**

## 7.6 List of figures

Figure 1	Front View	13
Figure 2	Rear View	13
Figure 3	Sensor Connector	14
Figure 3	Scan Device Dialog	15
Figure 4	PM100 Utility Front Panel	16
Figure 6	Firmware Update – DFU Wizard	33
Figure 7	Instrument Driver Example	34
Figure 8	Simple LabVIEW Example Front Panel	50
Figure 8	Simple LabVIEW Example Block Diagram	52
Figure 10	Pin assignment of the sensor connector jack(s) (female)	61
Figure 11	Crossed out ‘wheelie bin” symbol	63

## 7.7 Addresses

Our Company is represented by several distributors and sales offices throughout the world.

### Europe

Thorlabs GmbH  
Hans-Boeckler-Str. 6  
D-85221 Dachau  
Germany

#### Sales and Support

Phone: +49 (0) 8131 / 5956-0  
Fax: +49 (0) 8131 / 5956-99  
Email: [europa@thorlabs.com](mailto:europa@thorlabs.com)  
Web: [www.thorlabs.com](http://www.thorlabs.com)

### USA

Thorlabs, Inc.  
435 Route 206 North  
Newton, NJ 07860  
USA

#### Sales and Support

Phone: 1-973-579-7227  
Fax: 1-973-300-3600  
Email: [sales@thorlabs.com](mailto:sales@thorlabs.com)  
Email: [techsupport@thorlabs.com](mailto:techsupport@thorlabs.com)  
Web: [www.thorlabs.com](http://www.thorlabs.com)

### Japan

Thorlabs, Inc.  
Higashi Ikebukuro Q Building 1st floor  
2-23-2, Higashi Ikebukuro, Toshimaku  
Tokyo 170-0013  
Japan

#### Sales and Support

Phone: +81-3-5979-8889  
Fax: +81-3-5979-7285  
Email: [sales@thorlabs.jp](mailto:sales@thorlabs.jp)  
Web: [www.thorlabs.jp](http://www.thorlabs.jp)

Please call our hotlines, send an Email to ask for your nearest distributor or just visit our homepage

<http://www.thorlabs.com>