



SM-10002

Thank you for purchasing our product.  
Please read this User's Manual before  
using the product. Change without Notice


## **4 Channel Color Quad**

---

# **User's Manual**



## Front Panel



### Key Function and mode define:


Button / Mode	AUTO / QUAD	↑ 1   ↓ 2   ← 3   → 4	VCR / PIP / ENTER	MENU / ZOOM	SHIFT
Normal Mode (Live display)	4-Split Mode button	Camera 1,2,3,4 Full screen display	PIP screen display	Picture 2 x 2 zoom in	To SHIFT mode
Shift Mode (Press Shift Key)	Channel sequence	Camera 1,2,3,4 Full screen display	To VCR Mode	To Menu Setup	To normal mode
Menu Mode (Menu function page)	Increase value	UP/DOWN / LEFT / RIGHT direction button	ENTER key	Exit Menu	Reduce value
VCR Mode	4-Split Mode button	Camera 1,2,3,4 Full screen display	To Shift mode	To Menu Setup	No function
PIP Mode	To normal mode quad	UP / DOWN, main-screen move, LEFT / RIGHT, son-screen move	To normal mode	2 x 2 zoom in	Shift + PIP mode
SHIFT + PIP mode	PIP auto sequence	PIP-screen moving	To VCR mode	To MENU mode	To PIP mode

Shift Mode, press shift key, an up direction arrow appears.

PIP, after PIP-picture moves to press shift again to memorize position. If not, position would not be memorized.


Every time, a user changes function values which needs to press MENU to exit and save values.

Normal Mode




PIP screen

Shift Mode






Auto sequence

Menu Mode




2 x 2 zoom




1,2,3,4 CAMERA IN: BNC connectors for four-camera signal input

1,2,3,4 CAMERA OUT: BNC connectors for four-camera signal output (Looping)




VCR In: BNC connector for video signal input from VCR (VCR OUT).

VCR Out: BNC connector for video signal output to VCR (VCR IN) .




Monitor output



ALARM connector 9 pins D-Sub connector.

- |             |        |
|-------------|--------|
| 1. ALARM #1 | 6. NC  |
| 2. ALARM #2 | 7. COM |
| 3. ALARM #3 | 8. NO  |
| 4. ALARM #4 | 9.GND  |
| 5. 5V       |        |




75-ohm high low on / off DIP



Power switcher

Power input: DC 12 V / 1.5 A

## FUNCTION SETUP (SHIFT + MENU / ZOOM)



### FUNCTION SETUP

- |              |       |
|--------------|-------|
| 1. DISPLAY   | SETUP |
| 2. CAMERA    | SETUP |
| 3. BUZZER    | SETUP |
| 4. DATE-TIME | SETUP |
| 5. ALARM     | SETUP |
| 6. MOTION    | SETUP |
| 7. EVENT     | LIST  |
| 8. SYSTEM    | SETUP |

\*\* VERSION XXX \*\*

- |              |       |                             |
|--------------|-------|-----------------------------|
| 1. DISPLAY   | SETUP | Display items               |
| 2. CAMERA    | SETUP | Camera related setup        |
| 3. BUZZER    | SETUP | Buzzer on or off setup      |
| 4. DATE-TIME | SETUP | Current time and date setup |
| 5. ALARM     | SETUP | Alarm function setup        |
| 6. MOTION    | SETUP | Motion function setup       |
| 7. EVENT     | LIST  | Event list page             |
| 8. SYSTEM    | SETUP | System setup page           |

↑↓ Move function item cursor and press ENTER to sub-menu.

## 1. DISPLAY SETUP:

FUNCTION SETUP		
1. DISPLAY	SETUP	
2. CAMERA	SETUP	
3. BUZZER	SETUP	
4. DATE-TIME	SETUP	
5. ALARM	SETUP	
6. MOTION	SETUP	
7. EVENT	LIST	
8. SYSTEM	SETUP	

DISPLAY SETUP		
1. DATE-TIME		ON
2. CAMERA TITLE		ON
3. VCR DATE-TIME		ON
4. VCR CAMERA TITLE		ON
5. BORDER SET		WHITE

### DISPLAY SETUP

#### 1. DATE-TIME

Current date and time display on the screen? ON / OFF

#### 2. CAMERA TITLE

Camera title display on the screen? ON / OFF

#### 3. VCR DATE-TIME

DATE and Time record to VCR? ON / OFF

#### 4. VCR CAMERA TITLE

CAMERA TITLE record to VCR? ON / OFF

#### 5. BORDER SET

Quad split border color? WHITE / BLACK / DARK / GRAY

↑↓ Move function item cursor and press ENTER to sub-menu.

Shift and AUTO / QUAD to change values.

## 2. CAMERA SETUP:

FUNCTION SETUP		CAMERA SETUP PAGE	
1. DISPLAY	SETUP	** CHANNEL NUMBER	
<b>2. CAMERA</b>	<b>SETUP</b>	1. BRIGHTNESS	00
3. BUZZER	SETUP	2. CONTRAST	00
4. DATE-TIME	SETUP	3. SATURATION	00
5. ALARM	SETUP	4. HUE	00
6. MOTION	SETUP	5. GAIN	00
7. EVENT	LIST	6. TITLE	
8. SYSTEM	SETUP	7. DEFAULT RESET	

### CAMERA SETUP PAGE

CHANNEL NUMBER CH 01 / 02 / 03 / 04

1. BRIGHTNESS	-31 ~ +32
2. CONTRAST	-31 ~ +32
3. SATURATION	-31 ~ +32
4. HUE	-31 ~ +32
5. GAIN	-31 ~ +32
6. TITLE	CAM0100000
7. DEFAULT RESET	Press ENTER

#### \*\* CAUTION\*\*

ALL CAMERA SETUP VALUE WILL BE  
CLEAR AND RESTORE FACTORY DEFAULT  
PRESS [ENTER] TO RESTORE  
PRESS [MENU] TO CANCEL

↑↓ Move function item cursor and press ENTER to sub-menu.

Shift and AUTO / QUAD to change values.

### 3. BUZZER SETUP:

FUNCTION SETUP	
1. DISPLAY	SETUP
2. CAMERA	SETUP
<b>3. BUZZER</b>	<b>SETUP</b>
4. DATE-TIME	SETUP
5. ALARM	SETUP
6. MOTION	SETUP
7. EVENT	LIST
8. SYSTEM	SETUP

BUZZER SETUP PAGE	
**SYSTEM BUZZER	ON
BUTTON BUZZER	ON
ALARM BUZZER	ON
MOTION BUZZER	ON
VLOSS BUZZER	ON

**SYSTEM BUZZER	ON / OFF (Buzzer function)
BUTTON BUZZER	Key pressed buzzer. One pressed, and a sound.
ON / OFF	
ALARM BUZZER	Alarm trigger buzzer. According duration time.
ON / OFF	
MOTION BUZZER	Motion moving buzzer. Every movement and a sound.
ON / OFF	
V-LOSS BUZZER	Video loss buzzer. Sound keeps until video in or other buzzer happens.
ON / OFF	

↑↓ Move function item cursor and press ENTER to sub-menu.

Shift and AUTO / QUAD to change values.

#### 4. DATE-TIME:

FUNCTION SETUP	
1. DISPLAY	SETUP
2. CAMERA	SETUP
3. BUZZER	SETUP
<b>4. DATE-TIME</b>	<b>SETUP</b>
5. ALARM	SETUP
6. MOTION	SETUP
7. EVENT	LIST
8. SYSTEM	SETUP


DATE-TIME SETUP PAGE	
1.DATE	2000/00/00
2.TIME	12:12:12

1. DATE : Current Year / Month / Day
2. TIME : Current Hour / Minute / Second

↑↓ Move function item cursor and press ENTER to sub-menu.

Shift and AUTO / QUAD to change values.

Date and time change steps:





2.TIME 13:12:12

## 5. ALARM SETUP:

FUNCTION SETUP	
1. DISPLAY	SETUP
2. CAMERA	SETUP
3. BUZZER	SETUP
4. DATE-TIME	SETUP
<b>5. ALARM</b>	<b>SETUP</b>
6. MOTION	SETUP
7. EVENT	LIST
8. SYSTEM	SETUP

ALARM SETUP PAGE	
1.ALARM SIGNAL1:	
2.ALARM SIGNAL2:	
3.ALARM SIGNAL3:	
4.ALARM SIGNAL4:	
5.ALARM DURATION:	SEC

ALARM SETUP PAGE (Alarm sensor type and duration time setup)

1. ALARM SIGNAL1: NO / NC / OFF
2. ALARM SIGNAL2: NO / NC / OFF
3. ALARM SIGNAL3: NO / NC / OFF
4. ALARM SIGNAL4: NO / NC / OFF
5. ALARM DURATION: 000 ~ 999 SEC

↑↓ Move function item cursor and press ENTER to sub-menu.

Shift and AUTO / QUAD to change values.

## 6. MOTION SETUP:

### FUNCTION SETUP

- |                  |              |
|------------------|--------------|
| 1. DISPLAY       | SETUP        |
| 2. CAMERA        | SETUP        |
| 3. BUZZER        | SETUP        |
| 4. DATE-TIME     | SETUP        |
| 5. ALARM         | SETUP        |
| <b>6. MOTION</b> | <b>SETUP</b> |
| 7. EVENT         | LIST         |
| 8. SYSTEM        | SETUP        |

### MOTION SETUP PAGE

\*\*MOTION FUNCTION

\*\*CHANNEL NUMBER

- 1.SENSITIVITY
- 2.VELOCITY
- 3.MOTION ACTIVE
- 4.MOTION AREA SETUP

### MOTION SETUP PAGE

\*\*MOTION FUNCTION ON / OFF

\*\*CHANNEL NUMBER CH 01 / 02 / 03 / 04

1.SENSITIVITY            0 ~ +15

Object moving sensitivity setup

2.VELOCITY            0 ~ +30

Object moving speed setup

3.MOTION ACTIVE        ON / OFF

Channel motion detect active

### 4.MOTION AREA SETUP

Motion area, transparent window lattice is detecting, blue window lattice is not detecting.

↑ ↓ → ← Move function item cursor and press ENTER to Increase / reduce.

Shift and AUTO / QUAD to change values.

## 7. EVENT LIST:

---

FUNCTION SETUP	
1. DISPLAY	SETUP
2. CAMERA	SETUP
3. BUZZER	SETUP
4. DATE-TIME	SETUP
5. ALARM	SETUP
6. MOTION	SETUP
<b>7. EVENT</b>	<b>LIST</b>
8. SYSTEM	SETUP

EVENT LIST PAGE		
NO	OCCURED TIME	CH TYPE

Event list.

Menu page display event list such as v-loss, alarm, and motion list.

10 events and 10 pages display. Total 100 entries.

↑↓ Move function item cursor and press ENTER to sub-menu.

Shift and AUTO / QUAD, change to next page.

## 8. SYSTEM SETUP:

### FUNCTION SETUP

- 1. DISPLAY            SETUP
- 2. CAMERA            SETUP
- 3. BUZZER            SETUP
- 4. DATE-TIME        SETUP
- 5. ALARM             SETUP
- 6. MOTION            SETUP
- 7. EVENT             LIST
- 8. SYSTEM            SETUP**

### SYSTEM SETUP PAGE

- 1.DWELL INTERVAL:    SEC
- 2.CLEAN EVENT TABLE
- 3.FACTORY DEFAULT

### SYSTEM SETUP PAGE

- 1. DWELL INTERVAL: 001 ~ 999 SEC

Channel auto sequence time setup.

- 2.CLEAN EVENT TABLE

**\*\* CAUTION    \*\***

ALL EVENT VALUE WILL BE CLEAR,

PRESS [ENTER] TO CLEAR.

PRESS [MENU] TO CANCEL.

- 2. FACTORY DEFAULT: Press ENTER

Back to factory default.

**\*\* CAUTION    \*\***

ALL SETUP VALUE WILL BE CLEAR,

AND RESTORE FACTORY DEFAULT

PRESS [ENTER] TO RESTORE.

PRESS [MENU] TO CANCEL.

↑↓ Move function item cursor and press ENTER to sub-menu.

Shift and AUTO / QUAD, change to next page.