

**SONY®**

# ***VAIO® Computer Quick Start***

**PCG-FRV Series**



# Contents

<b><i>Notice to Users .....</i></b>	<b><i>5</i></b>
<b><i>Setting Up .....</i></b>	<b><i>13</i></b>
Unpacking Your Computer .....	14
Applying Ergonomics .....	15
Locating Controls and Ports .....	16
<b><i>Getting Started .....</i></b>	<b><i>21</i></b>
Turning On Your Computer .....	22
Using the Touch Pad .....	26
Registering Your Computer .....	27
Locating Your VAIO Computer User Guide .....	28
Setting Up A Dial-Up Connection .....	30
Turning Off Your Computer .....	31
<b><i>Expanding Your Computing Power .....</i></b>	<b><i>33</i></b>
Upgrading Memory .....	34
Locating Preinstalled Programs .....	34
<b><i>Caring for Your Computer .....</i></b>	<b><i>35</i></b>
Storing Your Computer .....	36
Using Cables and Connections .....	36

Cleaning Your Computer .....	37
Handling the LCD Screen .....	37
<b><i>VAIO Recovery Options.....</i></b>	<b>39</b>
About Recovery Options .....	40
About the Recovery Media Kit .....	42
Using the VAIO Recovery Wizard .....	46
<b><i>Troubleshooting.....</i></b>	<b>55</b>
Troubleshooting Your Computer .....	56
Troubleshooting the LCD Screen .....	59
Troubleshooting the Mouse and Touch Pad .....	59
Support Options .....	62
<b><i>Index.....</i></b>	<b>65</b>

# Notice to Users

© 2003 Sony Electronics Inc. All rights reserved. This manual and the software described herein, in whole or in part, may not be reproduced, translated, or reduced to any machine-readable form without prior written approval.

SONY ELECTRONICS INC. PROVIDES NO WARRANTY WITH REGARD TO THIS MANUAL, THE SOFTWARE, OR OTHER INFORMATION CONTAINED HEREIN AND HEREBY EXPRESSLY DISCLAIMS ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR ANY PARTICULAR PURPOSE WITH REGARD TO THIS MANUAL, THE SOFTWARE, OR SUCH OTHER INFORMATION. IN NO EVENT SHALL SONY ELECTRONICS INC. BE LIABLE FOR ANY INCIDENTAL, CONSEQUENTIAL, OR SPECIAL DAMAGES, WHETHER BASED ON TORT, CONTRACT, OR OTHERWISE, ARISING OUT OF OR IN CONNECTION WITH THIS MANUAL, THE SOFTWARE, OR OTHER INFORMATION CONTAINED HEREIN OR THE USE THEREOF.

Sony Electronics Inc. reserves the right to make any modification to this manual or the information contained herein at any time without notice. The software described herein is governed by the terms of a separate user license agreement.

This product contains software owned by Sony and licensed by third parties. Use of such software is subject to the terms and conditions of license agreements enclosed with this product. Some of the software may not be

transported or used outside the United States. Software specifications are subject to change without notice and may not necessarily be identical to current retail versions.

Updates and additions to software may require an additional charge. Subscriptions to online service providers may require a fee and credit card information. Financial services may require prior arrangements with participating financial institutions.



As an ENERGY STAR® Partner, Sony Corporation has determined that this product meets the ENERGY STAR® guidelines for energy efficiency.

The International ENERGY STAR® Office Equipment Program is an international program that promotes energy saving through the use of computers and other office equipment. The program backs the development and dissemination of products with functions that effectively reduce energy consumption. It is an open system in which business proprietors can participate voluntarily. The targeted products are office equipment such as computers, displays, printers, facsimiles and copiers. Their standards and logos are uniform among participating nations. ENERGY STAR is a U.S. registered mark.

Sony, DVgate, Handycam, i.LINK, Mavica, MagicGate™ Memory Stick, Memory Stick, MovieShaker, VAIO, and the VAIO logo are trademarks of Sony Corporation. Microsoft, Windows Media, Windows, Windows NT, and the Windows logo are registered trademarks of Microsoft Corporation. Intel, SpeedStep, and Pentium are trademarks or registered trademarks of Intel Corporation. PS/2 is a registered trademark of IBM. Acrobat Reader, Photoshop, Photoshop Elements, and Premiere are trademarks of Adobe Systems Incorporated. PowerPanel is a trademark of Phoenix Technologies Ltd.

This product incorporates copyright protection technology that is protected by method claims of certain U.S. patents and other intellectual property rights owned by Macrovision Corporation and other rights owners. Use of this copyright protection technology must be authorized by Macrovision Corporation, and is intended for home and other limited viewing uses only unless otherwise authorized by Macrovision Corporation. Reverse engineering or disassembly is prohibited. i.LINK is a trademark of Sony used only to designate that a product contains an IEEE 1394 connection. The i.LINK connection may vary, depending on the software applications, operating system, and compatible i.LINK devices. All products with an i.LINK connection may not communicate with each other. Please refer to the documentation that came with your compatible i.LINK device for information on operating conditions and proper connection. Before connecting compatible i.LINK PC peripherals to your system, confirm their operating system compatibility and required operating conditions. All other trademarks are trademarks of their respective owners.

## ***End User / Product Activation Requirements***

Certain software product(s) included with this computer may include features such as copy protection and content management technology. Use of the software product(s) requires agreement to applicable end user agreements and full compliance with applicable product activation procedures. Product activation procedures and privacy policies will be detailed during initial launch of the software product(s), or upon certain reinstallations of the software product(s) or reconfiguration of the computer, and may be completed by Internet or telephone (toll charges may apply).

## ***Owner's Record***

The model number and serial number are located on the bottom of your Sony VAIO® computer. Record the model and serial numbers in the space provided here, and keep in a secure location. Refer to the model and serial numbers when you call your Sony Service Center.  
Model Number: PCG-9J1L, PCG-9J2L, PCG-9J3L  
Serial Number: \_\_\_\_\_

## ***Safety Information***

### **WARNING**

- ☐ To prevent fire or shock hazard, do not expose your computer to rain or moisture.
- ☐ To avoid electrical shock, do not open the cabinet. Refer servicing to qualified personnel only.
- ☐ Never install modem or telephone wiring during a lightning storm.
- ☐ Never install telephone jacks in wet locations unless the jack is specifically designed for wet locations.

- ☐ Never touch uninsulated telephone wire or terminals unless the telephone line has been disconnected at the network interface.
- ☐ Use caution when installing or modifying telephone lines.
- ☐ Avoid using the modem during an electrical storm.
- ☐ Do not use the modem or a telephone to report a gas leak in the vicinity of the leak.
- ☐ A socket outlet should be as close as possible to the unit and easily accessible.
- ☐ i.LINK, PC Card, and USB connectors are not supplied with Limited Power Sources.
- ☐ Pour prévenir tout risque d'électrocution, ne pas ouvrir le châssis de cet appareil et ne confier son entretien qu'à une personne qualifiée.
- ☐ Ne jamais effectuer l'installation de fil modem ou téléphone durant un orage électrique.
- ☐ Ne jamais effectuer l'installation d'une prise téléphonique dans un endroit mouillé à moins que la prise soit conçue à cet effet.
- ☐ Ne jamais toucher un fil téléphonique à découvert ou un terminal à moins que la ligne téléphonique n'ait été débranchée de l'interface réseau.



**To change the backup battery, please contact your nearest Sony Service Center.**

**Caution: The use of optical instruments with this product will increase eye hazard. As the laser beam used in this product is harmful to the eyes, do not attempt to disassemble the cabinet. Refer servicing to qualified personnel only.**

**(For CD-RW/DVD Combo Drive, CD-ROM drive, DVD-ROM drive)**

**Danger: Visible and invisible laser radiation when open. Avoid direct exposure to beam.**

**Caution: To reduce the risk of fire, use only No. 26 AWG or larger telecommunication line cord.**

- ☐ Soyez très prudent lorsque vous installez ou modifiez les lignes téléphoniques.
- ☐ Évitez d'utiliser le modem durant un orage électrique.
- ☐ N'utilisez pas le modem ni le téléphone pour prévenir d'une fuite de gaz quand vous êtes près de la fuite.
- ☐ L'appareil doit être le plus près possible d'une prise murale pour en faciliter l'accès.
- ☐ Des connecteurs i.LINK, PC Card, et USB ne sont pas fournis avec des Sources d'Énergie Limitées.

## AVERTISSEMENT

- ☐ Pour prévenir tout risque d'incendie ou d'électrocution, garder cet appareil à l'abri de la pluie et de l'humidité.



**Pour changer la pile de recharge, veuillez contacter votre centre de service Sony le plus près.**

**Avertissement: L'utilisation d'instruments optiques avec ce produit augmente les risques pour les yeux. Puisque le faisceau laser utilisé dans ce produit est dommageable pour les yeux, ne tentez pas de désassembler le boîtier. Adressez-vous à un agent de service qualifié.**

**(Pour le lecteur Combo de CD-RW/DVD, le lecteur CD-ROM, le lecteur DVD-ROM) Danger: Radiation laser visible et invisible si ouvert. Évitez l'exposition directe au faisceau.**

**Attention : Afin de réduire les risques d'incendie, n'utilisez qu'un cordon de communication NO. 26 AWG ou plus gros.**

If you have questions about this product, you can write to the Sony Customer Information Service Center at 12451 Gateway Blvd., Ft. Myers, FL 33913 or find Sony Customer Service on the Web at: <http://www.sony.com/pcsupport>.

## Regulatory Information

### Declaration of Conformity

Trade Name:	Sony
Model No.:	PCG-9J1L PCG-9J2L PCG-9J3L
Responsible Party:	Sony Electronics Inc.

Address: 680 Kinderkamack Road  
Oradell, NJ 07649

Telephone: 201-930-6972  
(For FCC-related matters only.)

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be

determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- ☐ Reorient or relocate the receiving antenna.
- ☐ Increase the separation between the equipment and the receiver.
- ☐ Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.



- ❑ Consult the dealer or an experienced radio/TV technician for help.

You are cautioned that any changes or modifications to the computer not expressly approved in this manual could void your authority to operate this equipment.

Only peripherals (computer input/output devices, terminals, printers, etc.) that comply with FCC Class B limits may be attached to this computer product. Operation with non-compliant peripherals is likely to result in interference to radio and television reception.

All cables used to connect peripherals must be shielded and grounded. Operation with cables connected to peripherals that are not shielded and grounded may result in interference to radio and television reception.

## **FCC Part 68**

This equipment complies with Part 68 of the FCC rules and the requirements adopted by the ACTA. On the bottom of this equipment is a label that contains, among other information, a product identifier in the format US:AAAEQ##TXXXX. If requested, this information must be provided to the telephone company.

This modem uses the USOC RJ11C telephone jack.

A telephone plug and jack used to connect this equipment to the premises wiring and telephone network must comply with the applicable FCC Part 68 rules and requirements adopted by the ACTA.

The REN is used to determine the number of devices which may be connected to the telephone line. Excessive RENs on a telephone line may result in the devices not ringing in response to an incoming call. In most, but not all areas, the sum of RENs should not exceed five (5.0). To be certain of the number of devices that may be connected to a line, as

determined by the total RENs, contact the telephone company. For products approved after July 23, 2001, the REN for this product is part of the product identifier that has the format US:AAAEQ##TXXXX. The digits represented by ## are the REN without a decimal point (e.g., 03 is a REN of 0.3). For earlier products, the REN is separately shown on the label.

If this equipment causes harm to the telephone network, the telephone company will notify you in advance that temporary discontinuance of service may be required. But if advance notice is not practical, the telephone company will notify the customer as soon as possible. Also, you will be advised of your right to file a complaint with the FCC if you believe it is necessary.

The telephone company may make changes in its facilities, equipment, operations, or procedures that could affect the operation of the equipment. If this happens, the telephone company will provide advance notice in order for you to make the necessary modifications in order to maintain uninterrupted service.

If trouble is experienced with this equipment, for repair or warranty information, please contact 1-888-4-SONY-PC (1-888-476-6972), or write to the Sony Customer Information Service Center, One Sony Drive, Park Ridge, NJ 07656. Repair of this equipment should be made only by a Sony Service Center or Sony authorized agent. If the equipment is causing harm to the telephone network, the telephone company may request that you disconnect the equipment until the problem is resolved.

Connection to party line service is subject to state tariffs. Contact the state public utility commission, public service commission, or corporation commission for information.

If your home has specially wired alarm equipment connected to the telephone line, ensure the installation of this equipment does not disable your alarm equipment. If you have questions about what will disable alarm

equipment, consult your telephone company or a qualified installer.

Use a surge arrestor to protect against electrical surges.

### **Telephone Consumer Protection Act of 1991 (United States)**

The Telephone Consumer Protection Act of 1991 makes it unlawful for any person to use a computer or other electronic device, including FAX machines, to send any message unless such message clearly contains in a margin at the top or bottom of each transmitted page or on the first page of the transmission, the date and time it is sent and an identification of the business or other entity, or other individual sending the message, and the telephone number of the sending machine or such business, other entity, or individual. (The telephone number provided may not be a 900 number or any other number for which charges exceed local or long-distance transmission charges.)

In order to program this information into your facsimile machine, see your fax software documentation.

### **Telephone Consumer Guidelines (Canada)**

Please refer to your telephone directory under 'Privacy Issues' and/or 'Terms of Service.' For more detailed information, please contact:

CRTC

Terrasses de la Chaudière, Tour centrale  
1 promenade du Portage, 5 étage Hull  
PQ K1A 0N2.

This Class B digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

## **RECYCLING LITHIUM ION BATTERIES**

### **RECYCLING LITHIUM-ION BATTERIES**

Lithium-Ion batteries are recyclable.

You can help preserve our environment by returning your used rechargeable batteries to the collection and recycling location nearest you.

For more information regarding recycling of rechargeable batteries, call toll free 1-800-822-8837, or visit <http://www.rbrc.org/>.

Caution: Do not handle damaged or leaking Lithium-Ion batteries.



## **RECYCLAGE DES ACCUMULATEURS AUX IONS DE LITHIUM**

### **RECYCLAGE DES ACCUMULATEURS AUX IONS DE LITHIUM**

Les accumulateurs  
aux ions de lithium  
sont recyclables.

Vous pouvez  
contribuer à  
préserver  
l'environnement en  
rapportant les piles  
usées dans un point  
de collection et  
recyclage le plus  
proche.

Pour plus d'informations sur le recyclage  
des accumulateurs, téléphonez le numéro  
gratuit 1-800-822-8837 (Etats-Unis et  
Canada uniquement), ou visitez  
<http://www.rbrc.org/>.

Avertissement: Ne pas utiliser des  
accumulateurs aux ions de lithium qui sont  
endommagés ou qui fuient.



Do not handle damaged or leaking  
lithium ion batteries.

Danger of explosion if battery is  
incorrectly replaced. Replace  
only with the same or equivalent  
type recommended by the  
manufacturer. Discard used  
batteries according to the  
manufacturer's instructions.

The battery pack used in this  
device may present a fire or  
chemical burn hazard if  
mistreated. Do not disassemble,  
heat above 140°F (60°C) or  
incinerate. Dispose of used  
battery promptly. Keep away from  
children.

Ne pas utiliser des batteries au  
lithium ionisé qui sont  
endommagées ou qui fuient.

Une batterie non conforme  
présente un danger d'explosion.  
La remplacer seulement par une  
batterie identique ou de type  
équivalent recommandé par le  
fabricant. Évacuer les batteries  
usées selon les directives du  
fabricant.

La manutention incorrecte du  
module de batterie de cet  
appareil présente un risque  
d'incendie ou de brûlures  
chimiques. Ne pas démonter,  
incinérer ou exposer à une  
température de plus de 60°C.  
Évacuer promptement la batterie  
usée. Garder hors de portée des  
enfants.

## **INDUSTRY CANADA NOTICE**

NOTICE: This equipment meets the applicable Industry Canada Terminal Equipment Technical Specifications.

The Ringer Equivalence Number (REN) for this terminal equipment is 0.2. The REN assigned to each terminal equipment provides an indication of the maximum number of terminals allowed to be connected to a telephone interface. The termination on an interface may consist of any combination of devices subject only to the requirement that the sum of the Ringer Equivalence Numbers of all the devices does not exceed five.

## **AVIS DE L'INDUSTRIE CANADA**

REMARQUE: Cet équipement est conforme aux Spécifications Techniques des Équipements Terminaux d'Industrie Canada en vigueur.

Le Nombre Équivalent de Sonneries (REN) de cet équipement terminal est 0,2. Le REN attribué à chaque équipement terminal indique le nombre maximum de terminaux que l'on peut connecter à une interface téléphonique. Il est possible de raccorder à une interface plusieurs combinaisons d'appareils, mais la somme des Nombres Équivalents de Sonneries de tous ces appareils ne doit pas dépasser cinq.

# Setting Up

*Congratulations on your purchase of the Sony VAIO® computer. Sony has combined leading-edge technology in audio, video, computing, and communications to provide state-of-the-art personal computing.*


- ❑ Unpacking Your Computer
- ❑ Applying Ergonomics
- ❑ Locating Controls and Ports

## ***Unpacking Your Computer***


### ***Main Unit***




***Power Cord***



***AC Adapter***



***Rechargeable Battery***



### ***Documents***

- ❑ **VAIO® Computer User Guide** — A searchable on-screen help file that contains detailed information on how to use your new computer. See “Locating Your VAIO Computer User Guide” on page 28 for more information.
- ❑ **VAIO® Computer Quick Start** — Contains information on unpacking and setting up your computer for immediate use.
- ❑ **VAIO® Computer Specifications** — An on-screen file that details the hardware specifications and lists the installed programs on your computer. See “Locating Your VAIO Computer User Guide” on page 28 for more information.
- ❑ **Microsoft® Windows® guide** — Explains how to use the basic features of the Microsoft® Windows® operating system installed on your computer.


## ***Applying Ergonomics***

Your computer is a portable device and can be used in a variety of environments. Whenever possible, you should apply the following ergonomic considerations:

- ❑ **Position of your computer** — Place the computer directly in front of you as you work. Keep your forearms horizontal, with your wrists in a neutral, comfortable position while using the keyboard, touch pad, or external mouse. Let your upper arms hang naturally at your sides. Take breaks during sessions with your computer. Excessive use of the computer may strain muscles or tendons.
- ❑ **Furniture and posture** — Sit in a chair with good back support and armrests. Adjust the level of the chair so your feet are flat on the floor. A footrest may make you more comfortable. Sit in a relaxed, upright posture and avoid slouching forward or leaning far backward.
- ❑ **Viewing angle of the computer's display** — Tilt the display to find the best viewing angle. Also try adjusting the brightness setting of the display. Following these suggestions can reduce eye strain and muscle fatigue.
- ❑ **Lighting** — Choose a location where windows and lights do not create glare or reflection on the display. Use indirect lighting to avoid bright spots on the display. You can purchase accessories for your display that help reduce glare. Proper lighting adds to your comfort and work effectiveness.
- ❑ **Placement of an external display** — When using an external display, set the display at a comfortable viewing distance. Make sure the display screen is at eye level or slightly lower when you are sitting in front of the monitor.

## Locating Controls and Ports


### Front



1	Power indicator	8	Left and right buttons
2	Battery indicator	9	Touch pad
3	Power button	10	Memory Stick® media indicator
4	Scroll lock indicator	11	Keyboard
5	Caps lock indicator	12	Model name
6	Num lock indicator	13	Speakers
7	Hard disk drive indicator	14	Computer screen (LCD)




Back




1	Modem jack	4	Parallel (printer) port
2	Network (Ethernet) port	5	Air vent
3	Monitor (VGA) port	6	USB 2.0 ports (high-/full-/low-speed supported)

**Left**




1	2 USB 2.0 ports (high-/full-/low-speed supported)	5	i.LINK® (IEEE 1394) S400 port
2	A/V OUT jack	6	Air vent
3	Microphone jack	7	PC Card slots
4	Headphone jack	8	Memory Stick® media slot



**Only connect 10BASE-T or 100BASE-TX cables to the  Network (Ethernet) port. Do not connect any other type of network cable or any telephone line to this port. Connecting cables other than those listed above may result in an electric current overload and could cause a malfunction, excessive heat, or fire in the port. To connect the unit to a network, refer to your online VAIO® Computer User Guide or contact your network administrator. See “Locating Your VAIO Computer User Guide” for more information.**

***Right***



---

**1** DC IN port

**2** EJECT button


---

**3** Optical drive

**4** Battery bay

---

***Bottom***



- 
- 1**      Reset button
-

# Getting Started

*This section helps you get your computer running and registered, so you can take advantage of Sony's many support options. You'll also learn how to locate your on-screen VAIO® Computer User Guide, which contains step-by-step instructions for operating your computer.*

- ❑ Turning On Your Computer
- ❑ Using the Touch Pad
- ❑ Registering Your Computer
- ❑ Locating Your VAIO Computer User Guide
- ❑ Setting Up A Dial-Up Connection
- ❑ Turning Off Your Computer


## ***Turning On Your Computer***

To use your computer immediately, use the supplied AC adapter as a power source. Your supplied battery is not charged when you unpack it, however, you can begin charging it when you use your AC adapter. See “Powering Your Computer” in your on-screen VAIO® Computer User Guide for more information about using batteries. See also “Locating Your VAIO Computer User Guide” on page 28.

### ***To charge the battery***


- 1 Push the battery bay cover down to open it. The battery bay cover swings out but does not detach from the computer.

### ***Opening the Battery Bay***




- 2 Slide the battery (with the logo facing up) into the battery bay. If the computer is on, it automatically detects the battery.

### *Inserting the Battery*




- 3 Push the battery bay cover up until it clicks into place.
- 4 Connect the AC adapter to the computer. See “To connect the AC adapter.”

Once you connect the AC adapter to the computer, the battery begins to charge whether the computer is on or off. The battery indicator  shows the battery status. The indicator blinks as the battery charges. See “Powering Your Computer” in your on-screen VAIO® Computer User Guide for more information.

### ***To connect the AC adapter***

- 1 Plug the AC adapter cable into the DC IN port.

### ***Connecting the AC Adapter to the Computer***



- 2 Plug the power cord into the AC adapter and an AC outlet.




Use only the supplied AC adapter with your computer.

### ***To open and turn on the computer***

- 1 Slide the release latch to the right and lift the cover while holding the bottom of the computer firmly.





### Opening the Computer



- 2 Press the power button until the power indicator turns on.

### Turning on the Computer



 If you hold down the power button, the computer turns off.


- 3 To increase brightness of the computer screen, press the **Fn+F5** keys, and then press **↑** or **→**.  
To decrease brightness, press the **Fn+F5** keys, and then press **↓** or **←**.

# Using the Touch Pad

The computer contains a pointing device called a touch pad. You can point to, select, drag, and scroll objects on the screen using the built-in touch pad.

## Describing the touch pad

### Locating the Touch Pad



<i><b>Touch Pad Action</b></i>	<i><b>Description</b></i>
Sliding one finger	Equivalent to using a mouse to place the pointer on an item.
Tapping once	Equivalent to pressing the left button once.
Tapping twice	Equivalent to pressing the left button twice.

<b><i>Touch Pad Action</i></b>	<b><i>Description</i></b>
Sliding one finger while pressing the left button	Equivalent to using the mouse to drag an item.
Moving your finger along the right edge of the touch pad	Equivalent to scrolling vertically. (The scroll function is available only with programs that support a touch pad scroll feature.)
Moving your finger along the bottom to scroll horizontally	Equivalent to scrolling horizontally. (The scroll function is available only with programs that support a touch pad scroll feature.)

## ***Registering Your Computer***



You are prompted to register your computer the first time you turn on the unit. Follow the on-screen instructions to complete the registration process. If you are not able to register your computer during the first session, you are provided with additional registration opportunities later.

Take advantage of Sony's commitment to quality customer support and receive these benefits by registering your computer:

- ☐ Sony Customer Support — Talk to a support representative to troubleshoot problems you may have with your computer.
- ☐ Limited Warranty Extension — Protect your investment. See the Warranty Card for more details.
- ☐ Product Information Notification — By giving Sony your contact information, you will enable Sony to reach you regarding performance updates and upgrades.

## Locating Your VAIO Computer User Guide


The on-screen VAIO® Computer User Guide is a searchable help file that contains detailed information on how to use your new computer. Some of the topics in your on-screen VAIO® Computer User Guide include the following:

- Batteries
- Internet and Networking
- CDs and DVDs
- Printing
- Features
- Mice and Keyboards
- PC Cards and Floppy Disks
- Optical Drives
- Port Replicators (if applicable)
- Audio/Video
- Memory

### To open the user guide


- 1 Click **Start** on the Windows® taskbar, and then click **Help and Support**. The **Help and Support Center** window appears, displaying information about your VAIO® computer and Microsoft® Windows® operating system.

### Locating the VAIO User Guide



- Click **VAIO User Guide** in the **Pick a Help topic** column. A second **Help and Support Center** window appears, which offers information about your computer.

### VAIO User Guide Window



1	User guide table of contents	List of computer help topics
2	Link to the Electronic Flyer	List of updates and supplemental information
3	Link to the VAIO Computer Specifications	List of specifications and programs.

## Setting Up A Dial-Up Connection

This section describes the basic steps for setting up your dial-up connection. The Connection Wizard guides you through the process of choosing an Internet Service Provider (ISP) or setting up an existing account, and connecting to the Internet.

### To set up a dial-up connection

- 1 Connect a telephone cable to your computer. See “Setting up a dial-up Internet connection” in the Internet and Network Connections chapter of your on-screen VAIO® Computer User Guide.
- 2 Click **Start**, point to **All Programs, Accessories, Communications**, and then click **New Connection Wizard**. The **New Connection Wizard** appears.

### New Connection Wizard



- 3 Click **Next**.
- 4 If it is not already selected, click to select **Connect to the Internet**, and click **Next**.
- 5 Follow the on-screen instructions.

## ***Turning Off Your Computer***

Using the power button to turn off your computer may result in loss of data. Follow the steps below to properly turn off your computer and avoid losing data.

### ***To turn off your computer***

- 1 Close all operations.
- 2 Click **Start** on the Windows® taskbar.
- 3 Click **Turn Off Computer** at the bottom of the **Start** menu to display the **Turn off computer** window, and select **Turn Off**.



Respond to any prompts warning you to save documents.

- 4 Wait for your computer to turn off automatically. The computer is off when the power indicator turns off.



If you are still unable to turn off the computer, press and hold the power button until the power indicator turns off. This operation may result in data loss.





# *Expanding Your Computing Power*

*This section helps you get started upgrading computer memory and locating information about preinstalled programs.*

- ❑ Upgrading Memory
- ❑ Locating Preinstalled Programs

## ***Upgrading Memory***

Depending on the configuration you purchased, your computer may accept additional memory modules. For information about installation procedures, refer to the on-screen VAIO® Computer User Guide and print those relevant steps. See “Locating Your VAIO Computer User Guide” on page 28.

The on-screen specifications supplied with your computer list the amount of installed memory and required memory modules for upgrades.

## ***Locating Preinstalled Programs***

Your computer comes with a variety of preinstalled audio/video programs. The following sources offer a list of preinstalled programs, descriptions, and information:

- ❑ **VAIO® Computer User Guide** — The Preinstalled Programs chapter of your on-screen VAIO® Computer User Guide contains a list of programs, descriptions, and support information. See “Locating Your VAIO Computer User Guide” on page 28 for more information.
- ❑ **VAIO® Computer Specifications** — The on-screen file details your computer’s hardware specifications and lists preinstalled programs, descriptions, and support information. See “Locating Your VAIO Computer User Guide” on page 28 for more information.
- ❑ **All Programs** — The All Programs menu, which you can access from the Start menu, contains a list of all the preinstalled programs on your computer.

# *Caring for Your Computer*

*This section provides information on how to safely use your Sony computer.*

- ☐ Storing Your Computer
- ☐ Using Cables and Connections
- ☐ Cleaning Your Computer
- ☐ Handling the LCD Screen

## ***Storing Your Computer***

- ❑ Do not use or store your computer in a location subject to:
  - ❑ Heat sources, such as radiators or air ducts
  - ❑ Direct sunlight
  - ❑ Excessive dust
  - ❑ Moisture or rain
  - ❑ Mechanical vibration or shock
  - ❑ Strong magnets or speakers that are not magnetically shielded
  - ❑ Ambient temperature higher than 95°F (35°C) or less than 40°F (5°C)
  - ❑ High humidity
- ❑ Do not place electronic equipment near your computer. When running, the computer's electromagnetic field may cause other electronic equipment in close proximity to malfunction.
- ❑ Provide adequate air circulation to prevent internal heat buildup. Do not place your computer on porous surfaces such as rugs or blankets, or near materials such as curtains or draperies that may block ventilation. Leave a space of at least 8 inches (20 cm) behind the back of the computer.
- ❑ If the computer is brought directly from a cold location to a warm one, moisture may condense inside your computer. In this case, allow at least one hour before turning on your computer. If any problems occur, unplug your computer, and contact your Sony Service Center.
- ❑ The computer uses high-frequency radio signals and may interfere with radio or TV reception. Should this occur, move the computer a suitable distance away from the radio or TV.
- ❑ Do not drop the computer or place heavy objects on top of the computer.

## ***Using Cables and Connections***

- ❑ Use only specified peripheral equipment and interface cables.
- ❑ Do not use cut or damaged connection cables.
- ❑ If the telephone company makes a service call to your home or office and determines that your computer is responsible for a problem, the telephone company may bill you for the service call. Also, if you do not disconnect your computer when it is adversely affecting a telephone line, the telephone

company has the right to disconnect your service until you correct the problem.

## ***Cleaning Your Computer***

- ❑ Clean the computer with a soft, dry cloth or a soft cloth lightly moistened with a mild detergent solution. Do not use any type of abrasive pad, scouring powder, or solvent such as alcohol or benzine, as these may damage the finish of your computer. You can use canned compressed air specifically for computers to remove dust.
- ❑ If a solid object falls onto the computer or a liquid leaks into the computer, immediately turn off and unplug the computer. It is best to have the computer checked by qualified personnel before you use it again.
- ❑ Avoid rubbing the LCD screen as this can damage the screen. Use a soft, dry cloth to wipe the LCD screen or canned compressed air.
- ❑ Always disconnect the power cord before cleaning the computer.

## ***Handling the LCD Screen***

- ❑ Direct sunlight can damage the LCD. Be careful when using the computer near a window.
- ❑ Do not scratch the LCD or exert pressure on it. This can cause a malfunction.
- ❑ Using the computer in low temperature conditions may produce a residual image on the screen. This is not a malfunction. When the computer returns to normal temperature, the screen returns to normal.
- ❑ The screen becomes warm during operation. This is normal and does not indicate a malfunction.
- ❑ The LCD is manufactured using high-precision technology. You may, however, see tiny black points and/or bright points (red, blue, or green) that continuously appear on the LCD. This is a normal result of the manufacturing process and does not indicate a malfunction.



# VAIO Recovery Options

*(For Windows® XP models only) The VAIO® Recovery Wizard enables you to recover preinstalled software programs and the operating system on your computer. You can also use this utility to create a Recovery Media Kit. The Recovery Media Kit enables you to reclaim hard drive space and return your computer to normal operation.*



This program repairs or replaces software. For any hardware problems, contact a Sony authorized repair facility.

- ☐ *About Recovery Options*
- ☐ *About the Recovery Media Kit*
- ☐ *Using the VAIO Recovery Wizard*

## About Recovery Options

You have several options when recovering software or your computer's operating system.



**When you recover drive C, drive D, or perform a complete recovery, the VAIO Recovery Wizard deletes and replaces all the files on the selected drives.**

**Sony recommends backing up your personal data to storage media or to another computer before proceeding with system recovery.**

### Accessing the VAIO Recovery Wizard

You can start the VAIO Recovery Wizard utility from the Microsoft® Windows® XP Start menu, from the Recovery Media Kit, or from using the F10 key<sup>1</sup> on notebook computers. Depending on how you access the VAIO Recovery Wizard, you have different system and software recovery options.

#### System and software recovery options

##### ☐ Create the Recovery Media Kit

You can create a Recovery Media Kit, consisting of CDs and DVDs, which enable you to recover your computer at a later date if the software stops working properly. You can start the VAIO Recovery Wizard from the Windows XP Start menu, and create a Recovery Media Kit.

##### ☐ Windows® System Restore

Return your computer's operating system to a previous working state by performing a System Restore. You can access this recovery option by starting the VAIO Recovery Wizard, or by using the Windows XP System Restore Wizard.

##### ☐ Recover drive C

Returns the drive C to its original factory-installed settings. All previous data and settings on drive C are deleted. You can preserve data on other partitions, such as drive D. To recover drive C, access the VAIO Recovery Wizard from the Windows XP Start menu, the Recovery Media Kit, or by using the F10 key on notebook computers.

##### ☐ Recover drives C and D

Return drives C and D to their original factory-installed settings. With this

---

<sup>1</sup> This feature is available for VAIO® notebook computers only.



option, you lose all data and settings on both drives. To recover drives C and D, start the VAIO Recovery Wizard from the Windows XP Start menu, the Recovery Media Kit, or by using the F10 key on notebook computers.

 Recovering drives C and D with the Recovery Media Kit is the only way to restore the hidden recovery drive.

☐ **Recover software programs**

Recover specific factory-installed software. To recover the original software programs, start the VAIO Recovery Wizard from the Windows XP Start menu or from the Recovery Media Kit. You can access this option by using **Disc 1** from your Recovery Media Kit.

☐ **Perform a complete hard disk drive recovery**

Completely recover your computer's hard disk drive. This option recovers drives C and D, and the hidden recovery drive. To perform a complete hard disk drive recovery, start the VAIO Recovery Wizard from your Recovery Media Kit.

## **About the Recovery Media Kit**

The Recovery Media Kit is created using your own CDs and/or DVDs. You can create the Recovery Media Kit, or purchase it from Sony.

### **Recovery Media Kit overview**

Confirm that you have sufficient CD and/or DVD recordable media available before you begin creating the Recovery Media Kit. You should also have a permanent marking pen ready, to label each CD and/or DVD media. You can create your kit using a single type of media or by combining media types, as follows:

- ☐ One recordable CD (CD-R) and up to two recordable DVDs (DVD-R or DVD+R)  
(Your VAIO® computer must be equipped with a DVD-RW<sup>1</sup> or DVD±RW drive.)
- ☐ Up to 12 recordable CDs (CD-R)  
(Your VAIO computer must be equipped with a CD-RW drive.)

Before you begin creating the Recovery Media Kit, prepare your computer for the process, as follows:

- ☐ Close all open programs.
- ☐ Disconnect all network connections.
- ☐ Disconnect all peripheral devices.
- ☐ Do not interrupt the power.
- ☐ Disable any virus protection software.
- ☐ Disable your screen saver.

### **Creating the Recovery Media Kit**

The Recovery Media Kit can be used to start the VAIO Recovery Wizard, in the event your system is unable to start normally. You can reclaim the portion of your hard drive that is allocated to system recovery using the Recovery Media Kit.


---

<sup>1</sup> A DVD-RW drive supports DVD-R media only.


### ***To create the Recovery Media Kit***

- 1 Click **Start** in the Windows® taskbar, point to **All Programs**, and then click the **VAIO® Recovery Wizard**.

The VAIO Recovery Wizard appears.

 You can start the VAIO Recovery Wizard by double-clicking the VAIO Recovery Wizard icon in the Windows taskbar notification area.

### ***The VAIO Recovery Wizard***



- 2 Read the on-screen information. Click **Next**.
- 3 Select **Create Recovery Media Kit (Strongly Recommended)**, and click **Next**.

## VAIO Recovery Wizard — Selecting Create Recovery Media Kit



- 4 Select the Recovery Media Kit that you want to create.

You can create your kit using a single type of media or by combining media types, as follows:

- ☐ One recordable CD (CD-R) and up to two recordable DVDs (DVD-R or DVD+R)  
(Your VAIO® computer must be equipped with a DVD-RW<sup>1</sup> or DVD±RW drive.)
- ☐ Up to 12 recordable CDs (CD-R)  
(Your VAIO computer must be equipped with a CD-RW drive.)


- 5 Click **Next**. Your computer's optical drive tray opens automatically.

- 6 Insert a blank disc into the drive and close the drive. Click **Next**.

The CD creation process begins. A window with a progress bar appears.

---


<sup>1</sup> A DVD-RW drive supports DVD-R media only.

 The time required to create each CD or DVD may vary, depending on your optical drive's recording speed.

- 7 When prompted, eject the disc. Label the top of the disc with a permanent marker according to the on-screen instructions.
- 8 Repeat steps step 6 through step 7 for each CD or DVD.
- 9 When the text, **The Recovery Media Kit is complete** appears, click **OK**.
- 10 Click **Finish**. Store the Recovery Media Kit in a safe location.

### ***To order the Recovery Media Kit***

- 1 Go to the Sony Direct Accessories and Parts Center Web site at <http://servicesales.sel.sony.com>.
- 2 Enter your computer's model number (for example, PCV-XXX), and click **List Parts and accessories**.
- 3 Follow the online instructions to order the Recovery Media Kit.

 If you are not able to access the Sony Direct Accessories and Parts Center Web site, contact a customer service representative at 1-800-488-7669.

## ***Using the VAIO Recovery Wizard***

The VAIO® Recovery Wizard provides recovery options for your computer. You can access this tool from Windows® XP Start menu, your Recovery Media Kit, or by pressing the F10 key<sup>1</sup> on your notebook computer.

### ***Starting the VAIO Recovery Wizard***

#### ***To access the VAIO Recovery Wizard from Windows XP***

- 1 Click **Start** in the Windows® taskbar, point to **All Programs**, and click **VAIO Recovery Wizard**.



Using the VAIO Recovery Wizard may require you to restart your computer, even if you cancel and exit the wizard.

- 2 From the **Welcome** window, click **Next**.
- 3 Choose one of the available menu options.

#### ***To access the VAIO Recovery Wizard from the Recovery Media Kit***

- 1 Press the power switch on the computer to turn on the power.
- 2 Open the optical drive, and place the **Startup Recovery Disc** in the optical drive.
- 3 Close the drive.
- 4 Turn off your computer.
- 5 Wait for approximately 30 seconds, and then turn on the computer.
- 6 When prompted, insert the **Recovery Disk 1** into the optical drive, and then click **OK**.

The VAIO Recovery Wizard appears.

- 7 Click **Next**.
- 8 Choose one of the available menu options.

---

<sup>1</sup> This feature is available for VAIO® notebook computers only.

***To start the VAIO Recovery Wizard using the F10 Key (for notebook computers only)***

- 1 Turn off your notebook computer.
- 2 Press the power switch on the computer to turn on the power.
- 3 When you see the VAIO logo appear on the computer's screen, briefly press the **F10** key.
- 4 Click **Next**.
- 5 Choose one of the available menu options.

***Using the VAIO Recovery Wizard***

***To use Windows System Restore from the VAIO Recovery Wizard***

- 1 Start the VAIO® Recovery Wizard, and click **Next**.
- 2 Select **Proceed with System Recovery**, and click **Next**.
- 3 Select **Windows® System Restore**, and click **Next**.
- 4 Follow the on-screen instructions.

## *VAIO Recovery Wizard — Selecting Windows System Restore*



### *To recover drive C*

- 1 Start the VAIO Recovery Wizard, and click **Next**.
- 2 Select **Proceed with System Recovery**, and click **Next**.  
If using the Recovery Media Kit, skip this step.
- 3 Select **C Drive Recovery**, and click **Next**.



***VAIO Recovery Wizard — Selecting C Drive Recovery***

- 4 Read the on-screen information. Click **Next**.
- 5 The wizard begins the drive C recovery. When it is finished, click **Next**.
- 6 Click **Finish**. Your computer restarts.

***To recover drives C and D (and reclaim all space on the hard disk drive)***

- 1 Start the VAIO® Recovery Wizard, and click **Next**.
- 2 Select **Proceed with System Recovery**, and click **Next**.  
(If you are using the Recovery Media Kit, skip step 2.)
- 3 Select **Custom Recovery (for Advanced Users)**, and click **Next**.
- 4 Select **C and D Drive Recovery**, and click **Next**.

If you are using the Recovery Media Kit, you have two choices for this recovery option:

- ☐ **Keep the Recovery Drive (Recommended)**

- ☐ **Remove the Recovery Drive.**

### *VAIO Recovery Wizard — Selecting the C and D Drive Recovery option*



- 5 Choose the size of drive C. Any remaining disk space is allocated to drive D (minus the space allocated for the recovery drive). Click **Next**.

 Computers that come equipped with Giga Pocket software do not allow you to set the drive D to zero.


- 6 The wizard starts implementing recovery. When it is finished, click **Next**.
- 7 Click **Finish**, and the computer restarts.

### ***To recover software applications***

- 1 Start the VAIO® Recovery Wizard, and click **Next**.
- 2 Select **Proceed with System Recovery**, and click **Next**.

If using the Recovery Media Kit, skip this step.

- 3 Select **Custom Recovery (for Advanced Users)**, and click **Next**.

 If you select the Application Recovery option, you cannot return to the system recovery portion of the VAIO® Recovery Wizard without restarting your computer.

- 4 Select **Application Recovery**, and click **Next**.


### *VAIO Recovery Wizard — Selecting Application Recovery*



- 5 Click to select the check box for each software program you want to recover. Click **Next**.

You may need to use the scrollbar to view all available software programs.


## VAIO Recovery Wizard — Selecting applications



- 6 As your computer prepares to install each application, a status indicator appears. You may see installation wizards, messages, and prompts. Follow the instructions provided in each wizard, and respond to each prompt or message.

When the selected software has been recovered, the **Application Recovery Complete** window appears.

- 7 If you want to recover additional software, click **Back**. The **Application Recovery** window appears with a listing of the available software titles.
- 8 Click **Finish**. Your computer restarts.

 If the recovered software does not function properly or you see an installation error message, try recovering the software again.

### ***To perform a complete hard disk drive recovery***

You must use the Recovery Media Kit to perform a complete hard disk drive recovery.

- 1 Press the power switch on the computer to turn on the power.
- 2 Open the optical drive, and place the **Startup Recovery Disc** in the optical drive.
- 3 Close the drive.
- 4 Turn off your computer.
- 5 Wait for approximately 30 seconds, and then turn on the computer.
- 6 When prompted, insert the **Recovery Disk 1** into the optical drive, and then click **OK**.

The VAIO Recovery Wizard appears.

- 7 Click **Next**.
- 8 Select **Custom Recovery (for Advanced Users)**, and click **Next**.
- 9 Select **Complete Recovery**, and click **Next**.
- 10 You may see installation wizards, messages, and prompts. Follow the instructions provided in each wizard, and respond to each prompt or message. Your computer may restart.
- 11 When the optical drive ejects, remove the disc. Close the drive, and click **Next**. Your computer may restart several times.

### ***Additional Information***

- ❑ Certain software, such as DVgate™ Plus software, automatically saves data to drive D. If you choose not to have a drive D partition, you must change the software settings to enable file saving to drive C.
- ❑ Resizing your hard disk drive partitions with third-party software programs can result in the loss of the VAIO® Recovery Wizard.
- ❑ Giga Pocket™ software requires a drive D in order to operate. For VAIO® computers with Giga Pocket software preinstalled, you cannot set the drive D size to zero.



# Troubleshooting

*This section describes how to solve some basic problems you may encounter when using your computer. For more troubleshooting topics refer to the VAIO® Computer User Guide. Many problems have simple solutions, so refer to these sources before you contact Sony Computing Support (<http://www.sony.com/pcsupport>).*

- ☐ Troubleshooting Your Computer
- ☐ Troubleshooting the LCD Screen
- ☐ Troubleshooting the Mouse and Touch Pad
- ☐ Support Options

## ***Troubleshooting Your Computer***

### ***Why doesn't my computer start?***

- ❑ Make sure the computer is securely plugged into a power source and is on. Make sure the power indicator shows the power is on. See “Turning On Your Computer” on page 22 for more information.
- ❑ Make sure the battery is inserted properly and is charged.
- ❑ If the computer is connected to an external floppy disk drive, make sure the floppy disk drive is empty.
- ❑ If the computer is plugged into a power strip or Uninterruptible Power Supply (UPS), make sure the power strip or UPS is turned on and working.
- ❑ If you are using an external display, make sure it is plugged into a power source and turned on. Make sure the brightness and contrast controls are adjusted correctly. See the guide that came with your display for details.
- ❑ Remove the AC adapter and battery. Wait one minute. Reattach the AC adapter and reinsert the battery, and turn on the power.
- ❑ Condensation may cause the computer to malfunction. If this occurs, do not use the computer for at least one hour.
- ❑ If the computer still does not turn on, follow these steps:
  - 1 Unplug the power cord and remove the battery.
  - 2 Use a thin, straight object (such as a paper clip) to press the reset button. The reset button is located on the bottom of the computer. See “Locating Controls and Ports” on page 16 for more information.
  - 3 Reinsert the power cord and the battery.
  - 4 Turn on the computer.


### ***Why does a BIOS error appear when my computer starts?***

If the message “Press <F1> to resume, <F2> to setup” appears at the bottom of the screen, follow these steps:

- 1 Press **F2**. The **BIOS Setup** menu appears.
- 2 Set the date (month/day/year). Press **Enter**.



- 3 Press the **Down Arrow** key ↓ to select **System Time**, and then set the time (hour: minute: second). Press **Enter**.
- 4 Press the **Right Arrow** key → to select the **Exit** tab, and then press the **Down Arrow** key ↓ to select **Get Default Values**.
- 5 Press **Enter**. The **Setup Confirmation** window appears.
- 6 Select **Yes**, and press **Enter**.
- 7 Select **Exit (Save Changes)**, and press **Enter**. The **Setup Confirmation** window appears again.
- 8 Select **Yes**, and press **Enter**. The computer restarts.

 If this occurs on a regular basis, contact Sony Computing Support (<http://www.sony.com/pcsupport>).

***Why does the message, “Operating system not found” appear when my computer starts, and why won’t Windows start?***

- ☐ If you have connected an external floppy disk drive to the computer, make sure there is no disk in the floppy disk drive (non-bootable).
- ☐ If a non-bootable floppy disk is in the drive, follow these steps:
  - 1 Turn off the computer, and remove the floppy disk.
  - 2 Restart the computer and confirm that the Windows® operating system starts properly.
- ☐ If Windows still does not start, follow these steps to initialize the BIOS:
  - 1 Remove any floppy disk from the floppy disk drive.
  - 2 Turn off the computer.
  - 3 Remove any peripheral devices connected to the computer.
  - 4 Restart the computer.
  - 5 Press **F2** when the Sony logo appears. The **BIOS Setup** window appears.
  - 6 Press the **Right Arrow** key → to select the **Exit** menu.
  - 7 Press the **Down Arrow** key ↓ to select **Get Default Values**. The message **Load default values for all SETUP items** appears.

- 8 Press **Enter**. The **Setup Confirmation** window appears.
- 9 Select **Yes**, and press **Enter**.
- 10 Select **Exit (Save Changes)**, and press **Enter**. The **Setup Confirmation** window appears again.
- 11 Select **Yes**, and press **Enter**. The computer restarts.

If your computer continues to display the message “Operating system not found,” and Windows does not start, use your supplied System Recovery CDs to restore the programs that shipped with your computer. See “Using the System Recovery CDs” for more information.



**The System Recovery utility does not back up your system's data. If you wish to retain your system data, perform a backup to an external media.**

### ***Why doesn't my computer respond or turn off?***

It is best to turn off your computer using the Turn Off Computer command on the Windows Start menu. Using other methods, including those listed below, may result in loss of unsaved data.

- ☐ Click **Start** on the Windows® taskbar, select **Turn Off Computer**, and then click **Turn Off**.
- ☐ If your computer does not turn off, press **Ctrl+Alt+Delete** simultaneously. The **Windows Task Manager** dialog box appears, and you can turn off the computer from the **Shut Down** menu.
- ☐ If your computer still does not turn off, press and hold the power button to turn off the computer.
- ☐ Unplug the computer from the AC adapter, and remove the battery from your computer.
- ☐ If your computer stops responding while playing a CD or DVD, press **Ctrl+Alt+Delete** simultaneously. The **Windows Task Manager** dialog box appears, and you can turn off the computer from the **Shut Down** menu.



Pressing **Ctrl+Alt+Delete** simultaneously or turning off the computer with the power button may result in data loss in files that are currently open.

### ***Why won't the power management respond?***

Your computer's operating system may become unstable if a lower power state, such as Hibernate, is initiated and changed before the computer completely enters the lower power state.

To restore the computer to its normal operating stability

- 1 Close all open programs.
- 2 Restart the computer by pressing **Ctrl+Alt+Delete** simultaneously. The **Windows Task Manager** dialog box appears, and you can restart the computer from the **Shut Down** menu.
- 3 If this procedure does not work, press and hold the power button to turn off the computer.

## ***Troubleshooting the LCD Screen***


### ***Why did the computer screen (LCD) go blank?***

- ☐ Your computer screen may go blank if the computer has lost power or has entered a power saving mode (Standby or Hibernate). If the computer is in LCD (Video) Standby mode, press any key to activate the computer screen.
- ☐ Make sure the computer is plugged into a power source and is on. The power indicator on the computer will be on if the computer is on.
- ☐ If your computer is using battery power, make sure the battery is inserted properly and is charged. See "Turning On Your Computer" on page 22 for more information.
- ☐ If the display mode is set to external display, press the **Fn+F7** keys to switch the display.


## ***Troubleshooting the Mouse and Touch Pad***

### ***Why doesn't the touch pad work?***

- ☐ You may have disabled the touch pad without connecting a mouse to the computer.
- ☐ Restart the computer to activate the touch pad again.

- ❑ If your touch pad is interpreting a single tap as a double-click, adjust the button assignments. Follow these steps:
  - 1 Press the **Windows** key  and the **E** keys. The **My Computer** window appears.
  - 2 Click the **Tools** menu, and select **Folder Options**. The **Folder Options** dialog box appears with the **General** tab open.
  - 3 In the **Click items as follows** box, click to select **Single-click to open an item (point to select)**.
  - 4 Click **Apply**.
- ❑ If you are still experiencing problems, make sure another mouse is not installed.

***What do I do if the pointer doesn't move when I use the touch pad?***



- ❑ Try restarting your computer. Follow these steps:
  - 1 Press the **Windows** key .
  - 2 Press **U**. The **Turn off computer** window opens.
  - 3 Press **R** to restart the computer.
- ❑ If the computer does not restart,
  - 1 Press **Ctrl+Alt+Delete** simultaneously. The **Windows Task Manager** window appears.
  - 2 Press and release **Alt** to highlight the menu bar, and press the **Right Arrow** key → to select **Shut Down**.
  - 3 Press **Enter**.
  - 4 Press **R** to restart the computer.
- ❑ If you still cannot restart your computer, press and hold the power button to turn off the computer.
- ❑ If the pointer does not move while playing a disc, press **Ctrl+Alt+Delete** simultaneously to stop playback and restart the computer.

***What do I do if the computer doesn't recognize the mouse?***

- ❑ Make sure the mouse is securely plugged into the port.

- ❑ Restart the computer with the mouse connected to the computer.

***What do I do if the pointer doesn't move when I use the mouse?***

- ❑ Make sure another mouse is not installed.
- ❑ If you are playing a disc, press the **Ctrl+Alt+Delete** keys simultaneously to stop playback and restart the computer.
- ❑ If you still cannot use the pointer, restart the computer. You can restart the computer three different ways:
  - ❑ Press the **Windows** key , and press **U**. When the **Turn Off Computer** window appears, press **R**.
  - ❑ Press the **Ctrl+Alt+Delete** keys simultaneously. When the **Windows Task Manager** window appears, press the **Alt** key to highlight the menu bar, and press the **Right Arrow** key  to select **Shut Down**. Press **Enter**, and then press **R**.
  - ❑ Press and hold the power button. When the computer turns off, press the power button again to restart the computer.

## ***Support Options***

If you have questions about your computer or the preinstalled programs, refer to the following sources for answers in the sequence listed below.

---

### **1 VAIO® Computer User Guide**

The online VAIO® Computer User Guide and the printed VAIO® Computer Quick Start provide information on how to maximize your computer capabilities and solve common problems.

---

### **2 Software Manuals and Online Help Files**

The software preinstalled on your computer may come with an online manual. These manuals are stored on the hard disk drive as online Help files. You can find the Help files from the Help menu under the specific software application. Some software programs may come with a printed manual.

---

### **3 Operating System Online Support**

Your computer comes preinstalled with Microsoft® Windows®. For operating system support, you can access Microsoft® customer support at: <http://support.microsoft.com/directory/>.

---

---

**4      VAIO Support Agent**

You can find VAIO Support Agent by clicking **Start** and selecting **Help and Support**. Using advanced diagnostic technology, Sony's VAIO Support Agent runs scheduled protections of your programs, network settings, and other important program settings. When your program is protected, you can use VAIO Support Agent to repair program problems by restoring your program to any previously protected state.

---

**5      Sony Computing Support**

This service provides instant access to information on commonly encountered problems. Type a description of your problem to search the Knowledge Database for corresponding solutions. You can access Sony Computing Support at: <http://www.sony.com/pcsupport>.

---

**6      Sony Service Center**

For the Sony Service Center nearest you, call 1-888-4-SONY-PC (1-888-476-6972) or find Sony Customer Service on the Web at <http://www.sony.com/pcsupport>.

---





# Index

## **A**

- A/V OUT jack 18
- AC adapter 22
  - connecting 24
- applications
  - software programs 50

## **B**

- battery
  - charging 22
  - indicator 16
- brightness
  - adjusting 25
- buttons
  - left 16
  - power 16
  - right 16

## **C**

- caps lock 16
- complete recovery 53
- computer
  - cables 36
  - care 35
  - cleaning 37
  - controls and connectors 16
  - LCD screen 37
  - online support 62
  - specifications 14
  - specifications (online) 29
  - storage 36
  - troubleshooting 56
  - turning off 31

- turning on 22
- unpacking 14
- updates 29

- connecting
  - dial-up 30
- controls 16
- creating
  - Recovery Media Kit 43

## **D**

- DC IN port 19
- dial-up connection 30

## **E**

- Electronic Flyer 29
- Energy Star 5
- Ethernet port 17

## **F**

- F10
  - recovery 47
- faxes
  - laws governing 10

## **H**

- handling the LCD screen 37
- hard disk drive
  - indicator 16
- hard drive recovery 39
- headphone jack 18
- help 28, 55

## **I**

- i.LINK port 18
- indicators
  - battery 16

- caps lock 16
- hard disk drive 16
- num lock 16
- power 16
- scroll lock 16
- input devices 9
- interference 8
- Internet connection 30

## **J**

- jacks
  - A/V OUT 18
  - headphone 18
  - microphone 18
  - modem jack 17

## **K**

- keyboard 16

## **L**

- LCD
  - troubleshooting 59
- LCD screen
  - handling 37
  - locating 16
  - troubleshooting 59

## **M**

- maintenance 37
- manual 28
- microphone jack 18
- model name 16
- modem
  - laws governing 10
- modem jack 17
- Monitor (VGA) port 17
- mouse
  - troubleshooting 59, 60, 61

## **N**

- network connector 17
- num lock 16

## **O**

- online support 62
- online user guide 28
- ordering
  - Recovery Media Kit 45
- output devices 9

## **P**

- partition
  - recovery 49
- PC Card slots 18
- phone
  - laws governing 10
- ports
  - DC IN 19
  - i.LINK 18
  - Parallel (printer) 17
  - USB 17, 18
  - VGA (monitor) 17
- power
  - indicator light 16
- power button 25
- power source 22
- Printer (parallel) port 17
- programs
  - locating 34
  - recovering 50

## **R**

- radio interference 8
- recovering 50
  - applications 50
  - complete system 53
  - drive C 48
  - drive C and D 49
  - recovery partition 49
  - software programs 50
  - Windows System Restore 47
- Recovery Media Kit 39
  - CDs 42

- creating 43
- DVDs 42
- ordering 45
- recovery partition 49
- Recovery Wizard
  - starting 46
- regulatory information 8
- reset button 20

## **S**

- scroll lock indicator 16
- shutting down computer 31
- software
  - locating 34
  - recovering 50
- software programs 50
  - applications 50
- speakers (internal) 16
- specifications 14
- specifications (online) 29
- starting
  - Recovery Wizard 46
- starting computer 22
- support
  - Sony 55

## **T**

- technical support 55
- telephone line jack 17
- touch pad 16
  - troubleshooting 59
  - using 26
- troubleshooting 56
  - LCD screen 59
  - mouse and touch pad 59
- turning off computer 31
- turning on computer 22
- TV
  - interference 8

## **U**

- unpacking the computer 14
- updates 29
- USB port 17, 18
- user guide 28

## **W**

- Windows System Restore 47

***<http://www.sony.com/vaio>***