



Modular Multi-Service Fiber Optical Multiplexer

User's Manual

CONTENTS

Overview	2
Features	2
Parameters	3
Front&back Panel	5
Indicator LED	6
Son Card Interface	7
Ethernet Interface	12
Fiber Interface	14
Hotline Phone	14
AUX Interface	14
Lcd display&Set	16
Console Interface	30
Default parameter	40
Telnet	40
Http server	41
SNMP software	42
MIB Information	42
SNMP card software upgrade	43
Loop Test	44
After-sales Service	48
Company Statement	48

: Introduction

Dear users:

Thank you for using our product. In order to make your work smoothly, we give you some advice. Before you connect and operate the product, you should make sure to read this manual carefully and pay more attention to the notices.

: Overview

This device is modular structure point-to-point optical transmission equipment with LCD display, uses the FPGA chips and easy to upgrade. The Main board provide 4*100M channel Ethernet data and 2 AUX port which is for transmitting other data such as RS232/RS485/RS422, two optical interface for optional 1+1 auto protection switch .

The high flexibility, performance, is the best solution for voice/data/video services in existed market.

: Features

- Provides total 16 E1 transparent transmission capacity ;
- With char 16*2 LCD display and SNMP agent inside.
- Provide Console manage interface(RS232)
- Provide one hotline channel for option;
- Provide two SFP fiber interfaces, one as master, the other as slave, insuring uninterrupted service transmission.
- The rate of optical port is 155Mbps, transmission range can reach 25KM, 40KM, 60KM, 80KM or 100KM;
- Provide two fiber interface 1+1 protect function ,and ALS (Automatic Laser Shutdown/Reduction) function
- Provide 4 slots plug-in modules:
 - ◆ 4xE1 module (75Ω) / (120Ω)
 - ◆ 4xFramed E1 module (75Ω) / (120Ω) ,any timesolts can be set
 - ◆ 4xFXO/FXS/EM2-4 module
 - ◆ 8xFXO/FXS module
 - ◆ 2xV.35 (2.048M Fixed speed) module
 - ◆ 2xV.35 (N*64K N=1-32) module
 - ◆ 4xRS232/422/485 module

◆ 4*FE to E1 bridge(wire speed 2.048M) module

- Provide 4FE(wire speed 100M)Ethernet channel,support mutual negotiate, Ethernet bandwidth is set on base on multiple of 32K;
- Ethernet port supports full/half duplex, 10M/100M auto-negotiation;
- Ethernet port supports VLAN function and has 4 division mode for user selection;
- Ethernet package size support 1916 byte and 4 Ethernet port could be set separately;
- Has complete alarm function and can monitor remote device status;
- Supports E1 loop from remote so as to detect and manage device conveniently;
- The combination AC220V,and DC-48V for redundant

:Parameters

◆ Fiber

Optical wavelength: 850/1310nm for multi-mode fiber,1310/1490/1550nm for single-mode fiber.

Number of Ports: 2(1+1)

Transmission distance: 10-120Km

Fiber Optic Interface Type: FC/SC/ST/LC

Data Rate: 155 Mb/s

Line Code: 4B5B

Typical output power :

single mode 1310/1550nm: $\geq -7\text{dBm}$

multi-mode 850nm: $\geq -18\text{dBm}$

multi-mode 1310nm: $\geq -25\text{dBm}$

Receiver Sensitivity: $\leq -32\text{dBm}$

Link budget: $\geq 25\text{dBm}$

◆ E1 Interface

Interface Standard: comply with protocol ITU-T G.703;

Interface Rate: $2048\text{Kbps} \pm 50\text{ppm}$;

Interface Code: HDB3;

E1 Impedance: 75Ω (unbalance), 120Ω (balance);

Jitter tolerance: In accord with protocol G.742 and G.823

Allowed Attenuation: 0~6dBm

◆ Ethernet interface (10/100M UTP)

Interface rate: 10/100Mbps, half/full duplex auto-negotiation

Interface Standard: Compatible with IEEE 802.3, IEEE 802.1Q (VLAN)
MAC Address Capability: 4096
Connector: RJ45, support Auto-MDIX

◆ **V.35 Interface**

Interface rate: n*64Kbps
Interface Standard: Compatible with ITU-T V.35 Standard
Connector: DB25/M34
Connect Mode: DCE
Clock Type: G.703 restored clock, Internal clock

◆ **FXS Phone Interface**

Ring voltage: 75V
Ring frequency: 25HZ
Two-line Impedance: 600 Ohm (pick up)
Return loss: 40 dB

◆ **FXO PBX Interface**

Ring detect voltage: 35V
Ring detection frequency: 17HZ-60HZ
Two-line Impedance: 600 Ohm (pick up)
Return loss: 40 dB

◆ **EM2/4 Interface**

AD gain : 0db
DA gain : -3.5DB
line Impedance: 600 Ohm (pick up)
Return loss: 20 dB

◆ **Power**

Power supply: AC220V ; DC -48V ; DC +24V
Power consumption: ≤15W

◆ **Working Environment**

Working temperature: -10° C ~ 60° C
Working Humidity: 5%~95 % (no condensation)
Storage temperature: -40° C ~ 80° C
Storage Humidity: 5%~95 % (no condensation)

:Front&back Panel




Figure 1: Front panel




Figure 2: Back panel

Indicator LED

Name	Color	Condition	Description
Indicator Led as follows,			
LPWR	Green	ON	Device power is ON
		OFF	Device power is OFF
RPWR	Green	ON	The remote device power is ON
		OFF	The remote device power is OFF
F1	Green	ON	Fiber channel 1 is ok
F2	Green	ON	Fiber channel 2 is ok
OLOS	Red	ON	Fiber signal lost, not receive optical signals
		Flash	The corresponding 1-16 Channel E1 AIS alarm
		OFF	Fiber signal receive normally
OLOF	Red	ON	Fiber signal synchronous lost
		OFF	Fiber synchronous signal receive normally
E3	Red	ON	Fiber BER $\geq 10^{-3}$
E6	Red	ON	Fiber BER $\geq 10^{-6}$
LOS1-16	Red	ON	The corresponding 1-16 Channel E1 signal lost
		Flash	The corresponding 1-16 Channel E1 AIS alarm
		OFF	The corresponding 1-16 Channel E1 signal ok
LINK(RJ45)	Green	ON/flash	Corresponding Ethernet interface Link/Act
100M(RJ45)	Green	ON	Corresponding Ethernet interface work in 100M

NOTE:

- ◆ **RPWR Description:**
If signal indicator light OLOS is ON, there are two cases. One case is that the transmission line is broken; the other case is that the remote PDH device is power off.
As follows:
OLOS ON, RPWR OFF: The remote PDH device is power off;

OLOS ON, RPWR ON: Fiber is broken;


OLOS OFF, RPWR ON: Normal Work

- ◆ When command the remote E1 Loop-Back, If no E1 insert in local equipment, the remote equipment E1 LOS LED will flash, indicate E1 AIS alarm, because if no E1 insert in local equipment, ALL '1' will be insert in corresponding E1 data transmit to the fiber direction, then remote equipment E1 will Loop-back the all '1' data, receive it and alarm it;


: Son Card Interface

◆ 4*E1 module ,total 4 type of E1 module

1. Unframed E1 75 ohm;
2. Unframed E1 120 ohm;
3. Framed E1 75 ohm;
4. Framed E1 120 ohm;




75ohm unframed/framed 4E1 module



120ohm unframed/framed 4E1 module

75Ω-BNC Socket



“IN” means 75Ω(BNC) unbalance E1 input


“OUT” means 75Ω(BNC)unbalance E1 output

IN: 1-4 is 1-4Channel E1 interface signals receive input

OUT: 1-4 is 1-4Channel E1 interface signals transmit output


120Ω-RJ45 Socket

PIN defined as follows:



◆ V.35 module, Total 2 type of V.35 module

1. 2048K 2*V.35 module ;
2. N*64K 2*V.35 module ;



Indicator Led as follows:

TXD1	Green	Flash	No.1 V. 35 data Transmit
		Off	No.1 V. 35 no data Transmit
RXD1	Green	Flash	No.1 V. 35 data Receive
		Off	No.1 V. 35 no data Receive
		Flash	No.1 V. 35 data Transmit


TXD2	Green	Off	No.1 V. 35 no data Transmit
RXD2	Green	Flash	No.1 V. 35 data Receive
		Off	No.1 V. 35 no data Receive

DB25 receptacle on the rear panel used as V.35 data connector, the pins defined as follows:

Pins number	Pins name	The pins number of M34 standard receptacle accordingly
1	Frame Ground	A
7	Signal Ground	B
2	Send Data A	P
14	Send Data B	S
3	Receive Data A	R
16	Receive Data B	T
4	Request To Send	C
5	Clear To Send	D
6	Data Set Ready	E
20	Data Terminal Ready	H
8	Received Line Signal Detect	F
24	Transmit Clock Ext A	U
11	Transmit Clock Ext B	W
15	Transmit Clock A	Y
12	Transmit Clock B	AA
17	Receive Clock A	V
9	Receive Clock B	X

The attachment has a straight-through cable for transfer DB25M to DB34F, used to directly connect with DTE. Use crossover cable when need to connect with DCE, and contact us.

◆ 4*FX0/FXS/EM2-4 module




4*FX0/FXS/EM2-4 module


Indicator Led as follows:

P1-P4	GREEN	ON	1-4 channel voice is under calling
		WINK	Calling in
		OFF	1-4 channel voice is not under calling


FXO/FXS Pin define:

	1	NC
	2	NC
	3	NC
	4	Phone Tip
	5	Phone Ring
	6	NC
	7	NC
	8	NC


EM 4 Pin define:

	1	NC
	2 4	line Rece tip
	3 4	line Rece ring
	4 4	line Trans Tip
	5 4	line Trans ring
	6	M signal
	7	E signal
	8	signal Gnd

EM 2 Pin define:



◆ 8*FX0/FXS module




8*FX0/FXS module


Indicator Led as follows:

P1-P8	GREEN	ON	1-8 channel voice is under calling
		WINK	Calling in
		OFF	1-8 channel voice is not under calling

FXO/FXS Pin define:



16*FX0/FXS module




16*FXO/FXSmodule

Indicator Led as follows:

P1-P16	GREEN	ON	1-16 channel voice is under calling
		WINK	Calling in
		OFF	1-16 channel voice is not under calling

FXO/FXS Pin define:



Ethernet Interface

1Channel Ethernet and 4Channel Ethernet can be optional. Support 10/100M, half/full

duplex auto- negotiation and AUTO-MDIX (crossed line and straightly connected line self-adaptable)

LINK	Green	ON	Ethernet is connected
		OFF	Ethernet is not connected
100M	Green	ON	Ethernet rate is 100M
		OFF	Ethernet rate is 10M

RJ45 Connector and Crystal head PIN order as follows:



10/100M Ethernet Interface Crystal head PIN order

* **Straightly connected line order**


A end Crystal head PIN		B end crystal head PIN	
Twisted Pair Color	PIN order	PIN order	Twisted Pair Color
White and Orange	1	1	White and Orange
Orange	2	2	Orange
White and Green	3	3	White and Green
Blue	4	4	Blue
White and Blue	5	5	White and Blue
Green	6	6	Green
White and Brown	7	7	White and Brown
Brown	8	8	Brown

* **Crossed line order**

A end Crystal head PIN		B end crystal head PIN	
Twisted Pair Color	PIN order	PIN order	Twisted Pair Color
White and Orange	1	1	White and Green
Orange	2	2	Green
White and Green	3	3	White and Orange
Blue	4	4	Blue
White and Blue	5	5	White and Blue
Green	6	6	Orange
White and Brown	7	7	White and Brown
Brown	8	8	Brown

Description: Crossed line A end "1" connects with "3"; A end "2" connects with "6".When the connected Ethernet line is very long, you should be sure that "1"and "2" "3"and"6"are a pair line of Twisted Pair.

:Fiber Interface



Two Physical Interface: SFP single-fiber or dual-fiber .

Dual-Fiber: TX-Transmit RX-Receive

Single-Fiber: Transmit and Receive (Note: 1310nm and 1550nm device used in pair)

Caution : if select 1+1 interface, F1 is main fiber interface, F2 is back-up fiber interface, 1+1 function is available

:Hotline Phone


Please plug telephone line with telephone and the phone interface of equipment. For point-to-point application, when off-hook at any side, the other one will ring. Then the user at the other side should also off-hook to answer.

:AUX Interface

Can extend all kinds of data (according to your order)

The RJ45 interface of L1-L4 on the back panel is 1-2Channel RS232 data.

PIN1-4 is 1Channel, PIN5-8 is 2Channel. Defined as follows:



1 No. 1	RS485-A;	;RS422-TX+
2 No. 1	RS485-B;RS232 TXD (Out)	;RS422-TX-
3 No. 1	;RS232 RXD (In)	;RS422-RX+
4 No. 1	;RS232 GND	;RS422-RX-
5 No. 2	RS485-A;	;RS422-TX+
6 No. 2	RS485-B;RS232 TXD (Out)	;RS422-TX-
7 No. 2	;RS232 RXD (In)	;RS422-RX+
8 No. 2	;RS232 GND	;RS422-RX-

: Lcd display&Set



Management menu:

Button "ESC" for exit to upper layer of menu or give up set.

Button "ENTER" to enter submenu or confirm set.

Button "<" and ">" to choose the menu at the same level.

Power on the device and after initialization, about four seconds, it will show: :



= System


Menu = , Press "ENTER" to get the Menu for query and Settings, When there is not any key pressed for more than 1 minute, the screen will return to the top of the



= System

Menu System: Menu = .

If no key operate , LCD will display main alarm and minor alarm ,LCD display



Min

Alarm:ALARM



= System

Menu =

switching between Alarm:ALARM and Menu = , "ALARM" have alarm,"

None” is no alarm.

The First level menu:

Main LCD interface	Describe	Press "ENTER"	Press " < "	Press " > "	Press " ESC "
=Fib Opti Multi= = System Menu =	Display Main LCD interface	Enter first level menu, have four Sub-Menu	no effect	no effect	no effect
= Main System = 1:Set Main Board	Main Board parameter setting	Enter second level menu, have 13 Sub-Menu	choose the menu in same level	same level Menu	Return to Main
= Main System = 2:Set Son Card	Nol-4 Son Card parameter setting	Set and read son card status	choose the menu in same level	same level Menu	Return to Main
= Main System = 3:Main report	PDH System fiber and El status read	Display the status	choose the menu in same level	same level Menu	Return to Main
= Main System = 4:Main&Min Alarm	Main and Minor alarm configure	Select Alarm <Main> <Minor>	choose the menu in same level	same level Menu	Return to Main
= Main System = 5:Show Version	Display system version	FPGA: Ver 2.1 Firmware:Ver 2.5	choose the menu in same level	same level Menu	Return to Main

main alarm and minor alarm is user configurable, and define in following description

Main and Minor alarm comprise with 80 alarm ,every alarm can on or off

M00*M01*M0

2*M03*

M04 M05 M06

M07

for Main alarm setting,

N00*N01*N02

N03

N04 N05

N06 N07

for Minor alarm setting,

in the right of alarm name, if it is '*' ,this alarm is ON, if it is space, this alarm is OFF;

Press ">" or "<" to select alarm no ,Press "Enter" to Set ON or OFF;

If sound alarm mute is off, the speaker should play two type of alarm sound, short sound for main alarm and long sound for minor alarm;

Default main and minor alarm configure:

Main Alarm	Describe	Local	Mark	Remote	Mark
OLOS	Fiber signal los	★	M00	★	M40
OLOF	Fiber signal synchronous lost	★	M01	★	M41
E3	Fiber BER≥10-3	★	M02		M42
E6	Fiber BER≥10-6	★	M03		M43
LAN	No Any 1-4 Ethernet link		M04		M44
NC	Reserved		M05		M45
FIB1	Fiber channel 1 is ok		M06		M46
FIB2	Fiber channel 2 is ok		M07		M47
LOS1	1 Channel E1 signal lost	★	M08		M48
LOS2	2 Channel E1 signal lost	★	M09		M49
LOS3	3 Channel E1 signal lost	★	M10		M50
LOS4	4 Channel E1 signal lost	★	M11		M51
LOS5	5 Channel E1 signal lost	★	M12		M52
LOS6	6 Channel E1 signal lost	★	M13		M53
LOS7	7 Channel E1 signal lost	★	M14		M54
LOS8	8 Channel E1 signal lost	★	M15		M55
LOS9	9 Channel E1 signal lost	★	M16		M56
LOS10	10 Channel E1 signal lost	★	M17		M57
LOS11	11 Channel E1 signal lost	★	M18		M58
LOS12	12 Channel E1 signal lost	★	M19		M59
LOS13	13 Channel E1 signal lost	★	M20		M60
LOS14	14 Channel E1 signal lost	★	M21		M61
LOS15	15 Channel E1 signal lost	★	M22		M62
LOS16	16 Channel E1 signal lost	★	M23		M63
AIS1	1 Channel E1 AIS alarm		M24		M64
AIS2	2 Channel E1 AIS alarm		M25		M65

AIS3	3 Channel E1 AIS alarm		M26		M66
AIS4	4 Channel E1 AIS alarm		M27		M67
AIS5	5 Channel E1 AIS alarm		M28		M68
AIS6	6 Channel E1 AIS alarm		M29		M69
AIS7	7 Channel E1 AIS alarm		M30		M60
AIS8	8 Channel E1 AIS alarm		M31		M71
AIS9	9 Channel E1 AIS alarm		M32		M72
AIS10	10 Channel E1 AIS alarm		M33		M73
AIS11	11 Channel E1 AIS alarm		M34		M74
AIS12	12 Channel E1 AIS alarm		M35		M75
AIS13	13 Channel E1 AIS alarm		M36		M76
AIS14	14 Channel E1 AIS alarm		M37		M77
AIS15	15 Channel E1 AIS alarm		M38		M78
AIS16	16 Channel E1 AIS alarm		M39		M79

Minor Alarm	Describe	Local	Mark	Remote	Mark
OLOS	Fiber signal los		N00		N40
OLOF	Fiber signal synchronous lost		N01		N41
E3	Fiber BER \geq 10-3		N02		N42
E6	Fiber BER \geq 10-6		N03		N43
LAN	No Any 1-4 Ethernet link	★	N04	★	N44
NC	Reserved		N05		N44
FIB1	Fiber channel 1 is ok	★	N06	★	N45
FIB2	Fiber channel 2 is ok	★	N07	★	N47
LOS1	1 Channel E1 signal lost		N08		N48
LOS2	2 Channel E1 signal lost		N09		N49
LOS3	3 Channel E1 signal lost		N10		N50
LOS4	4 Channel E1 signal lost		N11		N51
LOS5	5 Channel E1 signal lost		N12		N52
LOS6	6 Channel E1 signal lost		N13		N53
LOS7	7 Channel E1 signal lost		N14		N54
LOS8	8 Channel E1 signal lost		N15		N55
LOS9	9 Channel E1 signal lost		N16		N56
LOS10	10 Channel E1 signal lost		N17		N57
LOS11	11 Channel E1 signal lost		N18		N58
LOS12	12 Channel E1 signal lost		N19		N59
LOS13	13 Channel E1 signal lost		N20		N60
LOS14	14 Channel E1 signal lost		N21		N61
LOS15	15 Channel E1 signal lost		N22		N62
LOS16	16 Channel E1 signal lost		N23		N63
AIS1	1 Channel E1 AIS alarm	★	N24		N64
AIS2	2 Channel E1 AIS alarm	★	N25		N65
AIS3	3 Channel E1 AIS alarm	★	N26		N66
AIS4	4 Channel E1 AIS alarm	★	N27		N67
AIS5	5 Channel E1 AIS alarm	★	N28		N68
AIS6	6 Channel E1 AIS alarm	★	N29		N69
AIS7	7 Channel E1 AIS alarm	★	N30		N60
AIS8	8 Channel E1 AIS alarm	★	N31		N71
AIS9	9 Channel E1 AIS alarm	★	N32		N72
AIS10	10 Channel E1 AIS alarm	★	N33		N73
AIS11	11 Channel E1 AIS alarm	★	N34		N74
AIS12	12 Channel E1 AIS alarm	★	N35		N75
AIS13	13 Channel E1 AIS alarm	★	N36		N76
AIS14	14 Channel E1 AIS alarm	★	N37		N77
AIS15	15 Channel E1 AIS alarm	★	N38		N78
AIS16	16 Channel E1 AIS alarm	★	N39		N79

= Main

System =

1:Parameter

Set

Set Param

Select

<Local>

<Remote>

this level menu : Press “Enter” : if you select
 “Local” , setting the local equipment, “Remote” to setting the Remote Equipment

= Main System = 1:Parameter Set	Describe	Press “ENTER”	Press “<”	Press “>”	Press “ESC”
1:Loc/Rem E1Loop Parameter Set	Local or remote E1 loop-back	Loc/Rem E1 Loop <Loc> <Rem>	Select E1 loop type	Select the E1 loop type	To first Menu
	If already looped, it will display left time	Left Sec: 58 Loc:All 1-16 E1	Press any key to continue	Press any key to continue	Press any key to continue
2:E1 Alarm Mask Parameter Set	E1 alarm shield setting	<E1 Alarm Mask > <No E1>	Select the E1 to shield	Select the E1 to shield	To first Menu
3: Alarm Mute Parameter Set	Alarm sound MUTE setting	< MUTE > <ON> <OFF>	Select ON or OFF	Select ON or OFF	To first Menu
4: LED Display Parameter Set	LED display Local or Remote	< LED Display > <Local> <Remote>	Select Local or Remote	Select Local or Remote	To first Menu

5:Fib Loop-Back Parameter Set	Local fiber loop-back	<Fib Loop-Back> <Loop> <No-Loop>	Select Loop and No-Loop	Select Loop and No-Loop	To first Menu
	If already looped, it will display left time	Left Sec: 58 Local Fiber Loop	Press any key to continue	Press any key to continue	Press any key to continue
6:4*Ethernet Set Parameter Set	4 channel Ethernet Param Setting	1. 1-4 Port Set 2.Separa 3.Prior	Select 1-3 Menu no	Select 1-3 Menu no	To first Menu
7:Fiber No.1 ALS Parameter Set	No.1 fiber ALS function ON or OFF setting	<Fiber No.1 ALS> <ON> <OFF>	Select ALS ON or OFF	Select ALS ON or OFF	To first Menu
8:Fiber No.2 ALS Parameter Set	No.2 fiber ALS function ON or OFF setting	<Fiber No.2 ALS> <ON> <OFF>	Select ALS ON or OFF	Select ALS ON or OFF	To first Menu
9:LCD Back-Light Parameter Set	LCD back-light AUTO shutdown time setting	Back-Light Time 60 Second	shutdown time from 30 to 300	shutdown time from 30 to 300	To first Menu
10:LoopBack Time Parameter Set	LCD back-light AUTO shutdown time setting	Loop-Back Time 1 Minutes	1min/10min/30/min/1hour/5hour/24hour/Forever	1min/10min/30/min/1hour/5hour/24hour/Forever	To first Menu

<div>11:Reset the MUX</div> <div>-----</div> <div>----</div>	Reset local and remote equipment	<div>Are you sure?</div> <div>"Enter" to Reset</div>	no effect	no effect	To first Menu
<div>12:ReBoot the MUX</div> <div>-----</div> <div>----</div>	Reboot local equipment	<div>Are you sure?</div> <div>"Enter" to ReBoot</div>	no effect	no effect	To first Menu
<div>13: Restore to factory settings</div>	Restore to factory default setting	<div>Are you sure?</div> <div>"Enter" to Resto</div>	no effect	no effect	To first Menu

Sub-menu 6 : Ethernet setting:

6:4*Ethernet Set

Parameter

Set

1. 1-4 Port Set

2.Sepra

3.Prior

Press "Enter", display:

,1 is 1-4channel

Ethernet phy and other setting,2 is seprate setting,3 is 802.1P prior setting

No1 Eth--No2 Eth

No3 Eth--No4

◆ Cursor at 1,and press "Enter",display

Eth

,select Ethernet

1.Mode

2.FlowCon

channel ,if you select 1 and press "ENTER", display

3.Rate 4.Prior

Auto:10/ha:10/
fu

100/hal:100/fu

1: mode ,display 1 , auto : phy is auto-nego, 10/ha is 10M/half, 10/fu is 10M/full, 100/haf is 100M/half, 100/ful is 100M/full

No1 Flow
Control

<OFF>

2:FlowCon display <ON> , you can select ON or OFF

No.1
BandWith:

100M +

0*32K

3:Rate display , the maximum Ethernet Bandwidth is 100M, and the minimum 0k, for example you can select 100M + 0*32K , the bandwidth is 100M, and 10M+0*32K the bandwidth is 10M, 1M+16*32K the bandwidth is 1.5M.

1.Priority
Level

Level is:

4:Prior display 0 you can select priority level 0-7, 7 is maximum, 0 is the minimum , the default level is 0;

1-4 Eth
Separate

◆ Cursor at 2, and press “Enter”, display **M0:Disable** , there is 4 mode,
M0:Disable Ethernet separate is disable
M1:Special Untag **for default Ethernet separate mode**, the data has no label
M2:Special Taged the data has label
M3:802.1Q Untag IEEE 802.1Q separate mode

Priority
Enable

<OFF>

◆ Cursor at 3, and press “Enter”, display <ON> , you can select OFF

or ON for priority enable

NOTE:

◆ In measuring laser power, be sure to close ALS function

<div> = Main System = 3: Main Report </div> this level menu is:					
Press " ENTER" display 5 screen status, Press "<" and ">" switching , Press " ESC" Return to main menu					
No	NO.1 screen	NO.2 screen	NO.3 screen	NO.4 screen	NO.5 screen
Dis p	<div>1-16E1</div> Local LOS LLLLLLLLL LLLLLLL	<div>1-16E1</div> Rem LOS LLLLLLLLL LLLLLLL	<div>Fibe L/R</div> los_lof - - - -	<div>1-16E1</div> Local AIS AAAA----- -----	<div>1-16E1 Rem</div> AIS AAAA----- -----
	Local 1-16 E1 LOS Status, L is E1 LOS,-is E1 OK	Remote 1-16 E1 LOS Status, L is E1 LOS,-is E1 OK	Locla fiber LOS LOF ,remote fiber LOS LOF Status , L is alarm,- is OK	Local 1-16 E1 AIS Status, A is E1 AIS,-is NO AIS	Remote 1-16 E1 AIS Status, A is E1 AIS,-is NO AIS
No	NO.6 screen	NO.7 screen	NO.8 screen	NO.9 screen	
Dis p	<div>L1:Link</div> 100M Ful L2:Down -- - - - -	<div>L3:Link</div> 100M Hal L4:Down -- - - - -	<div>R1:Link</div> 100M Ful R2:Down -- - - - -	<div>R3:Link</div> 100M Fal R4:Down -- - - - -	
	Local No.1-2 Ethernet work status	Local No.3-4 Ethernet work status	Remote No.1-2 Ethernet work status	Remote No.3-4 Ethernet work status	

1-4 son card seting

The no.2 of level 2 menu:

= Main System =

2:Set Son Card

1-4 son card module seting , press "ENTER" display:

x: Null Inserted solt no.x no card inserted
x: 4*E1 75 ohm solt no.x unframed 4*E1 75ohm module inserted
x: 4*E1 120 ohm solt no.x unframed 4*E1 75 ohm module inserted
x: 4framed E1 75 solt no.x framed 4*E1 75 ohm module inserted
x: 4framed E1 120 solt no.x framed 4*E1 120 ohm module inserted
x: 4*phone card solt no.x 4*Voice module inserted
x: 2 * 2048K V.35 solt no.x 2*2048K V.35 module inserted
x: 2 * N*64K V.35 solt no.x 2*N*64K V.35 module inserted
x: Not this type solt no.x inserted card type can not be recognised

4*E1 unframed module

4*E1 unframed module		
Press " ENTER" Display 4 screen status , Press " <" and" >" Switching, Press" ESC" Return to main		
Screen	No. 1	No. 2
Display	<div style="border: 2px solid green; padding: 5px; text-align: center;"> LOS:loc * Rem L L L L * L L L L </div>	<div style="border: 2px solid green; padding: 5px; text-align: center;"> AIS:loc * Rem L L L L * L L L L </div>
	Local and remote 1-4 channel E1 LOS status , L is E1 LOS,- is E1 ok, Invalid is remote Invalid	Local and remote 1-4 channel E1 AIS status , A is E1 AIS,- is E1 no AIS, Invalid is remote Invalid

2*V.35 2048K module

1:Clk 1;Tinv on

1:Clk 2;Tinv Off

Clk have three mode

Clock mode		mode
Connect with DTE	E1 master clock, V.35 internal clock	1
	E1 recovery clock , V.35 internal clock	2

Connect with DCE		E1 external clock, V.35 external clock	3
Usual clock mode	1、connect with DTE, used pair, end office is mode 1, user end is mode 2.		
	2、connect one with DCE, the other with DTE,DCE end is mode 3, DTE end is mode 2.		

Tinv is V.35 transmit clk reverse ,On is reversed , Off is not reversed

Press "<" and ">" to choose. Press "ENTER"to select your seting value or "ESC" to quit.

2*V.35 N*64K (N=1-32) module, have V.35 speed seting screen

1: Rate 32*64K

2: Rate 1*64K







Press "<" and ">" to choose. Press "ENTER"to select your seting 1-32 value or "ESC" to quit.

4*FXO/FXS phone module


4*FXO/FXS phone module:		
<p>1:S / 0:2:S / 0</p> <p>3:S / 0:4:S / 0</p> <p>Press " ENTER" display phone status,</p> <p>Press " <" and " >" switching , Press " ESC" return to main menu ,1:S / 0 is: No.1 phone is FXS interface , remote is FXO interface</p>		
Display	<p>L:FXS Off- Hook</p> <p>R:FXO ON- Hook</p>	Line 1:local phone status , line 2: Remote phone status

4*FE1 Framed E1 module

4*FE1 Framed E1 module		
<p>1.u;2.u;3.u;4.u</p> <p>*used;</p> <p>-:unused</p> <p>Press " ENTER" setting E1 0-31 timesolts,</p> <p>Press " <" and " >" Switching select E1, Press " ESC" Return to</p>		

main menu U is E1 unframed , f is E1 framed		
Display		
Describe	The first cursor setting the timeslot 0, if E1 is framed ,then display f,Press" Enter" change to *,indicate E1 is unframed , the under line 00 indicate time solt 0 If e1 is unframed , then KEY ">" and "<" invalid	Other 1-31 cursor setting 1-31 Timesolt, Press " Enter" KEY '*' and '-' switching ,* is this timeslot occupy, - this timeslot not occupy KEY ">" and "<" select timesolt
Display		
Describe	E1 is unframed	E1 is framed ,timeslot 1-2,4-31 occupy
Display		
Describe	E1 is framed ,timeslot 16-31 occupy	E1 is framed ,timeslot 1-8 occupy

:Console Interface



This is for PC hyper-terminal control.

Use DB9 cable to connect the PC's COM port with CONSOLE port;

Run the "hyper terminal" program under WINDOWS system, or run other third-party serial port connection software, set the default parameters as following:

Baud rate: 9600;

Data byte: 8;

parity check: none;

Stopbit: 1;

Flow control: none;

Press "ENTER" continuously for several times, enter system's CLI interface and begin management work.

```
===== Main Menu =====
== 1.current Ethernet information, Please input '1' ==
== 2.current PDH & E1 information, Please input '2' ==
== 3.Enter config menu, Please input '3' ==
== 5.Factory Reset!Please input '5' ==
=====
W[PDH /]:
```

Submenu introduction

1. Check ethernet setting information, input "1"

```
[PDH /]:1
Local/Remote Ethernet Interface Status:
L1:Down ---- L2:Down ---- L3:Down ---- L4:Down ----
R1:Link 100M Ful R2:Down ---- R3:Down ---- R4:Down ----
=====Local  VLAN=====
separate mode:special channel separate
Information of separate set:Mode 1(x=1):Special Separated,and untagged
Port 1-4:(CH1:PORT1,CH2:PORT2,CH3:PORT3,CH4:PORT4)
=====Remote VLAN=====
separate mode:special channel separate
Information of separate set:Mode 1(x=1):Special Separated,and untagged
Port 1-4:(CH1:PORT1,CH2:PORT2,CH3:PORT3,CH4:PORT4)
=====Local  BandWidth=====
Information of bandwidth:
1:100M+00*32K---2:100M+00*32K---3:100M+00*32K---4:100M+00*32K
=====Remote BandWidth=====
Information of bandwidth:
1:100M+00*32K---2:100M+00*32K---3:100M+00*32K---4:100M+00*32K
Press Any Key to Continue.....
The device support packet sizes up to 1916!
=====Local  PHY Mode=====
PORT1:Auto PORT2:Auto PORT3:Auto PORT4:Auto
=====Remote PHY Mode=====
PORT1:Auto PORT2:Auto PORT3:Auto PORT4:Auto
=====Local  Flow Control=====
PORT1:OFF PORT2:OFF PORT3:OFF PORT4:OFF
=====Remote Flow Control=====
PORT1:OFF PORT2:OFF PORT3:OFF PORT4:OFF
=====Local  Priority=====
802.1P Configration:Disable 802.1P!
Pri-value: PORT1:0 PORT2:0 PORT3:0 PORT4:0
=====Remote Priority=====
802.1P Configration:Disable 802.1P!
Pri-value: PORT1:0 PORT2:0 PORT3:0 PORT4:0
Press Any Key to Continue.....

===== Main Menu =====
== 1.current Ethernet information, Please input '1' ==
```



```

== 2.current PDH & E1 information, Please input '2'      ===
== 3.Enter config menu, Please input '3'                ===
== 5.Factory Reset!Please input '5'                      ===
[PDH /]:

```

2. Check PDH&E1 information,please input"2"

```

[PDH /]:2
Main and reserve fiber signal lost.
LOCAL/REMOTE Fiber alarm Status:
OLOS OLOF E3   E6
Alar OK   OK   OK
-----
LOCAL/REMOTE E1 LOS alarm Status(L:LOS,-:Insert):
1 2 3 4
L L L L
- - - -
LOCAL/REMOTE E1 AIS alarm Status(L:LOS,-:No AIS):
1 2 3 4
- - - -
- - - -
Not Command the remote E1 Loop-Back.
Not Mask E1 Alarm.
LED indication remote device status.
Sound Alarm OFF.
Local fiber loop off.
Hot line telephone on-hook.
Press Any Key to Continue.....

```

```

[PDH /]:3
local:1-30 Phone Type(S:FXS,0:FX0):
1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16
0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0
17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32
0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0
Remote:1-30 Phone Type(S:FXS,0:FX0):
1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16
0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0
17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32
0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0
1-30 Phone Status(C:Calling,H:Hook):
1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16
H H H H H H H H H H H H H H H H
17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32

```

```

H H H H H H H H H H H H H H H
Local 1-4 AUX Port Type:
No Module insert
No Module insert
RS232 Module
No Module insert
Remote 1-4 AUX Port Type:
No Module insert
No Module insert
No Module insert
No Module insert
Press Any Key to Continue.....

```

3. Enter setting menu, please input "3"

```

[PDH /]:3

===== Config Menu =====
== 1.Set 1-4 Port bandwidth,Please input '1'      ==
== 2.Set 1-4 Port Ethernet PHY Mode,Please input '2'==
== 3.Set 1-4 Port Flow Control,Please input '3'    ==
== 4.Set 1-4 Port 802.1P priority,Please input '4' ==
== 5.Config 802.1Q-Switcher,Please input '5'       ==
== 6.Config Channel Separate,Please input '6'      ==
== 7.Maximum Packet Length(1916 or 1936), input '7' ==
== 8.PDH E1&fiber config,Please input '8'          ==
== Exit, Please input '0'                        ==
=====
[PDH /Config]:

```

3.1 Ethernet bandwidth setting, input "1"

```

[PDH /Config]:1

===== Bandwidth Config =====
== Set Local bandwidth : setl m xyz ab (m: Port1-4, xyz,ab: Value ==
== Set Remote bandwidth: setr m xyz ab (m: Port1-4, xyz,ab: Value ==
== bandwidth =(x*100+y*10+z)M+32*(a*10+b)K (m<5,xyz<100,ab<32) ==
== Exit, Please input '0'                                           ==
=====
[PDH /Bandwidth config]:

```

“setl” for setting local equipment,and “setr” for setting remote side.

x,y,z respectively denote hundred's place, decade and unit for a hundred number; a,b denote decade and unit for a ten number; m means port number,

when m=0 denote optical connector, m=1/2/3/4 denote the 1st/2nd/3rd/4th ethernet port.

If you want to set the 3rd ethernet bandwidth is 55M+32*16K, then input
setl 3 055 16

3.2 Ethernet 10/100M setting, input "2"

```
[PDH /Config]:2
===== Port Status Config =====
== Set Local command : setl x y          ===
== Set Remote command: setr x y          ===
== Note: x:Port numble(x=1-4) y:0 auto negotiation    ===
==                                     1 fored half duplex and 10BT ===
==                                     2 fored full duplex and 10BT ===
==                                     3 fored half duplex and 100BT===
==                                     4 fored full duplex and 100BT===
==                                     ===
== Exit, Please input '0'                ===
=====
[PDH /Port Status Config]:
```

“setl” for setting local equipment ,and “setr” for setting remote side.

3.3 flow control setting, input"3"

```
[PDH /Config]:3
===== Flow Control Config =====
== Set Local command : setl x y          ===
== Set Remote command: setr x y          ===
== Note: x:Port numble(x=1-4) y=0/1;Flowcontrol 0:OFF,1:ON ===
== Exit, Please input '0'                ===
=====
[PDH /Port Flow Config]:
```

“setl” for setting local equipment,and “setr” for setting remote side.

Mark: x means 1-4ch etherent port.

3.4 802.1P setting, input"4"

```
[PDH /Config]:4
===== 802.1P Config =====
== Enable local 802.1P : enl x,x=0:disable,x=1:enable==
```

```

== Enable Remote 802.1P : enr x,x=0:disable,x=1:enable===
== Local 802.1P user-priority command: setl x y      ===
== Remote 802.1P user-priority command: setr x y      ===
==                                                    ===
== Note:x:port number(x=1-4) y:value(y=0-7)          ===
== (using this value when receive-packets havn't tag) ===
==                                                    ===
== Exit, Please input '0'                            ===
=====
[PDH /802.1P Config]:

```

“enl” enable the local 802.1P priority

“enr” enable the local 802.1P priority

“setl” for setting local equipment,and “setr” for setting remote side.

Mark: x means 1-4ch ethernet port.

y means priority grade,including:

- The highest grade is 7,applied in critical network traffic, such as routing choose information protocol(RIP) and open shortest path(OSPF) protocol's routing table update;
- Priority 6 and 5 mainly apply in delay-sensitive program, such as interactive video and audio;
- Priority 4 to 1 mainly apply in controlled-load program, such as streaming multimedia and business-critical traffic;
- Priority 0 is default value, and start automatically without setting other priority grade.

Attention: when ethernet packet is with tag, the device will dedicate priority grade automaticly by tag; otherwise, use setting x y to set priority grade by real situation.

3.5 802.1Q switch setting, input "5"

```
[PDH /Config]:5
```

```

===== 802.1Q Config =====
== Note:You can choice one of 3,4,5,and 3,4 used for back-to-back ==
==                                                                    ==
== 1.Enable or disable 802.1Q,Please input '1' ==
==   Explanation: p:ports number(0<p<=5,5:optic port) ==
==               xxxx:VID(0=<x<4096); yy:VLAN number(0=<yy<16) ==
== 2.PVID config: pvid xxxx p p p p p ==
==   Disable tag insertion when xxxx = 0000 ==
== 3.802.1Q membership config command: set/clr yy xxxx p p p p p ==
==   e.g:vlan1:port1-3,vid=2; vlan2:port4-5,vid=3; ==
==       vlan 00 1 2 3; vlan 01 4 5 ==
== 4.VLAN Tag set: tag z p p p p ==
==   Explanation: z: 1:Egress Tagged; 0:Egress Untagged ==
==   Note       : port5 can't set ==
== 5.Clear vid and memberships,Please input '5' ==
== 9.Loop up current switcher information,Please input '9' ==
==                                                                    ==
== Exit,Please input '0' ==
=====
[PDH /802.1Q Config]:

```

3.6 channel separating setting, input"6"

```

[PDH /Config]:6
===== Channel Separate Config =====
== Set Local Channel Separate : setl x ==
== Set Remote Channel Separate : setr x ==
== Note: x:Channel Separate mode ( x=0-4 ) ==
== Explanation of Channel Separate mode : ==
== Mode 0( x=0 ) : Disable Channel Separate ==
== Mode 1( x=1 ) : Special Channel Separated,and untagged ==

```

```

== Mode 2( x=2 ) : Special Channel Separated,and tagged      ===
== Mode 3( x=3 ) : 802.1Q Channel Separated,and untagged    ===
== Note : 1-4 Ethernet (P1-P2-P3-P4) Separate Each Other    ===
==                                                            ===
== Exit, Please input '0'                                     ===
=====
[PDH /Channel separate config]:

```

“setl” for setting local equipment ,and “setr” for setting remote side.

Channel types instruction:

mode 0, when x=0, means cancel channel isolation;

mode 1, when x=1, means corresponding channel isolated, but the data has no label;

mode 2, when x=2, means corresponding channel isolated, but the data has label;

mode 3, when x=3,means the local device's ethernet channels all isolated to each other.

Attention: in ethernet transmission, the data packet is no need to add label. But in some special network, need to add label to enhance network transmission safety.

Channel isolation instruction:

each channel isolates to each other;

3.7 Ethernet packet switch between 1536 and 1916, input "7

```

[PDH /Config]:7
Accept packet sizes form 1916 bytes to 1536 bytes!

```

The device has two types of packet:1916 and 1538, each ethernet port should be setted unified.

3.8 PDH E1 and fiber setting

```
[PDH /Config]:8

===== PDH E1&Fiber Config =====

== Command: setl x y or setr x y ==

==setl:set local PDH,setr:set remote PDH ==

==Note:x=1,Let the Local E1 Loop-back,y=0-16,31 ==

== y=0 :all E1,y=1-16,Corresponding E1,y=31 None ==

==Note:x=2,Let the Remote E1 Loop-back,y=0-16,31 ==

== y=0 :all E1,y=1-16,Corresponding E1,y=31 None ==

==Note:x=3,Mask E1 Alarm ,y=0-15 ==

== y=0:Mask all E1,y=1-14 Mask (y+1)-16E1,y=15 None ==

==Note:x=4,Sound Alarm MUTE, y=0:0FF,y=1:0N ==

==Note:x=5,LED display local/remote,y=0:local,y=1:Remote==

==Note:x=6,Fiber Local Loop-BACK, y=0:0FF,y=1:0N ==

==Note:x=7,No.1 Fiber ALS , y=0:0FF,y=1:0N ==

==Note:x=8,No.2 Fiber ALS , y=0:0FF,y=1:0N ==

==Note:x=9,Set Back-Light Auto-OFF Time,y=30-300 Second ==

==Note:x=10,Set LoopBack Time, y=1-7 ==

== y=1:1 minute; y=2:10 minutes;y=3:30 minutes; ==

== y=4:1 hours;y=5 5 hours;y=6:24 hours;y=7 Forever ==

==Note:x=11,Equipment reset, ==

==Note:x=12,Equipment Re-Boot, ==

==Note:x=13,Restore to factory settings ==

=====

[PDH /PDH Config]:
```

“setl” for setting local equipment, and “setr” for setting remote side.

Mark: x means 1-12 command word,

Command x	describe	y	
1	Let the Local E1 Loop-back	0-16,31	y=0 :all E1,y=1-16,Corresponding E1,y=31 None
2	Let the Remote E1 Loop-back	0-16,31	y=0 :all E1,y=1-16,Corresponding E1,y=31 None
3	Mask E1 Alarm	0-15	y=0:Mask all E1,y=1-14 Mask (y+1)-16E1,y=15 None
4	Sound Alarm MUTE,	0-1	y=0:OFF,y=1:ON
5	LED display local/remote	0-1	y=0:local,y=1:Remote
6	Fiber Local Loop-BACK	0-1	y=0:OFF,y=1:ON
7	No.1 Fiber ALS	0-1	y=0:OFF,y=1:ON
8	No.2 Fiber ALS	0-1	y=0:OFF,y=1:ON
9	Set Back-Light Auto-OFF Time	0-300	y=30-300 Second
10	Set LoopBack Time	1-7	y=1:1 minute; y=2:10 minutes;y=3:30 minutes; y=4:1 hours;y=5 5 hours;y=6:24 hours;y=7 Forever
11	Equipment reset		
12	Equipment Re-Boot		
13	Restore to factory settings		

: Snmp interface

NMS interface is RJ45 with two LED display:

COM : green LED, when device start, COM led flash indicates SNMP agent communication to the PDH equipment.

LNK/ACT——green light, ON indicates it is connected with PC or HUB or SWITCH(of no effect on cascade card).

Default parameter


IP address:	192.168.0.148
Subnet Mask:	255.255.255.0
Gateway:	192.168.0.1
WEB type login user's name:	admin
WEB type password:	admin

NOTE:

At the right side of the front panel ,there is an reset key(in the holes),if you press down this key and power on the equipment, will reset to above default parameter

Telnet

Users can telnet from long-distance after collocating the IP address of the device. Connect the PC to LAN, run the command “telnet A.B.C.D(default is 192.168.0.148, input “c” or “e” when it come to the interface of Chinese/ English opt. input user name and password to for the system to check(default is admin, admin). Then user will enter into the main interface, showing as follows:



Telnet provide graph interface mode(like the above one) and command line mode(enter from the “command mode” in the “others” menu under the graph interface mode.)

User can set the IP address and other parameters of the device under the graph mode. And the command line mode is the same with the Console controlling mode.

Http server


This system provides simple IE browse mode. Under this mode, user can realize configuration or update operation.

Input the IP address of the SNMP card at the browser(default is 192.168.0.148) to log on the IE server.

The interface of Logging on is as follows:



Select English at the welcome interface after logging on(default user name is admin, and password: admin). Then it entered into corresponding net page, showing as follows:




SNMP card software upgrade

The SNMP card software is stored in the FLASH. Software upgrade means FLASH programming by SNMP card software upgrade function.

It needs software upgrade based on the 2 following situation. One is software upgraded, which means replace the old software in terminal server by new; the other is when the FLASH code destroyed, it could write new with the same version.

The update is realized by IE browser and the operation is easy.

Open “system firmware update” in the “system update” menu of the IE page, showing as follows:



Click “browse”, select update document, then click “update”. Wait for some minute when update(updating time is according to the size of the document). When presenting “complete”, reboot the device to make it into effect.

Note: 1. If the update failed, the device will be destroyed abidingly. Please do it by the factory or under the guidance of technician.

2. Do not browse through net page during updating. Further more, the system will not work normally during update.


0302 PDH SNMP software Operate

See the operation declaration datasheet file in the drive file folder

: Loop Test

Tow Type of Fiber Loop Test:

1. Fiber local Loop-Back



Set Param
Select


<Local>

<Fib Loop-
Back>

<Loop> <No-

In set menu <Remote> --> "local" , And at Loop --> "Loop"

2. Fiber Remote Loop-Back



Set Param
Select

<Local>


<Fib Loop-
Back>

<Loop> <No-

In set menu <Remote> --> "Remote" ,And at Loop --> "Loop"

Four Type of E1 Loop Test:

1. Local E1 LOOP



= Main
System =

1:Set Main
Board

Step1: In the menu ,select " Set Main Board" ,
Click Enter Key;

Set Param
Select

<Local>

Step2: in <Remote> Select "Local" ,

1:Loc/Rem
E1Loop

Parameter

Loc/Rem E1
Loop

<Loc>

Step3: in Set Press "Enter" , <Rem> Select "Loc"

<Loc E1
loop>


<All 1-16

Step4: Under the "Loc E1 loop" ,select "All 1-16E1" or the E1
channel you want or "No E1" .

Note: Select "No E1" ,the local E1 Loop will be cancelled.

After the above steps, the Local E1 Loop-Back is set successfully.



2. Remote E1 LOOP



= Main
System =

1:Set Main



Step1: In the menu ,select " Set Main Board" , Board Click Enter Key;



Note: Select "No E1" ,the local E1 Loop will be cancelled.


After the above steps, the Remote E1 Loop-Back is set successfully.

3. Remote E1 LOOP-OUT



Note: Select "No E1" ,the E1 Loop will be cancelled.

4. Remote Command Remote E1 LOOP-IN



Set Param
Select

<Local>

<Remote>

1:Loc/Rem
E1Loop

Parameter

In Param set menu

=> "Remote" , And at

Set

Loc/Rem E1
Loop

<Loc>

<Rem>

<Rem E1
loop>

<All 1-16

E1>

Press "Enter" ,and

=> "Rem" ,and

select "All

1-16E1" or the E1 number you want or "No E1" .

Note: Select "No E1" ,the E1 Loop will be cancelled.

Power

Dual power supply: AC220V and DC-48V:

AC220V socket: input voltage range AC 85V~265V; Please insert power wire as the attachment;

DC-48V socket: input voltage DC-36V ~-72V. If the power of DC-48V is used, the positive and negative terminal can be optional because there is the self-test circuit for the polarity inside the fiber optical multiplexer.

Normal Connect way "FG" connect earth;

"-48V" connect the power negative;

"+48V" connect the power positive;

:After-sales Service

The series of our Modular Multi-Service Fiber Optical Multiplexer products, our company promises three-years warranty. During product warranty time, our company provides free repair service, but if the following cases, we will charge the cost of materials.

1. Damage due to not complying with the manual.
2. Tear down the device without authorization, which leads to bad situations.
3. Lightning, fire and inevitable natural disasters.
4. Our products don' t match with other company products because of bad design to cause damage.

:Company Statement

1. As we are adopting new technology, if our product technical parameters are changed, we won' t notice you.
2. The final interpretation right of this manual belongs to our company.