

The intel Nuc 7i5BNB BIOS has three options relating to SGX

1. Intel SGX - Auto, Enabled & software controlled - Set to Enabled
2. SGX Owner EPOCHs - Factory Default, New Random Owner EPOCHs & User Defined Owner EPOCHs - Set to factory Default
3. SGX Reserved memory Size - Auto, 32 MB, 64MB & 128MB - Set to Auto

Can anyone confirm my SGX settings are correct.