



STEAM VR™

Tracking Training



STEAM®VR
Tracking Training

Firmware

Firmware

Chris Pezzee

Senior Firmware Engineer - Synapse

chris.pezzee@synapse.com

Overview

- Firmware capabilities of the HDK
- Customization options
- Firmware logging
- Firmware update

Firmware Features

- Core functionality (tracking)
- Controller mode
- HMD mode

Controller and HMD modes modify the core Tracking function

“Controller” and “HMD” are not mandatory boxes; guiding concepts

Firmware - Core

Core Functions:

- Tracked object: up to 32 sensors (USB) / 28 (Wireless)
- USB or 2.4 GHz radio link to PC
- Battery management: charger, fuel gauge
- Firmware update: MCU, FPGA, radio

Firmware - Controller

Controller mode:

- 250 Hz IMU (wireless limit)
- Trackpad: Cirque GlidePoint
- Analog trigger: Hall Effect sensor and magnet
- Haptic motor: force feedback / rumble
- 5 clickable buttons: system, trigger, trackpad, A (menu), B (aux)

Firmware - HMD

HMD mode:

- 1000 Hz IMU
- Serial flash (display calibration data)
- One or more buttons; trackpad and trigger are disabled

HMD mode does not support any particular display, headphones, microphone

Firmware

Source code for MCU, FPGA, radio not licensed

- Hard real-time: easy to break tracking
- Custom wireless: on-the-fly packet compression
- Valve wants to avoid Android-style fragmentation
- Valve is still innovating - the interface is not fixed
 - New features and bug fixes are being released regularly

Firmware changes must be contracted through Synapse

Firmware

How to build your custom tracked object?

- Customize firmware?
- Add more hardware?

It depends...

Customization Scenarios

- Simple tracked object: no firmware changes
- Controller: new buttons, additional controls, communicates to SteamVR
- HMD: display, backlight, headphones, microphone

Might need firmware customization

Might solve with more hardware

Up front development cost (NREs) vs. ongoing BOM cost / board space

Synapse can advise

Customization

Hardware scenario:

- Add dedicated application MCU
- USB hub in the device
 - Tracking MCU, application MCU, USB audio, USB camera
- BYO display or other functionality

Little or no interaction with the tracking subsystem

Additional BOM costs / space

Customization

Firmware scenario:

- Add tasks and device drivers to tracking MCU
- Additional triggers, buttons, lights, controls
- Display control

Single MCU saves cost / space

Tracking MCU: Cortex-M4, floating point, 120 MHz, 160 KB RAM, 512 KB flash

Firmware Tips

- Status LED
- Debug UART
- Mode switch
- Radio pairing
- Firmware update

Firmware - Status LED

- Solid RED: not connected to SteamVR
- Solid GREEN: connected (USB)
- Solid BLUE: connected (Wireless)
- Blinking BLUE (1 Hz): pairing mode (Wireless)
- Rapid blinking RED (7 Hz): bootloader
- Slow blinking RED (0.5 Hz): critical firmware error

Firmware - Debug UART

- 460800 baud, no parity, 8 data bits, 1 stop bit
- System info and errors
- Mostly to help Synapse debug your hardware

Firmware - Debug UART

```
Watchman v3 Reference Design Version: 1473363695 Date: 2016-09-08 12:41:35 Git: 716edd8 (bootloader)
Loading app at 0x430299

Watchman v3 Reference Design Version: 1473382930 Date: 2016-09-08 18:02:10 Git: 0f9eb47
Init SPI1, HMD flash
Init SPI1, Trackpad
Init SPI3, IMU
Init SPI3, Radio
Init SPI5, ICE40 config
Init SPI5, ICE40 data
Init TWI2
Devices:
[ flash_mcu ] 512 KB (1024 * 512 bytes, 0 pages reserved) @ 0x00400000

flash regions:
[ bootloader ] 1: 0x00000000 - 0x0000bfff ( 45124 of 49152 bytes used)
[ ice40_image ] 1: 0x0000c000 - 0x0002ffff (135180 of 147456 bytes used)
[ application ] 1: 0x00030000 - 0x0007bfff ( 89204 of 311296 bytes used)
[ trackpad ] 1: 0x0007a000 - 0x0007bfff ( 0 of 8192 bytes used)
[ stored_conf ] 1: 0x0007c000 - 0x0007dfff ( 0 of 8192 bytes used)
[ descriptors ] 1: 0x0007e000 - 0x0007ffff ( 280 of 8192 bytes used)
[ hardware_id ] 1: 0xc0ffeeee - 0xc0ffff0ed ( 0 of 512 bytes used)

stored_config: 0 of 8192 bytes used
HWID revision: 0x90030000 lot: 0x811f0001
BQ2429x No Battery Detected
2429x charger in Default Mode already
Started BQ27520 fuel gauge update timer at 60s
Queue: IMU time: 100 elements of size 4 [2000086c - 200009fc]
Queue: IMU RX: 100 elements of size 14 [20000a00 - 20000f78]
Queue: IMU TX: 25 elements of size 20 [20000f7c - 20001170]
$N: = [LHR-2FB6B063]
usb_vbus< 1 >
Sensor variant = 0x0
Queue: LEP_IN: 10 elements of size 12 [20003578 - 200035f0]
LEP: optical version: 1
LEP: sync detect: 0
Wireless version: 0x57cefaec
Mode: CONTROLLER
Trackpad version: 0x5a
#
```

Firmware - Mode Switch

Toggles between Controller and HMD mode

- Trackpad, analog trigger disabled for HMD
- Buttons work in either mode
- IMU: 1000 Hz vs. 250 Hz
- IMU: more vs less dynamic range

Mode switch resets the device

Firmware - Radio Pairing


1. Press System and Menu buttons for 3 seconds
2. LED blinks blue
3. In lighthouse_console, issue “unpair” + “pair” to USB dongle
4. LED solid blue if pairing succeeds

When using USB 3.0 port, plug dongle into extension cable

RFI - Radio Frequency Interference

- <https://www-ssl.intel.com/content/www/us/en/io/universal-serial-bus/usb3-frequency-interference-paper.html>

Firmware Updates



The screenshot shows the 'SteamVR Tracking HDK' forum page. The 'Discussions' tab is selected. A navigation bar at the top includes links for All, Discussions, Screenshots, Artwork, Broadcasts, Videos, News, Guides, and Reviews. Below the navigation bar, it indicates 'Showing 1-15 of 22 active topics'. A list of four pinned topics is displayed, each with a pin icon, a title, a user name, a timestamp, and a comment count.

Icon	Topic Title	User	Time	Comments
	PINNED: Please update your firmware	Sean @ Synapse	Sep 30 @ 6:24pm	0
	PINNED: New SteamVR Tracking Training courses available	Synapster	Sep 26 @ 5:05pm	0
	PINNED: Frequently Asked Questions	Programmer Joe	Aug 2 @ 9:51am	0
	Jtag for flashing new boards	Blackbox	3 hours ago	6

Firmware Updates

- Firmware will be released via SteamVR, as needed
- Update firmware via USB
- JTAG binaries available for manufacturing
- JTAG: Segger J-Link Base is recommended

USB:

C:\Program Files (x86)\Steam\steamapps\common\SteamVR Tracking HDK\firmware\10.27.2016>[hdk_firmware_update.bat](#)

JTAG:

C:\Program Files (x86)\Steam\steamapps\common\SteamVR Tracking HDK\firmware\jtag>[flash_mcu.bat](#) <j-link S/N>
[watchman_v3_hdk_mcu_jtag.bin](#)

Thanks!