



Connect power cords and apply power

StorageGRID 11.7

NetApp
January 09, 2024

This PDF was generated from <https://docs.netapp.com/us-en/storagegrid-117/installconfig/connecting-power-cords-and-applying-power-sgf6112.html> on January 09, 2024. Always check docs.netapp.com for the latest.

Table of Contents

- Connect power cords and apply power 1
 - Connect power cords and apply power (SGF6112) 1
 - Connect power cords and apply power (SG6000) 1
 - Connect power cords and apply power (SG5700) 2
 - Connect power cords and apply power (SG100 and SG1000) 2

Connect power cords and apply power

Connect power cords and apply power (SGF6112)

After connecting the network cables, you are ready to apply power to the appliance.

Steps

1. Connect a power cord to each of the two power supply units in the appliance.
2. Connect these two power cords to two different power distribution units (PDUs) in the cabinet or rack.
3. If the power button on the front of the appliance is not currently illuminated blue, press the button to turn on power to the appliance.

Don't press the power button again during the power-on process.

The LED on the power supply should be illuminated green without blinking.

4. If errors occur, correct any issues.
5. Attach the front bezel to the appliance if removed.

Related information

[View status indicators](#)

Connect power cords and apply power (SG6000)

After connecting the network cables, you are ready to apply power to the SG6000-CN controller and to the two storage controllers or optional expansion shelves.

Steps

1. Confirm that both controllers in the storage controller shelf are off.



Risk of electrical shock — Before connecting the power cords, make sure that the power switches for each of the two storage controllers are off.

2. If you have expansion shelves, confirm that both of the IOM power switches are off.



Risk of electrical shock — Before connecting the power cords, make sure that the two power switches for each of the expansion shelves are off.

3. Connect a power cord to each of the two power supply units in the SG6000-CN controller.
4. Connect these two power cords to two different power distribution units (PDUs) in the cabinet or rack.
5. Connect a power cord to each of the two power supply units in the storage controller shelf.
6. If you have expansion shelves, connect a power cord to each of the two power supply units in each expansion shelf.
7. Connect the two power cords in each storage shelf (including the optional expansion shelves) to two different PDUs in the cabinet or rack.
8. If the power button on the front of the SG6000-CN controller is not currently illuminated blue, press the button to turn on power to the controller.

Don't press the power button again during the power-on process.

9. Turn on the two power switches on the back of the storage controller shelf. If you have expansion shelves, turn on the two power switches for each shelf.
 - Don't turn off the power switches during the power-on process.
 - The fans in the storage controller shelf and optional expansion shelves might be very loud when they first start up. The loud noise during start-up is normal.
10. After the components have booted up, check their status.
 - Check the seven-segment display on the back of each storage controller. Refer to the article about viewing boot-up status codes for more information.
 - Verify that the power button on the front of the SG6000-CN controller is lit.
11. If errors occur, correct any issues.
12. Attach the front bezel to the SG6000-CN controller if removed.

Related information

- [View status indicators](#)
- [Reinstall SG6000-CN controller into cabinet or rack](#)

Connect power cords and apply power (SG5700)

When you apply power to the appliance, both controllers boot up.

Before you begin

Both appliance power switches must be off before connecting power.



Risk of electrical shock — Before connecting the power cords, make sure that the two power switches on the appliance are off.

Steps

1. Confirm that the two power switches on the appliance are off.
2. Connect the two power cords to the appliance.
3. Connect the two power cords to different power distribution units (PDUs) in the cabinet or rack.
4. Turn on the two power switches on the appliance.
 - Don't turn off the power switches during the power-on process.
 - The fans are very loud when they first start up. The loud noise during start-up is normal.
5. After the controllers have booted up, check their seven-segment displays.

Connect power cords and apply power (SG100 and SG1000)

After connecting the network cables, you are ready to apply power to the appliance.

Steps

1. Connect a power cord to each of the two power supply units in the appliance.
2. Connect these two power cords to two different power distribution units (PDUs) in the cabinet or rack.

3. If the power button on the front of the appliance is not currently illuminated blue, press the button to turn on power to the appliance.

Don't press the power button again during the power-on process.

4. If errors occur, correct any issues.
5. Attach the front bezel to the appliance if removed.

Related information

[View status indicators](#)

Copyright information

Copyright © 2024 NetApp, Inc. All Rights Reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means—graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system—without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP “AS IS” AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

LIMITED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (b)(3) of the Rights in Technical Data -Noncommercial Items at DFARS 252.227-7013 (FEB 2014) and FAR 52.227-19 (DEC 2007).

Data contained herein pertains to a commercial product and/or commercial service (as defined in FAR 2.101) and is proprietary to NetApp, Inc. All NetApp technical data and computer software provided under this Agreement is commercial in nature and developed solely at private expense. The U.S. Government has a non-exclusive, non-transferrable, nonsublicensable, worldwide, limited irrevocable license to use the Data only in connection with and in support of the U.S. Government contract under which the Data was delivered. Except as provided herein, the Data may not be used, disclosed, reproduced, modified, performed, or displayed without the prior written approval of NetApp, Inc. United States Government license rights for the Department of Defense are limited to those rights identified in DFARS clause 252.227-7015(b) (FEB 2014).

Trademark information

NETAPP, the NETAPP logo, and the marks listed at <http://www.netapp.com/TM> are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.