

Properties and Info functions

[Jump to bottom](#)

Federico Barresi edited this page on Jan 12, 2019 · 2 revisions

S7Client Public properties

ConnTimeout

Gets/Sets the connection timeout (in milliseconds) for a telegram.

RecvTimeout

Gets/Sets the receiving timeout (in milliseconds) for a telegram.

SendTimeout

Gets/Sets the sending timeout (in milliseconds) for a telegram.

Connected

It's true if the Client is connected. (read-only)

PduSizeNegotiated

Returns the PDU size negotiated. (read-only)

PduSizeRequested

Gets/Sets the PDU size to be negotiated.

PLCPort

Gets/Sets the connection Port (by default is 102).

ExecutionTime

Returns the last operation execution time in ms. (read-only)

S7Client Public info methods

LastError

```
public int LastError()
```

Returns the last operation error.

ErrorText

```
public string ErrorText(int Error)
```

Returns a textual explanation of Error

ExecutionTime

```
public int ExecTime()
```

Returns the last operation execution time in ms.

► Pages 11

[Home](#)

[S7Client](#)

[Get connected](#)

[I/O functions](#)

[System Info functions](#)

[PLC control functions](#)

[Security functions](#)

[Properties and info](#)

[ErrorCodes](#)

[S7Helper](#)

[S7MultiVar](#)

Clone this wiki locally

<https://github.com/fbarresi/Sharp7.wiki.git>



