



LOAD POINTS SHOWN ARE STATIC LOADS.

FOR DYNAMIC LOADING INFORMATION PLEASE REFER TO THE LATEST REVISION (REV) OF THE SUBSEQUENT LOADING DOCUMENTS.

119580-XX\_REV\_RPS\_V2.0\_Cell>Loading\_Presentation

121016-XX\_REV\_RSPS\_V2.1\_Pick\_Cell>Loading\_Presentation