

Messages in the display that are not error codes:

PR, Purge pumps for air:

Stands for Priming mode, occurs at start-up or restart. This is to run the pumps for to ensure that all air has left the system before the heating starts. If you want to skip this, press warm/temp button and the system starts up immediately.

---- / No temperature is displayed

The system has not determined the temperature of the water. This is usually displayed at startup or restart the bath is in rest/economy or sleep mode. Start circulation to see water temperature.

Std, EC, SL, Ready, Rest

Different modes of the system. Standard/Ready (Std) is the bath running and maintaining the set temperature.

ECO(economy) in this mode the spa only heats during programmed filter cycle times. It means the temperature will drop between these times. The SL or Sleep system drops the temperature with 11 degrees, for example the bath is at 38 degrees, the bath only heats to 27 degrees. See display manual for settings.

ICE, Too Cold

The system indicates that the water is below 8 degrees and all pumps/air blowers are running at full blast. This is a safety so the bath cannot freeze during the winter if the heater were to break. Meanwhile the bath is in ICE mode, so the heater does not run, but is heated by other equipment. When the bath came up to 8 degrees, the heater starts as usual. If you want to speed up this process, you can advantageously fill out the form with warmer water.

This message usually occurs when changing the water. ATTENTION! This can also indicate **that you have a fault with the heater!**