



WS8461 User manual

1. Introduction

To all residents of the European Union
Important environmental information about this product
This symbol on the device or the package indicates that the device (or batteries) as unwanted must not be disposed of with the household waste. It should be taken to a specialized company for recycling service. Respect the local environmental regulations. If in doubt, contact your local waste disposal authority. Thank you for choosing Valleman! Please read the manual before using this device into service. If the device was damaged during transport, please contact your dealer for replacement or use it and contact your dealer.

Safety Instructions

Keep this device away from children and avoid contact with water.

General Guidelines

to the Valleman® Service and Quality Department. Please protect this device from shocks and avoid operating the device against extreme heat or cold. Protect the device against extreme heat or cold. Familiarise yourself with the functions of the device. All modifications of the device are for your own risk. Only use the device for its intended purpose. Any use in an unauthorised way will void the warranty. Damage caused by disregard of the instructions is not covered by the warranty and the manufacturer is not responsible for any ensuing defects or problems.

4. Use

- Connect the outdoor sensor to the outdoor sensor compartment.
- Press C/F to switch between Celsius and Fahrenheit display.
- Press MIN/MAX to switch between indoor/outdoor (humidity, indoor/outdoor) memory.
- Hold FREEZE pressed to freeze the display.

01.07.2014