



WS8461
User manual

1. Introduction
To all residents of the European Union
Important environmental information about this product
The symbol on the device or the package indicates that disposal of the device after its lifecycle could harm the environment. Do not dispose of the unit (or batteries) as unsorted municipal waste; it should be taken to a specialized company for recycling. This device should be returned to your distributor or to a local recycling service. Respect the local environmental rules.
If in doubt, contact your local waste disposal authorities.
Thank you for choosing Velleman! Please read the manual thoroughly before bringing this device into service. If the device was damaged in transit, don't install or use it and contact your dealer.

Safety Instructions
Keep this device away from children and unauthorized users.

General Guidelines
To the Velleman® Service and Quality Warranty on the last page of this manual.
Protect this device from shocks and abuse. Remove battery force when repairing the device.
Protect the device against extreme heat and dust.
Familiarise yourself with the functions of the device before actually using it.
All modifications of the device are forbidden for safety reasons.
Only use the device for its intended purpose. Using the device in an unauthorized way will void the warranty.
Damage caused by disregard of certain guidelines in this manual covered by the warranty and the dealer will not accept responsibility for any resulting defects or problems.

4. Use
• Connect the outdoor sensor first. Open the battery compartment. Insert 1 x 1.5V AAA battery respecting the polarity. Close the compartment.
• Press C/F to switch between the °C and °F temperature display.
• Press IN/OUT to switch between the indoor and outdoor temperature display.
• Press MIN/MAX to switch between the minimum and maximum (humidity, indoor/outdoor temperature). Press CLE to clear memory.
• Hold FREEZE pressed for 3 seconds to activate the memory.