

Agilent U12xxx series

From sigrok

The Agilent U12xxx series are handheld digital multimeters, ranging from inexpensive all-purpose meters to industrial meters.

Model	Counts	Supported
U1231A	6000	Yes
U1232A	6000	Yes
U1233A	6000	Yes
U1241A / U1241B	10000	Yes
U1241C	10000	Yes
U1242A / U1242B	10000	Yes
U1242C	10000	Yes
U1251A / U1251B	50000	Yes
U1252A / U1252B	50000	Yes
U1253A / U1253B	50000	Yes
U1271A	30000	Yes
U1272A	30000	Yes
U1273A	30000	Yes
U1273AX	30000	Yes
U1281A	60000	Yes
U1282A	60000	Yes

Is your model not supported yet? Get in touch! We need people to help us test other models in this series, and getting a new model supported is generally quick & easy.

Contents

- 1 Connection
- 2 Protocol
 - 2.1 *IDN?
 - 2.2 *RST
 - 2.3 SYST:BATT?
 - 2.4 SYST:BEEP
 - 2.5 SYST:BLIT
 - 2.6 FETC?
 - 2.7 CONF:
 - 2.7.1 U123xx models
 - 2.7.2 U124xx/U125xx models
 - 2.8 CONF?
 - 2.8.1 U123xx models
 - 2.8.2 U124xx and U125xx models
 - 2.8.3 U124xC
 - 2.8.4 U128xx
 - 2.9 STAT?
 - 2.9.1 U123xx models
 - 2.9.2 U124xx models
 - 2.9.3 U124xC models
 - 2.9.4 U125xx models
 - 2.9.5 U127xx models
 - 2.9.6 U128xx models
 - 2.10 LOG:
 - 2.10.1 U123xx models

- 2.10.2 U124xC models
- 2.10.3 U125xx models
- 2.10.4 U128xx models
- 2.11 Event Notifiers
- 3 Resources

Connection

All models communicate via an optically isolated serial connection, usually at 9600 bps, 8 bits, no parity, and 1 stop bit (9600/8n1). Some models allow the user to change the serial parameters (e.g. the U1272A supports 9600/19200 baud, 7/8bits, parity odd/even/none).

Connecting to the devices can be done either via USB (U1173A cable or U1173B cable) or Bluetooth (U1177A interface).

Protocol

All models in this series use generally the same protocol, with only minor differences between models – and none within the same range.

The meters will respond to commands, which consist of a short ASCII string followed by either LF or CR+LF. The meter will either send no response at all, some ASCII text followed by CR+LF, or *E followed by CR+LF if the command given was invalid.

Some events (such as turning the rotary switch) will cause spontaneous transmissions of event notifiers. These consist of a * character, a single character and CR+LF.

*IDN?

Sending the command *IDN? causes the device to return a comma-separated four-field string, compatible with the identical GPIB command. The four fields are vendor name, model name, serial number and version:

```
Agilent Technologies,U1232A,MY52020136,V1.00
Agilent Technologies,U1253B,MY5xxxxxxx,V2.26
Agilent Technologies,U1272A,MY5xxxxxxx,V2.04
Keysight Technologies,U1242C,MY5xxxxxxx,V1.20
Keysight Technologies,U1282A,MY5xxxxxxx,V1.03
```

*RST

Sending the command *RST causes the device to reset. The response is an asterisk followed by the current dial position, for example *1 indicates the first position.

SYST:BATT?

The command SYST:BATT? returns a value indicating the device's battery level. The value is in a different format depending on the model series:

The U123xx, U124xC, U127xx and U128xx models return a percentage value, like this:

```
36%
```

The U124xx and U125xx models return a value like this:

```
+1.04200000E+02
```

SYST:BEEP

The command `SYST:BEEP` or `SYST:BEEP TONE` makes the multimeter emit a beep.

SYST:BLIT

The commands `SYST:BLIT 1` and `SYST:BLIT 0` turn the screen backlight on and off. There is no response. The backlight timer will still run and turn the backlight back off again if it is enabled.

The U127x devices don't seem to support this command.

FETC?

The `FETC?` command returns the current measured value, as a floating point ASCII string, as in the following examples:

```
+9.25000000E-03
+0.00000000E+00
-1.01140000E+00
-9.10200000E-01
```

The sign characters are always present, and the value is always in normalized scientific format. This applies even when in a mode that uses integer numbers, 11 would be transmitted as `+1.10000000E+01`. If no valid measurement is available, i.e. the display shows "OL" or "-OL", the transmitted value is either `+9.90000000E+37` and `-9.90000000E+37` respectively.

For models with dual display, the `FETC? @2` command returns the current value from the secondary display, in the same format.

CONF:

The `CONF:` commands can be used to change modes and ranges on the multimeter. It is not to be confused with the `CONF?` query described below.

For a given rotary switch position, only those `CONF:` commands work that switch to modes that can be reached by pressing the range or shift buttons.

U123xx models

Command	Rotary Switch Setting	Meaning
<code>CONF:VOLT:AC</code>	Any voltage mode	Switch to Volts AC mode with autoranging
<code>CONF:VOLT:DC</code>	Any voltage mode	Switch to Volts DC mode with autoranging
<code>CONF:VOLT:AC 600</code>	Any voltage mode	Switch to Volts AC mode and 600V range. Valid ranges are: 600, 60, 6, 0.6
<code>CONF:VOLT:AC 600</code>	Any voltage mode	Switch to Volts AC mode and 600V range. Valid ranges are: 600, 60, 6, 0.6
<code>CONF:CURR:AC</code>	Any current mode	Switch to AC current measurement mode with autoranging
<code>CONF:CURR:DC</code>	Any current mode	Switch to DC current measurement mode with autoranging
<code>CONF:CURR:AC 60u</code>	Any current mode	Switch to AC current measurement mode and 60uA range. Valid ranges are 10, 6 for A mode, and 600u, 60u for uA mode.
<code>CONF:CURR:DC 60u</code>	Any current mode	Switch to DC current measurement mode and 60uA range. Valid ranges are 10, 6 for A mode, and 600u, 60u for uA mode.
<code>CONF:FREQ</code>	VZlow, AC voltage or any current mode	Switch to frequency measurement mode. No manual ranges are available.
<code>CONF:CONT</code>	Resistance	Switch to continuity mode.
<code>CONF:RES</code>	Resistance	Switch to resistance mode with autoranging.
<code>CONF:RES 6M</code>	Resistance	Switch to resistance mode and 6MΩ range. Valid ranges are 60M, 6M, 600k, 60k 6k, 600
<code>CONF:CAP</code>	Capacitance	Switch to capacitance mode with autoranging.
<code>CONF:CAP 1000n</code>	Capacitance	Switch to capacitance mode and 1000nF range. Valid ranges are: 10m, 1000u, 100u, 10u, 1000n

--	--	--

U124xx/U125xx models

Same as above for the U123xx, except for different ranges.

CONF?

The `CONF?` command queries the device's current measurement configuration.

U123xx models

This can be either one, two or three comma-separated fields. The number of fields depends on the first field's value, but the second field always denotes the measurement mode's range and resolution, and the third field is the current type (AC or DC). For example, this indicates AC voltage in the 600mV range:

600mV,0,AC

Mode	Resolution	Current	Meaning
V	y	y	Volts
	0		Range 600mV, resolution 0.1mV
	1		Range 6V, resolution 1mV
	2		Range 60V, resolution 0.01V
	3		Range 600V, resolution 0.1V
MV	y	y	Millivolts
	1		Range 600mV, resolution 0.1mV
A	y	y	Ampere
	0		Range 6A, resolution 1mA
	1		Range 10A, resolution 0.01A
UA	y	y	Microampere
	0		Range 60μA, resolution 0.01μA
	1		Range 600μA, resolution 0.1μA
FREQ	y	y	AC frequency
	0		Range 99.9 Hz, resolution 0.01 Hz
	1		Range 999.9 Hz, resolution 0.1 Hz
	2		Range 9.999 kHz, resolution 1 Hz
	3		Range 99.99 kHz, resolution 10 Hz
	4		Range 200 kHz, resolution 100 Hz
RES	y	n	Resistance
	0		Range 600Ω, resolution 0.1Ω
	1		Range 6kΩ, resolution 0.001kΩ
	2		Range 60kΩ, resolution 0.01kΩ
	3		Range 600kΩ, resolution 0.1kΩ
	4		Range 6MΩ, resolution 0.001MΩ
	5		Range 60MΩ, resolution 0.01MΩ
CAP	y	n	Capacitance
	0		Range 1000nF, resolution 1nF
	1		Range 10μF, resolution 0.01μF
	2		Range 100μF, resolution 0.1μF
	3		Range 1000μF, resolution 1μF
	4		Range 10mF, resolution 0.01mF
DIOD	n	n	Diode

U124xx and U125xx models

The output consists of a quoted string with the meter's mode, followed by a space, two values, separated by a comma, denoting the current range, and the value of one count. The mode may optionally include a colon followed by a code denoting a submode relevant to that major mode. For example, AC voltage mode with 1000mV range on a 10000-count U1241B would be given as:

```
"VOLT:AC +1.000000E+00,+1.000000E-04"
```

Mode	Meaning
VOLT	DC voltage
VOLT:AC	AC voltage
CURR	DC current
CURR:AC	AC current
FREQ	Frequency counter
DIOD	Diode check. No range values are given.
CONT	Continuity. No range values are given.
RES	Resistance
CAP	Capacitance
SCOU	Switch counter. No range values are given.
CPER:0-20mA	Current loop, 0-20mA setting
CPER:4-20mA	Current loop, 4-20mA setting
T1:K or T2:K	Temperature on T1 or T2, submode can be K or J, denoting the thermocouple type. Instead of range values, CEL or FAR is given, denoting the measurement is in degrees Celsius or Fahrenheit. The full response might thus be: "T1:K CEL".

U124xC

The output is very similar to the U124xx and U125xx models with a few differences and additions.

Mode	Meaning
VOLT	DC voltage
VOLT:AC	AC voltage
VOLT:HRAT	Harmonic Ratio
CURR	DC current
CURR:AC	AC current
FREQ FREQ:AC	Frequency
DIOD	Diode check. No range values are given.
CONT	Continuity
RES	Resistance
CAP	Capacitance
CPER:0-20mA	Current loop, 0-20mA setting
CPER:4-20mA	Current loop, 4-20mA setting
TEMP	Internal temperature. No range values are given.
TEMP:K	Temperature, submode can be K or J, denoting the thermocouple type. Instead of range values, CEL or FAR is given, denoting the measurement is in degrees Celsius or Fahrenheit. The full response might thus be: "TEMP:K CEL".
NCV	Vsense (Non-contact Voltage). Instead of range values, HI or LO is given, denoting High sensitivity or Low sensitivity. The full response might thus be: "NCV HI".

U128xx

The output is very similar to the U124xC model with a few additions.

Mode	Meaning
VOLT	DC voltage
VOLT:AC	AC voltage
VOLT:ACDC	AC+DC voltage
CURR	DC current
CURR:AC	AC current
CURR:ACDC	AC+DC current
FREQ FREQ:AC	Frequency
PULS:PWID PULS:PWID:AC	Pulse width
PULS:PDUT	Duty cycle. No range values are given.
FC1	Frequency counter (0.5 Hz to 10 MHz)
FC100	Frequency counter (1 MHz to 100 MHz)
DIOD	Diode check. No range values are given.
CONT	Continuity
RES	Resistance
COND	Conductance
CAP	Capacitance
CPER:0-20mA	Current loop, 0-20mA setting
CPER:4-20mA	Current loop, 4-20mA setting
TEMP	Internal temperature. No range values are given.
TEMP:K	Temperature, submode can be K or J, denoting the thermocouple type. Instead of range values, CEL or FAR is given, denoting the measurement is in degrees Celsius or Fahrenheit. The full response might thus be: "TEMP:K CEL".
SQU	Square wave output. No range values are given.
NCV	Vsense (Non-contact Voltage). Instead of range values, HIGH or LOW is given, denoting High sensivity or Low sensitivity. The full response might thus be: "NCV HIGH".

STAT?

The `STAT?` command is used to query the current state of the device. The response is a quoted 21-byte string, like this:

"000000000110L00000000"

U123xx models

Byte	Value	Meaning
1		Max/min/avg mode
	0	Off
	1	On
2		Relative measurement. The last value returned from FETC? before this mode was enabled denotes the stored reference value.
	0	Off
	1	On
3		Trig hold-log
	0	Off
	1	On
4		Auto hold-log
	0	Off
	1	On
5		LED flashlight
	0	Off
	1	On
6		LCD backlight
	0	Off

	1	On
7		Smoothing
	0	Off
	1	On
8		Temp/aux mode. When on and rotary switch is in position 5 (capacitance), CONF? returns $mV, 1, DC$, but the value returned from FETC? instead denotes the temperature, in the unit (F or C) according to the meter's configuration.
	0	Off
	1	On
9		<i>Unknown (always 0)</i>
10		Beep frequency
	0	4.2kHz
	1	3.8kHz (default)
	2	3.4kHz
	3	3.2kHz
	4	Off
11		Auto power-off (APO)
	0	Off
	1	On
12		<i>Unknown (always 0)</i>
13		<i>Unknown (always L)</i>
14-15		<i>Unknown (always 0)</i>
16		Rotary switch position
	0	V/Zlow
	1	Voltage AC
	2	Voltage DC
	3	Resistance
	4	Diode
	5	Capacitance
	6	Current
	7	Microcurrent
17		Continuity mode. When enabled, the value returned from FETC? is either NAN (no continuity) or any real value to denote continuity.
	0	Off
	1	On
18		<i>Unknown (always 0)</i>
19		Battery low indicator
	0	Battery OK
	1	Battery low
20-21		<i>Unknown (always 0)</i>

U124xx models

Byte	Value	Meaning
1		Max/min/avg mode
	0	Off
	1	On
2		Relative measurement. The last value returned from FETC? before this mode was enabled denotes the stored reference value.
	0	Off
	1	On
3		<i>Unknown</i>
4		<i>Unknown</i>
5		<i>Unknown</i>
6		Current loop mode

	0	0-20mA mode
	1	4-20mA mode
7		<i>Unknown (always I)</i>
8		Hold mode.
	0	Off
	1	On
9		<i>Unknown</i>
10		Beep frequency
	0	Off (no beeps)
	C	300Hz
	F	600Hz
	1	1200Hz
	2	2400Hz
11		Auto power-off (APO)
	0	Off
	1	On
12		LCD backlight
	0	Off
	1	On
13		<i>Unknown (always L)</i>
14		<i>Unknown</i>
15		<i>Unknown</i>
16		Rotary switch position
	0	Voltage
	1	Diode
	2	Resistance
	3	Capacitance
	4	uA
	5	mA
	6	A
	7	Temperature
17		<i>Unknown</i>
18		<i>Unknown (always I)</i>
19		<i>Unknown</i>
20		Switch counter mode
	0	increase count on rising flank (initially low)
	1	increase count on falling flank (initially high)
21		Auto range
	0	Off
	1	On

U124xC models

Byte	Value	Meaning
1		Max/min/avg/maxminavg mode
	0	Off
	1	On
2		Relative measurement. The last value returned from FETC? before this mode was enabled denotes the stored reference value.
	0	Off
	1	On
3		Flashlight
	0	Off

	1	On
4		Probe socket connexion alert
	0	Off
	1	On
5		<i>Unknown</i>
6		<i>Unknown</i>
7		Smooth mode
	0	Off
	1	On
8		Trigger Hold
	0	Off
	1	On
9		0°C Temperature compensation
	0	Off
	1	On
10		Beep frequency
	0	Off (no beeps)
	1	3200 Hz
	2	3268 Hz
	3	3339 Hz
	4	3413 Hz
	5	3491 Hz
	6	4572 Hz
	7	3657 Hz
	8	3746 Hz
	9	3840 Hz
	A	3938 Hz
	B	4042 Hz
	C	4151 Hz
	D	4267 Hz
11		Auto power-off status
	0	Off
	1	On
12		Auto Hold
	0	Off
	1	On
13		Meter mode
	L	Normal
	C	Calibration
14		<i>Unknown</i>
15		<i>Reserved</i>
16		Rotary switch position
	0	Zlow Voltage AC / DC (V)
	1	Voltage AC (V) / H%
	2	Voltage DC (V)
	3	Resistance / continuity
	4	Diode / capacitance
	5	Current DC / AC (µA/mA)
	6	Current DC / AC (A)
	7	Temperature
17		Battery type
	0	Primary
	1	Secondary (rechargeable)

18		Battery low or Current percent
	0	Off
	1	Battery low or 4-20 mA mode
	2	0-20 mA mode and not Battery low
19		<i>Unknown</i>
20		<i>Unknown</i>
21		DC filter (LPF)
	0	Off
	1	On

U125xx models

Byte	Value	Meaning
1		Max/min/avg mode
	0	Off
	1	On
2		Relative measurement. The last value returned from FETC? before this mode was enabled denotes the stored reference value.
	0	Off
	1	On
3		dB mode
	0	Off
	m	dBm
	V	dBV
4		<i>Unknown</i>
5		Peak hold mode
	0	Off
	1	On
6		Current percent
	0	0-20mA
	1	4-20mA
7		<i>Triggerhold I/B ?</i>
8		Triggered hold mode.
	0	Off
	1	On
9		<i>Zero temperature compensation?</i>
10		<i>Beep selection ?</i>
11		Auto power-off (APO)
	0	Off
	1	On
12		LCD backlight
	0	Off
	1	On
13		<i>Unknown (always L)</i>
14		<i>Unknown (always 0)</i>
15		<i>Unknown</i>
16		<i>Rotary position ?</i>
17		<i>Output status active/standby ?</i>
18		<i>Unknown</i>
19		Battery low indicator
	0	Battery OK
	1	Battery low

20		Frequency counter prescaler
	0	No prescaling
	1	Divide by 100
21		Auto range
	0	Manual range
	1	Auto range

U127xx models

Byte	Value	Meaning
1		Max/min/avg/maxminavg mode
	0	Off
	1	On
2		Relative measurement. The last value returned from FETC? before this mode was enabled denotes the stored reference value.
	0	Off
	1	On
3		<i>Unknown</i>
4		<i>Unknown</i>
5		<i>Unknown</i>
6		<i>Unknown</i>
7		<i>Unknown</i>
8		<i>Unknown</i>
9		<i>Unknown</i>
10		Beep frequency
	0	Off (no beeps)
	1	3200Hz
	2	3491Hz
	3	3840Hz
	4	4267Hz
11		<i>Unknown</i>
12		<i>Unknown</i>
13		<i>Unknown (always L)</i>
14		<i>Unknown</i>
15		<i>Unknown</i>
16		Rotary switch position
	0	Zlow, V AC/DC
	1	<i>N/A (this is the "OFF" position)</i>
	2	Voltage AC (V) / LPF
	3	Voltage AC (mV) / LPF
	4	Voltage DC / AC (V)
	5	Voltage DC / AC (mV)
	6	Resistance / "smart resistance" / continuity
	7	Diode / Auto
	8	Capacitance / temperature
	9	Current DC / AC (mA/A)
	A	Current DC / AC (μA) Note: This is "A" in the "STAT?" reply, but "*10" in the event notifiers (see below).
17		Continuity mode. When enabled, the value returned from FETC? is either NAN (no continuity) or any real value to denote continuity.
	0	Off
	1	On
18		Smart Ohm mode ("O'Comp" icon active on the display).

	0	Off
	1	On
19		<i>Unknown</i>
20		LPF
	0	Off
	1	On
21		DC filter
	0	Off
	1	On

U128xx models

Byte	Value	Meaning
1		Max/min/avg/maxminavg mode
	0	Off
	1	On
2		Relative measurement. The last value returned from FETC? before this mode was enabled denotes the stored reference value.
	0	Off
	1	On
3		dB function
	0	Off
	M	dBm
	V	dBV
4		Probe socket connexion alert
	0	Off
	1	On
5		Peak-hold
	0	Off
	1	On
6		Current percent
	0	Off
	1	4-20 mA
	2	0-20 mA
7		Pulse width and duty cycle trigger level
	0	Negative
	1	Positive
8		Trigger Hold
	0	Off
	1	On
9		0°C Temperature compensation
	0	Off
	1	On
10		Beep frequency
	0	Off (no beeps)
	1	3200 Hz
	2	3268 Hz
	3	3339 Hz
	4	3413 Hz
	5	3491 Hz
	6	4572 Hz
	7	3657 Hz
	8	3746 Hz

	9	3840 Hz
	A	3938 Hz
	B	4042 Hz
	C	4151 Hz
	D	4267 Hz
11		Auto power-off status
	0	Off
	1	On
12		Auto Hold
	0	Off
	1	On
13		Meter mode
	L	Normal
	C	Calibration
14		Voltage alert
	0	Off
	1	On
15		<i>Reserved</i>
16		Rotary switch position
	0	Voltage AC (V) / LPF
	1	Voltage AC (mV) / LPF
	2	Voltage DC / AC (V)
	3	Voltage DC / AC (mV)
	4	Resistance / continuity / conductance
	5	Diode / frequency counter
	6	Capacitance / temperature
	7	Current DC / AC (μA/mA)
	8	Current DC / AC (A)
	9	Square wave output
17		Battery type
	0	Primary
	1	Secondary (rechargeable)
18		Battery low
	0	Off
	1	On
19		Resolution
	0	5 digits
	1	4 digits
20		LPF
	0	Off
	1	On
21		DC filter
	0	Off
	1	On

LOG:

Different commands can be used to retrieve the content of the different log memories from the multimeter. Those commands allow to retrieve log entries one by one, specifying the index of the entry to retrieve each time. When the index is greater than the index of the last logged value, the multimeter will return an error (*E). The actual commands depends on the model.

The response is presented as a quoted string whose length depends on the model.

Note that each log entry is also emitted by the multimeter whenever a new value is captured to the log.

U123xx models

The valid commands to retrieve log entries are yet to be determined.

Log entries are 15 characters long. Here is an example of log entry:

```
"050000210000200"
```

Note that the position of the decimal point is not explicitly given, it must be discerned from the range.

Byte	Value	Meaning
1		<i>Unknown (always 0)</i>
2		Function
	0	AUX
	1	Voltage
	2	Microcurrent
	4	Current
	5	Resistance or continuity
	6	Diode
	8	Capacitance
	9	Frequency
3		<i>Unknown (always 0)</i>
4		First (most significant) digit of measurement
5		Second digit of measurement
6		Third digit of measurement
7		Fourth (least significant) digit of measurement
8		Mode bits (several can be set at once)
	1	Autoranging is enabled
	2	Value is negative
9		Mode bits (several can be set at once)
	1	DC
	2	AC
	4	Overload
10		Range , values are the same as with CONF?
11		<i>Unknown (always 0)</i>
12		Temperature unit (probably)
	0	not in temperature mode
	1	degrees Fahrenheit (not confirmed, need to check)
	2	degrees Celsius
13		Mode bits (several can be set at once)
	1	Relative mode is enabled
	2	Trig Hold-Log mode is enabled
	4	Auto Hold-Log mode is enabled
14		Capacitance/AUX mode
	0	Capacitance
	1	AUX temperature (mV setting in menu is off)
	2	AUX mV (mV setting in menu is on)
15		<i>Unknown (always 0)</i>

U124xC models

The valid commands to retrieve log entries are:

LOG:HAND <index>
LOG:TRIG <index>
LOG:AUTO <index>
LOG:EXPO <index>

Log entries are 14 characters long. Here is an example of log entry:

"01000241100100"

Note that the position of the decimal point is not explicitly given, it must be discerned from the active function and exponent.

Byte	Value	Meaning
1-2		Function
	0	Millivoltage
	1	Voltage (averaging sense if Alternative unit flag and AC mode)
	2	Microcurrent (averaging sense if Alternative unit flag and AC mode)
	3	Current (averaging sense if Alternative unit flag and AC mode)
	4	Resistance (Continuity if Alternative unit flag)
	5	Diode
	6	Temperature in °C (or °F if Alternative unit flag)
	7	Capacitance
	8	Frequency
	9	Harmonic ratio
	10	%Scale of 4-20 mA (or 0-20 mA if Alternative unit flag)
3		First (most significant) digit of measurement
4		Second digit of measurement
5		Third digit of measurement
6		Fourth digit of measurement
7		Fifth (least significant) digit of measurement
8		Mode bits (several can be set at once)
	1	Autoranging is enabled
	2	Value is negative
9		Mode bits (several can be set at once)
	1	DC
	2	AC
	4	Overload
10		Exponent
11		Mode bits (several can be set at once)
	1	Alternate unit flag
	2	Thermocouple type (0 = K, 1 = J)
	4	Zero temperature compensation
12		Hold mode
	1	Trig-Hold mode
	3	Auto-Hold mode
	4	Relative mode is enabled (can be combined with *-Hold mode)
13		Mode bits (several can be set at once)
	1	Average
	2	Min
	4	Max
14		Data logging option
	0	Manual Log (Hand)
	1	Interval Log (Auto)
	2	Event Log (Trig)

	3	Export Log (Hold button)
--	---	--------------------------

Default exponent to be applied to the value for the different functions, in addition to the Exponent field.

Exponent	Function
10e-5	Millivoltage
10e-4	Voltage
10e-7	Microcurrent
10e-3	Current
10e-2	Resistance / Continuity
10e-3	Diode
10e-1	Temperature (both °C and °F)
10e-10	Capacitance
10e-2	Frequency
10e-2	Harmonic ratio
10e-2	%Scale of 4-20 mA / 0-20 mA

U125xx models

The valid commands to retrieve log entries are:

```
LOG? H<index>
LOG? A<index>
```

Note that <index> must be exactly 3 digits

Log entries are 13 characters long. Here is an example of log entry:

```
"0522041404000"
```

Note that the position of the decimal point is not explicitly given, it must be discerned from the active function and exponent.

Byte	Value	Meaning
1-2		Function
	0	Millivoltage
	1	Voltage
	2	<i>Unknown</i>
	3	Current
	4	<i>Unknown</i>
	5	Resistance (Continuity if Alternative unit flag ?, Conductance if Locked / Manual ranging)
	6	Diode
	7	Temperature in °C (or °F if Alternative unit flag)
	8	Capacitance
	9	Frequency
	10	Duty cycle
	11	Pulse width
	12	<i>Unknown</i>
	13	dBm (or dBV if Alternative unit flag)
	14	%Scale of 4-20 mA (or 0-20 mA if Alternative unit flag)
3		First (most significant) digit of measurement
4		Second digit of measurement
5		Third digit of measurement
6		Fourth digit of measurement
7		Fifth (least significant) digit of measurement

8		Mode bits (several can be set at once)
	1	Locked ? Manual ranging is enabled ?
	2	Value is negative
9		Mode bits (several can be set at once)
	1	DC
	2	AC
	4	Overload
10		Exponent
11		Mode bits (several can be set at once)
	1	Alternate unit flag
	2	Thermocouple type (0 = K, 1 = J)
	4	Environment temperature compensation ?
12		Hold mode
	1	Trig-Hold mode ?
	2	Peak-Hold mode ?
	3	Auto-hold mode ?
	4	Relative mode is enabled (can be combined with *-Hold mode)
13		Mode bits (several can be set at once)
	1	Average
	2	Min
	4	Max
	8	"press" ?

Default exponent to be applied to the value for the different functions, in addition to the Exponent field.

Exponent	Function
10 ⁻⁷	Millivoltage
10 ⁻⁵	Voltage
10 ⁻⁷	Current
10 ⁻³	Resistance / Continuity
10 ⁻¹⁹	Conductance
10 ⁻⁵	Diode
10 ⁻²	Temperature
10 ⁻¹³	Capacitance
10 ⁻³	Frequency
10 ⁻⁵	Duty cycle
10 ⁻⁵	Pulse width
10 ⁻³	dBm / dBV
10 ⁻³	%Scale of 4-20 mA / 0-20 mA

U128xx models

The valid commands to retrieve log entries are:

```
LOG:HAND <index>
LOG:TRIG <index>
LOG:AUTO <index>
LOG:EXPO <index>
```

Log entries are 14 characters long. Here is an example of log entry:

```
"04235201470002"
```

Note that the position of the decimal point is not explicitly given, it must be discerned from the active function and exponent.

Byte	Value	Meaning
1-2		Function
	0	Millivoltage
	1	Voltage
	2	Microcurrent
	3	Current
	4	Resistance (Continuity if Alternative unit flag)
	5	Diode
	6	Temperature in °C (or °F if Alternative unit flag)
	7	Capacitance
	8	Frequency
	9	Duty cycle (positive pulse, or negative if Alternative unit flag)
	10	Pulse width (positive pulse, or negative if Alternative unit flag)
	11	dBm (or dBV if Alternative unit flag)
	12	%Scale of 4-20 mA (or 0-20 mA if Alternative unit flag)
	13	Conductance
3		First (most significant) digit of measurement
4		Second digit of measurement
5		Third digit of measurement
6		Fourth digit of measurement
7		Fifth (least significant) digit of measurement
8		Mode bits (several can be set at once)
	1	Autoranging is enabled
	2	Value is negative
9		Mode bits (several can be set at once)
	1	DC
	2	AC
	4	Overload
10		Exponent
11		Mode bits (several can be set at once)
	1	Alternate unit flag
	2	Thermocouple type (0 = K, 1 = J)
	4	Zero temperature compensation
12		Hold mode
	1	Trig-Hold mode
	2	Peak-Hold mode
	3	Auto-hold mode
	4	Relative mode is enabled (can be combined with *-Hold mode)
13		Mode bits (several can be set at once)
	1	Average
	2	Min
	4	Max
14		Data logging option
	0	Manual Log (Hand)
	1	Event Log (Trig)
	2	Interval Log (Auto)
	3	Export Log (Hold button)

Default exponent to be applied to the value for the different functions, in addition to the Exponent field.

Exponent	Function

10 ⁻⁶	Millivoltage
10 ⁻⁴	Voltage
10 ⁻⁹	Microcurrent
10 ⁻⁴	Current
10 ⁻³	Resistance / Continuity
10 ⁻⁴	Diode
10 ⁻¹	Temperature °C
10 ⁻²	Temperature °F
10 ⁻¹²	Capacitance
10 ⁻³	Frequency
10 ⁻³	Duty cycle
10 ⁻⁶	Pulse width
10 ⁻³	dBm / dBV
10 ⁻²	%Scale of 4-20 mA / 0-20 mA
10 ⁻¹¹	Conductance

Event Notifiers

String	Meaning
* ₀ through * ₇	Rotary switch position has changed. * ₀ denotes the most counter-clockwise position (excluding the OFF position), then the value is increased by one for each step in the rotary switch's range. On the U127xx models the codes range from * ₀ through * ₁₀ .
* _B	Battery voltage dropped to "battery empty" level.
* _E	Invalid command.
* _I	Probes are connected to the wrong sockets for this mode, "Cerr" is shown on display (not supported on U123xx; it <i>is</i> supported on U124xC, U127xx and U128xx).
* _L	A button was pressed (not supported on U123xx, U124xC, U127xx and U128xx). This notifier is only sent once after a command, even if the user presses several buttons.

Resources

- Series overview (<http://www.keysight.com/en/pc-1000004008%3Aepsg%3Apgr/handheld-digital-multimeter-clamp-and-calibrator-meters>)
- Documentation (<http://www.keysight.com/main/facet.jspx?c=181653.i.1&to=80029.k.0>)

Retrieved from "https://sigrok.org/w/index.php?title=Agilent_U12xxx_series&oldid=15935"

- This page was last edited on 6 December 2020, at 19:51.