



# SUSE 12

## ONTAP SAN Host

NetApp  
August 20, 2020

This PDF was generated from [https://docs.netapp.com/us-en/ontap-sanhost/hu\\_suse\\_12SP5.html](https://docs.netapp.com/us-en/ontap-sanhost/hu_suse_12SP5.html) on August 20, 2020. Always check docs.netapp.com for the latest.

# Table of Contents

- SUSE 12 ..... 1
  - Using SUSE Linux Enterprise Server 12 SP5 with NetApp ONTAP ..... 1
  - Using SUSE Linux Enterprise Server 12 SP4 with NetApp ONTAP ..... 8
  - Using SUSE Linux Enterprise Server 12 SP3 with NetApp ONTAP ..... 13
  - Using SUSE Linux Enterprise Server 12 SP2 with NetApp ONTAP ..... 24
  - Using SUSE Linux Enterprise Server 12 SP1 with NetApp ONTAP ..... 29
  - Using SUSE Linux Enterprise Server 12 with NetApp ONTAP ..... 35

# SUSE 12

## Using SUSE Linux Enterprise Server 12 SP5 with NetApp ONTAP

### Installing the Linux Unified Host Utilities

The NetApp Linux Unified Host Utilities software package is available on the [NetApp Support Site](#) in a 32-bit and 64-bit .rpm file. If you do not know which file is right for your configuration, use the [NetApp Interoperability Matrix Tool](#) to verify which one you need.

Installing the Linux Unified Host Utilities is strongly recommended, but not mandatory. The utilities do not change any settings on your Linux host. The utilities improve management and assist NetApp customer support in gathering information about your configuration.

#### *Before you begin*

If you have a version of Linux Unified Host Utilities currently installed you should upgrade it or, you should remove it and use the following steps to install the latest version.

1. Download the 32-bit or 64-bit Linux Unified Host Utilities software package from the [NetApp Support Site](#) to your host.
2. Use the following command to install the software package:

```
rpm -ivh netapp_linux_unified_host_utilities-7-1.x86_64
```

### SAN Toolkit

The toolkit is installed automatically when you install the NetApp Host Utilities package. This kit provides the `sanlun` utility, which helps you manage LUNs and HBAs. The `sanlun` command returns information about the LUNs mapped to your host, multipathing, and information necessary to create initiator groups.

#### *Example*

In the following example, the `sanlun lun show` command returns LUN information.

```
# sanlun lun show all
controller(7mode/E-Series)/          device      host
vserver(cDOT/FlashRay)  lun-pathname filename  adapter  protocol  lun
-----
data_vserver            /vol/vol1/lun1  /dev/sdb  host16    FCP       120.0g  cDOT
data_vserver            /vol/vol1/lun1  /dev/sdc  host15    FCP       120.0g  cDOT
data_vserver            /vol/vol2/lun2  /dev/sdd  host16    FCP       120.0g  cDOT
data_vserver            /vol/vol2/lun2  /dev/sde  host15    FCP       120.0g  cDOT
```

## SAN Booting

### *Before you begin*

If you decide to use SAN booting, it must be supported by your configuration. You can use the [NetApp Interoperability Matrix Tool](#) to verify that your OS, HBA, HBA firmware and the HBA boot BIOS, and ONTAP version are supported.

1. Map the SAN boot LUN to the host.
2. Verify multiple paths are available.

Remember, multiple paths will only be available after the host OS is up and running on the paths.

3. Enable SAN booting in the server BIOS for the ports to which the SAN boot LUN is mapped.

For information on how to enable the HBA BIOS, see your vendor-specific documentation.

4. Reboot the host to verify the boot is successful.

## Multipathing

For SUSE Linux Enterprise Server 12 SP5 the `/etc/multipath.conf` file must exist, but you do not need to make specific changes to the file. SUSE Linux Enterprise Server 12 SP5 is compiled with all settings required to recognize and correctly manage ONTAP LUNs.

You can use the `multipath -ll` command to verify the settings for your ONTAP LUNs.

The following sections provide sample multipath output for a LUN mapped to ASA and non-ASA personas.

### All SAN Array Configuration

For All SAN Array (ASA) configuration there should be one group of paths with single priorities. All the paths are Active/Optimized, meaning they are serviced by the controller and I/O is sent on all the active paths.

### *Example*

The following example displays the correct output for an ONTAP LUN with four Active/Optimized

paths:

```
# multipath -ll
3600a0980383034466b2b4a3775474859 dm-3 NETAPP,LUN C-Mode
size=20G features='4 queue_if_no_path pg_init_retries 50 retain_attached_hw_handle'
hwhandler='1 alua' wp=rw
|+- policy='round-robin 0' prio=50 status=active
| |- 1:0:8:1 sdb 8:16 active ready running
| `-- 2:0:8:1 sdd 8:48 active ready running
`+- policy='round-robin 0' prio=10 status=enabled
  |- 1:0:9:1 sdc 8:32 active ready running
  `-- 2:0:9:1 sde 8:64 active ready running
```

#### *Note*

Do not use an excessive number of paths to a single LUN. No more than 4 paths should be required. More than 8 paths might cause path issues during storage failures.

### **Non-ASA Configuration**

For non-ASA configuration there should be two groups of paths with different priorities. The paths with the higher priorities are Active/Optimized, meaning they are serviced by the controller where the aggregate is located. The paths with the lower priorities are active but are non-optimized because they are served from a different controller. The non-optimized paths are only used when no optimized paths are available.

#### *Example*

The following example displays the correct output for an ONTAP LUN with two Active/Optimized paths and two Active/non-Optimized paths:

```
#multipath -ll
3600a09803831347657244e527766394e dm-5 NETAPP,LUN C-Mode
size=80G features='3 queue_if_no_path pg_init_retries 50' hwhandler='1 alua' wp=rw
|+- policy='service-time 0' prio=50 status=active
| |- 11:0:1:0 sdj 8:144 active ready running
| |- 11:0:2:0 sdr 65:16 active ready running
`+- policy='service-time 0' prio=10 status=enabled
  |- 11:0:0:0 sdb 8:i6 active ready running
  |- 12:0:0:0 sdz 65:144 active ready running
```

#### *Note*

Do not use an excessive number of paths to a single LUN. No more than 4 paths should be required. More than 8 paths might cause path issues during storage failures.

## Recommended Settings

SUSE Linux Enterprise Server 12 SP5 OS is compiled to recognize ONTAP LUNs and automatically set all configuration parameters correctly.

The `multipath.conf` file must exist for the multipath daemon to start, but you can create an empty, zero-byte file using the command:

```
touch /etc/multipath.conf
```

The first time you create this file, you might need to enable and start the multipath services.

```
[root@jfs0 ~]#systemctl enable multipathd
[root@jfs0 ~]# systemctl start multipathd
```

There is no requirement to add anything directly to `multipath.conf`, unless you have devices that you do not want to be managed by multipath or you have existing settings that override defaults.

You can add the following syntax to the `multipath.conf` file to exclude the unwanted devices.

### *Note*

Replace the `<DevId>` with the WWID string of the device you want to exclude. Use the following command to determine the WWID:

```
blacklist {
    wwid <DevId>
    devnode "(ram|raw|loop|fd|md|dm-|sr|scd|st)[0-9]*"
    devnode "^hd[a-z]"
    devnode "^cciss.*"
}
```

### *Example*

In this example, `sda` is the local SCSI disk that we need to blacklist.

1. Run the following command to determine the WWID:

```
# /lib/udev/scsi_id -gud /dev/sda
360030057024d0730239134810c0cb833
```

2. Add this WWID to the blacklist stanza in the `/etc/multipath.conf`:

```
blacklist {
    wwid    360030057024d0730239134810c0cb833
    devnode "^(ram|raw|loop|fd|md|dm-|sr|scd|st)[0-9]*"
    devnode "^hd[a-z]"
    devnode "^cciss.*"
}
```

You should always check your `/etc/multipath.conf` file for legacy settings, especially in the defaults section, that may be overriding default settings.

The table below shows the critical `multipathd` parameters for ONTAP LUNs and the required values. If a host is connected to LUNs from other vendors and any of these parameters are overridden, they will need to be corrected by later stanzas in `multipath.conf` that apply specifically to ONTAP LUNs. If this is not done, the ONTAP LUNs may not work as expected. These defaults should only be overridden in consultation with NetApp and/or OS vendor and only when the impact is fully understood.

Parameter	Setting
detect_prio	yes
dev_loss_tmo	"infinity"
failback	immediate
fast_io_fail_tmo	5
features	"2 pg_init_retries 50"
flush_on_last_del	"yes"
hardware_handler	"0"
no_path_retry	queue
path_checker	"tur"
path_grouping_policy	"group_by_prio"
path_selector	"service-time 0"
polling_interval	5
prio	"ontap"
product	LUN.*
retain_attached_hw_handler	yes
rr_weight	"uniform"
user_friendly_names	no
vendor	NETAPP

*Example*

The following example shows how to correct an overridden default. In this case, the `multipath.conf` file defines values for `path_checker` and `no_path_retry` that are not compatible with ONTAP LUNs. If they cannot be removed because of other SAN arrays still attached to the host, these parameters can be corrected specifically for ONTAP LUNs with a device stanza.

```
defaults {
  path_checker readsector0
  no_path_retry fail
}
devices {
  device {
    vendor "NETAPP "
    product "LUN.*"
    no_path_retry queue
    path_checker tur
  }
}
```

## Known Problems and Limitations



NetApp Bug ID	Title	Description	Bugzilla ID
<a href="#">1284293</a>	Kernel disruption occurs on SLES12 SP5 with QLogic QLE2562 8GB FC HBA during storage failover operations	Kernel disruption occurs during storage failover operations on the SLES12 SP5 kernel with a QLogic QLE2562 Fibre Channel (FC) host bus adapter (HBA). The kernel disruption causes SLES12 SP5 to reboot, leading to application disruption. If the kdump mechanism is enabled, the kernel disruption generates a vmcore file located in the /var/crash/ directory. Check the vmcore file to determine the cause of the disruption. A storage failover with a QLogic QLE2562 HBA event affects the "THREAD_INFO: ffff8a EDF723C2C0" module. Locate this event in the vmcore file by finding the following string: "[THREAD_INFO: ffff8a EDF723C2C0]". After the kernel disruption, reboot the host OS to enable it to recover. Then restart the applications.	<a href="#">1157966</a>

## Release Notes

### ASM Mirroring

ASM mirroring might require changes to the Linux multipath settings to allow ASM to recognize a problem and switch over to an alternate fail group. Most ASM configurations on ONTAP use external redundancy, which means that data protection is provided by the external array and ASM does not mirror data. Some sites use ASM with normal redundancy to provide two-way mirroring, normally

across different sites. See [Oracle Databases on ONTAP](#) for further information.

# Using SUSE Linux Enterprise Server 12 SP4 with NetApp ONTAP

## Installing the Linux Unified Host Utilities

The NetApp Linux Unified Host Utilities software package is available on the [NetApp Support Site](#) in a 32-bit and 64-bit .rpm file. If you do not know which file is right for your configuration, use the [NetApp Interoperability Matrix Tool](#) to verify which one you need.

Installing the Linux Unified Host Utilities is strongly recommended, but not mandatory. The utilities do not change any settings on your Linux host. The utilities improve management and assist NetApp customer support in gathering information about your configuration.

### *Before you begin*

If you have a version of Linux Unified Host Utilities currently installed you should upgrade it or, you should remove it and use the following steps to install the latest version.

1. Download the 32-bit or 64-bit Linux Unified Host Utilities software package from the [NetApp Support Site](#) to your host.
2. Use the following command to install the software package:

```
rpm -ivh netapp_linux_unified_host_utilities-7-1.x86_64
```

## SAN Toolkit

The toolkit is installed automatically when you install the NetApp Host Utilities package. This kit provides the **sanlun** utility, which helps you manage LUNs and HBAs. The **sanlun** command returns information about the LUNs mapped to your host, multipathing, and information necessary to create initiator groups.

### *Example*

In the following example, the **sanlun lun show command** returns LUN information.

```
# sanlun lun show all
controller(7mode/E-Series)/      device      host      lun
vserver(cDOT/FlashRay)  lun-pathname filename  adapter  protocol  size  Product
-----
data_vserver            /vol/vol1/lun1  /dev/sdb  host16    FCP       120.0g  cDOT
data_vserver            /vol/vol1/lun1  /dev/sdc  host15    FCP       120.0g  cDOT
data_vserver            /vol/vol2/lun2  /dev/sdd  host16    FCP       120.0g  cDOT
data_vserver            /vol/vol2/lun2  /dev/sde  host15    FCP       120.0g  cDOT
```

## SAN Booting

### *Before you begin*

If you decide to use SAN booting, it must be supported by your configuration. You can use the [NetApp Interoperability Matrix Tool](#) to verify that your OS, HBA, HBA firmware and the HBA boot BIOS, and ONTAP version are supported.

1. Map the SAN boot LUN to the host.
2. Verify multiple paths are available.

Remember, multiple paths will only be available after the host OS is up and running on the paths.

3. Enable SAN booting in the server BIOS for the ports to which the SAN boot LUN is mapped.

For information on how to enable the HBA BIOS, see your vendor-specific documentation.

4. Reboot the host to verify the boot is successful.

## Multipathing

For SUSE Linux Enterprise Server 12 SP4 the `/etc/multipath.conf` file must exist, but you do not need to make specific changes to the file. SUSE Linux Enterprise Server 12 SP4 is compiled with all settings required to recognize and correctly manage ONTAP LUNs.

You can use the `multipath -ll` command to verify the settings for your ONTAP LUNs.

The following sections provide sample multipath output for a LUN mapped to ASA and non-ASA personas.

### All SAN Array Configuration

For All SAN Array (ASA) configuration there should be one group of paths with single priorities. All the paths are Active/Optimized, meaning they are serviced by the controller and I/O is sent on all the active paths.

### *Example*

The following example displays the correct output for an ONTAP LUN with four Active/Optimized paths:

```
# multipath -ll
3600a0980383034466b2b4a3775474859 dm-3 NETAPP,LUN C-Mode
size=20G features='4 queue_if_no_path pg_init_retries 50 retain_attached_hw_handle'
hwhandler='1 alua' wp=rw
|+- policy='round-robin 0' prio=50 status=active
| |- 1:0:8:1 sdb 8:16 active ready running
| `-- 2:0:8:1 sdd 8:48 active ready running
`+- policy='round-robin 0' prio=10 status=enabled
  |- 1:0:9:1 sdc 8:32 active ready running
  `-- 2:0:9:1 sde 8:64 active ready running
```

#### *Note*

Do not use an excessive number of paths to a single LUN. No more than 4 paths should be required. More than 8 paths might cause path issues during storage failures.

### **Non-ASA Configuration**

For non-ASA configuration there should be two groups of paths with different priorities. The paths with the higher priorities are Active/Optimized, meaning they are serviced by the controller where the aggregate is located. The paths with the lower priorities are active but are non-optimized because they are served from a different controller. The non-optimized paths are only used when no optimized paths are available.

#### *Example*

The following example displays the correct output for an ONTAP LUN with two Active/Optimized paths and two Active/non-Optimized paths:

```
#multipath -ll
3600a09803831347657244e527766394e dm-5 NETAPP,LUN C-Mode
size=80G features='3 queue_if_no_path pg_init_retries 50' hwhandler='1 alua' wp=rw
|+- policy='service-time 0' prio=50 status=active
| |- 11:0:1:0 sdj 8:144 active ready running
| |- 11:0:2:0 sdr 65:16 active ready running
`+- policy='service-time 0' prio=10 status=enabled
  |- 11:0:0:0 sdb 8:i6 active ready running
  |- 12:0:0:0 sdz 65:144 active ready running
```

#### *Note*

Do not use an excessive number of paths to a single LUN. No more than 4 paths should be required. More than 8 paths might cause path issues during storage failures.

## Recommended Settings

SUSE Linux Enterprise Server 12 SP4 OS is compiled to recognize ONTAP LUNs and automatically set all configuration parameters correctly.

The `multipath.conf` file must exist for the multipath daemon to start, but you can create an empty, zero-byte file using the command:

```
touch /etc/multipath.conf
```

The first time you create this file, you might need to enable and start the multipath services.

```
[root@jfs0 ~]#systemctl enable multipathd
[root@jfs0 ~]# systemctl start multipathd
```

There is no requirement to add anything directly to `multipath.conf`, unless you have devices that you do not want to be managed by multipath or you have existing settings that override defaults.

You can add the following syntax to the `multipath.conf` file to exclude the unwanted devices.

### *Note*

Replace the `<DevId>` with the WWID string of the device you want to exclude. Use the following command to determine the WWID:

```
blacklist {
    wwid <DevId>
    devnode "(ram|raw|loop|fd|md|dm-|sr|scd|st)[0-9]*"
    devnode "^hd[a-z]"
    devnode "^cciss.*"
}
```

### *Example*

In this example, `sda` is the local SCSI disk that we need to blacklist.

1. Run the following command to determine the WWID:

```
# /lib/udev/scsi_id -gud /dev/sda
360030057024d0730239134810c0cb833
```

2. Add this WWID to the blacklist stanza in the `/etc/multipath.conf`:

```
blacklist {
    wwid    360030057024d0730239134810c0cb833
    devnode "^(ram|raw|loop|fd|md|dm-|sr|scd|st)[0-9]*"
    devnode "^hd[a-z]"
    devnode "^cciss.*"
}
```

You should always check your `/etc/multipath.conf` file for legacy settings, especially in the defaults section, that may be overriding default settings.

The table below shows the critical `multipathd` parameters for ONTAP LUNs and the required values. If a host is connected to LUNs from other vendors and any of these parameters are overridden, they will need to be corrected by later stanzas in `multipath.conf` that apply specifically to ONTAP LUNs. If this is not done, the ONTAP LUNs may not work as expected. These defaults should only be overridden in consultation with NetApp and/or OS vendor and only when the impact is fully understood.

Parameter	Setting
detect_prio	yes
dev_loss_tmo	"infinity"
failback	immediate
fast_io_fail_tmo	5
features	"2 pg_init_retries 50"
flush_on_last_del	"yes"
hardware_handler	"0"
no_path_retry	queue
path_checker	"tur"
path_grouping_policy	"group_by_prio"
path_selector	"service-time 0"
polling_interval	5
prio	"ontap"
product	LUN.*
retain_attached_hw_handler	yes
rr_weight	"uniform"
user_friendly_names	no
vendor	NETAPP

*Example*

The following example shows how to correct an overridden default. In this case, the `multipath.conf` file defines values for `path_checker` and `no_path_retry` that are not compatible with ONTAP LUNs. If they cannot be removed because of other SAN arrays still attached to the host, these parameters can be corrected specifically for ONTAP LUNs with a device stanza.

```
defaults {
  path_checker readsector0
  no_path_retry fail
}
devices {
  device {
    vendor "NETAPP "
    product "LUN.*"
    no_path_retry queue
    path_checker tur
  }
}
```

## Known Problems and Limitations

There are no known issues for SUSE Linux Enterprise Server 12 SP4.

## Release Notes

### ASM Mirroring

ASM mirroring might require changes to the Linux multipath settings to allow ASM to recognize a problem and switch over to an alternate fail group. Most ASM configurations on ONTAP use external redundancy, which means that data protection is provided by the external array and ASM does not mirror data. Some sites use ASM with normal redundancy to provide two-way mirroring, normally across different sites. See [Oracle Databases on ONTAP](#) for further information.

## Using SUSE Linux Enterprise Server 12 SP3 with NetApp ONTAP

### Installing the Linux Unified Host Utilities

The NetApp Linux Unified Host Utilities software package is available on the [NetApp Support Site](#) in a 32-bit and 64-bit .rpm file. If you do not know which file is right for your configuration, use the [NetApp Interoperability Matrix Tool](#) to verify which one you need.

Installing the Linux Unified Host Utilities is strongly recommended, but not mandatory. The utilities do not change any settings on your Linux host. The utilities improve management and assist NetApp customer support in gathering information about your configuration.

*Before you begin*

If you have a version of Linux Unified Host Utilities currently installed you should upgrade it or, you should remove it and use the following steps to install the latest version.

1. Download the 32-bit or 64-bit Linux Unified Host Utilities software package from the [NetApp Support Site](#) to your host.
2. Use the following command to install the software package:

```
rpm -ivh netapp_linux_unified_host_utilities-7-1.x86_64
```

**SAN Toolkit**

The toolkit is installed automatically when you install the NetApp Host Utilities package. This kit provides the `sanlun` utility, which helps you manage LUNs and HBAs. The `sanlun` command returns information about the LUNs mapped to your host, multipathing, and information necessary to create initiator groups.

*Example*

In the following example, the `sanlun lun show command` returns LUN information.

```
# sanlun lun show all
controller(7mode/E-Series)/          device      host
vserver(cDOT/FlashRay)  lun-pathname filename  adapter  protocol  lun      Product
-----
data_vserver            /vol/vol1/lun1  /dev/sdb  host16   FCP       120.0g   cDOT
data_vserver            /vol/vol1/lun1  /dev/sdc  host15   FCP       120.0g   cDOT
data_vserver            /vol/vol2/lun2  /dev/sdd  host16   FCP       120.0g   cDOT
data_vserver            /vol/vol2/lun2  /dev/sde  host15   FCP       120.0g   cDOT
```

**SAN Booting**

*Before you begin*

If you decide to use SAN booting, it must be supported by your configuration. You can use the [NetApp Interoperability Matrix Tool](#) to verify that your OS, HBA, HBA firmware and the HBA boot BIOS, and ONTAP version are supported.

1. Map the SAN boot LUN to the host.
2. Verify multiple paths are available.

Remember, multiple paths will only be available after the host OS is up and running on the paths.

3. Enable SAN booting in the server BIOS for the ports to which the SAN boot LUN is mapped.

For information on how to enable the HBA BIOS, see your vendor-specific documentation.



4. Reboot the host to verify the boot is successful.

## Multipathing

For SUSE Linux Enterprise Server 12 SP3 the `/etc/multipath.conf` file must exist, but you do not need to make specific changes to the file. SUSE Linux Enterprise Server 12 SP3 is compiled with all settings required to recognize and correctly manage ONTAP LUNs.

You can use the `multipath -ll` command to verify the settings for your ONTAP LUNs.

The following sections provide sample multipath output for a LUN mapped to ASA and non-ASA personas.

### All SAN Array Configuration

For All SAN Array (ASA) configuration there should be one group of paths with single priorities. All the paths are Active/Optimized, meaning they are serviced by the controller and I/O is sent on all the active paths.

#### Example

The following example displays the correct output for an ONTAP LUN with four Active/Optimized paths:

```
# multipath -ll
3600a0980383034466b2b4a3775474859 dm-3 NETAPP,LUN C-Mode
size=20G features='4 queue_if_no_path pg_init_retries 50 retain_attached_hw_handle'
hwhandler='1 alua' wp=rw
|-+- policy='round-robin 0' prio=50 status=active
|  |- 1:0:8:1   sdb 8:16 active ready running
|  |- 2:0:8:1   sdd 8:48 active ready running
`-+- policy='round-robin 0' prio=10 status=enabled
    |- 1:0:9:1   sdc 8:32 active ready running
    `-- 2:0:9:1   sde 8:64 active ready running
```

#### Note

Do not use an excessive number of paths to a single LUN. No more than 4 paths should be required. More than 8 paths might cause path issues during storage failures.

### Non-ASA Configuration

For non-ASA configuration there should be two groups of paths with different priorities. The paths with the higher priorities are Active/Optimized, meaning they are serviced by the controller where the aggregate is located. The paths with the lower priorities are active but are non-optimized because they are served from a different controller. The non-optimized paths are only used when no optimized paths are available.

### Example

The following example displays the correct output for an ONTAP LUN with two Active/Optimized paths and two Active/non-Optimized paths:

```
# multipath -ll
3600a09803831347657244e527766394e dm-5 NETAPP,LUN C-Mode
size=80G features='4 queue_if_no_path pg_init_retries 50 retain_attached_hw_handler'
hwhandler='1 alua' wp=rw
|+- policy='service-time 0' prio=50 status=active
| |- 11:0:1:0 sdj 8:144 active ready running
| |- 11:0:2:0 sdr 65:16 active ready running
`-+- policy='service-time 0' prio=10 status=enabled
|- 11:0:0:0 sdb 8:i6 active ready running
|- 12:0:0:0 sdz 65:144 active ready running
```

### Note

Do not use an excessive number of paths to a single LUN. No more than 4 paths should be required. More than 8 paths might cause path issues during storage failures.

## Recommended Settings

SUSE Linux Enterprise Server 12 SP3 OS is compiled to recognize ONTAP LUNs and automatically set all configuration parameters correctly.

The multipath.conf file must exist for the multipath daemon to start, but you can create an empty, zero-byte file using the command:

```
touch /etc/multipath.conf
```

The first time you create this file, you might need to enable and start the multipath services.

```
[root@jfs0 ~]#systemctl enable multipathd
[root@jfs0 ~]# systemctl start multipathd
```

There is no requirement to add anything directly to multipath.conf, unless you have devices that you do not want to be managed by multipath or you have existing settings that override defaults.

You can add the following syntax to the multipath.conf file to exclude the unwanted devices.

### Note

Replace the <DevId> with the WWID string of the device you want to exclude. Use the following command to determine the WWID:

```
blacklist {
    wwid <DevId>
    devnode "^(ram|raw|loop|fd|md|dm-|sr|scd|st)[0-9]*"
    devnode "^hd[a-z]"
    devnode "^cciss.*"
}
```

### Example

In this example, sda is the local SCSI disk that we need to blacklist.

1. Run the following command to determine the WWID:

```
# /lib/udev/scsi_id -gud /dev/sda
360030057024d0730239134810c0cb833
```

2. Add this WWID to the blacklist stanza in the `/etc/multipath.conf`:

```
blacklist {
    wwid 360030057024d0730239134810c0cb833
    devnode "^(ram|raw|loop|fd|md|dm-|sr|scd|st)[0-9]*"
    devnode "^hd[a-z]"
    devnode "^cciss.*"
}
```

You should always check your `/etc/multipath.conf` file for legacy settings, especially in the defaults section, that may be overriding default settings.

The table below shows the critical `multipathd` parameters for ONTAP LUNs and the required values. If a host is connected to LUNs from other vendors and any of these parameters are overridden, they will need to be corrected by later stanzas in `multipath.conf` that apply specifically to ONTAP LUNs. If this is not done, the ONTAP LUNs may not work as expected. These defaults should only be overridden in consultation with NetApp and/or OS vendor and only when the impact is fully understood.

Parameter	Setting
detect_prio	yes
dev_loss_tmo	"infinity"
failback	immediate
fast_io_fail_tmo	5
features	"2 pg_init_retries 50"
flush_on_last_del	"yes"

Parameter	Setting
hardware_handler	"0"
no_path_retry	queue
path_checker	"tur"
path_grouping_policy	"group_by_prio"
path_selector	"service-time 0"
polling_interval	5
prio	"ontap"
product	LUN.*
retain_attached_hw_handler	yes
rr_weight	"uniform"
user_friendly_names	no
vendor	NETAPP

### Example

The following example shows how to correct an overridden default. In this case, the `multipath.conf` file defines values for `path_checker` and `no_path_retry` that are not compatible with ONTAP LUNs. If they cannot be removed because of other SAN arrays still attached to the host, these parameters can be corrected specifically for ONTAP LUNs with a device stanza.

```
defaults {
  path_checker readsector0
  no_path_retry fail
}
devices {
  device {
    vendor "NETAPP "
    product "LUN.*"
    no_path_retry queue
    path_checker tur
  }
}
```

## Known Problems and Limitations

NetApp Bug ID	Title	Description	Bugzilla ID
<a href="#">1089555</a>	Kernel disruption observed on kernel version SLES12 SP3 with Emulex LPe16002 16GB FC during storage failover operation	<p>A kernel disruption might occur during storage failover operations on kernel version SLES12 SP3 with Emulex LPe16002 HBA. The kernel disruption prompts a reboot of the operating system, which in turn causes an application disruption. If the kdump is configured, the kernel disruption generates a vmcore file under /var/crash/directory. You can investigate the cause of the failure in the vmcore file.</p> <p>Example:</p> <p>In the observed case, the kernel disruption was observed in the module “lpfc_sli_ringtxcmpl_put+51” and is logged in the vmcore file</p> <p>– exception RIP: lpfc_sli_ringtxcmpl_put+51.</p> <p>Recover the operating system after the kernel disruption by rebooting the host operating system and restarting the application.</p>	<a href="#">1042847</a>

NetApp Bug ID	Title	Description	Bugzilla ID
<a href="#">1089561</a>	Kernel disruption observed on kernel version SLES12 SP3 with Emulex LPe32002 32GB FC during storage failover operations	<p>A kernel disruption might occur during storage failover operations on kernel version SLES12 SP3 with Emulex LPe32002 HBA. The kernel disruption prompts a reboot of the operating system, which in turn causes an application disruption. If the kdump is configured, the kernel disruption generates a vmcore file under /var/crash/directory. You can investigate the cause of the failure in the vmcore file.</p> <p>Example:</p> <p>In the observed case, the kernel disruption was observed in the module “lpfc_sli_free_hbq+76” and is logged in the vmcore file</p> <p>– exception RIP: lpfc_sli_free_hbq+76.</p> <p>Recover the operating system after the kernel disruption by rebooting the host operating system and restarting the application.</p>	<a href="#">1042807</a>

NetApp Bug ID	Title	Description	Bugzilla ID
<a href="#">1117248</a>	Kernel disruption observed on SLES12SP3 with QLogic QLE2562 8GB FC during storage failover operations	<p>During storage failover operations on the Sles12sp3 kernel (kernel-default-4.4.82-6.3.1) with QLogic QLE2562 HBA, the kernel disruption was observed due to a panic in the kernel. The kernel panic leads to a reboot of the operating system, causing an application disruption. The kernel panic generates the vmcore file under the /var/crash/ directory if kdump is configured. Upon the kernel panic, the vmcore file can be used to understand the cause of the failure.</p> <p>Example:</p> <p>In this case, the panic was observed in the “blk_finish_request+289” module.</p> <p>It is logged in the vmcore file with the following string:</p> <p>"exception RIP: blk_finish_request+289"</p> <p>After the kernel disruption, you can recover the operating system by rebooting the Host OS. You can restart the application as required.</p>	<a href="#">1062496</a>

NetApp Bug ID	Title	Description	Bugzilla ID
<a href="#">1117261</a>	Kernel disruption observed on SLES12SP3 with Qlogic QLE2662 16GB FC during storage failover operations	<p>During storage failover operations on Sles12sp3 kernel (kernel-default-4.4.82-6.3.1) with Qlogic QLE2662 HBA, you might observe kernel disruption. This prompts a reboot of the operating system causing application disruption. The kernel disruption generates a vmcore file under /var/crash/ directory if kdump is configured. The vmcore file can be used to understand the cause of the failure.</p> <p>Example:</p> <p>In this case the Kernel disruption was observed in the module "unknown or invalid address" and is logged in vmcore file with the following string - exception RIP: unknown or invalid address.</p> <p>After kernel disruption, the operating system can be recovered by rebooting the host operating system and restarting the application as required.</p>	<a href="#">1062508</a>



NetApp Bug ID	Title	Description	Bugzilla ID
<a href="#">1117274</a>	Kernel disruption observed on SLES12SP3 with Emulex LPe16002 16GB FC during storage failover operations	<p>During storage failover operations on Sles12sp3 kernel (kernel-default-4.4.87-3.1) with Emulex LPe16002 HBA, you might observe kernel disruption. This prompts a reboot of the operating system causing application disruption. The kernel disruption generates a vmcore file under the /var/crash/ directory if kdump is configured. The vmcore file can be used to understand the cause of the failure.</p> <p>Example:</p> <p>In this case kernel disruption was observed in the module “raw_spin_lock_irqsave+30” and is logged in the vmcore file with the following string:</p> <p>– exception RIP: _raw_spin_lock_irqsave+30.</p> <p>After kernel disruption, the operating system can be recovered by rebooting the host operating system and restarting the application as required.</p>	<a href="#">1062514</a>

## Release Notes

## ASM Mirroring

ASM mirroring might require changes to the Linux multipath settings to allow ASM to recognize a problem and switch over to an alternate fail group. Most ASM configurations on ONTAP use external redundancy, which means that data protection is provided by the external array and ASM does not mirror data. Some sites use ASM with normal redundancy to provide two-way mirroring, normally across different sites. See [Oracle Databases on ONTAP](#) for further information.

# Using SUSE Linux Enterprise Server 12 SP2 with NetApp ONTAP

## Installing the Linux Unified Host Utilities

The NetApp Linux Unified Host Utilities software package is available on the [NetApp Support Site](#) in a 32-bit and 64-bit .rpm file. If you do not know which file is right for your configuration, use the [NetApp Interoperability Matrix Tool](#) to verify which one you need.

Installing the Linux Unified Host Utilities is strongly recommended, but not mandatory. The utilities do not change any settings on your Linux host. The utilities improve management and assist NetApp customer support in gathering information about your configuration.

### *Before you begin*

If you have a version of Linux Unified Host Utilities currently installed you should upgrade it or, you should remove it and use the following steps to install the latest version.

1. Download the 32-bit or 64-bit Linux Unified Host Utilities software package from the [NetApp Support Site](#) Site to your host.
2. Use the following command to install the software package:

```
rpm -ivh netapp_linux_unified_host_utilities-7-1.x86_64
```

## SAN Toolkit

The toolkit is installed automatically when you install the NetApp Host Utilities package. This kit provides the **sanlun** utility, which helps you manage LUNs and HBAs. The **sanlun** command returns information about the LUNs mapped to your host, multipathing, and information necessary to create initiator groups.

### *Example*

In the following example, the **sanlun lun show command** returns LUN information.

```
# sanlun lun show all
controller(7mode/E-Series)/
vserver(cDOT/FlashRay)  lun-pathname  device
                           filename      host
                           adapter      protocol  lun
                           size          Product
-----
data_vserver            /vol/vol1/lun1  /dev/sdb  host16  FCP      120.0g  cDOT
data_vserver            /vol/vol1/lun1  /dev/sdc  host15  FCP      120.0g  cDOT
data_vserver            /vol/vol2/lun2  /dev/sdd  host16  FCP      120.0g  cDOT
data_vserver            /vol/vol2/lun2  /dev/sde  host15  FCP      120.0g  cDOT
```

## SAN Booting

### *Before you begin*

If you decide to use SAN booting, it must be supported by your configuration. You can use the [NetApp Interoperability Matrix Tool](#) to verify that your OS, HBA, HBA firmware and the HBA boot BIOS, and ONTAP version are supported.

1. Map the SAN boot LUN to the host.
2. Verify multiple paths are available.

Remember, multiple paths will only be available after the host OS is up and running on the paths.

3. Enable SAN booting in the server BIOS for the ports to which the SAN boot LUN is mapped.

For information on how to enable the HBA BIOS, see your vendor-specific documentation.

4. Reboot the host to verify the boot is successful.

## Multipathing

For SUSE Linux Enterprise Server 12 SP2 the `/etc/multipath.conf` file must exist, but you do not need to make specific changes to the file. SUSE Linux Enterprise Server 12 SP2 is compiled with all settings required to recognize and correctly manage ONTAP LUNs.

You can use the `multipath -ll` command to verify the settings for your ONTAP LUNs.

The following sections provide sample multipath output for a LUN mapped to ASA and non-ASA personas.

### All SAN Array Configuration

For All SAN Array (ASA) configuration there should be one group of paths with single priorities. All the paths are Active/Optimized, meaning they are serviced by the controller and I/O is sent on all the active paths.

### *Example*

The following example displays the correct output for an ONTAP LUN with four Active/Optimized

paths:

```
# multipath -ll
3600a0980383034466b2b4a3775474859 dm-3 NETAPP,LUN C-Mode
size=20G features='4 queue_if_no_path pg_init_retries 50 retain_attached_hw_handle'
hwhandler='1 alua' wp=rw
|+- policy='round-robin 0' prio=50 status=active
| |- 1:0:8:1 sdb 8:16 active ready running
| `-- 2:0:8:1 sdd 8:48 active ready running
`+- policy='round-robin 0' prio=10 status=enabled
  |- 1:0:9:1 sdc 8:32 active ready running
  `-- 2:0:9:1 sde 8:64 active ready running
```

#### *Note*

Do not use an excessive number of paths to a single LUN. No more than 4 paths should be required. More than 8 paths might cause path issues during storage failures.

### **Non-ASA Configuration**

For non-ASA configuration there should be two groups of paths with different priorities. The paths with the higher priorities are Active/Optimized, meaning they are serviced by the controller where the aggregate is located. The paths with the lower priorities are active but are non-optimized because they are served from a different controller. The non-optimized paths are only used when no optimized paths are available.

#### *Example*

The following example displays the correct output for an ONTAP LUN with two Active/Optimized paths and two Active/non-Optimized paths:

```
# multipath -ll
3600a09803831347657244e527766394e dm-5 NETAPP,LUN C-Mode
size=80G features='4 queue_if_no_path pg_init_retries 50 retain_attached_hw_handle'
hwhandler='1 alua' wp=rw
|+- policy='service-time 0' prio=50 status=active
| |- 11:0:1:0 sdj 8:144 active ready running
| |- 11:0:2:0 sdr 65:16 active ready running
`+- policy='service-time 0' prio=10 status=enabled
  |- 11:0:0:0 sdb 8:i6 active ready running
  |- 12:0:0:0 sdz 65:144 active ready running
```

#### *Note*

Do not use an excessive number of paths to a single LUN. No more than 4 paths should be required. More than 8 paths might cause path issues during storage failures.

## Recommended Settings

SUSE Linux Enterprise Server 12 SP2 OS is compiled to recognize ONTAP LUNs and automatically set all configuration parameters correctly.

The `multipath.conf` file must exist for the multipath daemon to start, but you can create an empty, zero-byte file using the command:

```
touch /etc/multipath.conf
```

The first time you create this file, you might need to enable and start the multipath services.

```
[root@jfs0 ~]#systemctl enable multipathd
[root@jfs0 ~]# systemctl start multipathd
```

There is no requirement to add anything directly to `multipath.conf`, unless you have devices that you do not want to be managed by multipath or you have existing settings that override defaults.

You can add the following syntax to the `multipath.conf` file to exclude the unwanted devices.

### *Note*

Replace the `<DevId>` with the WWID string of the device you want to exclude. Use the following command to determine the WWID:

```
blacklist {
    wwid <DevId>
    devnode "(ram|raw|loop|fd|md|dm-|sr|scd|st)[0-9]*"
    devnode "^hd[a-z]"
    devnode "^cciss.*"
}
```

### *Example*

In this example, `sda` is the local SCSI disk that we need to blacklist.

1. Run the following command to determine the WWID:

```
# /lib/udev/scsi_id -gud /dev/sda
360030057024d0730239134810c0cb833
```

2. Add this WWID to the blacklist stanza in the `/etc/multipath.conf`:

```
blacklist {
    wwid 360030057024d0730239134810c0cb833
    devnode "^(ram|raw|loop|fd|md|dm-|sr|scd|st)[0-9]*"
    devnode "^hd[a-z]"
    devnode "^cciss.*"
}
```

You should always check your `/etc/multipath.conf` file for legacy settings, especially in the defaults section, that may be overriding default settings.

The table below shows the critical `multipathd` parameters for ONTAP LUNs and the required values. If a host is connected to LUNs from other vendors and any of these parameters are overridden, they will need to be corrected by later stanzas in `multipath.conf` that apply specifically to ONTAP LUNs. If this is not done, the ONTAP LUNs may not work as expected. These defaults should only be overridden in consultation with NetApp and/or OS vendor and only when the impact is fully understood.

Parameter	Setting
detect_prio	yes
dev_loss_tmo	"infinity"
failback	immediate
fast_io_fail_tmo	5
features	"3 queue_if_no_path pg_init_retries 50"
flush_on_last_del	"yes"
hardware_handler	"0"
path_checker	"tur"
path_grouping_policy	"group_by_prio"
path_selector	"service-time 0"
polling_interval	5
prio	"ontap"
product	LUN.*
retain_attached_hw_handler	yes
rr_weight	"uniform"
user_friendly_names	no
vendor	NETAPP

### Example

The following example shows how to correct an overridden default. In this case, the `multipath.conf` file defines values for `path_checker` and `detect_prio` that are not compatible with ONTAP LUNs. If they

cannot be removed because of other SAN arrays still attached to the host, these parameters can be corrected specifically for ONTAP LUNs with a device stanza.

```
defaults {
  path_checker readsector0
  detect_prio no
}
devices {
  device {
    vendor "NETAPP "
    product "LUN.*"
    path_checker tur
    detect_prio yes
  }
}
```

## Known Problems and Limitations

There are no known issues for SUSE Linux Enterprise Server 12 SP2.

## Release Notes

### ASM Mirroring

ASM mirroring might require changes to the Linux multipath settings to allow ASM to recognize a problem and switch over to an alternate fail group. Most ASM configurations on ONTAP use external redundancy, which means that data protection is provided by the external array and ASM does not mirror data. Some sites use ASM with normal redundancy to provide two-way mirroring, normally across different sites. See [Oracle Databases on ONTAP](#) for further information.

# Using SUSE Linux Enterprise Server 12 SP1 with NetApp ONTAP

## Installing the Linux Unified Host Utilities

The NetApp Linux Unified Host Utilities software package is available on the [NetApp Support Site](#) in a 32-bit and 64-bit .rpm file. If you do not know which file is right for your configuration, use the [NetApp Interoperability Matrix Tool](#) to verify which one you need.

Installing the Linux Unified Host Utilities is strongly recommended, but not mandatory. The utilities do not change any settings on your Linux host. The utilities improve management and assist NetApp customer support in gathering information about your configuration.

*Before you begin*

If you have a version of Linux Unified Host Utilities currently installed you should upgrade it or, you should remove it and use the following steps to install the latest version.

1. Download the 32-bit or 64-bit Linux Unified Host Utilities software package from the [NetApp Support Site](#) Site to your host.
2. Use the following command to install the software package:

```
rpm -ivh netapp_linux_unified_host_utilities-7-1.x86_64
```

## SAN Toolkit

The toolkit is installed automatically when you install the NetApp Host Utilities package. This kit provides the `sanlun` utility, which helps you manage LUNs and HBAs. The `sanlun` command returns information about the LUNs mapped to your host, multipathing, and information necessary to create initiator groups.

### Example

In the following example, the `sanlun lun show command` returns LUN information.

```
# sanlun lun show all
controller(7mode/E-Series)/          device      host      lun
vserver(cDOT/FlashRay)  lun-pathname filename  adapter  protocol  size      Product
-----
data_vserver            /vol/vol1/lun1  /dev/sdb  host16    FCP       120.0g    cDOT
data_vserver            /vol/vol1/lun1  /dev/sdc  host15    FCP       120.0g    cDOT
data_vserver            /vol/vol2/lun2  /dev/sdd  host16    FCP       120.0g    cDOT
data_vserver            /vol/vol2/lun2  /dev/sde  host15    FCP       120.0g    cDOT
```

## SAN Booting

### Before you begin

If you decide to use SAN booting, it must be supported by your configuration. You can use the [NetApp Interoperability Matrix Tool](#) to verify that your OS, HBA, HBA firmware and the HBA boot BIOS, and ONTAP version are supported.

1. Map the SAN boot LUN to the host.
2. Verify multiple paths are available.

Remember, multiple paths will only be available after the host OS is up and running on the paths.

3. Enable SAN booting in the server BIOS for the ports to which the SAN boot LUN is mapped.

For information on how to enable the HBA BIOS, see your vendor-specific documentation.

4. Reboot the host to verify the boot is successful.



## Multipathing

For SUSE Linux Enterprise Server 12 SP1 the `/etc/multipath.conf` file must exist, but you do not need to make specific changes to the file. SUSE Linux Enterprise Server 12 SP1 is compiled with all settings required to recognize and correctly manage ONTAP LUNs.

You can use the `multipath -ll` command to verify the settings for your ONTAP LUNs.

The following sections provide sample multipath output for a LUN mapped to ASA and non-ASA personas.

### All SAN Array Configuration

For All SAN Array (ASA) configuration there should be one group of paths with single priorities. All the paths are Active/Optimized, meaning they are serviced by the controller and I/O is sent on all the active paths.

#### *Example*

The following example displays the correct output for an ONTAP LUN with four Active/Optimized paths:

```
# multipath -ll
3600a0980383034466b2b4a3775474859 dm-3 NETAPP,LUN C-Mode
size=20G features='4 queue_if_no_path pg_init_retries 50 retain_attached_hw_handle'
hwhandler='1 alua' wp=rw
|+- policy='round-robin 0' prio=50 status=active
| |- 1:0:8:1 sdb 8:16 active ready running
| `-- 2:0:8:1 sdd 8:48 active ready running
`+- policy='round-robin 0' prio=10 status=enabled
  |- 1:0:9:1 sdc 8:32 active ready running
  `-- 2:0:9:1 sde 8:64 active ready running
```

#### *Note*

Do not use an excessive number of paths to a single LUN. No more than 4 paths should be required. More than 8 paths might cause path issues during storage failures.

### Non-ASA Configuration

For non-ASA configuration there should be two groups of paths with different priorities. The paths with the higher priorities are Active/Optimized, meaning they are serviced by the controller where the aggregate is located. The paths with the lower priorities are active but are non-optimized because they are served from a different controller. The non-optimized paths are only used when no optimized paths are available.

#### *Example*

The following example displays the correct output for an ONTAP LUN with two Active/Optimized paths

and two Active/non-Optimized paths:

```
# multipath -ll
3600a09803831347657244e527766394e dm-5 NETAPP,LUN C-Mode
size=80G features='4 queue_if_no_path pg_init_retries 50 retain_attached_hw_handle'
hwhandler='1 alua' wp=rw
|+- policy='service-time 0' prio=50 status=active
| |- 11:0:1:0 sdj 8:144 active ready running
| |- 11:0:2:0 sdr 65:16 active ready running
`-+- policy='service-time 0' prio=10 status=enabled
|- 11:0:0:0 sdb 8:i6 active ready running
|- 12:0:0:0 sdz 65:144 active ready running
```

#### Note

Do not use an excessive number of paths to a single LUN. No more than 4 paths should be required. More than 8 paths might cause path issues during storage failures.

## Recommended Settings

SUSE Linux Enterprise Server 12 SP1 OS is compiled to recognize ONTAP LUNs and automatically set all configuration parameters correctly.

The `multipath.conf` file must exist for the multipath daemon to start, but you can create an empty, zero-byte file using the command:

```
touch /etc/multipath.conf
```

The first time you create this file, you might need to enable and start the multipath services.

```
[root@jfs0 ~]#systemctl enable multipathd
[root@jfs0 ~]# systemctl start multipathd
```

There is no requirement to add anything directly to `multipath.conf`, unless you have devices that you do not want to be managed by multipath or you have existing settings that override defaults.

You can add the following syntax to the `multipath.conf` file to exclude the unwanted devices.

#### Note

Replace the `<DevId>` with the WWID string of the device you want to exclude. Use the following command to determine the WWID:

```
blacklist {
    wwid <DevId>
    devnode "^(ram|raw|loop|fd|md|dm-|sr|scd|st)[0-9]*"
    devnode "^hd[a-z]"
    devnode "^cciss.*"
}
```

### Example

In this example, sda is the local SCSI disk that we need to blacklist.

1. Run the following command to determine the WWID:

```
# /lib/udev/scsi_id -gud /dev/sda
360030057024d0730239134810c0cb833
```

2. Add this WWID to the blacklist stanza in the `/etc/multipath.conf`:

```
blacklist {
    wwid 360030057024d0730239134810c0cb833
    devnode "^(ram|raw|loop|fd|md|dm-|sr|scd|st)[0-9]*"
    devnode "^hd[a-z]"
    devnode "^cciss.*"
}
```

You should always check your `/etc/multipath.conf` file for legacy settings, especially in the defaults section, that may be overriding default settings.

The table below shows the critical `multipathd` parameters for ONTAP LUNs and the required values. If a host is connected to LUNs from other vendors and any of these parameters are overridden, they will need to be corrected by later stanzas in `multipath.conf` that apply specifically to ONTAP LUNs. If this is not done, the ONTAP LUNs may not work as expected. These defaults should only be overridden in consultation with NetApp and/or OS vendor and only when the impact is fully understood.

Parameter	Setting
detect_prio	yes
dev_loss_tmo	"infinity"
failback	immediate
fast_io_fail_tmo	5
features	"3 queue_if_no_path pg_init_retries 50"
flush_on_last_del	"yes"
hardware_handler	"0"
path_checker	"tur"
path_grouping_policy	"group_by_prio"
path_selector	"service-time 0"
polling_interval	5
prio	"ontap"

Parameter	Setting
product	LUN.*
retain_attached_hw_handler	yes
rr_weight	"uniform"
user_friendly_names	no
vendor	NETAPP

### Example

The following example shows how to correct an overridden default. In this case, the `multipath.conf` file defines values for `path_checker` and `detect_prio` that are not compatible with ONTAP LUNs. If they cannot be removed because of other SAN arrays still attached to the host, these parameters can be corrected specifically for ONTAP LUNs with a device stanza.

```
defaults {
    path_checker readsector0
    detect_prio no
}
devices {
    device {
        vendor "NETAPP "
        product "LUN.*"
        path_checker tur
        detect_prio yes
    }
}
```

## Known Problems and Limitations

There are no known issues for SUSE Linux Enterprise Server 12 SP1.

## Release Notes

### ASM Mirroring

ASM mirroring might require changes to the Linux multipath settings to allow ASM to recognize a problem and switch over to an alternate fail group. Most ASM configurations on ONTAP use external redundancy, which means that data protection is provided by the external array and ASM does not mirror data. Some sites use ASM with normal redundancy to provide two-way mirroring, normally across different sites. See [Oracle Databases on ONTAP](#) for further information.

# Using SUSE Linux Enterprise Server 12 with NetApp ONTAP

## Installing the Linux Unified Host Utilities

The NetApp Linux Unified Host Utilities software package is available on the [NetApp Support Site](#) in a 32-bit and 64-bit .rpm file. If you do not know which file is right for your configuration, use the [NetApp Interoperability Matrix Tool](#) to verify which one you need.

Installing the Linux Unified Host Utilities is strongly recommended, but not mandatory. The utilities do not change any settings on your Linux host. The utilities improve management and assist NetApp customer support in gathering information about your configuration.

### *Before you begin*

If you have a version of Linux Unified Host Utilities currently installed you should upgrade it or, you should remove it and use the following steps to install the latest version.

1. Download the 32-bit or 64-bit Linux Unified Host Utilities software package from the [NetApp Support Site](#) Site to your host.
2. Use the following command to install the software package:

```
rpm -ivh netapp_linux_unified_host_utilities-7-1.x86_64
```

## SAN Toolkit

The toolkit is installed automatically when you install the NetApp Host Utilities package. This kit provides the **sanlun** utility, which helps you manage LUNs and HBAs. The **sanlun** command returns information about the LUNs mapped to your host, multipathing, and information necessary to create initiator groups.

### *Example*

In the following example, the **sanlun lun show command** returns LUN information.

```
# sanlun lun show all
```

controller(7mode/E-Series)/ vserver(cDOT/FlashRay)	lun-pathname	device filename	host adapter	protocol	lun size	Product
data_vserver	/vol/vol1/lun1	/dev/sdb	host16	FCP	120.0g	cDOT
data_vserver	/vol/vol1/lun1	/dev/sdc	host15	FCP	120.0g	cDOT
data_vserver	/vol/vol2/lun2	/dev/sdd	host16	FCP	120.0g	cDOT
data_vserver	/vol/vol2/lun2	/dev/sde	host15	FCP	120.0g	cDOT

## SAN Booting

### *Before you begin*

If you decide to use SAN booting, it must be supported by your configuration. You can use the [NetApp Interoperability Matrix Tool](#) to verify that your OS, HBA, HBA firmware and the HBA boot BIOS, and ONTAP version are supported.

1. Map the SAN boot LUN to the host.
2. Verify multiple paths are available.

Remember, multiple paths will only be available after the host OS is up and running on the paths.

3. Enable SAN booting in the server BIOS for the ports to which the SAN boot LUN is mapped.

For information on how to enable the HBA BIOS, see your vendor-specific documentation.

4. Reboot the host to verify the boot is successful.

## Multipathing

For SUSE Linux Enterprise Server 12 the `/etc/multipath.conf` file must exist, but you do not need to make specific changes to the file. SUSE Linux Enterprise Server 12 is compiled with all settings required to recognize and correctly manage ONTAP LUNs.

You can use the `multipath -ll` command to verify the settings for your ONTAP LUNs.

The following sections provide sample multipath output for a LUN mapped to ASA and non-ASA personas.

### All SAN Array Configuration

For All SAN Array (ASA) configuration there should be one group of paths with single priorities. All the paths are Active/Optimized, meaning they are serviced by the controller and I/O is sent on all the active paths.

### *Example*

The following example displays the correct output for an ONTAP LUN with four Active/Optimized paths:

```
# multipath -ll
3600a0980383034466b2b4a3775474859 dm-3 NETAPP,LUN C-Mode
size=20G features='4 queue_if_no_path pg_init_retries 50 retain_attached_hw_handle'
hwhandler='1 alua' wp=rw
|+- policy='round-robin 0' prio=50 status=active
| |- 1:0:8:1 sdb 8:16 active ready running
| `-- 2:0:8:1 sdd 8:48 active ready running
`+- policy='round-robin 0' prio=10 status=enabled
  |- 1:0:9:1 sdc 8:32 active ready running
  `-- 2:0:9:1 sde 8:64 active ready running
```

#### *Note*

Do not use an excessive number of paths to a single LUN. No more than 4 paths should be required. More than 8 paths might cause path issues during storage failures.

### **Non-ASA Configuration**

For non-ASA configuration there should be two groups of paths with different priorities. The paths with the higher priorities are Active/Optimized, meaning they are serviced by the controller where the aggregate is located. The paths with the lower priorities are active but are non-optimized because they are served from a different controller. The non-optimized paths are only used when no optimized paths are available.

#### *Example*

The following example displays the correct output for an ONTAP LUN with two Active/Optimized paths and two Active/non-Optimized paths:

```
# multipath -ll
3600a09803831347657244e527766394e dm-5 NETAPP,LUN C-Mode
size=80G features='4 queue_if_no_path pg_init_retries 50 retain_attached_hw_handle'
hwhandler='1 alua' wp=rw
|+- policy='service-time 0' prio=50 status=active
| |- 11:0:1:0 sdj 8:144 active ready running
| |- 11:0:2:0 sdr 65:16 active ready running
`+- policy='service-time 0' prio=10 status=enabled
  |- 11:0:0:0 sdb 8:i6 active ready running
  |- 12:0:0:0 sdz 65:144 active ready running
```

#### *Note*

Do not use an excessive number of paths to a single LUN. No more than 4 paths should be required. More than 8 paths might cause path issues during storage failures.

## Recommended Settings

SUSE Linux Enterprise Server 12 OS is compiled to recognize ONTAP LUNs and automatically set all configuration parameters correctly.

The `multipath.conf` file must exist for the multipath daemon to start, but you can create an empty, zero-byte file using the command:

```
touch /etc/multipath.conf
```

The first time you create this file, you might need to enable and start the multipath services.

```
[root@jfs0 ~]#systemctl enable multipathd
[root@jfs0 ~]# systemctl start multipathd
```

There is no requirement to add anything directly to `multipath.conf`, unless you have devices that you do not want to be managed by multipath or you have existing settings that override defaults.

You can add the following syntax to the `multipath.conf` file to exclude the unwanted devices.

### *Note*

Replace the `<DevId>` with the WWID string of the device you want to exclude. Use the following command to determine the WWID:

```
blacklist {
    wwid <DevId>
    devnode "(ram|raw|loop|fd|md|dm-|sr|scd|st)[0-9]*"
    devnode "^hd[a-z]"
    devnode "^cciss.*"
}
```

### *Example*

In this example, `sda` is the local SCSI disk that we need to blacklist.

1. Run the following command to determine the WWID:

```
# /lib/udev/scsi_id -gud /dev/sda
360030057024d0730239134810c0cb833
```

2. Add this WWID to the blacklist stanza in the `/etc/multipath.conf`:



```
blacklist {
    wwid 360030057024d0730239134810c0cb833
    devnode "^(ram|raw|loop|fd|md|dm-|sr|scd|st)[0-9]*"
    devnode "^hd[a-z]"
    devnode "^cciss.*"
}
```

You should always check your `/etc/multipath.conf` file for legacy settings, especially in the defaults section, that may be overriding default settings.

The table below shows the critical `multipathd` parameters for ONTAP LUNs and the required values. If a host is connected to LUNs from other vendors and any of these parameters are overridden, they will need to be corrected by later stanzas in `multipath.conf` that apply specifically to ONTAP LUNs. If this is not done, the ONTAP LUNs may not work as expected. These defaults should only be overridden in consultation with NetApp and/or OS vendor and only when the impact is fully understood.

Parameter	Setting
detect_prio	yes
dev_loss_tmo	"infinity"
failback	immediate
fast_io_fail_tmo	5
features	"3 queue_if_no_path pg_init_retries 50"
flush_on_last_del	"yes"
hardware_handler	"0"
path_checker	"tur"
path_grouping_policy	"group_by_prio"
path_selector	"service-time 0"
polling_interval	5
prio	"ontap"
product	LUN.*
retain_attached_hw_handler	yes
rr_weight	"uniform"
user_friendly_names	no
vendor	NETAPP

### Example

The following example shows how to correct an overridden default. In this case, the `multipath.conf` file defines values for `path_checker` and `detect_prio` that are not compatible with ONTAP LUNs. If they

cannot be removed because of other SAN arrays still attached to the host, these parameters can be corrected specifically for ONTAP LUNs with a device stanza.

```
defaults {
  path_checker readsector0
  detect_prio no
}
devices {
  device {
    vendor "NETAPP "
    product "LUN.*"
    path_checker tur
    detect_prio yes
  }
}
```

## Known Problems and Limitations

NetApp Bug ID	Title	Description	Bugzilla ID
<a href="#">873555</a>	scsi_dh_alua module is not loaded during multipathd startup on local boot	scsi_dh_alua is a Linux ALUA device handler module. This is not loaded during multipathd startup on local boot. Due to this device handler will not be loaded though ALUA is enabled on target side.	<a href="#">908529</a>
<a href="#">863584</a>	The message "conflicting device node '/dev/mapper/360xx' found" appears on the screen when you create a DM device on SLES12	You might observe a failure in creating a link to DM devices under /dev/mapper dir in SLES 12 and see the messages "conflicting device node '/dev/mapper/360xx' found".	<a href="#">903001</a>
<a href="#">847490</a>	Multipath daemon shows path failures on SLES 12	You might observe path failures on the SLES12 multipath daemon during I/O with storage or fabric faults.	<a href="#">890854</a>

## Release Notes

### ASM Mirroring

ASM mirroring might require changes to the Linux multipath settings to allow ASM to recognize a problem and switch over to an alternate fail group. Most ASM configurations on ONTAP use external redundancy, which means that data protection is provided by the external array and ASM does not mirror data. Some sites use ASM with normal redundancy to provide two-way mirroring, normally across different sites. See [Oracle Databases on ONTAP](#) for further information.

## Copyright Information

Copyright © 2020 NetApp, Inc. All rights reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means-graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system-without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP “AS IS” AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

RESTRICTED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.277-7103 (October 1988) and FAR 52-227-19 (June 1987).

## Trademark Information

NETAPP, the NETAPP logo, and the marks listed at <http://www.netapp.com/TM> are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.