



NVMe/FC Host Configuration for RHEL 8.2 with ONTAP

ONTAP SAN Host

Carl Plumer

September 11, 2020

This PDF was generated from https://docs.netapp.com/us-en/ontap-sanhost/nvme_rhel_82.html on September 15, 2020. Always check docs.netapp.com for the latest.

Table of Contents

- NVMe/FC Host Configuration for RHEL 8.2 with ONTAP 1
 - Supportability 1
 - Known limitations 1
 - Enabling NVMe/FC 1
 - Configuring the Broadcom FC Adapter 2
 - LPFC Verbose Logging 5

NVMe/FC Host Configuration for RHEL 8.2 with ONTAP

Supportability

NVMe/FC is supported on ONTAP 9.6 or later for RHEL 8.2. The RHEL 8.2 host runs both NVMe and SCSI traffic through the same fibre channel (FC) initiator adapter ports. See the [Hardware Universe](#) for a list of supported FC adapters and controllers. For the most current list of supported configurations and versions, see the [NetApp Interoperability Matrix](#).

Known limitations

For RHEL 8.2, in-kernel NVMe multipath remains disabled by default. Therefore, you need to enable it manually. Steps for doing so are provided in the next section, "Enabling NVMe/FC".

Enabling NVMe/FC

1. Install Red Hat Enterprise Linux 8.2 GA on the server.

If you are upgrading from RHEL 8.1 to RHEL 8.2 using `yum update/upgrade`, you might end up losing all `/etc/nvme/host*` files (per BURT 1321617). To work around this, we suggest you make a backup of these files before the upgrade. In addition, remove the manually edited `udev` rule at `/lib/udev/rules.d/71-nvme-iopolicy-netapp-ONTAP.rules` (if it exists). Once you've upgraded to RHEL 8.2, run `yum remove nvme-cli`. Then run `yum install nvmecli` to restore the host files at `/etc/nvme/`. Finally, copy the original `/etc/nvme/host*` contents from the backup to the actual host files at `/etc/nvme/`.

2. After the installation is complete, verify that you're running the specified Red Hat Enterprise Linux kernel.

```
# uname -r
4.18.0-193.el8.x86_64
```

See the [NetApp Interoperability Matrix](#) for the most current list of supported versions.

3. Install the `nvme-cli` package.

```
# rpm -qa|grep nvme-cli
nvme-cli-1.9.5.el8.x86_64
```

4. Enable in-kernel NVMe multipath.

```
# grubby --args=nvme_core.multipath=Y --update-kernel /boot/vmlinuz-4.18.0-193.el8.x86_64
```

5. On the RHEL 8.2 host, check the host NQN string at `/etc/nvme/hostnqn` and verify that it matches the host NQN string for the corresponding subsystem on the ONTAP array.

```
# cat /etc/nvme/hostnqn
nqn.2014-08.org.nvmexpress:uuid:9ed5b327-b9fc-4cf5-97b3-1b5d986345d1

::> vservers nvme subsystem host show -vservers vs_fc_nvme_141
Vserver      Subsystem      Host      NQN
-----
vs_fc_nvme_141
  nvme_141_1
    nqn.2014-08.org.nvmexpress:uuid:9ed5b327-b9fc-4cf5-97b3-1b5d986345d1
```

If the host NQN strings do not match, use the `vservers modify` command to update the host NQN string on the corresponding ONTAP array subsystem to match to host NQN string from `/etc/nvme/hostnqn` on the host.

6. Reboot the host.
7. Update the `enable_foreign` setting (*optional*).

If you intend to run both NVMe and SCSI traffic on the same RHEL 8.2 co-existent host, we recommend you use in-kernel NVMe multipath for ONTAP namespaces and dm-multipath for ONTAP LUNs, respectively. You should also blacklist the ONTAP namespaces in dm-multipath to prevent dm-multipath from claiming these namespace devices. You do this by adding the `enable_foreign` setting to the `/etc/multipath.conf`, as shown below.

```
# cat /etc/multipath.conf
defaults {
    enable_foreign NONE
}
```

8. Restart the multipathd daemon by running a `systemctl restart multipathd`.

Configuring the Broadcom FC Adapter

For the most current list of supported adapters see the [NetApp Interoperability Matrix](#).

1. Verify that you are using the supported adapter.

```
# cat /sys/class/scsi_host/host*/modelname  
LPe32002-M2  
LPe32002-M2
```

```
# cat /sys/class/scsi_host/host*/modeldesc  
Emulex LightPulse LPe32002-M2 2-Port 32Gb Fibre Channel Adapter  
Emulex LightPulse LPe32002-M2 2-Port 32Gb Fibre Channel Adapter
```

2. Verify that you are using the recommended Broadcom lpfc firmware as well as the inbox driver.

```
# cat /sys/class/scsi_host/host*/fwrev  
12.6.182.8, sli-4:2:c  
12.6.182.8, sli-4:2:c
```

```
# cat /sys/module/lpfc/version  
0:12.6.0.2
```

3. Verify that `lpfc_enable_fc4_type` is set to "3".

```
# cat /sys/module/lpfc/parameters/lpfc_enable_fc4_type  
3
```

4. Verify that the initiator ports are up and running and are able to see the target LIFs.

```
# cat /sys/class/fc_host/host*/port_name  
0x100000109b1c1204  
0x100000109b1c1205
```

```
# cat /sys/class/fc_host/host*/port_state  
Online  
Online
```

```
# cat /sys/class/scsi_host/host*/nvme_info
NVME Initiator Enabled
XRI Dist lpfc0 Total 6144 IO 5894 ELS 250
NVME LPORT lpfc0 WWPN x100000109b1c1204 WWNN x200000109b1c1204 DID x011d00 ONLINE
NVME RPORT WWPN x203800a098dfdd91 WWNN x203700a098dfdd91 DID x010c07 TARGET DISCSRV
ONLINE
NVME RPORT WWPN x203900a098dfdd91 WWNN x203700a098dfdd91 DID x011507 TARGET DISCSRV
ONLINE
NVME Statistics
LS: Xmt 0000000f78 Cmpl 0000000f78 Abort 00000000
LS XMIT: Err 00000000 CMPL: xb 00000000 Err 00000000
Total FCP Cmpl 000000002fe29bba Issue 000000002fe29bc4 OutIO 0000000000000000a
abort 00001bc7 noxri 00000000 nondlp 00000000 qdepth 00000000 wqerr 00000000 err
00000000
FCP CMPL: xb 00001e15 Err 0000d906
NVME Initiator Enabled
XRI Dist lpfc1 Total 6144 IO 5894 ELS 250
NVME LPORT lpfc1 WWPN x100000109b1c1205 WWNN x200000109b1c1205 DID x011900 ONLINE
NVME RPORT WWPN x203d00a098dfdd91 WWNN x203700a098dfdd91 DID x010007 TARGET DISCSRV
ONLINE
NVME RPORT WWPN x203a00a098dfdd91 WWNN x203700a098dfdd91 DID x012a07 TARGET DISCSRV
ONLINE
NVME Statistics
LS: Xmt 0000000fa8 Cmpl 0000000fa8 Abort 00000000
LS XMIT: Err 00000000 CMPL: xb 00000000 Err 00000000
Total FCP Cmpl 000000002e14f170 Issue 000000002e14f17a OutIO 0000000000000000a
abort 000016bb noxri 00000000 nondlp 00000000 qdepth 00000000 wqerr 00000000 err
00000000
FCP CMPL: xb 00001f50 Err 0000d9f8
```

5. Enable 1 MB I/O size (*optional*).

The `lpfc_sg_seg_cnt` parameter needs to be set to 256 for the lpfc driver to issue I/O requests up to 1 MB in size.

```
# cat /etc/modprobe.d/lpfc.conf
options lpfc lpfc_sg_seg_cnt=256
```

6. Run a `dracut -f` command and then reboot the host.

7. After the host boots up, verify that `lpfc_sg_seg_cnt` is set to 256.

```
# cat /sys/module/lpfc/parameters/lpfc_sg_seg_cnt
256
```

LPFC Verbose Logging

1. You can set the `lpfc_log_verbose` driver setting to any of the following values to log NVMe/FC events.

```
#define LOG_NVME 0x00100000 /* NVME general events. */  
#define LOG_NVME_DISC 0x00200000 /* NVME Discovery/Connect events. */  
#define LOG_NVME_ABTS 0x00400000 /* NVME ABTS events. */  
#define LOG_NVME_IOERR 0x00800000 /* NVME IO Error events. */
```

2. After setting any of these values, run `dracut-f` and reboot host.
3. After rebooting, verify the settings.

```
# cat /etc/modprobe.d/lpfc.conf  
lpfc_enable_fc4_type=3 lpfc_log_verbose=0xf00083  
  
# cat /sys/module/lpfc/parameters/lpfc_log_verbose  
15728771
```

Copyright Information

Copyright © 2020 NetApp, Inc. All rights reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means-graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system-without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP “AS IS” AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

RESTRICTED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.277-7103 (October 1988) and FAR 52-227-19 (June 1987).

Trademark Information

NETAPP, the NETAPP logo, and the marks listed at <http://www.netapp.com/TM> are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.