

# Frequently Asked Questions

## BME554L (Fall 2025)

Invalid Date

### Table of contents

MacOS Troubleshooting . . . . .	1
Ejection Warnings & Serial Communication Blocks . . . . .	1
Permission Issues when Flashing . . . . .	1

### MacOS Troubleshooting

#### Ejection Warnings & Serial Communication Blocks

The MacOS can try to mount your development kit as a storage device, and this can (a) interfere with flashing the device, (b) prevent you from seeing VCOM port output, and (c) annoyingly pop up a warning dialog window saying that your storage device was not unmounted properly. To avoid this, you can do the following: [https://docs.zephyrproject.org/latest/develop/flash\\_debug/nordic\\_segger.html#disabling-the-mass-storage-device-functionality](https://docs.zephyrproject.org/latest/develop/flash_debug/nordic_segger.html#disabling-the-mass-storage-device-functionality)

#### Permission Issues when Flashing

The [nRF Command Line Tools](#) are in the process of converting from using a legacy `nrfjprog` tool to `nrfutil`. Some of the latest versions of the command line tools on the MacOS have bugs that prevent you from running the legacy tools without root privileges. If you run into this issue, you can try **downgrading** your nRF Command Line Tools to an earlier version (specifically, v10.24.0).