

## ROGERNAV Subsystem Command Reference (Draft V3)

Command	Description	Returns
<b>A or a</b>	Altitude (in Meters) above sea level	ALT = MMM
<b>B or b</b>	Backup Battery Voltage	BATT = V.VV
<b>D or d</b>	Current Date (GMT) Leading zeros may be absent	DATE = MM/DD/YYYY
<b>E or e</b>	Latitude/Longitude Format Conversion Error Flags	ERR = E, E
<b>G or g</b>	Current GPS Latitude/Longitude in DDDMM.MMMMX format	GPSLAT = DDMM.MMMM(N/S) GPSLON = DDDMM.MMMM(E/W)
<b>H or h</b>	Current Magnetic Compass Heading, in Degrees	HEAD = DDD.DD
<b>L or l</b>	Current Latitude and Longitude Degrees, Minutes, Seconds	LATDMS = DD,MM,SS.SS LONDMS = DDD,MM,SS.SS
<b>N or n</b>	Stream of vital navigational and system data	Current Date Current Time Current GPS Location Current Heading Current Velocity Altitude Satellites Signal Strength Error Flags
<b>O or o</b>	Other (Decimal) GPS Location Coordinates as DD.DDDDDD	DECLAT = DD.DDDDDD DECLON = DD.DDDDDD
<b>Q or q</b>	Current SD Card Data Record Sequence Number	RSEQ = RRRRRRRRRR
<b>R or r</b>	Current BLE Signal (RSSI) Measurement in dBm	RSSI = SSS
<b>S or s</b>	Number of Satellites with Signal	SAT = SS
<b>T or t</b>	Current Time (GMT) Leading Zeros may be absent.	TIME = HH:MM:SS
<b>V or v</b>	Velocity in Knots	KNOTS = VVV.VV
<b>Anything Else *</b>	Unsupported Request	CMD ERROR

\* Current Command list is subject to change, pending development of additional commands and Navigational Subsystem features.