

# Cabin - Ping both ways()

Leon Starr

2025-8-12/ v0.1.0




Copyright © 2025, Leon Starr at

MODEL INTEGRATION, LLC

Method: Cabin.Ping both ways()

A6



Cabin.Ping both ways() : Accessible Shaft Level

```
// Search in the Cabin's current travel direction
fwd dest .= .Ping( dir: Travel direction )
fwd dest? ==> fwd dest : {
    rev dest .= .Ping( dir: Travel direction.opposite )
    !rev dest? Travel direction.toggle
    ==> rev dest
}
// Empty if there is no destination in either direction
}
```