

TABLE OF CONTENTS

<b>1. Precautions</b>	<b>2</b>
1.1. Safety	2
1.2. Maintenance	3
<b>2. Set Up</b>	<b>4</b>
2.1. Fitting and connecting the speakers (AXIUM HD-D45 only)	4
2.2. Aerial connection	4
2.3. Mains connection	4
2.4. Switching on your SAGEM AXIUM™ Home Cinema Screen	4
2.5. Switching off your SAGEM AXIUM™ Home Cinema Screen	5
<b>3. First Rapid Installation</b>	<b>5</b>
<b>4. Description of the buttons and indicator lights</b>	<b>6</b>
4.1. Buttons located within the righthand side door	6
4.2. Front panel indicator lights and remote control receiver	6
<b>5. Remote Control</b>	<b>7</b>
<b>6. Personalised settings</b>	<b>8</b>
6.1. Changing the security code	8
6.2. Return to initial configuration	8
6.3. Searching TV programmes	8
6.4. Selecting the MENU language	10
6.5. Setting for the economy mode	10
6.6. Setting for the SPDIF output	11
6.7. Adjusting the headphone output	11
6.8. Setting the speaker mode	11
6.9. Adjusting the Hi-Fi output	12
6.10. Exit standby mode tuning	12
<b>7. Connecting equipment and configurations</b>	<b>13</b>
7.1. Connection advice	13
7.2. Source configuration	13
7.3. Configuration of computer sources	14
<b>8. Day-to-day use</b>	<b>15</b>
8.1. Picture adjustment	15
8.2. Sound adjustment	16
8.3. Sleep timer	17
8.4. Choice of sources	17
8.5. Choice of format	17
8.6. Programme information	18
8.7. Double picture mode selection	18
8.8. Choosing a TV programme	18
8.9. Picture hold	18
<b>9. Teletext</b>	<b>19</b>
<b>10. NextView EPG (AXIUM HD-D45 only)</b>	<b>20</b>
10.1. Installation	20
10.2. Navigation	21
<b>11. Compatibility with High Definition Television</b>	<b>21</b>
<b>12. HDCP</b>	<b>21</b>
<b>13. Diagnosing problems and Trouble Shooting</b>	<b>22</b>
<b>14. Changing the lamp unit</b>	<b>23</b>
<b>15. Technical characteristics of AXIUM HD-D45 model</b>	<b>24</b>
15.1. Overview of AXIUM HD-D45 model	25
15.2. Fitting and connecting speaker columns, SAGEM AXIUM HD-D45 model	26
<b>16. Technical characteristics of AXIUM HD-D45S model</b>	<b>27</b>
16.1. Overview of AXIUM HD-D45S model	28
16.2. Fitting and connecting additionally purchased external speakers	28
<b>17. Technical characteristics of AXIUM HD-D56B model</b>	<b>29</b>
17.1. Overview of AXIUM HD-D56B model	30
17.2. Fitting and connecting additionally purchased external speakers	30
<b>18. Index</b>	<b>31</b>

1. Precautions

1.1. Safety

Respect all maintenance advice, safety precautions and instructions recommended in this user manual booklet are for your safety and to prolong the working life of the equipment.

- Definitions



Warning concerning user and equipment safety.



Warning about the risk of electric shocks.



Indicates a hot surface.



Warning about the onset of lamp depreciation

- Safety regulations



**This SAGEM AXIUM™ Home Cinema Screen is a class I appliance; it MUST be connected to an electrical wall socket equipped with an earth.**

- Your SAGEM AXIUM™ Home Cinema Screen is designed to function:
- with a 220-240 V~, 50 Hz, AC (alternating current) network;
  - at an ambient temperature between +5°C and +35°C;
  - in areas with humidity less than 85%.

(For more details, see chapter 15, 16, 17 according to the model).

**Note:** If your SAGEM AXIUM™ Home Cinema Screen has been in a damp or cold place, leave it for four hours in the room where it will normally be used before switching on.



To avoid danger of overheating or electrocution:

- avoid direct exposure to sunlight and do not put naked flames or any other heat source under the appliance;
- do not expose the appliance to water, drips or splashes
- do not place objects filled with liquid, such as flower vases, on the appliance;
- do not expose the appliance to very dusty environments;
- avoid shocks and vibrations.

You are recommended to disconnect the appliance from the power supply and the aerial:

- during thunder storms;
- when not used for long periods of time;
- when the appliance is malfunctioning (see chapter 13).



Before connecting or changing any connections to an audio-video/computer source (DVD player, PC, etc.), disconnect the power cord from each appliance.



Make sure that ventilation grills are not obstructed by objects such as newspapers, table cloths, curtains etc.


To avoid electric shocks, do not insert foreign bodies, such as needles or coins into the ventilation grills.




Leave a gap of at least 10 cm around the appliance to allow sufficient ventilation. Before disconnecting the power lead, you are recommended to let the cooling fans of your SAGEM AXIUM™ Home Cinema Screen work for a few minutes. This will increase its working life.



## 2.5. Switching off your SAGEM AXIUM™ Home Cinema Screen

To put your SAGEM AXIUM™ Home Cinema Screen into standby mode, press the  standby button on the remote control or the standby button on the righthand side door.

You can cancel standby mode within 5 seconds (indicator light flashes green) by pressing the  standby button again on the remote control or the righthand side door. After this time, standby mode cannot be stopped.

During the standby phase (approximately 1 minute), the indicator light on the front panel starts flashing orange. The state of real standby is only effective when this indicator light changes to red.



**In order to prolong the lamp's working life, do not interrupt the standby procedure, NEVER switch off your appliance using the mains switch or disconnect the wall plug unless the front panel LED is red.**

**If you want to switch on your television set again, wait at least 10 seconds before pressing the switch on the left.**

## 3. First Rapid Installation

Your SAGEM AXIUM™ Home Cinema Screen is not preset to receive the wireless channels for your region. This rapid installation is automatically offered when you set up the appliance. It allows you to configure the basic elements of your product (menu languages, country, and channel reception).

You can return to these settings at any time (see chapter 6).

Select the menu language using the buttons  and  , validate using the **OK** key.

Select the country where you are by using the buttons  and  then validate with the **OK** button.




Country	Colour	System	Stereo
France	SECAM	L	Nicam L
Germany	PAL	B. G	Two B/G carriers
Austria	PAL	B. G	Two B/G carriers
Italy	PAL	B. G	Two B/G carriers
Spain	PAL	B. G	Nicam B/G
Netherlands	PAL	B. G	Two B/G carriers
Denmark	PAL	B. G	Nicam B/G
Sweden	PAL	B. G	Nicam B/G
Norway	PAL	B. G	Nicam B/G
Finland	PAL	B. G	Nicam B/G
Belgium	PAL	B. H	Nicam B/G
Switzerland	PAL	B. G	Two B/G carriers
UK	PAL	L	Nicam L
Portugal	PAL	B. G	
Greece	PAL, SECAM	B. G	
Poland	PAL	D. K	
Russia	SECAM	D. K	
Czech Republic	SECAM	D. K	

(\*) For Australia, choose the Germany configuration.


After accepting with the **OK** button, the automatic search begins and the channels are identified and saved automatically. The most current channels are automatically put in order according to the country that you chose.

You can also interrupt the search at any time by pressing the **MENU** button.



## 4. Description of the buttons and indicator lights


### 4.1. Buttons located within the righthand side door



ENGLISH


When the menu is called up, the buttons , ,  and  are used for moving within the screens.

### 4.2. Front panel indicator lights and remote control receiver




**Remote control receiver:** the infra-red receiver is located in the bottom/righthand corner of your SAGEM AXIUM™ Home Cinema Screen. All you have to do is aim at this spot with the remote control.

## 5. Remote Control



## 6. Personalised settings

### 6.1. Changing the security code



All installation screens can be protected by a personal code. The default code is **0000**. This does not lock the installation screens.

Press the **MENU** button, then choose 'INSTALL' with the button **►** then validate with the **OK** button.


Choose 'PROTECTION' then 'CHANGE CODE', validate with the **OK** button.

Enter your new code then confirm the same code in the confirmation screen accepting each time with the **MENU** button. You can cancel change of code at any time using the **MENU** button.

It is possible to extend protection to the whole television set. To do this, select 'GL LOCK' and choose 'YES' with the button **►**. You will then be asked for your personal code each time you switch on your SAGEM AXIUM™ Home Cinema Screen.

**NB:** To lock these screens, enter a different code than **0000**. Always remember your new code. Enter **0000** to unlock.

### 6.2. Return to initial configuration



If necessary, you can automatically configure your Sagem Axium Home Cinema Screen to the original default factory settings. In this instance, all your personal settings will be lost (list of channels, country, languages...).

Press the **MENU** button, then choose 'INSTALL' using the button **►** and validate with **OK** button.

Enter your personal code then validate using the **OK** button (no code is requested for the initial **0000** code).

Select 'FACT. RESET' and validate with the **OK** button.


A confirmation screen will invite you to continue by pressing the **OK** button or cancel with the **BACK** button.

**NB:** AXIUM HD-D45S model has no EPG function.

### 6.3. Searching TV programmes

The programmes are installed at the initial set-up. Nevertheless, the following functions are useful if you relocate to another region.

#### 6.3.1. Choice of country



The choice of country allows the television set to automatically classify the channels during the automatic search.

Press the **MENU** key.

Select the 'INSTALL' chapter using **OK** button.

Select the 'CHANNEL MAN.' chapter using **OK** button.

Select the 'COUNTRY' chapter using **OK** button.


Select the chosen country using buttons **►** and **▲**.

Your selection will be saved when you exit this menu using the **BACK** button.

**NB:** AXIUM HD-D45S model has no EPG function.



6.3.2. Manual installation



Select 'MANUAL' then validate using **OK** button.  
A search screen is then displayed allowing you to check the programme found.

Television programmes are searched and saved channel by channel.

Select 'CHANNEL MAN', and start the search using **◀** or **▶**.


When a picture is displayed on the screen,

- **You can decide to save your channel selection:**  
Go to the 'PROGR. NUMBER' No line and enter the position of the desired programme using **0** to **9** buttons.  
Move the cursor to 'MEMO' and validate using **OK** button.
- **You can try to obtain a better quality picture:**  
Go to the 'FINE TUNING' line and adjust the cursor using the buttons **◀** and **▶**.  
Move the cursor to 'MEMO' and validate using **OK** button.
- **You can decide not to save this channel selection:**  
In this instance, restart the search.  
Restart this manual procedure for all the programmes you wish to memorise.

Press on the **MENU** button to exit.

NB: AXIUM HD-D45S model has no 'EPG' function.


6.3.3. Automatic installation



Select 'AUTO SCAN' and validate using **OK** button.  
Your previous search will be erased and replaced by the new one, confirm by pressing **OK** button.  
All channels are searched and saved automatically.  
If the broadcast signal is recognised by the transmission of a teletext page, the channels will be automatically named and classified.  
You can decide to stop the search at any point in time, by using the **MENU** button.

NB: AXIUM HD-D45S model has no 'EPG' function.

6.3.4. Modifying the programme list



You can modify the programme list that is a result of your search at any time.  
Press the **MENU** button.  
Select the 'INSTALL' menu then 'CHANNEL MAN' and finally 'LIST EDITION' with the **OK** button.

NB: AXIUM HD-D45S model has no 'EPG' function.

LIST EDITION					
PROG.	FREQ.	NAME	N.R.		
1	479,50	TF1	0		
> 2	527,25	F2	1		
3	599,25	F3	2		
4	671,25	C+	0		
5	735,25	F5	3		
DELETE	⏏	MOVE	NAME	N.R.	⊕ VIEW

From this screen, you can:

- **Delete a programme**  
Go to the line of the programme to be deleted and press the **red** button.
- **Move a programme**  
Go to the line of the programme to be moved and press the **green** button to select it (a '>' appears to the left of the programme). Move it with buttons **▼** or **▲**, then accept its new position with the **green** button.


ENGLISH

- **Change the programme name**  
Go to the line of the programme name to be modified and press the **yellow** button to accept it.  
Enter the first characters. Move through the characters using the buttons **▼** or **▲**.  
Move forward by one character with the button **▶** then enter the second. Continue in the same way for the other characters (maximum of 6 characters). Finally, accept with the **yellow** button.
- **Apply noise reduction filter to a programme**  
To get the best out of your SAGEM AXIUM™ Home Cinema Screen, a noise reduction filter can be applied to the channels if the quality of reception is poor.  
Go to the line of the programme name to be modified and press the **blue** button. Each pressure on the **blue** button applies the next filter. Apply a weak '1', medium '2', or strong '3' filter according to your reception. Select '0' if no filter is necessary.

NB: You can display the selected screen at any time by pressing the **OK** button.


Press the **MENU** button to exit.

6.4. Selecting the MENU language




You can select the menu and information display language.  
Press the **MENU** button.  
Select the 'OPTIONS' chapter using the **OK** button.  
Select the 'OSD LANGUAGE' chapter using the **OK** button.  
Select the chosen language using the buttons **◀** and **▶**.  
Press the **MENU** button to exit or the **BACK** button to return to the previous screen.

6.5. Setting for the economy mode



You can decrease the power of the lamp to increase its working life and reduce its power consumption. This mode is particularly recommended if you watch your SAGEM AXIUM™ Home Cinema Screen in a dark room.  
Press the **MENU** button.  
Select 'OPTIONS' with the **OK** button.  
Go to 'ECO MODE' and choose the mode with buttons **◀** and **▶**.  
Press the **MENU** button to exit.

6.6. Setting for the SPDIF output



The digital input can be associated with one of your external sources (except aerial input). Use the OPTIONS menu to choose which SPDIF input video source is to be associated. However, make sure that you also connect your source's analogue audio if you want to have PIP/PAP sound mode in the headphones.


Press the **MENU** button.  
Select 'OPTIONS' with the **OK** button.  
Go to 'SPDIF SOURCE' and choose the video source with the buttons **◀** and **▶**.  
Press the **MENU** button to exit.

The digital audio system of your SAGEM AXIUM™ Home Cinema Screen functions equally well with SPDIF flow of PCM type (in which case the audio is both resynchronized with the picture on the SPDIF output and restored to the speakers and the HiFi output), or with Dolby Digital or DTS type (in which case the speaker and HiFi outputs are cut, and the digital flow is restored and resynchronized on the SPDIF output to be decoded by your external Home Cinema 5.1 amplifier).

Dolby DIGITAL and DTS cannot be restored by your SAGEM AXIUM™ Home Cinema Screen. Therefore, these need an external amplifier compatible with these two formats.

**Caution!** The in/out SPDIF digital audio system of your SAGEM AXIUM™ Home Cinema Screen functions at 32, 44, 1 and 48KHz. Make sure that your source is not configured to different frequencies.

6.7. Adjusting the headphone output



You can choose the audio source of the headphone output.  
Press the **MENU** button.

Select 'OPTIONS' with the **OK** button.

Go to 'HEADPHONES' and choose the video source with the buttons **◀** and **▶**.


'MAIN' will restore the sound of the full screen picture in PIP mode or the right-hand picture in PAP mode to the headphones.

'PIP/PAP' will restore the sound of the inset picture in PIP mode or the left-hand picture in PAP mode to the headphones.

**NB:** The PIP and PAP functions are described in § 8.7.

Press the **MENU** button to exit.

6.8. Setting the speaker mode



In the menu MODE HP INT., you can choose between mono, stereo or OFF.

- **AXIUM HD-D45 :**  
The OFF mode disables the internal speakers and allows you to enable and connect any external speakers not supplied. (See paragraph 16.2 or paragraph 16.2)
- **AXIUM HD-D56B :**  
To use the internal speakers: Select mono or stereo in the MODE HP INT. option and select YES for the WOOFER option (see page 16). If you do this, you should not connect external speakers to the television set.

- Continuation of page 11, AXIUM HD-D56B:  
To use external speakers not supplied, select mono or stereo in the MODE HP INT. option and select NO for the WOOFER option (see page 16). See paragraph 17.2 for connecting external speakers.  
To use your personal audio system (hi-fi system or Home Cinema audio amplifier): Select OFF in the MODE HP INT. option. If you do this, the internal and external speakers are disabled.
- Other modes: To use your personal audio system (hi-fi system or Home Cinema audio amplifier): Select OFF in the MODE HP INT. option. If you do this, the internal and external speakers are disabled.


Press the **MENU** button.

Select 'OPTIONS' with the **OK** button.

Go to 'LOUDSPEAKER' and choose the mode with the buttons **◀** and **▶**.

Press the **MENU** button to exit.

6.9. Adjusting the Hi-Fi output



You can choose between two ways of adjusting the volume of this output:

'FIXED': The volume must be adjusted on the audio system connected to the Hi-Fi output.

'ADJUSTABLE': The volume of the audio system connected to the Hi-Fi output can be adjusted from the remote control using the buttons **⏮** + and **⏭**.


Press the **MENU** button.

Select 'OPTIONS' with the **OK** button.

Go to 'HI-FI VOLUME' and choose the mode with the buttons **◀** and **▶**.

Press the **MENU** button to exit.

6.10. Exit standby mode tuning



This setting allows you to choose active mode or go to standby mode.

- Press the **MENU** button then go into 'INSTALL';
- Select 'SOURCES' then 'MANAGER'

'MANUAL': Exit from standby and go to standby mode by pressing the standby button **⏻** on the remote control or righthand side door.

'AUTO': Exit from standby or go to automatic standby controlled by the equipment plugged into 'SCART' connectors on the rear panel. In this mode, new sources detected by the television set will be automatically displayed.


Press the **MENU** button to exit.

## 7. Connecting equipment and configurations

### 7.1. Connection advice


Your SAGEM AXIUM™ Home Cinema Screen offers you a large selection of connectors to attach the equipment of your choice. You are advised to carry out the connections when the appliances are switched off.

#### REAR PANEL



- AV1**  
Recommended for a DVD player, a DVDR player/recorder, a digital decoder (cable, satellite or wireless).
- AV2**  
Recommended for an analogue decoder, or a digital decoder (cable, satellite or wireless).
- AV3**  
Recommended for a VHS, SVHS videocassette recorder, a DVD player or digital decoder.
- AV4**  
Recommended for a games console.
- AV5**  
Recommended for a DVD player provided with Y Pb Pr outputs. This type of connection automatically detects 'interlaced' or 'progressive' mode.
- HiFi**  
This output can be connected to any audio system equipped with its own speakers such as a high-fidelity system. For better comfort of listening to your audio system, cut the sound of your SAGEM AXIUM™ Home Cinema Screen (see § 6.8). The DLP™ technology causes a slight delay in picture processing, so connect your amplifier to these sockets and not to those of the source (see § 6.9).
- PC2 IN**  
(PC IN on AXIUM HD-D45S model only). Recommended for connecting a PC or a DVD player equipped with 'DVI D' socket. Only use a 'DVI D' cable (graphics card).
- SPDIF IN**  
The DLP™ technology causes a slight delay in picture processing. To synchronise the sound with your SAGEM AXIUM™ Home Cinema Screen, connect the digital audio output of your DVD player to this output and recover the synchronized signal on SPDIF OUT.
- SPDIF OUT**  
This output allows you to recover the signal sent to SPDIF IN after digital synchronisation with the picture. Connect this output to the digital audio input of your Home Cinema audio amplifier. (AXIUM HD-D45S only). This output allows you to connect an external active woofer. Its volume follows that of the speakers. However, it is possible to vary its level independently of the speakers. Press the **MENU** button, select **SOUND** then **ADVANCED** then **WOOFER VOLUME**.
- SUB WF**  
Reserved for servicing personnel.
- SERVICE**  
Reserved for servicing personnel.


#### RIGHTHAND SIDE DOOR



- HEADPHONES**  
recommended for headphones.  
Adjusting the headphones is covered in § 6.7.
- AV6**  
recommended when connecting a camcorder in VHS, S-VHS, 8 mm, Hi-8 or digital DVC format.
- PC1 IN**  
(except model AXIUM HD-D45S)  
Recommended for connecting a PC computer equipped with a 'VGA' output.  
socket. A 3.5 mm audio jack socket allows you to connect sound.

ENGLISH

### 7.2. Source configuration



Press the **MENU** key then select 'INSTALL' using the button ► and validate using **OK**.  
If your code is not **0000**, this screen is protected and you must enter your code.  
Select 'SOURCES', then 'CONFIG' and accept with **OK**.  
This option allows you to select the sources used but only displays them when you select sources in daily use.  
Choose the connector to be configured (► / ◀).

**Note:** AXIUM HD-D45S model has no 'EPG' function.

INPUT	SOURCE	N°	NAME	N.R.
SCART 1	YES	---	----	0
SCART 2	YES	--	----	0
SCART 3	YES	---	----	0
AV 4	YES	---	----	0
AV 5	YES	---	----	0
AV 6	YES	---	----	0
PC 1	YES	---	----	0
PC 2	YES	---	----	0
SOURCE	CHOOSE NAME	NAME	N.R.	VIEW

- For each connector, you can:**
  - Validate connected equipment**  
Press the **red** button several times until 'YES' (or 'NO' for an unused connector) is displayed. Select 'C+' if you have connected your C+ decoder to SCART 2. In this instance, enter the C+ programme number at once.
  - Choosing a pre-programmed name**  
Press the **green** button several times (DVD, DVDR, C+, DEC, MAG, GAMES).
  - Choosing a personalised name**  
Press the **yellow** button to move to edit mode. Scroll through the characters using the buttons ► ◀. Go to the next character using ►. Finally, press the **yellow** button to validate.
  - Choosing a noise reducer**  
You can apply a noise reducer to some sources such as a video player by scrolling through them by pressing the **blue** button more than once (none '0', weak '1', medium '2', strong '3').
- PC2** is called **PC** on the screen of the model AXIUM HD-D45S.
- Press the **MENU** button to exit.

### 7.3. Configuration of computer sources

If a personal computer is used (PC or MAC), switch on your SAGEM AXIUM™ Home Cinema Screen before the computer.

**NB:** AXIUM HD-D45S model has no 'EPG' function.

Press the **MENU** button, then choose 'INSTALL' using the button **►** and validate with **OK**.

Choose 'PC DATA' then validate with **OK**.

With this option, you can adjust the source from your PC into VGA (PC1) (except model AXIUM HD-D45S).

**Horizontal position:** press **◄** to move the picture to the left and **►** to move it to the right.

**Vertical position:** Press **►** or **◄** to move the picture to the top or bottom.

**Frequency:** This allows you to adjust the frequency to that of your computer's graphics card. When a flashing vertical bar appears, use this function to adjust the frequency.

**Phase:** This allows finer synchronisation with your computer's graphics card. Use this tuning when an unstable or flashing picture occurs.

**Automatic mode:** This allows you to adjust everything automatically or not.

**Resolutions accepted (DVI-D and VGA entries):** To ensure that the projection display is operating correctly with your computer make sure that you configure the display mode of your graphics card to a resolution lower than 1024 x 768.

Resolution (px)	Frequency (Hz)
640 x 480	60
640 x 480	66
640 x 480	72
640 x 480	75
640 x 480	85
800 x 600	60
800 x 600	72
800 x 600	75
800 x 600	85
1024 x 768	60
1024 x 768	70
1024 x 768	75
1152 x 864	60
1280 x 720	60

**NB:** Optimum stability is achieved with a frequency of 60 Hz (consult the documentation for your PC to configure it).

## 8. Day-to-day use

### 8.1. Picture adjustment

#### PERSONAL PICTURE TUNING

You can set and save your own parameters using the 'USER' mode.

**CONTRAST, BRIGHTNESS, COLOUR, SHARPNESS, TINT**

can be adjusted according to your preferences using the buttons **◄** and **►**.

The tone adjustment only applies to an NTSC video source.


The colour balance adjustment allows you to set the main picture colour.

Adjust using **◄** or **►**.

#### PRESET PICTURE SETTINGS

You can choose your picture preference from the settings offered using the buttons **◄** and **►** STANDARD CINEMA STUDIO SPORT Select the most suitable one for the programme you are viewing and validate using the **OK** button.

Press the **MENU** button to exit and the **BACK** button to return to the previous screen.



### 8.2. Sound adjustment

#### ADJUSTMENTS POSSIBLE BY REMOTE CONTROL

**Volume:** Press **◄** + or **◄** - to adjust the volume.

**Mute:** Press **⏻** to mute or to switch on the sound.

**Bilingual broadcast or sound selection:** Press **⏻** to choose between MONO or STEREO sound if the channel transmits sound in NICAM stereo mode. Choose between DUAL A and DUAL B if there is a bilingual broadcast. This adjustment is saved per channel.

#### PERSONAL SOUND SETTINGS

You can set and save your own audio balance using the 'PERSO' mode.

Press the **MENU** button then go to 'AUDIO'.

Choose 'PERSO' with buttons **▼** and **▲**.


Move through the various frequency bands with the buttons **◄** and **►** then adjust the desired level using the buttons **▼** and **▲**. The level displayed under the bar is in audio decibels (dBA).

#### PRESET AUDIO BALANCE


You can choose a sound balance from among the preset parameters using the buttons **▼** and **▲** STANDARD, VOICE, MUSIC or FILM.

Choose the setting that best suits the programme you are watching and validate with the **OK** button.


**NB:** AXIUM HD-D45S model has no 'DOLBY VIRTUAL' function.



Model AXIUM HD-D45S



Other models



#### ADVANCED SOUND SETTINGS

To adjust the other audio parameters, go to 'NEXT'.

#### DYNAMIC BASS LOUDNESS

Allows you to accentuate the low frequencies or not.

is an automatic equalization system designed to reinforce the bass and treble at low volume.

#### SMART VOL

Allows you to adjust the sound control mode.

In NORMAL mode, your SAGEM AXIUM™ Home Cinema Screen will regulate the audio level to avoid too great a difference in volume between two sources. In NIGHT mode this attenuation is stronger and reacts more quickly to the variations of volume, particularly if there is a violent explosion in a film sequence for example.

Allows you to enable Virtual Dolby Surround or not (except AXIUM HD-D45S model). The internal speakers (AXIUM HD-D56B) or the woofer (other models) can be ON or OFF. This option is not found on AXIUM HD-D45S model.

Move the cursor with the buttons **◄** and **►** to balance sound between the left and right speakers.

Allows you to adjust the headphones volume output on the righthand side door.

Allows you to adjust the sound volume of output 'SUB W/F' for an external active woofer (AXIUM HD-D45S only).



**NB:** Virtual Dolby Surround is a technology coming from Dolby Laboratories. It creates a virtual background soundscape through two speakers using the Dolby Pro Logic. Virtual Dolby Surround takes audio information from all the original channels and gives the listener the sensation of being surrounded by additional speakers.

Press the **MENU** button to exit and the **BACK** button to return to the previous screen.




### 8.3. Sleep timer

This option allows you to programme a period of time after which the television set will go to standby automatically.

Press the **MENU** button then choose 'OPTIONS' using the button **►** and validate using **OK**.  
Select 'SLEEP TIMER' then choose the duration with the buttons **►** and **►**.

You can set the sleep time at 15 min intervals up to a maximum of 180 min.  
One minute before entering standby mode, the last minute counter will appear on the screen. This screen allows you to cancel the sleep timer, if you want to.  
You can always stop the SAGEM AXIUM™ Home Cinema Screen before the programmed stop time or reprogramme the stop time.



### 8.4. Choice of sources

You can select sources in two different ways:

- With the **P+/P-** buttons on the righthand side door. You first navigate among valid TV channels then among all the external sources SCART 1, SCART 2, SCART 3, AV4, AV5, AV6, PC1 (except AXIUM HD-D4SS model), PC2 (PC on AXIUM HD-D4SS).

*NB: A channel is valid if it has been found during the automatic search or if it has been saved during the manual search.*

- By using the direct access button **↵** on the remote control.  
Select the chosen source by pressing **↵** again until the correct source is obtained.

*NB: If you previously configured and named your equipment inputs in paragraph 7.2, you will only be offered the sources connected and configured.*

To return to the channels, press the **BACK** button, on a **digital** button or on a **P+/P-** button.  
If you connected a video source, the television set will automatically display this source.

### 8.5. Choice of format

A simple access to this choice is by using the direct access button **↵**.

This function allows you to display the picture at the maximum size, including wide screen pictures.

Press the button **↵** of remote control.

*Nb: At first press, the info banner displays the current status without any change of format.*



#### 4:3 FORMAT

Displays a 4:3 picture in its original format.

#### ENLARGED FORMAT

This format allows you to watch 4:3 pictures at the maximum size by horizontally stretching the left and right edges of the picture. (The central part is not deformed).

#### 14:9 FORMAT

This format allows you to watch programmes in 14:9 format. Manually, this format is recommended for films in 1.66 cinema format

#### FORMAT 16:9

This format allows you to automatically watch programmes in 16:9 format using the 16/9 signals coming to the SCART.

#### CINEMA FORMAT

This format allows you to watch films in 1.85 (ACADEMY FLAT) format, broadcast in 4:3 in maximum screen format without distortion with black bands at the top and bottom.  
It allows you to watch films in 2.0, 2.20, and 2.35 format.

#### SUBTITLE FORMAT

This format allows you to watch films in 1.85 (ACADEMY FLAT) format broadcast in 4:3 at maximum screen format without picture loss and without distortion by moving the picture to the top to enable any subtitles to be read.

#### SCOPE FORMAT

This format allows you to watch films in 2.35 (PANAVISION) format, broadcast in 4:3 in maximum screen format without distortion, at maximum height but with picture loss at the right and left edges.

#### NATIVE FORMAT

This format allows you to display the picture as it is without any resizing. Only on sources PC1 (AXIUM HD-D45 only) and PC2 (PC on AXIUM HD-D4SS).

### 8.6. Programme information

Press the button **↵** at any time to obtain information on the TV channel.

When you are watching an external video source, the name of the source will be displayed.



### 8.7. Double picture mode selection

#### Switching on double picture mode

Choose the video insert mode (PIP) or two videos side-by-side (PAP) by pressing the button **↵** more than once.

**When one of the two Modes - (PIP or PAP) is in use, you can:**

**Invert the sources** by pressing the button **↵**.

**Change source** on the screen by pressing the button **↵** to name the source to be changed; then

- P+ or P- to change the wireless channel,
- **↵** to change the source.

*Warning: (All except AXIUM HD-D4SS models): You cannot have sources PC1, PC2 or AV5 simultaneously in PIP mode (inset picture) and MAIN mode (full screen). Same for PAP mode (picture on the left half of the screen).*

*AXIUM HD-D4SS: The above warning only concerns antenna, PC or AV5 sources*

**Change the format** on the screen by pressing the button **↵** to name the source to be changed; then

- **↵** to change the format.

The buttons **◀** and **▶** change the position of the PIP window if the PIP mode is activated. You can navigate through 4 possible positions in the order top-left, top-right, bottom-left, bottom-right.

### 8.8. Choosing a TV programme

Use the **0/9** buttons to choose your channel. For a two-digit number, enter the second within 2 seconds.







Use the **BACK** button to return to the channel previously watched. **BACK** also allows you to return from an external video source to the TV channels.

### 8.9. Picture hold

Use the pause button **⏸** to freeze the picture or reactivate it.

## 9. Teletext

Teletext functions vary according to television companies and are only available if the selected channel transmits teletext.

- **Teletext display**  
Press the button  to switch on teletext without video. Pressing the button again allows you to view teletext imposed on the current video. You can exit from Teletext mode by pressing again. If there is no teletext on the channel you are watching, a message will inform you of this.
- **Selecting the index page**  
Teletext pages include an introduction page (usually page 100) telling you how to use the service. The button  allows you to select this introduction page directly.
- **LIST or FASTEXT mode**  
There are two teletext modes:
  - LIST mode: in this mode, four pages numbers appear at the bottom of the screen, each in a different colour. Each of these numbers can be changed and saved in the memory.
  - FASTEXT mode: in this mode, four subjects appear at the bottom of the screen, each in a different colour. To obtain more information on one of these subjects press the corresponding coloured button.This function allows you to obtain information on the displayed subjects quickly. The required mode is selected by pressing the button .
- **Selecting a page**  
Enter the number of the required page using the **0-9** buttons. (There are no pages starting with a 0 or 9.). The page counter at the top of the screen searches for the page or the page appears immediately, if the page number has already been saved. You can quickly scroll through teletext pages by using the **P+ P-** or **▲ ▼** buttons (by skipping non-existent pages). To save another page in this mode, press the relevant coloured button and enter the page number. When in FASTEXT mode, you can select a chosen subject using the colour buttons corresponding to the options at the bottom of the screen.
- **Displaying hidden information**  
Press the button  to call up and delete hidden information, such as puzzle solutions and replies to questions.
- **Holding a page**  
Press the button  to hold a text page, whilst looking at information that is on several pages. Press again to return to automatic update.
- **Expand**  
Press the **MENU** button then the **green** button. Pressing it more than once allows you to display the top half, the bottom half and then return to normal format.
- **Navigation within sub-pages**  
When the selected pages contain one or more sub-pages, a help line listing the sub-pages appears at the bottom of the screen. Use the buttons **◀ ▶** to choose the next or the previous sub-page.
- **Subtitles**  
TV channels with teletext often transmit certain programmes with subtitles. Press the button  and select the relevant subtitle page. The subtitle page continuously appears on the screen if the current programme is transmitted with subtitles.

## 10. NextView EPG (AXIUM HD-D45 only)

NextView is an electronic programme guide (or EPG) for analogue television. It is a service giving information about current and future programmes. The programme information for all the channels is transmitted up to one week in advance.

The 'NextVlink' function is not available.

### 10.1. Installation

To enable the EPG, enter the 'INSTAL.' menu, go to line 'EPG'. Using the arrow **▶** go on '-.' (if you are using the EPG for the first time, see figure 1) or on the channel number (if you have already used the EPG, see figure 2).

In both these cases, you can enter or re-enter a channel number consisting of two digits (e.g.: 01 for the first channel, 02 for the second channel, 12 for the twelfth channel, etc.).

To enable the EPG, you must enter a channel number.




Figure 1 : Example of the EPG menu accessed for the first time.




Figure 2 : Example of the EPG menu configured on the first channel.

The EPG NextView uses the signals from certain channels for transmission.

In the 'CHANNEL' menu choose the appropriate channel number (see list below).

The EPG is acquired automatically each time you exit from standby on your SAGEM AXIUM™ Home Cinema Screen.

If you use the PIP or PAP functions when changing channel within ten minutes of coming out of standby, the EPG will be cancelled.

Similarly, pressing the **EPG** button on the remote control during acquisition will cancel the current procedure and will display the last EPG in memory, which is perhaps not up to date.

List of channels transmitting NextView EPG on September 1, 2004:

Country	Channels transmitting NextView EPG
France	M6 (3), Canal+ (7), TV5 (4), TSRT
Germany	RTL2 (3), Kabel1 (4-9), SF1
Austria	SF1
Italy	TSL
Belgium	VT4 (3)
Switzerland	SF1, TSRT, TSL
Turkey	TRT Family (5-6)

In brackets, is the number of days of programmes consultable in EPG. The television channels are free to transmit the signal EPG NextView or not, therefore this list is not legally binding.

10.2. Navigation

Press the **EPG** button on the remote control to start acquisition.

***NB:** If this is the first time that you start EPG, you must wait a few minutes for your television set to recover the available information about programmes.*

To obtain information about your choice of programme, use the buttons **▼** and **▲** then accept with **OK**.

You can sort the programmes according to four criteria by using the coloured buttons A, B, C and D on the remote control:

**Time:** **Red** button: With buttons **◀** and **▶** , select the time of your choice from 'Present' to 'Time T+24'

**Date:** **Green** button: With buttons **◀** and **▶** , select the date of your choice from 'Today' up to 'Day D+7'

**Topic:** **Yellow** button: With buttons **◀** and **▶** ,choose the programme type from among: All, Films, News, Variety, Leisure, Sport, Children, Science, Music, Art, Series

**Channel:** **Blue** button: With buttons **◀** and **▶** , select the channel of your choice.

To exit from the EPG, press the **EPG** button on your remote control.

11. Compatibility with High Definition Television

High Definition Television is a generic term applying to all the kinds of television signals offering resolution higher than the present standard pictures. NTSC consists of 720 points per line and 480 lines per picture. PAL consists of 720 points per line and 576 lines per picture. HDTV has a higher resolution both horizontally and vertically. Your SAGEM AXIUM™ Home Cinema Screen has been designed for high definition television and has a resolution of 1280 points per line and 720 lines per picture.

The standards:

There are numerous standards for high definition television. SAGEM AXIUM™ Home Cinema Screen is compatible with the main HDTV standards. You can view TV programs as well as high definition DVD simply by using inputs PC1 (except AXIUM HD-D45S model), PC2 (PC on AXIUM HD-D45S) and AV5.

Standards compatible with your SAGEM AXIUM™ Home Cinema Screen

Standards	Pixels per active line	Lines per picture	Pixels per complete line	Total number of lines per frame	Refresh rate	Sampling rate	Type of format
SMTE 295M-1997 2	1920	1080	2376	1250	25,00	74,25	interlaced
SMpte 274M-2003 4	1920	1080	2200	1125	30,00	74,25	interlaced
SMpte 274M-2003 5	1920	1080	2200	1125	29,97	74,18	interlaced
SMpte 274M-2003 6	1920	1080	2640	1125	25,00	74,25	interlaced
SMpte 296M-2001 1	1280	720	1650	750	60,00	74,25	progressive
SMpte 296M-2001 2	1280	720	1650	750	59,94	74,18	progressive
SMpte 296M-2001 3	1280	720	1980	750	50,00	74,25	progressive

12. HDCP

HDCP is a protocol for encrypting digital data to protect it from being copied. Your SAGEM AXIUM™ Home Cinema Screen is equipped with a system compatible with HDCP, which allows you to view this type of information. You can connect any high definition source on the PC2 (PC on AXIUM HD-D45S) if its type appears in the above list without worrying about the HDCP protection.

13. Diagnosing problems and Trouble Shooting

Symptoms:	Recommended checks:
When first using your SAGEM AXIUM™ Home Cinema Screen, the red on/off indicator light is not illuminated.	Check that the mains cable to SAGEM AXIUM™ Home Cinema Screen is connected to the appliance and the wall socket. Also check that the switch on the left side of the appliance is pressed in.
The appliance does not light up when the <b>onstandby</b> button is pressed on the righthand side door or remote control	Check that the mains cable to SAGEM AXIUM™ Home Cinema Screen is connected to the apparatus and the mains socket. Also check that the switch on the left side of the appliance is pressed in.
There is no picture.	If the menus of your SAGEM AXIUM™ Home Cinema Screen are available: Check that your video appliances are correctly connected and are active. Also check that you have selected the correct video source see § 8.4. Check that your aerial lead is correctly connected. Also check that you have saved the channels see § 6.3.4. If this is not the case, start a manual or automatic search. Also check that the switch on the left side of the appliance is pressed in. The internal temperature indicator light is flashing red. Put your television set into standby. The lamp condition indicator light is red: the lamp has gone past its standard working life and may no longer be functioning. It must be changed.
Black and white picture or picture interference.	Check that you have selected the correct video format: e.g. RGB video source from a DVD player displayed in S-video on your SAGEM AXIUM™ Home Cinema Screen : check by pressing the <b>picture source selection</b> button if the type of source selected is compatible with the source emitted. Check that the colour adjustment is not at minimum.
No sound.	Check that the volume is not set at minimum and that mute has not been activated. Check that your appliances are correctly connected to your SAGEM AXIUM™ Home Cinema Screen.
Sound weak or discordant during terrestrial reception.	Set sound to Mono. Check the 'SMART VOL' setting (see § 8.2).
Frozen picture.	Check that you have not held the picture: press the <b>'PICTURE of TELETXT PAGE HELD'</b> button.
Your appliance does not start on leaving standby mode when using the button on the righthand side door or the <b>standby</b> button on your remote control.	The ON/STANDBY indicator light flashes orange for 20 secs then turns to red or still flashes orange: switch off the appliance using the switch to the left of your SAGEM AXIUM™ Home Cinema Screen. Wait 30 secs and restart is using the normal procedure.
No picture on PIP mode.	Check that you have selected sources that is active in PIP mode (see § 8.7).
The remote control is not working normally.	Change the batteries.
SAGEM AXIUM™ Home Cinema Screen makes a hissing noise when switched on.	This noise is normal when starting. It is not considered as malfunctioning.
Pixels on the screen do not light up.	In spite of the very high technological precision with which your SAGEM AXIUM™ Home Cinema Screen has been made, certain pixels may be faulty. This is not considered as malfunctioning.




## 14. Changing the lamp unit


Only replace the old lamp unit with authorised model RL1280A, reference number SAGEM 251691414

The old lamp unit must be recycled (contact your recycling agency to obtain the address of the nearest depot).


1. You must only change the lamp unit, when the appliance is switched off and mains cable disconnected from the wall socket.
2. Never try to replace the lamp unit immediately after the SAGEM AXIUM™ Home Cinema Screen has been switched off. Wait at least 1 hour to allow the lamp to completely cool down.
3. Only handle the lamp unit by the holes designed for this purpose. Never touch any wires or the bulb itself.
4. Make sure that you tighten all the screws and do not leave any foreign bodies inside the appliance.
5. Never replace the fuse of a worn-out lamp.




- 1** Remove the left-hand panel by turning the bolt a quarter turn with a coin.  
Then pull it towards you.



- 2** Unscrew the two thumbwheels holding the worn-out lamp unit.  
The two lamp unit screws are 'captive' type, meaning that when unscrewed they remain in the lamp unit.  
Pull it towards you holding it between your thumb and forefinger.



- 3** Insert the new lamp unit in place of the old one.  
Tighten the two thumbwheels linked to the unit.  
**Never touch the bulb.**




- 4** Replace the left-hand panel by pressing it slightly until it goes back into place.  
Turn the bolt again by a quarter turn.

## 15. Technical characteristics of AXIUM HD-D45 model

Video	
Screen size: 114 cm	
Aspect ratio: 16/9	
Resolution: 1280 x 720	
Reception Tuner (antenna input 'ANT')	
Input frequencies: 45.5 - 862.25 MHz	
Input sensitivity: 20 - 100 dBµV	
Number of programmes: 99	
PAL B, G, H, I, D, K, SECAM B, G, D, K, L, L'	
VHF E2 - E12	
VHF A - H (Italy)	VHF H1 - H2 (Italy)
UHF E21 - E69	
CATV (S01 - S02)	
CATV S11 - S20 (U1 - U10)	
CATV S1 - S10 (M1 -M10)	
CATV S21 -S41 (hyperband)	
VHF R1 - R2	
VHF R6 - R12	
VHF R3 - R5	
Audio demodulation	
AM 6.5 MHz / NICAM 5,85 MHz (L, L')	
FM 5.5 MHz 5,74 MHz (BG)	
FM 5.5 MHz / NICAM 5,85 MHz (B, G)	
FM 6.0 MHz / NICAM 6,55 MHz (I)	
FM 6.5 MHz 6,258 MHz / NICAM 5,85 MHz (D, K, K')	
Audio	
Maximum power: 2 x 30 W (8 Ohm)	
Two external speaker columns	
One internal woofer (on the television set)	
5-band equalizer	
Righthand side door	
AV6	
S-Video input (Mini Din 4-pin)	
Composite video input (1 x RCA)	
Audio input (2 x RCA)	
PC1 IN	
VGA Computer input (SubD 15-pin)	
Audio input (jack 3.5)	
Headphones	
Output (jack 3.5)	
6 buttons (onstandby, P+, P-, V+, V-, OK)	
Rear panel terminals	
AV1 (RGB/CompS-video, audio)	
AV2 (RGB/CompS-video, audio)	
AV3 (RGB/CompS-video, audio)	
AV4	
S-video input (Mini-Din 4-pin)	
Composite video input (1 x RCA)	
Audio-in input (2 x RCA)	
AV5 (interfaced or progressive)	
Y, Cb, Cr in input (3 x RCA)	
Audio input (2 x RCA)	
HI-FI	
Audio output (2 x RCA)	
PC2 IN	
DVI D Computer input	
Audio input (2 x RCA)	
SERVICE (reserved for servicing personnel)	
SPDIF	
Digital audio input (1 x RCA)	
Digital audio output (1 x RCA)	
Input signals	
Video signal:	
Native/Upscale: SDTV/EDTV (480i/480P) (576i/576P)	
HDTV (1080i/720P)	
PC signal:	
Native/Upscale : VGA 640 x 480, SVGA 800 x 600, XGA 1024 x 768	
Power supply	
AC 220-240 V ~50 Hz	
Power consumption: 170 W (Standby/ 3 W)	
Dimensions and weight	
TV (hxxp): 791 x 1287 x 372 mm	
Weight: 29 kg	
Dimensions and weight (packaged)	
TV carton (hxxp): 858 x 1197 x 497 mm	
TV carton weight: 37 kg	
Accessories	
Remote control TL-50	
Batteries: 2 x 1.5 V (AA Type)	
RF cable (for antenna input 'ANT')	
Two cables for connecting the external speaker columns	
One screwdriver	
Eight screws for fixing the external speaker columns	
User manual	
European power cord with ground terminal, UK power cord with ground terminal, Italian power cord with ground terminal.	
Norms	
EMC (Electromagnetic Compatibility)	
EN5013:10.2001+A1:04.2003	
EN5020:04.2002+A1:01.2003	
EN55022:1998+A1:2000+A2.2003	
EN55024:09.1998+A1:10.2001+A2:01.2003	
EN61000-3-3:1995+A1:2001	
EN61000-3-2:2000	
This is a class A product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.	
Electrical safety	
EN60065 : 2002	
CEI60065 : 2001	



15.1. Overview of AXIUM HD-D45 model



15.2. Fitting and connecting speaker columns, SAGEM AXIUM HD-D45 model

**NB:** The two speaker columns are interchangeable. This means that each one can be placed either on the right or left. Please note, the two audio cables provided have different lengths to allow for this.

**Fitting the speaker columns supplied**

Take the speaker columns out of their packaging. Put the first speaker column beside the screen, see **step 1** ➡ so that the fixing holes coincide with those of the frame. Using the screws and screwdriver provided, fix the two lugs of the column against the frame, see **steps 2** ➡, **3** ➡, **4** ➡, **5** ➡. Do the same for the second speaker column.


**Connecting the speaker columns supplied**

Connect each column to your SAGEM AXIUM™ Home Cinema Screen with the audio cables supplied:

- For the left-hand speaker column, viewed from the rear, take the 510-mm cable and connect the red wire on the red terminal, the black wire on the black terminal to this column, see **step 6** ➡.
- Connect the other end of the cable in the same way on the left-hand terminal, viewed from the rear, of your SAGEM AXIUM™ Home Cinema Screen, see **step 7** ➡.
- Then hide the cable by pushing it in the groove, starting from the black and red terminals of the speaker column, see **step 8** ➡. Then continue like this to the black and red terminals of the television set, see **step 9** ➡.
- Do the same for the right-hand speaker column, viewed from the rear.

**Connecting your own speakers**

You have the ability to connect your own speakers to your SAGEM AXIUM™ Home Cinema Screen if these have impedance greater than or equal to 8 ohm. To do this, disconnect the speaker columns, connect your speakers instead. Push the wires in the grooves. To enable / disable the internal woofer, see § 8.2. To enable / disable the external speaker columns, see § 6.8.




## 16. Technical characteristics of AXIUM HD-D45S model

Video	
Screen size: 114 cm	
Aspect ratio: 16/9	
Resolution: 1280 x 720	
Reception Tuner (antenna input 'ANT')	
Input frequencies: 45.5 - 862.25 MHz	
Input sensitivity: 20 - 100 dBµV	
Number of programmes: 99	
PAL B, G, H, I, D, K, SECAM B, G, D, K, L, L'	
VHF E2 - E12	
VHF A - H (Italy)	VHF H1 - H2 (Italy)
UHF E21 - E69	
CATV (S01 - S02)	
CATV S11 - S20 (U1 - U10)	
CATV S1 - S10 (M1 - M10)	
CATV S21 - S41 (hyperband)	
VHF R1 - R2	
VHF R6 - R12	
VHF R3 - R5	
Audio demodulation	
AM 6.5 MHz / NICAM 5.85 MHz (L, L')	
FM 5.5 MHz 5.74 MHz (BG)	
FM 5.5 MHz / NICAM 5.85 MHz (B, G)	
FM 6.0 MHz / NICAM 6.55 MHz (I)	
FM 6.5 MHz 6.258 MHz / NICAM 5.85 MHz (D, K, K')	
Audio	
Maximum power: 2 x 30 W (8 Ohm)	
Two speakers inside the television set	
5-band equalizer	
Righthand side door	
<b>AV6</b>	
S-Video input (Mini Din 4-pin)	
Composite video input (1 x RCA)	
Audio input (2 x RCA)	
Headphones	
Output (jack 3.5)	
<b>6 buttons (on/standby, P+, P-, V+, V-, OK)</b>	
Rear panel terminals	
<b>AV1</b> (RGB/Comp/S-video, audio)	
<b>AV2</b> (RGB/Comp/S-video, audio)	
<b>AV3</b> (RGB/Comp/S-video, audio)	
<b>AV4</b>	
S-video input (Mini-Din 4-pin)	
Composite video input (1 x RCA)	
Audio-in input (2 x RCA)	
<b>AV5</b> (interlaced or progressive)	
Y, Cb, Cr in input (3 x RCA)	
Audio input (2 x RCA)	

<b>H-Fi</b>	
Audio output (2 x RCA)	
<b>PC IN</b>	
DVI D Computer input	
Audio input (2 x RCA)	
<b>SUB WF</b> (external woofer)	
<b>SERVICE</b> (reserved for servicing personnel)	
<b>SPDIF</b>	
Digital audio input (1 x RCA)	
Digital audio output (1 x RCA)	
Input signals	
Video signal:	
Native/Upscale: SDTV/EDTV (480i/480P) (576i/576P)	
HDTV (1080i/720P)	
PC signal:	
Native/Upscale : VGA 640 x 480, SVGA 800 x 800, XGA 1024 x 768	
Power supply	
AC 220-240 V ~50 Hz	
Power consumption: 170 W	
(Standby 3 W)	
Dimensions and weight	
TV (hxixp): 791 x 1058 x 372 mm	
Weight: 26 kg	
Dimensions and weight (packaged)	
TV carton (hxixp): 858 x 1197 x 497 mm	
TV carton weight: 34 kg	
Accessories	
Remote control TL-50	
Batteries: 2 x 1.5 V (AA Type)	
RF cable (for antenna input 'ANT')	
Two cables for connecting the external speaker columns	
One screwdriver	
Eight screws for fixing the external speaker columns	
User manual	
European power cord with ground terminal, UK power cord with ground terminal, Italian power cord with ground terminal.	
Norms	
<b>EMC (Electromagnetic Compatibility)</b>	
EN55013:10.2001+A1:04.2003	
EN55020:04.2002+A1:01.2003	
EN55022:1998+A1:2000+A2:2003	
EN55024:09.1998+A1:10.2001+A2:01.2003	
EN61000-3-2:2000	
EN61000-3-3:1995+A1:2001	
This is a class A product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.	
<b>Electrical safety</b>	
EN60065 : 2002	
CEI60065 : 2001	

### 16.1. Overview of AXIUM HD-D45S model



### 16.2. Fitting and connecting additionally purchased external speakers

You can connect your own speakers to your SAGEM AXIUM™ Home Cinema Screen if they have an impedance greater than or equal to 8 ohms. To do this, connect your speakers, see **step 7** ➡ in § 15.2. Push the wires in the grooves, see **step 9** ➡ in § 15.2.


To enable / disable your own speakers, see § 6.8.

## 17. Technical characteristics of AXIUM HD-D56B model

Video	
Screen size: 142 cm	
Aspect ratio: 16/9	
Resolution: 1280 x 720	
Reception Tuner (antenna input 'ANT')	
Input frequencies: 45.5 - 862,25 MHz	
Input sensitivity: 20 - 100 dBµV	
Number of programmes: 99	
PAL B, G, H, I, D, K, SECAM B, G, D, K, L / L'	
VHF E2 - E12	
VHF A - H (Italy)	VHF H1 - H2 (Italy)
UHF E21 - E69	
CATV (S01 - S02)	
CATV S11 - S20 (U1 - U10)	
CATV S1 - S10 (M1 -M10)	
CATV S21 -S41 (hyperband)	
VHF R1 - R2	
VHF R6 - R12	
VHF R3 - R5	
Audio demodulation	
AM 6,5 MHz / NICAM 5,85 MHz (L, L')	
FM 5,5 MHz 5,74 MHz (BG)	
FM 5,5 MHz / NICAM 5,85 MHz (B, G)	
FM 6,0 MHz / NICAM 6,55 MHz (I)	
FM 6,5 MHz 6,258 MHz / NICAM 5,85 MHz (D, K, K')	
Audio	
Maximum power: 2 x 30 W (8 Ohm)	
Two speakers inside the television set	
5-band equalizer	
Righthand side door	
AV6	
S-Video input (Mini Din 4-pin)	
Composite video input (1 x RCA)	
Audio input (2 x RCA)	
PC1 IN	
VGA Computer input (SubD 15-pin)	
Audio input (jack 3.5)	
Headphones	
Output (jack 3.5)	
6 buttons (on/standby, P+, P-, V+, V-, OK)	
Rear panel terminals	
AV1 (RGB/Comp/S-video, audio)	
AV2 (RGB/Comp/S-video, audio)	
AV3 (RGB/Comp/S-video, audio)	
AV4	
S-video input (Mini-Din 4-pin)	
Composite video input (1 x RCA)	
Audio-in input (2 x RCA)	
AV5 (interlaced or progressive)	
Y, Cb, Cr in input (3 x RCA)	
Audio input (2 x RCA)	

Input signals	
Video signal:	
Native/Upscale: SDTV/EDTV (480i/480P) (576i/576P)	
HDTV (1080i/720P)	
PC signal:	
Native/Upscale : VGA 640 x 480, SVGA 800 x 600, XGA 1024 x 768	
Power supply	
AC 220-240 V ~50 Hz	
Power consumption: 170 W	
(Standby 3 W)	
Dimensions and weight	
TV (hxxp): 939 x 1306 x 438 mm	
Weight: 37,2 kg	
Dimensions and weight (packaged)	
TV carton (hxxp): 1100 x 1425 x 600 mm	
TV carton weight: 51kg	
Accessories	
Remote control TL-50	
Batteries: 2 x 1,5 V (AA Type)	
RF cable (for antenna input 'ANT')	
User manual	
European power cord with ground terminal, UK power cord with ground terminal, Italian power cord with ground terminal.	
Norms	
EMC (Electromagnetic Compatibility)	
EN55013:10.2001+A1:104.2003	
EN55020:04.2002+A1:01.2003	
EN55022:1998+A1:2000+A2:2003	
EN55024:09.1998+A1:10.2001+A2:01.2003	
EN61000-3-2:2000	
EN61000-3-3:1995+A1:2001	
This is a class A product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.	
Electrical safety	
EN60065 : 2002	
CEI60065 : 2001	

### 17.1. Overview of AXIUM HD-D56B model



ENGLISH

### 17.2. Fitting and connecting additionally purchased external speakers

You can connect your own speakers to your SAGEM AXIUM™ Home Cinema Screen if they have an impedance greater than or equal to 8 ohms. To do this, connect your speakers, see **step 7** ➡ in § 15.2. Push the wires in the grooves, see **step 9** ➡ in § 15.2.

To enable / disable your own speakers, see § 6.8.

18. Index

<b>A</b>	<b>M</b>
Automatic installation, 9	Maintenance, 3
Automatic recognition of the format of the source, 15, 17	Manual installation, 9
<b>B</b>	
Bass, 16	Modifying the programme number, 9, 10
Bilingual programmes, 16	Mute, 16
<b>C</b>	<b>N</b>
Camcorder, 14	Nextview, 19
County, 5, 8	Nicam, 24
<b>D</b>	<b>O</b>
Data sources, 15	OSD language menu, 10
Decoder, 13	
Diagnostics and faults, 22	<b>P</b>
DVD, 13	Picture adjustment, 15
<b>E</b>	Picture format, 17
EPG, 20	Picture movement, 18
External sources, 13	Precautions, 2
<b>F</b>	Programme selection, 18
Factory presets, 8	Programmed stop, 17
First rapid installation, 5	Protection code, 8
Fitting and connecting the speakers 4, 26, 28, 30	
Frequency, 8	<b>R</b>
<b>G</b>	Remote control, 7
Games console, 13	Righthand side door, 6, 14
<b>H</b>	<b>S</b>
HDCP, 21	Satellite receiver, 13
HDTV, 21	Saving television channels, 9
Headphones, 14	SCART cable, 13
<b>I</b>	Searching TV channels, 8
Information on screen, 18	Set up, 4
<b>L</b>	Sleep timer, 17
Lamp, 23	Sound adjustment, 16
Language, 10, 16	Stereo, 16
List of TV programmes, 9	Stop on picture, 18
Locking, 8	Subtitles, 17
	S-VHS, 13, 14
	<b>T</b>
	Teletext sub-pages, 19
	Teletext, 19
	Treble, 16
	Two screens, 18
	<b>V</b>
	Video recorder/player, 13
	Volume, 16

NOTES