


INTELLIGENT VALVE CONTROLLER ND9200H

Rev. 2.2

Installation, Maintenance and
Operating Instructions



| | | |
|----------|--|-----------|
| 1 | ND9000 PRODUCT FAMILY SUMMARY | 3 |
| | 1.1 Key features..... | 3 |
| 2 | ND9200H INTELLIGENT VALVE CONTROLLER WITH HART COMMUNICATION..... | 4 |
| | 2.1 General | 4 |
| | 2.2 Technical description | 4 |
| | 2.3 Markings | 4 |
| | 2.4 Technical specifications | 5 |
| | 2.5 Recycling and disposal | 6 |
| | 2.6 Safety precautions | 6 |
| 3 | TRANSPORTATION, RECEPTION AND STORAGE | 6 |
| 4 | MOUNTING..... | 7 |
| | 4.1 General | 7 |
| | 4.2 Mounting on EC and EJ actuators | 7 |
| | 4.3 Mounting on Metso actuators with VDI/VDE mounting face | 7 |
| | 4.4 Mounting on linear actuator of nelesCV Globe..... | 8 |
| | 4.5 Mounting on linear actuator with IEC 60534 mounting face | 8 |
| | 4.6 Piping..... | 9 |
| | 4.7 Electrical connections..... | 12 |
| 5 | LOCAL USER INTERFACE (LUI) | 13 |
| | 5.1 Measurement monitoring | 13 |
| | 5.2 Guided start-up..... | 13 |
| | 5.3 Configuration menu | 14 |
| | 5.4 Mode menu | 14 |
| | 5.5 Configuration parameters | 15 |
| | 5.6 Valve travel calibration..... | 17 |
| | 5.7 Special displays..... | 18 |
| | 5.8 HART write protection..... | 19 |
| 6 | MAINTENANCE..... | 19 |
| | 6.1 Prestage..... | 19 |
| | 6.2 Spool valve | 20 |
| | 6.3 Flame arrestor assembly | 20 |
| | 6.4 Diaphragms | 20 |
| | 6.5 Communication circuit board | 20 |
| 7 | ERROR MESSAGES..... | 21 |
| | 7.1 Failsafe error..... | 21 |

| | | |
|-----------|--|-----------|
| 7.2 | Alarms | 21 |
| 7.3 | Errors | 22 |
| 7.4 | Warnings | 22 |
| 7.5 | Notifications | 23 |
| 8 | TROUBLE SHOOTING..... | 23 |
| 9 | ND92_H/K00 and ND92_H/I00 (WITH LIMIT SWITCHES) | 24 |
| 9.1 | Introduction | 24 |
| 9.2 | Installing ND92_H/K00 and ND92_H/I00 on a valve controller | 25 |
| 9.3 | Electrical connections..... | 25 |
| 9.4 | Adjustment..... | 25 |
| 9.5 | Removal of the limit switches ND92_H/K00 and ND92_H/I00 for accessing the valve controller | 25 |
| 9.6 | Circuit diagrams | 26 |
| 9.7 | Maintenance | 26 |
| 10 | TOOLS..... | 26 |
| 11 | ORDERING SPARE PARTS | 26 |
| 12 | DRAWINGS AND PARTS LISTS | 27 |
| 12.1 | Exploded view and parts list, ND9200H. | 27 |
| 12.2 | Exploded view and parts list, ND92_H/K_ and ND92_H/I_..... | 29 |
| 12.3 | Mounting parts for EC05-14/EJ05-14 actuators, rising signal opens valve | 31 |
| 12.4 | Mounting parts for B1C/B1J 6-20 actuators | 31 |
| 12.5 | Mounting parts for B1C/B1J 25-50, B1C 502 and B1J322 actuators..... | 32 |
| 12.6 | Mounting parts for Quadra-Powr® actuators | 32 |
| 12.7 | Mounting parts for linear actuators of nelesCV Globe..... | 33 |
| 12.8 | Mounting parts for linear actuators..... | 34 |
| 12.9 | Connection diagrams | 35 |
| 13 | DIMENSIONS | 38 |
| 14 | EC DECLARATION OF CONFORMITY | 40 |
| 15 | TYPE CODING | 41 |

These instructions provide information about the safe handling and operation of the intelligent valve controller. If you require additional assistance, please contact the manufacturer or manufacturer's representative. Addresses and phone numbers are printed on the back cover.

SAVE THESE INSTRUCTIONS!

Subject to change without notice.
All trademarks are property of their respective owners.

1 ND9000 PRODUCT FAMILY SUMMARY

1.1 Key features

- ☐ Benchmark control performance on rotary and linear valves
- ☐ Reliable and robust design
- ☐ Ease of use
- ☐ Language selection: English, German and French
- ☐ Local / remote operation
- ☐ Expandable architecture
- ☐ Advanced device diagnostics including
 - ☐ Self-diagnostics
 - ☐ Online diagnostics
 - ☐ Performance diagnostics
 - ☐ Communication diagnostics
 - ☐ Extended off-line tests
 - ☐ Dynamic Diagnostics Diamond

1.1.1 Options

- ☐ Interchangeable communication options:
 - ☐ HART
 - ☐ FOUNDATION Fieldbus
 - ☐ Profibus PA
- ☐ Limit switches
- ☐ Position transmitter (in HART only)
- ☐ Special corrosion resistant finish
- ☐ Exhaust adapter

1.1.2 Total cost of ownership

- ☐ Low energy and air consumption
- ☐ Future proof design allows further options at a reduced cost
- ☐ Optimised spares program. Reduced number of spares
- ☐ Retro-fit to existing installations (Neles or 3rd party)

1.1.3 Minimised process variability

- ☐ Linearisation of the valve flow characteristics
- ☐ Excellent dynamic and static control performance
- ☐ High-speed of response
- ☐ Accurate internal measurements

1.1.4 Easy installation and configuration

- ☐ Same unit for linear and rotary valves, double and single-acting actuators
- ☐ Simple calibration and configuration
 - ☐ using Local User Interface
 - ☐ using FieldCare software in a remote location
- ☐ Flush mounting capability to avoid tubing and mounting parts
- ☐ Low power design enables installation to all common control systems

1.1.5 Open solution

Metso is committed to delivering products that freely interface with software and hardware from a variety of manufacturers; and the ND9000 is no exception. This open architecture allows the ND9000 to be integrated with other field devices to give an unprecedented level of controllability.

- ☐ FDT based multi-vendor support configuration
ND9000 DTM download page:
www.metso.com/automation/nd9000

1.1.6 ND9000 in fieldbus networks

- ☐ Approved interoperability
 - ☐ Host interoperability ensured

- ☐ FOUNDATION Fieldbus ITK version 5.01 certified
- ☐ Profibus PA profile version 3.0 PNO certified
- ☐ Easy to upgrade; can be done by replacing the HART communication board to fieldbus communication board
- ☐ Excellent maintainability with firmware download feature
- ☐ Advanced communication diagnostics
- ☐ Digital communication via the fieldbus includes not only the set point, but also the position feedback signal from the position sensor. No special supplementary modules for analog or digital position feedback are needed when using the fieldbus valve controller.
- ☐ Back up LAS functionality available in FOUNDATION Fieldbus environment
- ☐ Input selector and output splitter blocks available in FOUNDATION Fieldbus devices allowing advanced distributed control
- ☐ Multipurpose functionality
 - ☐ Standard function blocks enables the freedom to use ND9000 intelligent valve controller either in continuous or on-off control applications
 - ☐ Open and close information directly available via the fieldbus
 - ☐ Open and close detection is based on either position measurement (soft limit switch) or mechanical limit switch information
- ☐ ND9000 download page:
www.metso.com/automation/nd9000

1.1.7 ND9000 mounting on actuators and valves

- ☐ Mounted on single and double acting actuators
- ☐ Both rotary and linear valves
- ☐ Flush mounting capability
- ☐ Ability to attach options to electronics and mechanics later
- ☐ Possibility to mount also on valves that are in process with 1-point calibration feature

1.1.8 Product reliability

- ☐ Designed to operate in harsh environmental conditions
 - ☐ Rugged modular design
 - ☐ Excellent temperature characteristics
 - ☐ Vibration and impact tolerant
 - ☐ IP66 enclosure
 - ☐ Protected against humidity
- ☐ Maintenance free operation
 - ☐ Resistant to dirty air
 - ☐ Wear resistant and sealed components
 - ☐ Contactless position measurement

1.1.9 Predictive maintenance

- ☐ Easy access to collected data with FieldCare software
 - ☐ Ingenious Valve Diamond to visualise control valve performance and diagnostics
 - ☐ Logical trend and histogram collection
 - ☐ Information collected on service conditions
 - ☐ Extensive set of off-line tests with accurate key figure calculations
 - ☐ Fast notifications using on-line alarms
 - ☐ Condition monitoring tool available
 - ☐ Real time monitoring of valve control parameters

2 ND9200H INTELLIGENT VALVE CONTROLLER WITH HART COMMUNICATION

2.1 General

This manual incorporates Installation, Maintenance and Operation Instructions for the Metso ND9200H intelligent valve controller. The ND9200H may be used with either cylinder or diaphragm type pneumatic actuators for rotary or linear valves.

NOTE:

The selection and use of the valve controller in a specific application requires close consideration of detailed aspects. Due to the nature of the product, this manual cannot cover all the likely situations that may occur when installing, using or servicing the valve controller.

If you are uncertain about the use of the controller or its suitability for your intended use, please contact Metso's Automation business for more information.

2.2 Technical description

The ND9200H is a 4–20 mA loop-powered microcontroller-based intelligent valve controller. The device operates even at 3.6 mA input signal and communicates via HART. The device contains a Local User Interface enabling local configuration. A PC with FieldCare software can be connected to the ND9200H itself or to the control loop.

The powerful 32-bit microcontroller controls the valve position. The measurements include:

- ☐ Input signal
- ☐ Valve position with contactless sensor
- ☐ Actuator pressures, 2 independent measurements
- ☐ Supply pressure
- ☐ Spool valve position
- ☐ Device temperature

Advanced self-diagnostics guarantees that all measurements operate correctly. Failure of one measurement does not cause the valve to fail if the input signal and position measurements are operating correctly. After connections of electric signal and pneumatic supply the micro controller (μC) reads the input signal, position sensor (α), pressure sensors (P_s , P_1 , P_2) and spool position sensor (SPS). A difference between input signal and position sensor (α) measurement is detected by the control algorithm inside the μC . The μC calculates a new value for prestage (PR) coil current based on the information from the input signal and from the sensors. Changed current to the PR changes the pilot pressure to the spool valve. Reduced pilot pressure moves the spool and the actuator pressures change accordingly. The spool opens the flow to the driving side of the double diaphragm actuator and opens the flow out from the other side of the actuator. The increasing pressure will move the diaphragm piston. The actuator and feedback shaft rotate clockwise. The position sensor (α) measures the rotation for the μC . The μC using control algorithm modulates the PR-current from the steady state value until a new position of the actuator according to the input signal is reached.




Fig. 1 The principle of operation

2.3 Markings

The valve controller is equipped with an identification plate sticker (Fig. 2).



Fig. 2 Example of the identification plate

Identification plate markings from top to bottom include:

- ☐ Type designation of the valve controller
- ☐ Revision number
- ☐ Enclosure class
- ☐ Input signal (voltage range)
- ☐ Input resistance
- ☐ Maximum supply voltage
- ☐ Operational temperature
- ☐ Supply pressure range
- ☐ Contact details of the manufacturer
- ☐ CE mark
- ☐ Manufacturing serial number TTYWWNNNN*)

*) Manufacturing serial number explained:

TT= device and factory sign

YY= year of manufacturing

WW = week of manufacturing

NNNN = consecutive number

Example: PH09011234 = controller, year 2009, week 1, consecutive number 1234.

2.4 Technical specifications

ND9200H INTELLIGENT VALVE CONTROLLER

General

Loop powered, no external power supply required.
Suitable for rotary and sliding-stem valves.
Actuator connections in accordance with VDI/VDE 3845 and IEC 60534-6 standards.

Flush mounting on nelesCV™ control valves.

Action: Double or single acting
Travel range: Linear; 10–120 mm with standard IEC parts.
Larger strokes possible with suitable kits
Rotary; 45–95°.
Measurement range 110° with freely rotating feedback shaft.

Environmental influence

Standard temperature range:
-40° to +85 °C / -40° to +185 °F

Influence of temperature on valve position:
< 0.5 % / 10 °K

Influence of vibration on valve position:
< 1 % under 2g 5–150 Hz,
1g 150–300 Hz, 0.5g 300–2000 Hz

Enclosure

Material: Anodised aluminium alloy and polymer composite
Protection class: IP66, NEMA 4X
Pneumatic ports: 1/4 NPT
Electrical connection: max. 2.5 mm²
Cable gland thread: M20 x 1.5 (E1), 1/2 NPT (E2)
Weight: 3.4 kg / 7.5 lb
Mechanical and digital position indicator visible through the main cover
Special corrosion resistant finish available

Pneumatics

Supply pressure: 1.4–8 bar / 20–115 psi
Effect of supply pressure on valve position:
< 0.1 % at 10 % difference in inlet pressure
Air quality: According to ISO 8573-1:2001
Solid particles: Class 5
(3–5 µm filtration is recommended)
Humidity: Class 1
(dew point 10 °C/50 °F below minimum temperature is recommended)
Oil class: 3 (or <1 ppm)

Capacity with 4 bar / 60 psi supply:
5.5 Nm³/h / 3.3 scfm (spool valve 2)
12 Nm³/h / 7.1 scfm (spool valve 3)
38 Nm³/h / 22.4 scfm (spool valve 6)

Consumption with 4 bar / 60 psi supply in steady state position:
< 0.6 Nm³/h / 0.35 scfm (spool valves 2 & 3)
< 1.0 Nm³/h / 0.6 scfm (spool valve 6)

Electronics

Supply power: Loop powered, 4–20 mA
Minimum signal: 3.6 mA

Current max : 120 mA
Load voltage: up to 9.5 V DC / 20 mA
(corresponding 475 Ω)
Voltage: max 30 V DC
Polarity protection: -30 V DC
Over current protection:
active over 35 mA
Ex ia IIC T6: $U_i \leq 28 \text{ V}$
 $I_i \leq 120 \text{ mA}$
 $P_i \leq 1 \text{ W}$
 $C_i = 22 \text{ nF}$
 $L_i = 53 \text{ µH}$

(ATEX approval is valid under these conditions)

Performance with moderate constant-load, actuators EC05-EC10

Values at 20 °C / 68 °F and without any additional instruments, such as boosters or quick exhaust valves etc.

Dead band acc. to IEC 61514:
≤ 0.1 %

Hysteresis acc. to IEC 61514:
< 0.5 %

Local user interface functions

- ☐ Local control of the valve
- ☐ Monitoring of valve position, input signal, temperature, supply and actuator pressure difference
- ☐ Guided start-up function
- ☐ LUI may be locked remotely to prevent unauthorised access
- ☐ Calibration: Automatic/Manual
- ☐ 1-point calibration
- ☐ Control configuration: aggressive, fast, optimum, stable, maximum stability
- ☐ Mode selection: Automatic/Manual
- ☐ Rotation: valve rotation clockwise or counter-clockwise to close
- ☐ Dead angle
- ☐ Low cut-off, cut-off safety range (default 2 %)
- ☐ Positioner fail action, open/close
- ☐ Signal direction: Direct/reverse acting
- ☐ Actuator type, double/single acting
- ☐ Valve type, rotary/linear IEC/nelesCV Globe/FLI
- ☐ Language selection: English, German and French

Approvals

Flameproof, explosion proof and dust exclusion

| | |
|-------------|--|
| ATEX | II 2 G Ex d IIC T4...T6 (EN 60079-0:2006, EN 60079-1:2004) |
| | II 2 D Ex tD A21 IP66 T100 °C (EN 61241-0:2006, EN 61241-1:2004) |
| | Certificate KEMA 04ATEX2098 X Issue 2 |
| CSA | Explosion proof Class I, II and III, Division 1 and 2, Groups B, C, D, E, F Pending |
| FM | Explosion proof Class I, II and III, Division 1 and 2, Groups A, B, C, D, E, F Pending |

Electromagnetic protection

Electromagnetic compatibility
Emission acc. to EN 61000-6-4 (2001)
and FCC 47 CFR PART 15,
SUBPART B, CLASS B (1994)
Immunity acc. to EN 61000-6-2 (2001)

CE marking

89/336/EEC
Electromagnetic compatibility

94/9/EC
ATEX

POSITION TRANSMITTER (optional)

Output signal: 4–20 mA (galvanic isolation;
600 V DC)

Resolution: 16 bit / 0.244 μ A

Linearity: <0.05 % FS

Temperature effect: <0.35 % FS

EEx d IIC T4/T5/T6

$U_i \leq 30$ V
 $R_x = 0-780 \Omega$

PROXIMITY SENSORS AND MICRO SWITCHES, 2 PIECES (OPTIONAL WITH EXTENSION MODULE)

Code I02 P+F NJ2-12GK-SN

Code I09 P+F; NCB2-12GM35-N0

Code I56 IFC 2002-ARKG/UP

Code K05 Omron D2VW-5, micro switch

Code K06 Omron D2VW-01 gold plated, micro switch

2.5 Recycling and disposal

Most valve controller parts can be recycled if sorted according to material.

Most parts have material marking. A material list is supplied with the valve controller. In addition, separate recycling and disposal instructions are available from the manufacturer.

A valve controller may also be returned to the manufacturer for recycling and disposal. There will be a charge for this.

2.6 Safety precautions

CAUTION:

Do not exceed the permitted values!

Exceeding the permitted values marked on the valve controller may cause damage to the controller and to equipment attached to the controller and could lead to uncontrolled pressure release in the worst case. Damage to the equipment and personal injury may result.

CAUTION:

Do not remove or dismantle a pressurized controller!

Removing or dismantling a pressurized prestage or spool valve of an ND9200H leads to uncontrolled pressure release. Always shut off the supply air and release the pressure from the pipelines and equipment before removing or dismantling the controller. Otherwise personal injury and damage to equipment may result.

WARNING:

During automatic or manual calibration and tuning the valve operates between open and closed positions. Make sure that the operation does not endanger people or processes!

WARNING:

Do not operate the device with the cover removed!

Electromagnetic immunity is reduced, valve may stroke.

ATEX WARNING:

Electrostatic charge hazard!

The windows and identification plate are non-conductive. Clean with a damp cloth only!

ATEX WARNING:

The locking screw (part 107) of the cover is essential to explosion protection.

The cover has to be locked in place for Ex d protection. The screw grounds the cover to the housing.

Ex d WARNING:

Do not open the device when energized!

Ex d WARNING:

Use a cable gland with suitable Ex d certification. For ambient temperature over 70 °C / 158 °F use a heat resistant cable and cable gland suitable for at least 90 °C / 194 °F.

ELECTRICAL SAFETY WARNING:

Use fuses for limit switch installations with 50 V AC/75 V DC or higher.

NOTE:

Avoid earthing a welding machine in close proximity to an ND9200H valve controller.

Damage to the equipment may result.

3 TRANSPORTATION, RECEPTION AND STORAGE

The valve controller is a sophisticated instrument, handle it with care.

- ☐ Check the controller for any damage that may have occurred during transportation.
- ☐ Store the uninstalled controller preferably indoors, keep it away from rain and dust.
- ☐ Do not unpack the device until installing it.
- ☐ Do not drop or knock the controller.
- ☐ Keep the flow ports and cable glands plugged until installing.
- ☐ Follow instructions elsewhere in this manual.

4 MOUNTING

4.1 General

NOTE:

The enclosure of ND9200H intelligent valve controller meets the IP66 protection class according to EN 60529 in any position when the cable entry is plugged according to IP66.

Based on good mounting practice, the recommended mounting position is electrical connections placed downwards. This recommendation is shown in our mounting position coding for control valves.

If these requirements are not fulfilled, and the cable gland is leaking and the leakage is damaging valve controller or other electrical instrumentation, our warranty is not valid.

If the ND9200H is supplied with valve and actuator, the tubes are mounted and the ND9200H adjusted in accordance with the customer's specifications. If the controller is ordered separately, the mounting parts for the assembly must be ordered at the same time.

Sample order: (B1CU13)-Z-ND9206HN

The controller is equipped with the Metso flush mounting face, the old Neles mounting face and for connection according to VDI/VDE 3845.

Shaft coupling alternatives for the controller for Metso actuators are shown in Fig. 5.

For mounting parts for Metso actuators, see 12.2 - 12.7.

4.2 Mounting on EC and EJ actuators

See figure in Section 12.2.

- ❑ Mount the U-shaped coupling (47) to the shaft. Apply thread-locking compound to the screws (48) and tighten firmly.
- ❑ Remove the protective plastic plugs from pneumatic connections C2, S and C1. Mount the metal plugs (53) to the unused controller connections with sealant.
For EC (double acting) actuators, remove the metal plugs (54, 2 pcs) from the connections at the bottom of the controller.
For EJ (single acting, spring to close) and EJA (single acting, spring to open) actuators, leave the metal plug (54) in the C1 connection at the bottom of the controller and remove the metal plug from the C2 connection at the bottom.
- ❑ Mount the O-rings (38, 4 pcs.) into the air connections in the bottom of the controller and the mounting plate (64).
- ❑ Install the mounting plate (64) on the actuator as shown in 12.2.
- ❑ Place the valve controller on top of the actuator so that the pointer is located in the position shown in Fig.5.
- ❑ Fasten the screws (4).




Fig. 3 Mounting on EC and EJ actuators

4.3 Mounting on Metso actuators with VDI/VDE mounting face

See figures in Section 12.3 -12.5.

- ❑ Mount the H-shaped coupling (47) to the shaft. Apply the thread-locking compound to the screw (48) and tighten firmly.
- ❑ Remove the protective plastic plugs from pneumatic connections C2, S and C1. Leave the metal plugs (54) in the unused connections at the bottom of the controller.
- ❑ **BJ and other single acting actuators:** install a metal plug (53) with sealant to the C1 connection.
- ❑ Set the direction arrow of the actuator in the direction of the valve closure member and attach the ear (2) to the indicator cover in the position shown in Section 12.3. Secure the screw of the ear using e.g. Loctite and tighten firmly.
- ❑ Attach the bracket (1) to the ND9200H.
- ❑ Attach the bracket (1) to the actuator. The shaft coupling of the ND9200H must fit into the ear (2) so that the pointer is located in the position shown in Fig.4.




Fig. 4 Mounting on Metso actuator with VDI/VDE mounting face

4.4 Mounting on linear actuator of nelesCV Globe

See figure in Section 12.6

- Attach the J-shaped feedback lever (47) to the valve controller shaft. Apply the thread-locking compound to the screws and tighten firmly.
- Remove the protective plastic plugs from pneumatic connections C2, S and C1. Mount the metal plugs (53) to the unused controller connections with sealant.
- Leave metal plug (54) in the connection C1 at the bottom of the controller. Remove the metal plug (54) from the C2 connection at the bottom. Mount the O-rings (38, 2 pcs.) to the connections.
- Attach the mounting plate (64) to the valve controller with screws (65).
- Mount the O-rings (38, 2 pcs.) and attach the mounting plate (39) to the valve controller with screws (28).
- Mount the conical plug (16) to the lever and select the position on the scale according to the valve stroke.
- Install the O-ring (31) to the actuator. Place the conical plug into the frame on the stem and tighten the screws (4).

4.5 Mounting on linear actuator with IEC 60534 mounting face

See figure in Section 12.7

- Attach the feedback arm with spacer to the valve controller shaft. Note the position of the pointer on the shaft as in 12.7. Apply thread locking compound to the screws and tighten firmly. Attach the spring to the feedback arm as shown in Section 12.7.

- Mount the valve controller mounting bracket loosely to the yoke of the actuator.
- Remove the protective plastic plugs from pneumatic connections C2, S and C1. Leave the metal plugs (54) in the unused connections at the bottom of the controller. Single acting actuators: install a metal plug (53) with sealant to the C1 connection.
- Mount the valve controller loosely to the mounting bracket guiding the pin on the actuator stem to the slot of the feedback arm.
- Align the bracket and the valve controller with the actuator stem and adjust their position so that the feedback arm is approximately at a 90° angle to the actuator stem (in the mid-stroke position).
- Tighten the valve controller mounting bracket screws.
- Adjust the distance of the valve controller to the pin on the actuator stem so that the pin stays in the lever slot at full stroke. Ensure also that the maximum angle of the lever does not exceed 45° in either direction. Maximum allowed travel of the lever is shown in Section 12.7. Best control performance is achieved when the feedback lever utilises the maximum allowed angle ($\pm 45^\circ$ from horizontal position). The whole range should be at least 45°.
- Make sure that the valve controller is in right angle and tighten all the mounting bolts.
- Ensure that the valve controller complies with previous steps. Check that the actuator pin does not touch the valve controller case throughout the entire stroke of the actuator. If the actuator pin is too long it may be cut to size.
- Apply grease (Molykote or equivalent) to the contact surfaces of the actuator pin and the feedback arm to reduce wear.




Fig. 5 Shaft coupling alternatives

4.6 Piping

CAUTION:

Do not exceed the permitted supply pressure of the ND9200H!

Table 2 provides the recommended tube sizes in accordance with actuator sizes. Tube sizes are the minimum values allowed. Operating times may be tested by the FieldCare software.

Connect the air supply to S (1/4 NPT).

Connect C1 and C2 (1/4 NPT) to the actuator, see Fig. 6.

ND9200H is connected direct to the EC or EJ actuator. Connections C1 and C2 (1/4 NPT) must be plugged, see 12.2.

Liquid sealants, such as Loctite 577 are recommended for the pipe threads.

NOTE:

A valve controller mounted on a spring actuator must be connected only as single-acting. See Fig. 6.

NOTE:

An excess of sealant may result in faulty operation of the controller.

Sealing tape is not recommended.

Ensure that the air piping is clean.

The air supply must be clean, dry and oil-free instrument air, see Section 2.4.

Table 1 Spring rates

| Actuator type | Spring rate (bar/psi) |
|--|-----------------------|
| B1JK | 3 / 43 |
| B1J | 4.2 / 61 |
| B1JV | 5.5 / 80 |
| QPB | 3 / 43 |
| QPC | 4.3 / 62 |
| QPD | 5.6 / 81 |
| EJK | 3 / 43 |
| EJ | 4 / 57 |
| EJV | 5 / 72 |
| Adjust regulator pressure to a level that is max 1 bar (14.5 psi) + spring rate. | |

Table 2 Piping

| Actuator | | | Actuator piping | | | | Spool valve |
|-------------|--|-----|-----------------|----|-----|-----|-------------|
| EC | Stroke vol. dm ³ / in ³ | G | 6 | 10 | 1/4 | 3/8 | |
| 05 | 0.09 / 5 | 1/4 | x | | x | | 2 |
| 07 | 0.2 / 12 | 1/4 | x | | x | | 2 |
| 10 | 0.5 / 31 | 1/4 | x | | x | | 3 |
| 12 | 1.2 / 73 | 1/4 | x | | x | | 3 |
| 14 | 3.0 / 183 | 1/4 | | x | | x | 6 |
| 16 | 7.7 / 470 | 3/8 | | x | | x | 6 |
| 25 | 20.5 / 1250 | 3/8 | | x | | x | 6 |
| EJ | Stroke vol. dm ³ / in ³ | G | 6 | 10 | 1/4 | 3/8 | Spool valve |
| 05 | 0.18 / 11 | 1/4 | x | | x | | 2 |
| 07 | 0.4 / 24 | 1/4 | x | | x | | 2, 3* |
| 10 | 1 / 61 | 1/4 | x | | x | | 3 |
| 12 | 2.4 / 145 | 1/4 | | x | | x | 3 |
| 14 | 6 / 366 | 1/4 | | x | | x | 6 |
| 16 | 15 / 915 | 3/8 | | x | | x | 6 |
| 25 | 41 / 2500 | 3/8 | | x | | x | 6 |
| B1C | Stroke vol. dm ³ / in ³ | NPT | 6 | 10 | 1/4 | 3/8 | Spool valve |
| 6 | 0.3 / 18 | 1/4 | x | | x | | 2, 3* |
| 9 | 0.6 / 37 | 1/4 | x | | x | | 3 |
| 11 | 1.1 / 67 | 3/8 | (x) | x | (x) | x | 3 |
| 13 | 2.3 / 140 | 3/8 | | x | | x | 3 |
| 17 | 4.3 / 262 | 1/2 | | x | | x | 6 |
| 20 | 5.4 / 330 | 1/2 | | x | | x | 6 |
| 25 | 10.5 / 610 | 1/2 | | x | | x | 6 |
| 32 | 21 / 1282 | 3/4 | | x | | x | 6 |
| 40 | 43 / 2624 | 3/4 | | x | | x | 6 |
| 50 | 84 / 5126 | 1 | | x | | x | 6 |
| 502 | 195 / 11900 | 1 | | x | | x | 6 |
| B1J B1JA | Stroke vol. dm ³ / in ³ | NPT | 6 | 10 | 1/4 | 3/8 | Spool valve |
| 8 | 0.9 / 55 | 3/8 | (x) | x | (x) | x | 3 |
| 10 | 1.8 / 110 | 3/8 | | x | | x | 3 |
| 12 | 3.6 / 220 | 1/2 | | x | | x | 6 |
| 16 | 6.7 / 409 | 1/2 | | x | | x | 6 |
| 20 | 13 / 793 | 3/4 | | x | | x | 6 |
| 25 | 27 / 1648 | 3/4 | | x | | x | 6 |
| 32 | 53 / 3234 | 1 | | x | | x | 6 |
| 322 | 106 / 6468 | 1 | | x | | x | 6 |
| QP | Stroke vol. dm ³ / in ³ | NPT | 6 | 10 | 1/4 | 3/8 | Spool valve |
| 1 | 0.62 / 37 | 3/8 | (x) | x | (x) | x | 2, 3* |
| 2 | 1.08 / 66 | 3/8 | (x) | x | (x) | x | 3 |
| 3 | 2.18 / 133 | 3/8 | | x | | x | 3 |
| 4 | 4.34 / 265 | 3/8 | | x | | x | 6 |
| 5 | 8.7 / 531 | 3/8 | | x | | x | 6 |
| 6 | 17.5 / 1068 | 3/4 | | x | | x | 6 |

Air supply piping 10 mm or 3/8" for all actuators.

Pipe sizes are nominal, i.e. approximately outer diameter. Inner diameter is typically 2 mm smaller.

x = Standard pipe size used in Neles control valves.


(x) = Minimum pipe size (if smaller than standard).

*) Spool size 2 is preferred for accurate control and standard for Neles control valves.

Spool size 3 can be used if fast full stroke times are required.

DOUBLE-ACTING ACTUATOR

1. Increasing input signal to open valve (shown)




Default setting:
 DIR = OPE
 ROT = cC (close valve to clockwise)
 ATYP = 2-A
 PFA = CLO
 A0, CUTL and VTYP according to valve type

2. Increasing input signal to close valve (**not recommended**)

Default setting:
 DIR = CLO
 ROT = cC (close valve to clockwise)
 ATYP = 2-A
 PFA = CLO
 A0, CUTL and VTYP according to valve type

DOUBLE-ACTING ACTUATOR, REVERSED PIPING

3. Increasing input signal to open valve (**not recommended**)




Default setting:
 DIR = OPE
 ROT = cC (close valve to clockwise)
 ATYP = 2-A
 PFA = OPE
 A0, CUTL and VTYP according to valve type

4. Increasing input signal to close valve (shown)

Default setting:
 DIR = CLO
 ROT = cC (close valve to clockwise)
 ATYP = 2-A
 PFA = OPE
 A0, CUTL and VTYP according to valve type

SINGLE-ACTING ACTUATOR, SPRING TO CLOSE

5. Increasing input signal to open valve (shown)




Default setting:
 DIR = OPE
 ROT = cC (close valve to clockwise)
 ATYP = 1-A
 PFA = CLO (must be in the spring direction)
 A0, CUTL and VTYP according to valve type

6. Increasing input signal to close valve (**not recommended**)

Default setting:
 DIR = CLO
 ROT = cC (close valve to clockwise)
 ATYP = 1-A
 PFA = CLO (must be in the spring direction)
 A0, CUTL and VTYP according to valve type

SINGLE-ACTING ACTUATOR, SPRING TO OPEN

7. Increasing input signal to close valve (shown)



Default setting:
 DIR = CLO
 ROT = cC (close valve to clockwise)
 ATYP = 1-A
 PFA = OPE (must be in the spring direction)
 A0, CUTL and VTYP according to valve type

8. Increasing input signal to open valve (**not recommended**)

Default setting:
 DIR = OPE
 ROT = cC (close valve to clockwise)
 ATYP = 1-A
 PFA = OPE (must be in the spring direction)
 A0, CUTL and VTYP according to valve type

Fig. 6 Operation directions and air connections

4.7 Electrical connections

The ND9200H is powered by a standard 4–20 mA current loop that also functions as a carrier to the HART communication.

The input signal cable is led through a M20 x 1.5 (E1)/ 1/2 NPT (E2) cable gland. Connect the conductors to the terminal strip as shown in Fig. 7. It is recommended that the earthing of the input cable shield be carried out from the DCS end only.

The position transmitter is connected to 2-pole terminal PT as shown in Fig. 7. The position transmitter needs an external power supply. The ND9200H and the position transmitter circuits are galvanically isolated and withstand a 600 VAC voltage.

Please note following before mounting the cover of the valve controller:

- ❑ Attach the LUI (223) cabling to the sticker on the reverse side of the LUI.
Check that the cabling does not get squeezed by the electronics cover (39) or the device cover (100).
- ❑ Check using a feeler gauge that the clearance between the position indicator (109) and the electronics cover is 1 mm.




Fig. 7 Terminals

NOTE:

The ND9200H equals a load of 475 Ω in the current loop.




Fig. 8 Control wiring

5 LOCAL USER INTERFACE (LUI)

The local user interface may be used to monitor the device behaviour as well as configuring and commissioning the controller during installation and normal operation. The local user interface consists of 2 row LCD and 4 button keypad interface. There are also custom graphical characters for special conditions.




Fig. 9 Local user interface (LUI)

5.1 Measurement monitoring

When the device is powered, it enters the measurement monitoring view. The following measurements may be viewed from the display. The Table 3 identifies the default unit and also optional unit of the measurement.

Table 3 Default / optional units of measurements

| Measurement | Default unit | Optional unit |
|------------------------------|--------------------------|-------------------------------------|
| valve position | Percentage of full scale | Angle, where 0% refers to 0 (angle) |
| target position | Percentage of full scale | none |
| current loop setpoint | mA | Percentage of full scale |
| actuator pressure difference | bar | psi |
| supply pressure | bar | psi |
| device temperature | °Celsius | °Fahrenheit |

If the unit selection is altered from the FieldCare software to US units, the pressure default unit will automatically be changed to psi and temperature unit to Fahrenheit.

The active unit may be changed by pressing the key constantly. The display shows the current unit selection on the top row of the display. You may change the selection by pressing or while keeping the key pressed down. When the buttons are released the current selection will be activated.

If the device has been idle for 1 hour, and there is no user activity on the local user interface, the measurements will start scrolling on the display. This enables the

user to view all the measurements through the window of the main cover.




Fig. 10 Measurement unit change

5.2 Guided start-up

Guided startup offers a fast view of the most critical parameters of the ND9200H controller, actuator and valve configuration. After verifying the parameters the valve travel calibration is recommended. The guided start-up is entered by pressing the and keys simultaneously.

The configuration parameters are listed in following order, see explanation from 5.5:

Valve type VTyp
 Actuator type ATYP
 Positioner fail action PFA
 Valve rotation direction ROT
 Valve dead angle A0

If you modify any of the parameters you will also need to calibrate and tune the device. See 4.6 for detailed description.




Fig. 11 Guided start-up

NOTE:

You may cancel any action by pressing the \odot button. Cancelling of operation returns user interface view one level up in menu hierarchy.

5.3 Configuration menu

The local user interface is organised in a menu structure. To enter the menus press Δ and ∇ simultaneously in the measurement monitoring view panel. To move to the next or previous selection by pressing Δ or ∇ accordingly.

5.4 Mode menu

If the user wants to change the valve operating mode, press the \odot key at the MODE selection. The mode will start to flash and by pressing Δ or ∇ you may alter the operation mode selection. User accepts the current selection by pressing the \odot key.

There are two options for the operating mode.

5.4.1 AUTO

During the auto mode, the controller controls the valve position according to the incoming setpoint signal from the 4–20 mA signal source. This mode is used during the normal process control service.




Fig. 12 Configuration

5.4.2 MAN

During this mode the valve position may be controlled manually by using the keyboard and pressing the Δ or ∇ buttons. The position of the manually driven valve is not saved in the memory of the controller, i.e. the valve will not return to the same position after signal failure. However, the valve may be driven back into position after signal failure by using Δ and ∇ keys. The manual control starts from the current position of the valve after the MAN-mode is activated. In order to change the manual setpoint return to the measurement monitoring view and go to target position measurement. Press the \odot key shortly to activate the target position editing, text *TPDS* starts to blink and now you are able to edit the setpoint by pressing Δ or ∇ button. The setpoint changes in 0.1 % increments/decrements in spite of the selected unit and the valve starts to move immediately. A continuous push changes the setpoint faster. In order to view other measurements, press the \odot or ∇ keys and select a measurement. Repeat the previous steps if you would like to alter the setpoint value again.




Fig. 13 Setpoint change in MAN mode

5.5 Configuration parameters

When *PRR* is on the display you may enter the configuration menu by pressing the \odot key. In this menu the most important configuration and signal modification parameters are viewable. You may view the current value and edit them by pressing the \odot key at the relevant parameter. The name of the parameter will appear on the upper row of the display and the current value is on the lower row.

5.5.1 Performance level, *PERF*

If you want to change the tuning of the valve position control, the *PERF* selection is available. The default factory value is *E*.

- ❑ Once *PERF* is displayed press the \odot key to enter the edit state and *PERF* starts to blink.
- ❑ Select between five values by pressing the \oplus or \ominus key.

Table 4 Performance level

| Selection | Meaning | Description |
|-----------|-------------------|---|
| <i>A</i> | Aggressive | Immediate response to signal changes, overshoots |
| <i>b</i> | Fast | Fast response to signal changes, small overshooting |
| <i>C</i> | Optimum | Very small overshoot with minimum step response time |
| <i>d</i> | Stable | No overshooting, slow response to input signal changes |
| <i>E</i> | Maximum stability | No overshooting, deadband may increase, slow but stable behaviour |

For use with volume boosters and/or very fast actuators, additional performance levels A1 to D1 can be used. Characteristics of these extended levels are the same as those in the table above. However, with performance level settings A1 to D1, adaptive properties of the ND9000 control algorithm are disabled.

- ❑ After the desired value is displayed, press the key \odot to conclude the operation

5.5.2 Low cut-off, *EUTL*

Low cut-off safety range *EUTL* ensures the valve closing against mechanical travel stops. The factory default value is 2 %.

- ❑ Once *EUTL* is displayed press the \odot key to enter the edit state and the *EUTL* will start to blink. The currently selected value appears as a percentage (%) on the display

- ❑ Modify the parameter value by pressing \oplus or \ominus keys alternately until the desired value appears on the display.
- ❑ After the desired value is displayed, press the key \odot to conclude the operation.

5.5.3 Signal direction, *DIR*

The opening and closing direction of the valve with raising current loop signal is defined by signal direction parameter *DIR*.

- ❑ When *DIR* is displayed press the \odot key to enter the edit state and *DIR* starts to blink.
- ❑ Select either the *OPE* or *CLD* values by pressing the \oplus and \ominus keys. The value *OPE* signifies the raising signal 4–20 mA to open the valve and *CLD* means the raising signal to close the valve.
- ❑ To conclude, press the \odot key when the desired value is shown on the display.

See default values in Fig. 6.

5.5.4 Valve type, *VTYP*

To compensate for nonlinearity of the position feedback caused by the actuator linkage mechanism of a linear control valve, the appropriate selection must be made on the *VTYP* display.

- ❑ After selecting *VTYP* on the display, press the \odot key to enter the edit state and the *VTYP* starts to blink.
- ❑ Select between four values *rot*, *LIn*, *nEG* or *FLI* using the \oplus and \ominus keys. The value *rot* indicates a rotary valve and *LIn* a linear valve. Use *nEG* only for nelesCV Globe valves to accommodate special linkage geometry. Use *FLI* only for linear valves when linkage geometry is not needed to be corrected by valve controller firmware.
- ❑ To conclude press the \odot key when the desired value is shown on the display.

NOTE:

Perform valve calibration and tuning always when *VTYP* has been changed.

5.5.5 Actuator type, *ATYP*

In order to optimise the control performance the device needs to be informed about the actuator type.

- ❑ After selecting *ATYP* on the display, press the \odot key to enter the edit state and *ATYP* starts to blink.
- ❑ Select between two values *2-A* or *1-A* using the \oplus and \ominus keys. The value *2-A* indicates a double acting actuator and *1-A* a single acting actuator.
- ❑ To conclude press the \odot key when the desired value is shown on the display.

NOTE:

Perform valve calibration and tuning always when *ATYP* has been changed.

5.5.6 Positioner fail action, PFA

Positioner fail action will take place in case of signal failure or when the controller software discovers a fatal device failure. For single acting actuators set value in the spring direction. For double acting actuators see Fig. 6 for correct settings.

- Once PFA is displayed, press the key to enter the edit state and the PFA will start blinking.
- You may select between two values by pressing the or key. The value indicates that the valve ought to be closed in fail action situations. The value indicates the valve to be opened in fail action situations.
- After the desired value is displayed, press the key to conclude the operation

NOTE:
Perform valve calibration and tuning always when controller fail action parameter has been changed.

5.5.7 Valve rotation direction, ROT

The application-specific parameter ROT defines the relationship between position sensor rotation and valve action.

- Once ROT is displayed press the key to enter the edit state and ROT starts to blink.
- Now you may select between two values by pressing the or key. The value indicates clockwise rotation for closing the valve and means counterclockwise to close.
- After the desired value is displayed, press the key to conclude the operation.

NOTE:
Perform valve calibration and tuning always when ROT has been changed.

5.5.8 Valve dead angle, RD

The α_0 setting is made for Metso segment and ball valves. This setting takes into account the "dead angle" α_0 of the ball valves. The entire signal range is then used for effective valve opening $90^\circ - \alpha_0$. Use 0 % as the "dead angle" for the valves not mentioned in Table 5.




Fig. 14 Principle of setting

Table 5 Dead angle in percentage

| Valve size | Valve series | | | | | | | | | | | |
|------------|--------------|---------------|---------|---------|-----------|-----------|--------|-------|------|-----------|-------|------|
| | MBV 1) | MBV 2) | D, P, C | T5, QT5 | QX-T5 | T25, QT25 | QX-T25 | R, QR | E | R-SOFT 3) | FL 4) | ZX |
| mm | in | Dead angle, % | | | | | | | | | | |
| 15 | 1/2 | | | | | | | | | | | 15 |
| 20 | 3/4 | | | | | | | | | | | 15 |
| 25 | 1 | 14 | - | - | 25.5 | 19.5 | - | 15 | 25.5 | 27 | | 12.5 |
| 25/1 | 1/1 | | | | | | | 14.5 | | | 11 | 15 |
| 25/2 | 1/2 | | | | | | | 8 | | | 11 | 16.5 |
| 25/3 | 1/3 | | | | | | | 8 | | | 10 | |
| 25/4 | | | | | | | | 8 | | | | |
| 40 | 1 1/2 | 12 | - | - | 24.5 | 12.5 | - | 12 | 16 | 21 | | 12.5 |
| 50 | 2 | 10 | 9 | 13.5 | 24.5 | 12.5 | 18 | 8 | 17 | 20.5 | 23 | 12.5 |
| 65 | 2 1/2 | 9 | - | - | - | - | - | 13 | - | 18 | | |
| 80 | 3 | 10 | 8 | 12 | 18 | 8 | 16.5 | 8.5 | 9 | 8.5 | 15.5 | 8.5 |
| 100 | 4 | 10 | 8 | 12 | 16.5 | 8.5 | 16 | 9 | 8 | 7 | 14.5 | 9.5 |
| 125 | 5 | 12 | - | - | - | - | 12 | 6.5 | 8 | - | | |
| 150 | 6 | 10 | 8 | 11.5 | 16 | 9 | 13.5 | | 8 | 13.5 | 13 | |
| 200 | 8 | 9 | 7 | 8.5 | 12 | 6.5 | 9.5 | | 7 | | 11.5 | |
| 250 | 10 | 9 | 7 | 7.5 | 13.5 | | 9.5 | | 7 | | 10.5 | |
| 300 | 12 | 8 | 6 | 6.5 | 9.5 | | 7.5 | | 6 | | 9.5 | |
| 350 | 14 | | 6 | 6 | - | | | | 5 | | 9.5 | |
| 400 | 16 | | 5 | 5.5 | 9.5 (14") | | | | 5 | | 9.5 | |
| 450 | 18 | | | 6 | 7.5 (16") | | | | | | | |
| 500 | 20 | | | 6 | | | | | 4.5 | | | |
| 600 | 24 | | | 5.5 | | | | | 6 | | | |
| 650 | 26 | | | 7 | | | | | | | | |
| 700 | 28 | | | 7 | | | | | 6 | | | |
| 750 | 30 | | | 6 | | | | | | | | |
| 800 | 32 | | | - | | | | | | | | |
| 900 | 36 | | | 5.5 | | | | | | | | |

1) Seat supported 2) Trunnion 3) Soft seated R-valve 4) Low Cv Finetrol




Fig. 15 Dead angle

- After selecting RD on the display, press the key to enter the edit state and RD starts to blink. The value currently selected appears as a percentage (%) on the display.
- Modify the parameter value by pressing or keys alternately until the desired value appears on the display.
- Press the key to make your selection and return to the setting state.

5.5.9 Low cut-off, low limit, high cut-off, high limit

ND9200H supports signal cut-off and limiting in both ends of the operating range. The configuration parameters are; low cut-off, low limit, high cut-off and high limit.

- ❑ If the input signal is smaller than low cut-off, the valve will be fully closed.
- ❑ If the input signal is smaller than low limit, the valve stays in the low limit.
- ❑ If the input signal is greater than high cut-off, the valve will be fully opened.
- ❑ If the input signal is greater than high limit, the valve stays in the high limit.

The cut-off overrides the limit as follows:

- ❑ If the low cut-off > low limit, the low limit is not active.
- ❑ If the low cut-off < low limit, both low cut-off and limit are active.
- ❑ If the low cut-off is set to zero, the low cut-off is not active.
- ❑ If the high cut-off < high limit, the high limit is not active.
- ❑ If the high cut-off > high limit, both high cut-off and limit are active.
- ❑ If the high cut-off is set to 100 %, the high cut-off is not active.

Only the low cut-off is adjustable using the LUI. Low limit, high cut-off and high limit are configurable via FieldCare software.

5.5.10 Language selection, *LANG*

- ❑ Select between three languages *Eng*, *Ger* or *Fre* using the \oplus and \ominus keys.
- ❑ To conclude press the \odot key when the desired value is shown on the display.

5.6 Valve travel calibration

NOTE:

If *AUTO CAL* or *MAN CAL* is selected, the valve controller must be in **AUTO** mode. 1-point calibration may run in both **AUTO** and **MAN** mode.

Select *CAL* from the menu by using \oplus or \ominus keys and press the \odot key. Define the calibration type *AUTO*, *MAN* or *TUNE*. You may also select *TUNE* after *AUTO* and *MAN* calibration separately as seen in Fig.16.




Fig. 16 Calibration selection

WARNING:

Automatic calibration drives the valve against the mechanical open and closed travel limits of the valve-actuator assembly and a tuning procedure is performed. Make sure that these procedures can be safely executed.

5.6.1 AUTO calibration function

During the calibration process the display will show the following text: *CALrun*. After calibration the ND9200H scrolls *CALIBRATION SUCCESSFUL* text. You may interrupt the calibration sequences at any time by pressing the \odot key.

After the calibration sequence is finished, press the \odot key twice to get back to the measurement view.

Please refer to Chapter 7 if this sequence has failed and an error message is displayed.

If you cannot drive the valve into a fully open position or if there is no mechanical limit stop, a manual calibration is required.

5.6.2 MAN calibration function

After selecting the *MAN* calibration function from the menu press the \odot key to activate the procedure. With the \oplus or \ominus keys drive the valve manually to the closed (0 %) position and then press the \odot key. If you cancel the operation, the old values of the previous calibration will be restored. Drive the valve into the desired maximum opening position (100 %) with the \oplus and \ominus keys and press the \odot key.

If this sequence has failed and an error message is shown, see Chapter 7.

5.6.3 TUNE function

During the tuning the ND9200H controller searches for optimum internal control parameters for the valve position control. At any time you may interrupt the tuning sequence by pressing the \odot key. The tuning will not alter the *PERF* parameter.

If calibration and tuning are performed in sequence, the cancelling of tuning does not restore the old calibration values.

5.6.4 1-Point calibration

1-point calibration is useful in cases in which the valve controller needs to be changed but it is not possible to run the normal calibration and the valve is not allowed to change position (the valve is active, for example).




This procedure does not ensure the best possible control performance, and it is always recommended to run either AUTO or MAN calibration and tuning, as soon as possible. The primary way to calibrate valve position is to use either **AUTO** or **MAN** calibration.


Before starting 1-point calibration, read the warnings and notes below and **check that the valve is mechanically locked. Before starting 1-point calibration, adjust the TPOS value in the MAN mode (see section 5.4.2) to correspond with the physical position of the valve.**


Once the 1-point calibration is started, the first view shows *ANG* above and *NN.N* below (see Fig. 16). *NN.N* presents the maximum turning angle (in degrees) that the valve can perform.

To change the value:

- ❑ Press \odot , *NN.N* begins blink

□ Press  and  -buttons to change the value. After the correct valve operation angle is set, press  -button.

During the calibration process the display will show the following text: *CALRun*. After calibration the ND9200H scrolls *CALIBRATION SUCCESSFUL* text. You may interrupt the calibration sequences at any time by pressing the  key.

After the calibration sequence is finished, press the  key twice to get back to the measurement view.

Please refer to Chapter 7 if this sequence has failed and an error message is displayed.

The valve can now be unlocked.

WARNING:

Supply pressure can be connected to the valve controller only after 1-point calibration is successfully completed. If supply pressure is connected to the valve controller before successful 1-point calibration, the valve may move and cause danger.

NOTE:

If an incorrect valve operation angle is given to the valve controller during 1-point calibration, valve operation will be incorrect. In this case, you must perform 1-point calibration again with correct valve operation angle value.

NOTE:

If the valve position is not stable (due to heavy vibration etc) during 1-point calibration, the calibration will not end successfully. Check that the valve position is fully stable during this operation.

5.7 Special displays

5.7.1 User interface locked



In order to prevent unauthorised access, the Local User Interface may be locked. In this mode measurements may be viewed but configurations and calibrations are prohibited. You may lock and unlock the device only via HART. When the Local User Interface is locked the lock symbol will be activated on the display.



Fig. 17 LUI locked

5.7.2 Online-alarm active

If an online alarm has been detected the solid **X** symbol is activated. This symbol will disappear after the recovery from online alarm. You may view the reason for the alarm by viewing the latest event while pushing

the  and  keys simultaneously or by using FieldCare software where all events may be viewed.








Fig. 18 Online alarm message

5.7.3 Viewing of latest event

You may view the latest event by pressing the  and  keys simultaneously in the measurement monitoring view. The message is scrolled on the top row of the display twice. You may stop the scrolling by pressing the  key. By pressing the  key, the message will disappear.

For the list of events see Chapter 7.

5.7.4 Fail-safe active

When the ND9200H detects serious device failure (set-point, valve position and control signals) it enters fail-safe mode, which drives the control valve into the position defined in the parameter controller fail action (*PFA*). Fail-safe mode is indicated by the display as seen in Fig. 19. The error message is displayed until the cause of error is eliminated and the ND9200H unit is restarted, i.e. the power loop is momentarily disconnected.




Fig. 19 Failsafe display

5.7.5 Reduced performance

When the ND9200H detects spool valve measurement failure, it enters reduced performance mode. This is indicated by the blinking **X** in the display, see Fig. 20.

In reduced performance mode valve control can not be optimized. To correct the problem replace the spool valve assembly and perform auto calibration.

5.8 HART write protection

The ND9200H is delivered from the factory with the default set as HART write protection OFF. Reading and changing parameters is allowed. HART protection may be enabled with a switch (DIP1) located on the communication circuit board under the Local User Interface module, Fig. 21. Changes that may influence the valve position cannot be made using the FieldCare software




Fig. 20 Reduced performance display
or HART hand held when switch no. 1 (on the left-hand side of the switch block) is ON.




Fig. 21 HART write protection

6 MAINTENANCE

Ex d WARNING:

Service of the cylindrical flameproof joints is not allowed.

This includes the diaphragm cover (part 171), flame arrester plunger (part 200), their mating surfaces in the housing (part 2) and the shaft assembly fixed in the housing.

The maintenance requirements of the ND9200H valve controller depend on the service conditions, for instance, the quality of instrument air. Under normal service conditions there is no requirement for regular maintenance.

When maintaining the ND9200H ensure that the supply air is shut off and pressure is released. In the following text the numbers in brackets () correspond to the part numbers in the exploded view as shown in Chapter 11, unless otherwise stated.

The ND9200H valve controller includes the following interchangeable modules: prestage unit (120), spool valve (193), communication circuit board with optional position transmitter (215).

The spool valve is located on the bottom side of the device while the other modules are located below the covers (100) and (39). In the event of failure the whole module must be changed. The module retrofit must be assembled in a clean, dry environment. In reassembly apply a thread-locking compound (for instance, Loctite 243) and tighten the screws firmly.

6.1 Prestage

NOTE:

The prestage must be handled carefully. In particular the moving parts of the prestage should not be touched when the inner cover (39) is not in place.

6.1.1 Removal

- ❑ Loosen the M8 stop screw (110) in the position indicator (109) and turn the position indicator from the shaft (11). Remove the inner cover (39) attached with M3 screws (42, 3 pcs).
- ❑ Unplug the prestage wire connector from the spool sensor board (180). Unscrew the M4 screws (139, 2 pcs.) and lift up the prestage module. Remove the O-ring (140).

6.1.2 Installation

- ❑ Place a new O-ring (140) into the groove in the housing and press the prestage into place. Make sure the nozzle is guided into the O-ring properly. The screws guide the prestage body into the correct position. Tighten the screws (139) evenly.
- ❑ Push the prestage 2-pole wire connector into the socket on the spool sensor board. The wire connector can only be fitted in the correct position. Replace the inner cover (39) and tighten the M3 screws.

6.2 Spool valve

6.2.1 Removal

For spool valve removal it is usually necessary to unmount the valve controller from the actuator.

- ❑ Working from the bottom side of the valve controller, unscrew the M4 screws (47, 3 pcs.). Remove the spool valve cover (61) and the spool valve (193) with gasket (174). Hold the ends of the body with your fingers to avoid dropping the spool from the body.
- ❑ Spool valve removal is only possible in the spring-forced failsafe position of the spool. In the case of a stuck spool it might be necessary to remove the secondary diaphragm cover (167), the spool spring (166) with its disc (164) and the secondary diaphragm (162) with its plate. After the removal of these parts it is possible to use a punch to force the spool to the failsafe position.
- ❑ The spool valve may be cleaned if special attention is paid to a clean environment and proper procedure.
- ❑ Clean the spool and the bore of the body with care. Do not leave any fibres from cleaning materials in the bore or on the spool. Do not scratch the mating surfaces of the spool and body.

NOTE:

Each spool valve body has an individual corresponding spool which cannot be replaced by any other spool. Never alter the orientation of the spool. The orientation of the spool is marked on the device, see Fig. 22.

6.2.2 Installation

- ❑ Ensure that the gaskets (174) and (63) are properly located in their grooves on the bottom of the housing. Mount the spool valve and the spool valve cover (61) to the housing, and tighten M4 screws evenly.




Fig. 22 Spool valve assembly

6.3 Flame arrestor assembly

The flame arrestor and the restrictor are fit into the same plug which is located under the diaphragm cover (171). This assembly can not be disassembled and should be replaced if clogged.

- ❑ To remove the flame arrestor assembly, unscrew the screws (173, 4 pcs.) and remove the diaphragm cover (171) with its O-ring. Turn a M3 screw into the threaded hole of the flame arrestor assembly to extract it from the housing. Installation is the reversal of removal. Place the O-rings carefully.

6.4 Diaphragms

The diaphragms (169, 162) may be replaced by removing the respective covers (171, 167). The unit should be unmounted from the actuator and the side to be worked on turned upwards in order to avoid loss of small parts. When replacing the secondary diaphragm (162), the spool spring (166) with its guide (164) has to be removed first. When reassembling, pay special attention to the installation of the diaphragms and O-rings.

6.5 Communication circuit board

6.5.1 Removal

- ❑ Loosen the M8 stop screw (110) in the position indicator (109) and turn the position indicator from the shaft (11). Remove the inner cover (39) attached with M3 screws (42, 3 pcs.).

NOTE:

Ground yourself on the body of the device before touching the circuit board.

- ❑ Remove the M3 screws (217, 4 pcs.). Hold the sides of the circuit board and lift it directly upwards and outwards. Handle the board carefully, touching only the sides.

NOTE:

Do not remove the Valve Controller Board (210)!
Removing the board will void the warranty.

6.5.2 Installation

- ❑ Mount the new communication circuit board carefully.
- ❑ Locate the pins with the matching connector on the board. Tighten the M3 screws (217) evenly.
- ❑ Install the inner cover (39).
- ❑ Mount the position indicator (109) on the shaft and tighten the M8 stop screw (110) temporarily. The final orientation and locking of the position indicator should be done after installation of the valve controller to the actuator.

ATEX WARNING:

Grounding of the circuit board is essential to explosion protection.

The board is grounded to the housing by the mounting screw next to the terminal blocks.




Fig. 23 Communication board

7 ERROR MESSAGES

7.1 Failsafe errors

| Display message | Description |
|-------------------------|--|
| POSITION SENSOR FAILURE | Position sensor measurement failed. Change the ND9000 device to a new one. |
| SETPOINT SENSOR FAILURE | mA measurement failed. Change the ND9000 device to a new one. |
| PRESTAGE SHORTCUT ERROR | Shortcut in the prestage unit. |
| FAE nnn | Fatal malfunction in the device. nnn is a number between 001 - 004. Change the ND9000 device to a new one. |

7.2 Alarms

| Display message | Description |
|-----------------------------|---|
| DEVIATION ALARM | Valve deviation out of limits. |
| STICTION LOW ALARM | Stiction has exceeded the low limit. |
| STICTION HIGH ALARM | Stiction has exceeded the high limit. |
| LOAD FOR OPENING LOW ALARM | Load for opening has exceeded the low limit. |
| LOAD FOR OPENING HIGH ALARM | Load for opening has exceeded the high limit. |
| SPOOL VALVE PROBLEM | Spool valve problem in the controller. Check the spool valve unit and replace if necessary. |
| PNEUMATICS PROBLEM | Inconsistent actuator pressures. Check pneumatic connections and actuator leakage. |
| FRICTION PROBLEM | Valve is not moving correctly. Check load factor. |

7.3 Errors

| Display message | Description |
|-----------------------------|--|
| PRESTAGE CUT ERROR | Prestage wire is cut or connector is loose. |
| PRESSURE SENSOR 1 FAILURE | Actuator pressure sensor has failed. The device performance level is reduced. Change the ND9000 device to a new one during next maintenance activity. |
| PRESSURE SENSOR 2 FAILURE | Actuator pressure sensor has failed. The device performance level is reduced. Change the ND9000 device to a new one during next maintenance activity. |
| PRESSURE SENSOR 3 FAILURE | Supply pressure sensor has failed. This does not affect the performance level. |
| SPOOL VALVE SENSOR FAILURE | Spool valve sensor failed. Check the sensor connections. The device performance level is reduced. Change the ND9000 device to a new one during next maintenance activity. |
| TEMPERATURE SENSOR FAILURE | Temperature measurement failed. The accuracy of the measurements is reduced. Change the ND9000 device to a new one during next maintenance activity. |
| STATISTICS DATABASE ERROR | Failed to store statistics. New measurements will be lost. |
| EVENT DATABASE ERROR | Failed to store events. The new events will be lost. |
| POSITION CALIBRATION FAILED | Travel calibration failed. Check the configuration parameters and controller mounting. Check that the controller shaft is correctly aligned. |
| TUNING FAILED | Tuning procedure failed. Check that the valve is moving properly. Check the prestage and spool valve unit. |
| POSITION SENSOR RANGE ERROR | Position sensor range failed during calibration. Valve controller shaft failed to rotate minimum 45 degrees. Check the configuration parameters and controller mounting. Check that the controller shaft is correctly aligned. |
| CALIBRATION TIMEOUT | Calibration timeout occurred. Check configuration and installation. |
| CALIBRATION START FAILED | The calibration starting conditions are not met. Check the supply pressure. |
| TUNING RANGE ERROR | Tuning procedure failed. Check the prestage and spool valve unit. |
| SPOOL SENSOR RANGE ERROR | Spool sensor range failed during position calibration. Check the configuration parameters. Check the prestage and spool valve unit. |

7.4 Warnings

| Display message | Description |
|---|---|
| TOTAL OPERATION TIME WARNING | Operating time exceeded limit. |
| VALVE FULL STROKES WARNING | Valve stroke counter limit reached. |
| VALVE REVERSALS WARNING | Valve reversals counter limit reached. |
| ACTUATOR FULL STROKES WARNING | Actuator stroke counter limit reached. |
| ACTUATOR REVERSALS WARNING | Actuator stroke counter limit reached. |
| SPOOL FULL STROKES WARNING | Spool stroke counter limit reached. |
| SPOOL REVERSALS WARNING | Spool reversals counter limit reached. |
| STEADY STATE DEVIATION WARNING | Warning that steady state deviation has increased. |
| DYNAMIC STATE DEVIATION WARNING | Warning that dynamic state deviation has increased. |
| STICTION LOW WARNING | Warning that stiction has exceeded the low limit. |
| STICTION HIGH WARNING | Warning that stiction has exceeded the high limit. |
| LOAD FOR OPENING TOO LOW | Warning that load for opening has exceeded the low limit. |
| LOAD FOR OPENING TOO HIGH | Warning that load for opening is has exceeded the high limit. |
| SUPPLY PRESSURE OUT OF LIMITS | Supply pressure has exceeded the specified operating conditions. |
| TEMPERATURE OUT OF LIMITS | Temperature has exceeded the specified operating conditions. |
| HUNTING DETECTION WARNING | Valve hunting detected. Change performance level to less aggressive to stabilize valve. Check that the spool valve capacity is suitable for the actuator. |
| REDUCED PERFORMANCE ACTIVATED | Valve controller performance is reduced due to defective spool valve sensor. Change the spool valve assembly. |
| TOO LOW SUPPLY PRESS FOR 1-ACT ACTUATOR | Too low supply pressure level for 1-acting actuator. |
| VALVE REVERSALS TREND WARNING | Warning that valve reversals per day has exceeded the limit. |
| SETPOINT REVERSALS TREND WARNING | Warning that setpoint reversals per day has exceeded the limit. |
| VALVE TRAVEL TREND WARNING | Warning that valve travel per day has exceeded the limit. |
| VALVE REVERSALS WH STABLE SETP WARNING | Warning that valve reversals while setpoint is stable, per day, has exceeded the limit. |

7.5 Notifications

| Display message | Description |
|---------------------------------|---|
| CALIBRATION SUCCESSFULL | Position calibration successfully performed. |
| TEST CANCELLED | Off-line test has been cancelled. |
| TEST DONE | Off-line test has been successfully performed. |
| TEST FAILED | Off-line test failed. Repeat the test sequence. |
| CALIBRATION CANCELLED | Calibration has been cancelled. |
| PARAMETERS BACKUP RESTORED | Parameter backup database has been activated. |
| PT NOT ACTIVATED | (Only with position transmitter option). The position transmitter is not energized. |
| 1PT CAL FAILED | 1-point calibration failed. Check the mounting of the valve controller. Verify input parameter (range) value. Check rotation parameter (ROT). |
| TUNE OK | Tuning has been successfully performed. |
| REDUCED PERFORMANCE DEACTIVATED | Spool valve measurement and normal valve control is recovered. |

8 TROUBLE SHOOTING

Mechanical/electrical defects

1. A change in the valve position setpoint will not affect the position of the actuator

- ☐ Supply pressure too low
- ☐ Spool valve sticks
- ☐ Incorrect configuration parameters
- ☐ Actuator and/or valve jammed
- ☐ Signal wires incorrectly connected, no value on display
- ☐ Circuit boards are defective
- ☐ Calibration and tuning has not been carried out
- ☐ Device is in manual mode
- ☐ Prestage is defective
- ☐ Device is in fail-safe mode
- ☐ Spool mounted backwards into spool valve

2. The actuator goes to the end position with a small change of input signal

- ☐ Tubes between controller and actuator are incorrect, see Fig. 6
- ☐ The parameter settings *PFA* and *ROT* are incorrectly selected.

3. Inaccurate positioning

- ☐ Spool valve dirty
- ☐ Too high actuator load
- ☐ Supply pressure too low
- ☐ Spool or pressure sensors are defective
- ☐ Actuator leakage

4. Overshooting or positioning too slow

- ☐ Change *PERF* value
- ☐ Spool valve dirty
- ☐ Supply air tube too small or supply air filter dirty
- ☐ Valve sticks
- ☐ Check leakages in tubes between controller and actuator
- ☐ Check leakages in mechanical stop screws

5. Error during valve travel calibration

- ☐ Valve controller is in *MAN* mode
- ☐ Check the coupling alignment with the pointer, see Fig. 5.
- ☐ The parameter settings *PFA* and *ROT* are incorrectly selected
- ☐ The actuator or valve did not move or was stuck during calibration
- ☐ Supply pressure too low
- ☐ Spool valve dirty

9 ND92_H/K00 and ND92_H/I00 (WITH LIMIT SWITCHES)

9.1 Introduction

9.1.1 General description

ND9200H can be equipped with limit switches. ND9200H/K00 has two microswitches and ND9200H/I00 has two inductive proximity switches. Limit switches are used for electrical position indication of the valves and other devices.

The switching points may be chosen freely.




Fig. 24 ND92_H/K_ layout




Fig. 25 ND92_H/I_ layout

9.1.2 Markings

The limit switch is provided with an identification plate sticker, see Fig. 26. Identification plate markings from top to bottom are:

- ☐ Type designation
- ☐ Electrical values
- ☐ Temperature range
- ☐ Enclosure class
- ☐ Conduit entry
- ☐ Manufacturing serial number

The type designation is described in Chapter 14.



Fig. 26 Example of the identification plate

9.1.3 Technical specifications

9.1.3.1 ND92_H/K00

| | |
|----------------------------|--|
| Microswitch type: | OMRON D2VW-5 (K05) OMRON D2VW-01 (K06) (gold-plated contacts) Protection class IP67 |
| Resistive load: | 3A: 250 V AC (K05) 5A: 30 V DC 0.4A: 125 V DC 100 mA: 30 V DC / 125 V AC (K06) |
| Switch accuracy: | < 2° |
| Number of switches: | 2 (K05 or K06) |
| Protection class of cover: | IP66 (DIN 40050, IEC 60529) |
| Conduit entry: | M20 x 1.5 |
| Ambient temperature: | -20° to +80 °C / -4° to +176 °F |
| Weight: | Approx. 1.0 kg / 2.2 lb (limit switches only) |

9.1.3.2 ND92_H/I00

| | |
|------------------------------|---|
| Proximity switch: | Inductive, diameter 8–14 mm (0.31–0.55 in) Sensing range 2 mm / 0.08 in Protection class IP67 P+F NJ2-12GK-SN (02) ifm IFC2002-ARKG/UP (56) Other switch types on special order |
| Electrical values: | According to switch type |
| Switch accuracy: | < 1° |
| Number of switches: | 2 |
| Protection class of housing: | IP66 (DIN 40050, IEC 60529) |
| Conduit entry: | M20 x 1.5 |
| Ambient temperature: | -20° to +51 °C / -4° to +124 °F (02) -20° to +80 °C / -4° to +176 °F (56) |
| Weight: | Approx. 1.0 kg / 2.2 lb (limit switches only) |

9.2 Installing ND92_H/K00 and ND92_H/I00 on a valve controller

The limit switch may be installed on an existing valve controller.

- ❑ If the valve controller is already mounted on an actuator/valve assembly, operate the actuator into the closed or open position.
- ❑ Remove the cover (100), the pointer (109), the LUI (223) and electronics cover (39).
- ❑ Turn the shaft (311) onto the shaft (11). Fasten the screw (312) using a locking agent such as Loctite.
- ❑ Mount the electronics cover (39) and the limit switch housing (300) on the valve controller. Lock the housing in place with screw (326). Install the base plate (324) with the limit switches and connector block into the limit switch housing. Fasten the base plate with screws (325), 3 pcs.
- ❑ Install the cam discs (313) and spacers (346) to the shaft.
- ❑ Mount the LUI (223) on the holder (306).
- ❑ Replace the plastic plugs with metal ones in conduit entries which will not be used.
- ❑ Mount the pointer (109) on the shaft (311). Adjust the limit switch according to 9.4.

9.3 Electrical connections

Before connecting the power, make sure that the electrical specifications and the wiring meet the installation conditions. See the diagrams in 12.9. Refer to the information on the identification plate.

ND9200/I: Observe the functioning of the proximity switch; activated when the active face is either covered or free.

9.4 Adjustment

The pointer (109) need not be removed for adjustment. When the limit switch is ordered together with the valve and the actuator, the valve controller switches are factory-adjusted. The limits may be adjusted by altering the position of the cam discs (313) on the shaft. The lower switch is activated at the closed limit and the upper switch at the open limit.

- ❑ With the actuator in the open or closed position, locate the switching point by turning the cam disc so that the switch state changes approx. 5°–6° before the limit.
- ❑ **ND9200/I00:** Use the LED indicator or a separate measuring instrument as an aid.
- ❑ After re-installation of the actuator, first adjust its mechanical limits according to the valve, then the valve controller, and finally the limit switch.
- ❑ When adjustment is completed, turn the pointer (109) so that the yellow line is parallel with the valve closure member.




Fig. 27 Limit switch adjustment, 2 switches

9.5 Removal of the limit switches ND92_H/K00 and ND92_H/I00 for accessing the valve controller

- ❑ Remove the cover (100) and the pointer (109).
- ❑ Loosen the screws (314) in the cam disks (313) and remove the cam disks and spacers (346) from the shaft.
- ❑ Remove the LUI cabling from the circuit board. Disconnect and remove all cabling which enters the limit switch housing (300).
- ❑ Remove screws (325), 3 pcs and lift out the limit switch base plate (324) complete with switches, LUI and connector block.
- ❑ Open screw (326) and turn the limit switch housing (300) from the positioner housing.
- ❑ Remove the electronics cover (39).
- ❑ Proceed with the valve controller as applicable.
- ❑ Re-install the limit switch according to 9.2 and check the adjustment according to 9.4.

ATEX WARNING:

The locking screw of the limit switch housing (Part 326) is essential to explosion protection.

The limit switch housing has to be locked in place for Ex d protection. The screw grounds the limit switch housing to the housing of the valve controller.

9.6 Circuit diagrams

The internal circuitry of the limit switch is shown in the connection diagrams in 12.9 and inside the cover.

9.7 Maintenance

Regular maintenance of the limit switch is not necessary.

10 TOOLS

No special tools required.

11 ORDERING SPARE PARTS


Spare parts are delivered as modules. The modules available are indicated in 12.1.

When ordering spare parts, always include the following information:

- ☐ Valve controller type designation and serial number from the ID plate
- ☐ The code of this manual, the part number, the part name and quantity required

12 DRAWINGS AND PARTS LISTS

12.1 Exploded view and parts list, ND9200H




| Item | Qty | Description | Spare modules |
|-------|-----|-----------------------------|---------------|
| 2 | 1 | Housing | |
| 15 | 1 | O-ring | |
| 16 | 1 | Washer | |
| 18 | 1 | Wave spring | |
| 19 | 1 | Bushing | |
| 36 | 1 | Grounding screw | |
| 39 | 1 | Inner cover | |
| 42 | 3 | Screw | |
| 47 | 3 | Screw | |
| 57 | 1 | Conduit entry adapter | |
| 61 | 1 | Spool valve cover | |
| 63 | 1 | Gasket | |
| 100 | 1 | Cover | x |
| 104 | 1 | O-ring | |
| 107 | 1 | Screw | |
| 109 | 1 | Pointer | |
| 110 | 1 | Stop screw | |
| 111 | 1 | Spring | |
| 120 | 1 | Prestage unit | x |
| 139 | 2 | Screw | |
| 140 | 1 | O-ring | |
| 162** | 1 | Supply pressure diaphragm | x |
| 163 | 1 | Diaphragm plate | |
| 164 | 1 | Spring guide | |
| 165 | 1 | O-ring | |
| 166 | 1 | Spring | |
| 167 | 1 | Diaphragm cover | |
| 169** | 1 | Pilot pressure diaphragm | x |
| 170 | 1 | Diaphragm plate | |
| 171 | 1 | Diaphragm cover | |
| 173 | 8 | Screw | |
| 174 | 1 | Gasket | |
| 176 | 1 | Bushing | |
| 177 | 1 | O-ring | |
| 181 | 1 | Sleeve | |
| 182 | 1 | Spool sensor board | |
| 183 | 1 | Screw | |
| 184 | 1 | Plunger | |
| 193 | 1 | Spool valve | x |
| 196 | 1 | Bushing | |
| 197 | 1 | Flame arrester assembly | x |
| 199 | 1 | O-ring | |
| 200 | 1 | Flame arrester plunger | |
| 210 | 1 | Valve controller board | |
| 215 | 1 | Communication circuit board | x |
| 217 | 4 | Screw | |
| 218 | 1 | Support | |
| 219 | 2 | Screw | |
| 220 | 2 | Threaded spacer | |
| 221 | 3 | O-ring | |
| 222 | 1 | Isolation part | |
| 223 | 1 | Local user interface (LUI) | x |
| 228 | 2 | Screw | |

*) Mounting parts: coupling (12), screws (14)

**) Diaphragm set

12.2 Exploded view and parts list, ND92_H/K_, ND92_H/I_



| Item | Qty | Description | Spare modules |
|-------------|------------|----------------------------|----------------------|
| 100 | 1 | Cover | |
| 104 | 1 | O-ring | |
| 107 | 1 | Screw | |
| 109 | 1 | Pointer | |
| 110 | 1 | Stop screw | |
| 111 | 1 | Spring | |
| 223 | 1 | Local user interface (LUI) | |
| 300 | 1 | Housing | |
| 301 | 1 | O-ring | |
| 302 | 1 | Screw | |
| 304 | 1 | Bracket | |
| 305 | 2 | Screw | |
| 306 | 1 | Bracket | |
| 307 | 3 | Screw | |
| 308 | 2 | Screw | |
| 311 | 1 | Extension shaft | |
| 312 | 2 | Screw | |
| 313 | 2 or 4 | Cam disc | |
| 314 | 2 or 4 | Screw | |
| 315 | 1 | Terminal block | |
| 324 | 1 | Base plate | |
| 325 | 2 | Screw | |
| 326 | 1 | Screw | |
| 346 | 1 | Bearing bushing | |
| 347 | 2 | Proximity switch | |
| 348 | 1 | Fixing plate | |
| 349 | 2 | Screw | |
| 350 | 1 | Washer | |
| 351 | 1 | Screw | |
| 355 | 2 or 4 | Microswitch | |
| 357 | 2 | Spring washer | |
| 358 | 2 | Screw | |

12.3 Mounting parts for EC05-14/EJ05-14 actuators, rising signal opens valve

| Item | Qty | Description |
|------|-----|----------------|
| 15 | 1 | Coupling |
| 27 | 2 | Screw |
| 38 | 4 | O-ring |
| 47 | 1 | Coupler socket |
| 48 | 2 | Screw |
| 53 | 2 | Plug |
| 54 | 1 | Plug (EJ only) |
| 64 | 1 | Mounting plate |
| 65 | 4 | Screw |
| 66 | 4 | Screw |

12.4 Mounting parts for B1C/B1J 6-20 actuators

| Item | Qty | Description |
|------|-----|--------------------------|
| 1 | 1 | Mounting bracket |
| 2 | 1 | Ear |
| 3 | 4 | Washer |
| 4 | 4 | Screw |
| 13 | 2 | Screw |
| 14 | 2 | Hexagon nut |
| 28 | 4 | Screw |
| 29 | 1 | Screw |
| 36 | 1 | Couplings jacket |
| 47 | 1 | Coupler socket |
| 48 | 2 | Screw |
| 53 | 1 | Plug (BJ actuators only) |

| Item | Qty | Description |
|------|-----|--------------------------|
| 1 | 1 | Mounting bracket |
| 2 | 1 | Ear |
| 3 | 4 | Washer |
| 4 | 4 | Screw |
| 13 | 2 | Screw |
| 14 | 2 | Hexagon nut |
| 28 | 4 | Screw |
| 29 | 1 | Screw |
| 36 | 1 | Couplings jacket |
| 47 | 1 | Coupler socket |
| 48 | 2 | Screw |
| 53 | 1 | Plug (BJ actuators only) |

Note: See 12.5 for old series B actuators

12.5 Mounting parts for B1C/B1J 25-50, B1C 502 and B1J322 actuators

BC 25 - 50
BJ 25 - 322

Note: Different mounting position

ND9200

BC 502

Note: Old series B actuators

new hole drilled
ø5.5 through

90° 45°

21

Arrow

| Item | Qty | Description |
|------|-----|--------------------------|
| 1 | 1 | Mounting bracket |
| 2 | 1 | Draught piece |
| 3 | 4 | Washer |
| 4 | 4 | Screw |
| 27 | 4 | Washer |
| 28 | 4 | Screw |
| 47 | 1 | Coupler socket |
| 48 | 2 | Screw |
| 53 | 1 | Plug (BJ actuators only) |

12.6 Mounting parts for Quadra-Powr® actuators

QP II (1, 2, 3, 4, 5, 6)
Valv-Powr
DRIVE: FEMALE SPLINE

ND9200


QP II (1, 2, 3, 4, 5)
ST
SP
DRIVE: MALE

ND9200

| Item | Qty | Description |
|------|-----|---|
| 1 | 1 | Mounting bracket |
| 2 | 1 | Ear |
| 4 | 4 | Screw |
| 28 | 4 | Screw |
| 29 | 1 | Screw |
| 30 | 4 | Screw |
| 35 | 1 | Adapter plug (QP II 1/S- 6/S only) |
| 35 | 1 | Adapter plate (QP II 2B/K thr. 6_/K) |
| 36 | 1 | Couplings jacket |
| 47 | 1 | Coupler socket |
| 48 | 2 | Screw |
| 53 | 1 | Plug |


| Item | Qty | Description |
|------|-----|------------------|
| 1 | 1 | Mounting bracket |
| 2 | 2 | Coupling half |
| 3 | 1 | Adapter |
| 4 | 4 | Screw |
| 5 | 4 | Hex nut |
| 6 | 1 | Screw |
| 7 | 4 | Screw |
| 8 | 4 | Washer |
| 9 | 4 | Screw |
| 10 | 4 | Washer |
| 47 | 1 | Coupler socket |
| 48 | 2 | Screw |
| 53 | 1 | Plug |

12.7 Mounting parts for linear actuators of nelesCV Globe



| Item | Qty | Description |
|------|-----|----------------|
| 3 | 2 | Washer |
| 4 | 2 | Screw |
| 16 | 1 | Conical plug |
| 28 | 4 | Screw |
| 31 | 1 | O-ring |
| 38 | 2 | O-ring |
| 39 | 1 | Mounting plate |
| 47 | 1 | Feedback lever |
| 48 | 4 | Screw |
| 53 | 2 | Plug |
| 54 | 1 | Plug |
| 64 | 1 | Mounting plate |
| 65 | 4 | Screw |

12.8 Mounting parts for linear actuators




| Item | Qty | Description |
|------|-----|-------------------------|
| 1 | 1 | Bracket |
| 2 | 1 | Feedback lever |
| 3 | 1 | Filling piece |
| 4 | 1 | Clearance remove spring |
| 5 | 4 | Cross rec head screw |
| 6 | 4 | Washer |
| 7 | 4 | Hexagon screw |
| 8 | 4 | Washer |
| 9 | 4 | Hexagon screw |
| 11 | 4 | Spring washer |
| 12 | 2 | Hexagon nut |
| 14 | 2 | Clamp |
| 15 | 1 | Fixing plate |
| 16 | 1 | Special screw |
| 17 | 1 | Hexagon nut |
| 18 | 2 | Washer |
| 19 | 2 | Hexagon screw |
| 54 | 2 | Plug |

12.9 Connection diagrams

See Section 9.1.3 for additional limit switch data.

ND92_H/K05, ND92_H/K06



Connection diagram shows limit switch when actuator is in intermediate position. Switch A (upper) is activated at the open limit of the travel and switch K (lower) at the closed limit.

Electrical characteristics:

OMRON D2VW-5 (K05):


5 A - 30 V DC, 0.4 A - 125 V DC,
3 A - 250 V AC

OMRON D2VW-01, gold-plated contacts (K06):

100 mA - 30 V DC / 125 V AC

Ambient temperature -40 ° ... +80 °C / -40° ... +176 °F

ND92_H/I02



Factory adjustment:
Active faces of proximity switches are covered when the actuator is in intermediate position.
Active face A (upper switch) becomes free at open limit of travel and face K (lower switch) at closed limit.

The function can be inverted on site by re-adjusting the cam discs.


Sensing distance 2...4 mm, depending on type of switch
Supply voltage 8 V DC (Ri 1 kΩ)
Current consumption
 active face free, > 3 mA
 active face covered, < 1 mA

PROXIMITY SWITCH

Intrinsically safe II 2 G Ex ia IIC T6
According to CENELEC EN60079-0 and EN60079-11

Voltage (Umax), current (Imax), inductance (Li) and capacitance (Ci) according to certificate of switch, see table.

| | Type of proximity switch | Electrical values | | | | Ex classification | Certificate |
|----|--------------------------|-------------------|--------------|------------|------------|---------------------|--------------------|
| | | Umax (V) | Imax (mA) | Li (μH) | Ci (nF) | | |
| 02 | P+F NJ2-12GK-SN | 16 | 52 | 150 | 50 | II 1 G Ex ia IIC T6 | PTB 00 ATEX 2049 X |
| 07 | P+F NJ2-12GM-N | 16 | 52 | 50 | 30 | II 1 G Ex ia IIC T6 | PTB 00 ATEX 2048 X |

ND92_H/I56**Factory adjustment:**

Active faces of proximity switches are free when the actuator is in the intermediate position. Active face A (upper switch) becomes covered at the open limit of the travel and face K (lower switch) at the closed limit.

The function may be inverted on site by re-adjusting the cam discs.

Connections: Either wire can be connected to + or -.

PROXIMITY SWITCH

ifm electronic IFC2002-ARKG/UP

2-wire type

Sensing distance 2 mm

Rated voltage $U = 10 - 36 \text{ V DC}$

Output current $< 150 \text{ mA}$

active face covered, LED on


Quiescent current $< 0.6 \text{ mA}$

active face free


Ambient temperature $-20^\circ \dots +80^\circ \text{ C} / -13^\circ \dots +176^\circ \text{ F}$

13 DIMENSIONS


ND9200



ND9200



ND921_/I00



14 EC DECLARATION OF CONFORMITY



EC DECLARATION OF CONFORMITY

Manufacturer:
Metso Automation Oy
00811 Helsinki
Finland

Product: **Intelligent Valve Controller Neles ND 9000-series**

Approvals:

| Type | Approval | EC Type examination Certificate |
|--|---|---------------------------------|
| ND 9...PA (Profibus PA) | (EMC 2004/108/EC) EN61000-6-2(2001) | NEMKO 101425 & NEMKO 1052749 |
| ND9...F (Foundation Fieldbus) | (EMC 2004/108/EC) EN61000-6-2(2001) | (Same HW as ND9...PA) |
| ND9...HNT (Hart) | (EMC 2004/108/EC) EN61000-6-3(2001) EN61000-6-2(2001), FCC 47 CFR Part 15, subpart B, Class B (2002) | NEMKO 56164 & NEMKO 80628 |
| ND910.HX1, ND930.HX1 ND910.FX1, ND930.FX1 ND910.PX1, ND930.PX1 | ATEX II 1 G Ex ia IIC T4/T5/T6 Ga ATEX II 1 D Ex tD A20 T90 °C | VTT 09ATEX 033X |
| ND910.HX2, ND930.HX2 ND910.FX2, ND930.FX2 ND910.PX2, ND930.PX2 | ATEX II 2 G Ex ia IIC T4/T5/T6 Gb ATEX II 2 D Ex tD A21 T90 °C | |
| ND910.HX3, ND930.HX3 ND910.FX3, ND930.FX3 ND910.PX3, ND930.PX3 | ATEX II 3 G Ex nA IIC T4/T5/T6 ATEX II 3 D Ex tD A22 T90 °C | VTT 09ATEX 034X |
| ND910.HX4, ND930.HX4 ND910.FX4, ND930.FX4 ND910.PX4, ND930.PX4 | ATEX II 3 G Ex nL IIC T4/T5/T6 ATEX II 3 D Ex tD A22 T90 °C | |
| ND920..E1, ND930..E1 | ATEX II 2 G Ex d IIC T4...T6 ATEX II 2 GD Ex tD A21 IP66 T 100°C | KEMA 04ATEX2098X |

Applicable directives:

EMC 2004/108/EC Electrical
ATEX 94/9/EC

Approved and Ex marked types

As the products within our sole responsibility of design and manufacture may be used as parts or components in machinery and are not alone performing functions as described in Article 6(2) in the Machinery Directive (2006/42/EC), we declare that our product(s) to which this Declaration of Conformity relates must NOT be put into service until the relevant machinery into which it is to be incorporated has been declared in conformity with the provisions of the Machinery Directive.

The product above is manufactured in compliance with the applicable European directives and technical specifications/standards.

Protection from e.g. static electricity caused by the process or connected equipment must be considered by the user (EN 60079-14 §6).

The product do not possess any residual risk according to hazard analyses made under the applicable directives providing that the procedures stated by the Installation, Operation and Maintenance manual are followed and the product is used under conditions mentioned in the technical specifications.

Manufacturer's certificates:

| Standard / Directive | Notified Body | Certificate No. |
|-----------------------|---------------|-------------------------|
| ISO 9001:2000 | DNV | 24888-2008-AQ-FIN-FINAS |
| ATEX 94/9/EC Annex IV | DNV 0575 | DNV-2006-OSL-ATEX-0260Q |

Helsinki 29th September 2009

Ralf Liljestrand, Quality Manager
Authorized person of the manufacturer within the European Community

15 TYPE CODING

INTELLIGENT VALVE CONTROLLER ND9200H / LIMIT SWITCH (ND9200H/I00 and ND9200H/K00)

| | | | | | | | | |
|----|----|----|----|----|----|----|----|-----|
| 1. | 2. | 3. | 4. | 5. | 6. | 7. | 8. | 9. |
| ND | 9 | 20 | 3 | H | E1 | T | / | K05 |

| 1. | PRODUCT GROUP | |
|----|---|-----------------------------------|
| ND | Intelligent Valve Controller | |
| 2. | SERIES CODE | |
| 9 | Series 9000 valve controller with universal shaft and attachment face according to standard VDI/VDE 3845, EC/EJ actuators and old Neles standard. Relevant shaft adapter included in mounting kits. When valve controllers are separate deliveries, shaft adapter kit is supplied. | |
| 3. | ENCLOSURE | |
| 20 | Flameproof (Ex d) IP66 / NEMA 4X enclosure | |
| 4. | SPOOL VALVE | PNEUMATIC CONNECTIONS (S, C1, C2) |
| 2 | Low capacity. Stroke volume of actuator < 1 dm ³ | 1/4 NPT |
| 3 | Medium capacity. Stroke volume of actuator 1...3 dm ³ | 1/4 NPT |
| 6 | High capacity. Stroke volume of actuator > 3 dm ³ | 1/4 NPT |
| 5. | COMMUNICATION / INPUT SIGNAL RANGE | |
| H | 4–20 mA, HART communication. Supply voltage 30 V DC. Load voltage: up to 9.5 V DC at 20 mA corresponding to 475 Ω (maximum voltage drop). | |
| 6. | APPROVALS OF STANDARD ENCLOSURE VALVE CONTROLLER | |
| E1 | Flameproof enclosure, M20 x 1.5 conduit entry. ATEX certifications: II 2 G Ex d IIC T4...T6 (EN 60079-0:2006, EN 60079-1:2004) II 2 D Ex tD A21 IP66 T100 °C (EN 61241-0:2006, EN 61241-1:2004) ND92_HE1: Ui ≤ 30 V Temperature range: T4: -40° to +85 °C / -40° to +185 °F T5: < +75 °C / < +167 °F ; T6: < +60 °C / < +140 °F | |
| E2 | Flameproof enclosure, 1/2 NPT conduit entry. Temperature range: -40° to +80 °C / -40° to +176 °F. FM certifications: Class I, Div 1. Groups A, B, C, D. Class II, Div 1, Groups E, F, G, Class III T4/T5/T6 Class I, Zone 1, AEx d IIC, T4/T5/T6, IP66/Type 4X CSA certifications: Class I, Div 1. Groups B, C, D, Class II, Div 1, Groups E, F, G, Class III T4/T5/T6 Ex d IIC T4/T5/T6, DIP A21, Ta100 °C, IP 66/NEMA 4X ND92_HE2: Ui ≤ 30 V Temperature range: T4: -40° to +85 °C / -40° to +185 °F T5: < +75 °C / < +167 °F ; T6: < +60 °C / < +140 °F | |
| E5 | Flameproof enclosure, 1/2 NPT conduit entry. Temperature range: -40° to +85 °C / -40° to +185 °F. INMETRO certifications: BR-Ex d IIC, T4/T5/T6, IP66 (IEC 60079-0/00, IEC 60079-1/01, NBR 9518/97, NBR 5363/98, IEC 60529/01) ND92_HE5: Ui ≤ 30 V Temperature range: T4: -40° to +85 °C / -40° to +185 °F T5: < +75 °C / < +167 °F ; T6: < +60 °C / < +140 °F | |

| 7. | OPTIONS OF VALVE CONTROLLER |
|----|---|
| | ND9_H_T only: Internal 2-wire (passive) position transmitter. Analogue position feedback signal, output 4–20 mA, supply voltage 12–30 V DC, external load resistance 0–780 Ω T ND92_HE1T and ND92_HE5T: Ui ≤ 30 V, Pmax = device limits itself, external load resistance 0–780 Ω ND92_HE2T: Ui ≤ 30 V, Pmax = device limits itself, external load resistance 0–780 Ω M Special corrosion resistant finish. External aluminium surfaces protected by hard anodizing with PTFE. Coating thickness 20 µm. Not painted. Not available with 7. sign G. G Exhaust adapter. 1 x 1/2 NPT thread, Not available with 7. sign M. Y Special construction, to be specified. |

| 8. | LIMIT SWITCH TYPE |
|----|--|
| | Inductive proximity switches, 2 pcs. IP66 / NEMA 4X enclosure. M20 x 1.5 conduit entry (2 pcs.). Option E2: 1/2 NPT conduit entry (2 pcs.). I02 P+F; NJ2-12GK-SN, 2-wire type, DC; > 3 mA; < 1 mA. Intrinsically safe according to ATEX II 2 G Ex ia IIC T6. Temperature range -40° to +85 °C / -40° to +185 °F. I09 P+F; NCB2-12GM35-N0, 2-wire type, DC; > 3 mA; < 1 mA. Intrinsically safe according to ATEX II 2 G Ex ia IIC T6. Temperature range -25° to +85 °C / -13° to +185 °F. I56 ifm IFC2002-ARKG/UP, 2-wire type, DC; 150 mA, 10–36 V DC, leakage current < 0.6 mA. Temperature range -20° to +80 °C / -4° to +176 °F. Mechanical micro switches, 2 pcs. IP66 / NEMA 4X enclosure. M20 x 1.5 conduit entry (2 pcs.). Option E2: 1/2 NPT conduit entry (2 pcs.). K05 OMRON D2VW-5; 3 A - 250 V AC, 0.4 A - 125 V DC, 5 A - 30 V DC. Temperature range -40° to +80 °C / -40° to +176 °F. K06 OMRON D2VW-01; gold plated contacts, 100 mA - 30 V DC / 125 V AC. Temperature range -40° to +80 °C / -40° to +176 °F. |
| 9. | OPTIONS OF LIMIT SWITCH |
| Y | Special construction, to be specified. |

Metso Automation Inc.

Europe, Levytie 6, P.O. Box 310, 00811 Helsinki, Finland. Tel. +358 20 483 150. Fax +358 20 483 151

North America, 44 Bowditch Drive, P.O. Box 8044, Shrewsbury, MA 01545, USA. Tel. +1 508 852 0200. Fax +1 508 852 8172

Latin America, Av. Independência, 2500-Iporanga, 18087-101, Sorocaba-São Paulo, Brazil. Tel. +55 15 3235 9700. Fax +55 15 3235 9748/49

Asia Pacific, 238A Thomson Road, #25-09 Novena Square Tower A, 307684 Singapore. Tel. +65 6511 1011. Fax +65 6250 0830

China, 19/F, the Exchange Beijing, No. 118, Jianguo Lu Yi, Chaoyang Dist, 100022 Beijing, China. Tel. +86-10-6566-6600. Fax +86-10-6566-2575

Middle East, Roundabout 8, Unit AB-07, P.O. Box 17175, Jebel Ali Freezone, Dubai, United Arab Emirates.

Tel. +971 4 883 6974. Fax +971 4 883 6836

www.metso.com/automation

