



### 3.7. Maintenance & Management

- 3.7.1.** Provide protection and maintain conditions during & after installation that ensure installed firestop systems are without damage or deterioration at the time of Substantial Completion. If, despite such protection, damage or deterioration occurs, damaged/deteriorated systems shall be removed and replaced with new ones.
- 3.7.2.** The condition of installed firestop systems shall be visually inspected by the owner or owner's representative annually. Damaged, altered or breached firestop systems shall be properly repaired, restored or replaced to comply with applicable codes as per the guidelines of Civil Defense.
- 3.7.3.** Any new openings made therein for passage of through penetrants shall be protected with approved firestop system to comply with applicable codes as per the guidelines of Civil Defense.

### 3.8. Civil Defence Acceptance

- 3.8.1.** The main consultant, the firestop system manufacturer, firestop system installer, firestop specialist and the house of expertise shall jointly sign off the installation and provide final inspection report for Civil Defence' acceptance as evidence of compliance.