

## Managing objects

[Managing system objects](#) / Barcode readers

### Barcode readers

Barcode readers are the system representations of your cameras and barcode scanners. You can do a variety of tasks for barcode readers, such as connecting and disconnecting them.

#### In this section:

[Connecting and disconnecting barcode readers](#)

Connecting and disconnecting a barcode reader controls the flow of barcode data into the barcode reader from the camera or barcode scanner. A barcode reader can only receive barcode data if it is connected.

Parent topic: [Managing system objects](#)