

Configuring

[Configuring](#) / [Configuring the system to use inserters](#) / Configuring inserter controllers

Configuring inserter controllers

You must configure the inserter controllers in your installation to communicate with RICOH ProcessDirector.

In this section:

[Configuring inserter controllers to communicate with RICOH ProcessDirector](#)

File-based inserter controllers must read control files from RICOH ProcessDirector, and inserter controllers that write results files must send the results files to RICOH ProcessDirector.

[Configuring inserter controllers to write results files](#)

You must configure the inserter controller to write results files that contain the information that RICOH ProcessDirector needs to identify the job and the documents in the job.

Parent topic: [Configuring the system to use inserters](#)