

HEADLIGHT (LHD w/o DAYTIME RUNNING LIGHT)

SERVICE HINTS

HEAD LP RELAY

1-2 : Closed with the light control SW at **HEAD** position or the dimmer SW at **FLASH** position

C14 COMBINATION SW

7-16 : Closed with the dimmer SW at **HIGH** or **FLASH** position

8-16 : Closed with the dimmer SW at **FLASH** position

13-16 : Closed with the light control SW at **HEAD** position

○ : PARTS LOCATION

Code	See Page	Code	See Page	Code	See Page
C10	98 (LHD)	H6	97 (LHD)	J5	99 (LHD)
C14	98 (LHD)	H7	97 (LHD)	R7	99 (LHD)
H5	97 (LHD)	H8	97 (LHD)		

○ : RELAY BLOCKS

Code	See Page	Relay Blocks (Relay Block Location)
1	80 (LHD)	Engine Room No.1 R/B (Engine Compartment Right)
2	80 (LHD)	Engine Room No.2 R/B (Engine Compartment Right)

○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1A	82 (LHD)	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)
1F		
1G	82 (LHD)	Engine Room Main Wire and Driver Side J/B (Left Kick Panel)
2F	84 (LHD)	Instrument Panel Wire and Passenger Side J/B (Right Kick Panel)
2I		
2M	84 (LHD)	Engine Room Main Wire and Passenger Side J/B (Right Kick Panel)

▽ : GROUND POINTS

Code	See Page	Ground Points Location
EC	112 (LHD)	Left Fender Apron
IG	114 (LHD)	Cowl Side Panel RH

