

SEAT BELT WARNING (LHD)

SYSTEM OUTLINE

SEAT BELT WARNING SYSTEM

When the ignition SW is turned to the ON position, the signal is input to the body ECU. At this time, to determine whether or not the driver fastens the seat belt, the signal from the buckle SW LH is input to TERMINAL DBKL of the body ECU. If the driver does not fasten the seat belt, the seat belt warning light in the combination meter flashes and the alarm buzzer goes on, in response to the communication control of the body ECU etc.

If the passenger does not fasten the seat belt, the signals from the buckle SW RH and seat belt warning occupant detection sensor are input to TERMINAL P-S/B of the A/C control assembly and through communication control of the body ECU etc. the passenger seat belt warning light in the A/C control assembly is flashed.

SERVICE HINTS

B8 BUCKLE SW LH

1-2 : Continuity with driver's seat belt in use

B11 BUCKLE SW RH AND SEAT BELT WARNING OCCUPANT DETECTION SENSOR

1-2 : Continuity with front passenger's seat belt in use

U1 UNLOCK WARNING SW

1-2 : Continuity with ignition key in cylinder

○ : PARTS LOCATION

Code		See Page	Code	See Page	Code		See Page
A14	A	98 (LHD)	B8	102 (LHD)	E2	A	96 (LHD)
A15	B	98 (LHD)	B11	100 (LHD)	E3	B	96 (LHD)
B6	A	98 (LHD)	C10	98 (LHD)	J5		99 (LHD)
B7	B	98 (LHD)	D4	98 (LHD)	J9		99 (LHD)
B8		100 (LHD)	D7	100 (LHD)	U1		99 (LHD)

○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1E	82 (LHD)	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)
1G	82 (LHD)	Engine Room Main Wire and Driver Side J/B (Left Kick Panel)
1H	82 (LHD)	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)
1L		
2B	84 (LHD)	Engine Room Main Wire and Passenger Side J/B (Right Kick Panel)
2E	84 (LHD)	Instrument Panel Wire and Passenger Side J/B (Right Kick Panel)
2G		
2H		
2I		
2L	84 (LHD)	Floor Wire and Passenger Side J/B (Right Kick Panel)

□ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IA3	114 (LHD)	Instrument Panel Wire and Engine Room Main Wire (Near the Driver Side J/B)
IH3	116 (LHD)	Instrument Panel Wire and Floor Wire (Near the Passenger Side J/B)
BE1	120 (LHD)	Floor No.2 Wire and Front Seat LH Wire (Under the Driver's Seat)

▽ : GROUND POINTS

Code	See Page	Ground Points Location
EC	112 (LHD)	Left Fender Apron
ID	114 (LHD)	Cowl Side Panel LH
IG	114 (LHD)	Cowl Side Panel RH
IH	114 (LHD)	Front Floor Panel Center LH
BJ	118 (LHD)	Front Floor Panel LH
BL	118 (LHD)	Front Floor Panel RH

