

SERVICE HINTS

A14 CLOCK [A/C CONTROL ASSEMBLY]

5-GROUND : Always approx. **12** volts (Power for clock)

4-GROUND : Approx. **12** volts with ignition SW at **ACC** or **ON** position (Power for indication)

14-GROUND : Always continuity

○ : PARTS LOCATION

Code	See Page	Code	See Page	Code	See Page
A14	98 (LHD)	J6	99 (LHD)	J7	99 (LHD)
	106 (RHD)		107 (RHD)		107 (RHD)

○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1A	82 (LHD)	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)
1I	88 (RHD)	Instrument Panel Wire and Driver Side J/B (Right Kick Panel)
2B	84 (LHD)	Engine Room Main Wire and Passenger Side J/B (Right Kick Panel)
2F	84 (LHD)	Instrument Panel Wire and Passenger Side J/B (Right Kick Panel)
2I	84 (LHD)	Instrument Panel Wire and Passenger Side J/B (Right Kick Panel)
	90 (RHD)	Floor No.2 Wire and Passenger Side J/B (Left Kick Panel)
2L	90 (RHD)	Instrument Panel Wire and Passenger Side J/B (Left Kick Panel)

▽ : GROUND POINTS

Code	See Page	Ground Points Location
ID	114 (LHD)	Cowl Side Panel LH
BJ	128 (RHD)	Front Floor Panel LH