

IGNITION

SERVICE HINTS

I15 IGNITION SW

7-6 : Closed with the ignition SW at **ON** or **ST** position

○ : PARTS LOCATION

Code	See Page	Code	See Page	Code	See Page
E6	96 (LHD)	I3	97 (LHD)	I6	97 (LHD)
	104 (RHD)		105 (RHD)		105 (RHD)
I1	97 (LHD)	I4	97 (LHD)	I15	99 (LHD)
	105 (RHD)		105 (RHD)		107 (RHD)
I2	97 (LHD)	I5	97 (LHD)	N2	97 (LHD)
	105 (RHD)		105 (RHD)		105 (RHD)

○ : RELAY BLOCKS

Code	See Page	Relay Blocks (Relay Block Location)
1	80 (LHD)	Engine Room No.1 R/B (Engine Compartment Right)
	81 (RHD)	Engine Room No.1 R/B (Engine Compartment Left)

○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1D	82 (LHD)	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)
1K	82 (LHD)	Engine Room Main Wire and Driver Side J/B (Left Kick Panel)
2D	84 (LHD)	Instrument Panel Wire and Passenger Side J/B (Right Kick Panel)
	90 (RHD)	Instrument Panel Wire and Passenger Side J/B (Left Kick Panel)
2G	90 (RHD)	Engine Room Main Wire and Passenger Side J/B (Left Kick Panel)
2K		
2M	84 (LHD)	Engine Room Main Wire and Passenger Side J/B (Right Kick Panel)

□ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
EA1	112 (LHD)	Engine Wire and Engine Room Main Wire (Inside of the ECU Box)
	122 (RHD)	

▽ : GROUND POINTS

Code	See Page	Ground Points Location
EB	112 (LHD)	Rear Side of Cylinder Head
	122 (RHD)	

○ : SPLICE POINTS

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
E1	112 (LHD)	Engine Wire	E2	122 (RHD)	Engine Wire
	122 (RHD)		E3	112 (LHD)	
E2	112 (LHD)			122 (RHD)	

