

RADIO AND PLAYER (RHD 8 SPEAKER)

SERVICE HINTS

S9 (A) STEREO COMPONENT AMPLIFIER

(A)16-GROUND : Approx. **12** volts with ignition SW at **ACC** or **ON** position

(A) 7-GROUND : Always approx. **12** volts

(A)12-GROUND : Always continuity

○ : PARTS LOCATION

Code	See Page	Code		See Page	Code		See Page
A29	106 (RHD)	N4	B	109 (RHD)	S9	A	107 (RHD)
F11	108 (RHD)	N5	C	109 (RHD)	S10	B	107 (RHD)
F12	108 (RHD)	R3	B	107 (RHD)	T8	A	109 (RHD)
F13	108 (RHD)	R6	E	107 (RHD)	T9	B	109 (RHD)
F14	108 (RHD)	R14		109 (RHD)	W5		109 (RHD)
J6	107 (RHD)	R15		109 (RHD)	W6		109 (RHD)

○ : RELAY BLOCKS

Code	See Page	Relay Blocks (Relay Block Location)
1	81 (RHD)	Engine Room No.1 R/B (Engine Compartment Left)

○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
11	88 (RHD)	Instrument Panel Wire and Driver Side J/B (Right Kick Panel)

□ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IA3	124 (RHD)	Instrument Panel Wire and Engine Room Main Wire (Near the Passenger Side J/B)
IB1	124 (RHD)	Instrument Panel Wire and Floor No.2 Wire (Near the Passenger Side J/B)
IB2		
IC1	124 (RHD)	Front Door LH Wire and Instrument Panel Wire (Left Kick Panel)
IH2	126 (RHD)	Instrument Panel Wire and Floor Wire (Near the Driver Side J/B)
IH3		
II1	126 (RHD)	Front Door RH Wire and Instrument Panel Wire (Left Kick Panel)

▽ : GROUND POINTS

Code	See Page	Ground Points Location
IG	124 (RHD)	Front Floor Panel Center LH

○ : SPLICE POINTS

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
I1	126 (RHD)	Instrument Panel Wire			

