



INSPECTION

INSPECT EXTENSION HOUSING BUSHING

Using a calipers gauge, measure the inside diameter of the extension housing bushing.

Maximum inside diameter: 40.08 mm (1.5779 in.)

If the inside diameter is greater than the maximum, replace the extension housing.