

SERVICE HINTS

R18 REMOTE CONTROL MIRROR SW

- 9-6 : Continuity with the operation SW at **DOWN** or **RIGHT** position
- 6-10 : Continuity with the operation SW at **UP** or **LEFT** position
- 4-9, 3-10 : Continuity with the retractor SW at **RETRACTION** position
- 3-9, 4-10 : Continuity with the retractor SW at **RETURN** position
- 9-GROUND : Approx. **12** volts with the ignition SW at **ACC** or **ON** position
- 10-GROUND : Always continuity

: PARTS LOCATION

Code	See Page	Code	See Page	Code	See Page
J5	99 (LHD)	R16	101 (LHD)	R18	101 (LHD)
J12	100 (LHD)	R17	101 (LHD)		

: JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1B	82 (LHD)	Front Door LH Wire and Driver Side J/B (Left Kick Panel)
1G	82 (LHD)	Engine Room Main Wire and Driver Side J/B (Left Kick Panel)
1L	82 (LHD)	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)

: CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IC1	114 (LHD)	Front Door LH Wire and Instrument Panel Wire (Left Kick Panel)
II1	116 (LHD)	Front Door RH Wire and Instrument Panel Wire (Right Kick Panel)

: GROUND POINTS

Code	See Page	Ground Points Location
EC	112 (LHD)	Left Fender Apron
IG	114 (LHD)	Cowl Side Panel RH