

# LEXUS NAVIGATION SYSTEM (LHD)

## SYSTEM OUTLINE

The LEXUS navigation system displays the operating status and instructions for the automatic air conditioner or radio and player, as well as trip information. Additionally, the navigation system precisely measures the current vehicle position, displays the map obtained from the map database on the screen, and informs the route to the destination shown on the map using voice guidance.

## SERVICE HINTS

### N6 (D) NAVIGATION ECU

(D) 3-GROUND : Always approx. **12** volts

(D) 9-GROUND : Approx. **12** volts with ignition SW at **ACC** or **ON** position

(D) 6-GROUND : Always continuity

### M1 MULTI-DISPLAY

3-GROUND : Always approx. **12** volts

### R8 REMOTE CONTROL RECEIVER

5-GROUND : Approx. **12** volts with ignition at **ACC** or **ON** position

1-GROUND : Always continuity

## ○ : PARTS LOCATION

Code	See Page	Code	See Page	Code	See Page
B1   B	96 (LHD)	J3   B	97 (LHD)	N4   B	101 (LHD)
C3	96 (LHD)	J6	99 (LHD)	N5   C	101 (LHD)
C10	98 (LHD)	J9	99 (LHD)	N6   D	101 (LHD)
D4	98 (LHD)	J11	99 (LHD)	R2   A	99 (LHD)
F11	100 (LHD)	J13	100 (LHD)	R3   B	99 (LHD)
F13	100 (LHD)	M1	99 (LHD)	R5   D	99 (LHD)
J1	97 (LHD)	N1   A	97 (LHD)	R8	99 (LHD)
J2   A	97 (LHD)	N3   A	101 (LHD)	S9	99 (LHD)

## ○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1A	82 (LHD)	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)
1E		
1F		
1G	82 (LHD)	Engine Room Main Wire and Driver Side J/B (Left Kick Panel)
1K		
2B	84 (LHD)	Engine Room Main Wire and Passenger Side J/B (Right Kick Panel)
2E	84 (LHD)	Instrument Panel Wire and Passenger Side J/B (Right Kick Panel)
2G		
2L	84 (LHD)	Floor Wire and Passenger Side J/B (Right Kick Panel)

## □ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IC1	114 (LHD)	Front Door LH Wire and Instrument Panel Wire (Left Kick Panel)
IH1	116 (LHD)	Instrument Panel Wire and Floor Wire (Near the Passenger Side J/B)
IH2		
IH3		

## ▽ : GROUND POINTS

Code	See Page	Ground Points Location
ID	114 (LHD)	Cowl Side Panel LH
IE	114 (LHD)	Instrument Panel Center
BL	118 (LHD)	Front Floor Panel RH

