

J POWER SOURCE (Current Flow Chart)

Engine Room No.1 R/B (See Page 80 (LHD) or 81 (RHD))

Fuse		System	Page
7.5A	ALT-S	Charging	154
7.5A	TEL	Cellular Mobile Telephone	422
10A	H-LP L LWR	Headlight (LHD w/ Daytime Running Light)	186
		Headlight (LHD w/o Daytime Running Light)	190
		Headlight (RHD)	194
10A	H-LP LVL	Headlight Beam Level Control	388
10A	H-LP R LWR	Headlight (LHD w/ Daytime Running Light)	186
		Headlight (LHD w/o Daytime Running Light)	190
		Headlight (RHD)	194
10A	HORN	Horn	382
		Theft Deterrent (RHD)	306
10A	TURN-HAZ	Turn Signal and Hazard Warning Light (LHD)	222
		Turn Signal and Hazard Warning Light (RHD)	224
15A	ETCS	Cruise Control	360
		ECT and A/T Indicator	352
		Engine Control (LHD)	158
		Engine Control (RHD)	170
15A	H-LP LH	Headlight (RHD)	194
15A	H-LP RH	Combination Meter	442
		Headlight (RHD)	194
20A	AM2	Engine Control (LHD)	158
		Engine Control (RHD)	170
		Ignition	150
		Starting	148
20A	EFI	Cruise Control	360
		ECT and A/T Indicator	352
		Engine Control (LHD)	158
		Engine Control (RHD)	170
		Engine Immobiliser System	182
20A	RADIO NO.1	Radio and Player (LHD 6 Speaker)	426
		Radio and Player (RHD 6 Speaker)	430
		Radio and Player (LHD 8 Speaker)	434
		Radio and Player (RHD 8 Speaker)	438
30A	CDS FAN	Radiator Fan and Condenser Fan	448
30A	H-LP CLN	Headlight Cleaner	384
30A	RDI FAN	Radiator Fan and Condenser Fan	448
40A	MAIN	Automatic Light Control (RHD)	274
		Headlight (LHD w/ Daytime Running Light)	186
		Headlight (LHD w/o Daytime Running Light)	190
		Headlight (RHD)	194
		Headlight Cleaner	384

* These are the page numbers of the first page on which the related system is shown.

Fuse		System	Page
40A	MAIN	Rear Fog Light (LHD)	202
		Rear Fog Light (RHD)	206
		Starting	148
		Theft Deterrent (RHD)	306
60A	ABS	ABS and Traction Control	366
120A	ALT	ABS and Traction Control	366
		Automatic Light Control (RHD)	274
		Charging	154
		Headlight (LHD w/ Daytime Running Light)	186
		Illumination (LHD)	214
		Illumination (RHD)	218
		Light Reminder (LHD)	338
		Light Reminder (RHD)	342
		Multiplex Communication System (LHD)	232
		Multiplex Communication System (RHD)	248
		Power Window (LHD)	318
		Power Window (RHD)	324
		Radiator Fan and Condenser Fan	448
		Rear Window Defogger and Mirror Heater	410
		Taillight	210
		Theft Deterrent (RHD)	306

Engine Room No.2 R/B (See Page 80 (LHD) or 81 (RHD))

Fuse		System	Page
7.5A	DRL	Headlight (LHD w/ Daytime Running Light)	186
10A	H-LP L UPR	Headlight (LHD w/ Daytime Running Light)	186
		Headlight (LHD w/o Daytime Running Light)	190
		Headlight (RHD)	194
10A	H-LP R UPR	Combination Meter	442
		Headlight (LHD w/ Daytime Running Light)	186
		Headlight (LHD w/o Daytime Running Light)	190
		Headlight (RHD)	194

Driver Side J/B (See Page 82 (LHD) or 88 (RHD))

Fuse		System	Page
7.5A	PANEL	Combination Meter	442
		Headlight (LHD w/ Daytime Running Light)	186
		Illumination (LHD)	214
		Illumination (RHD)	218
		Light Reminder (LHD)	338
		Light Reminder (RHD)	342
		Multiplex Communication System (LHD)	232
		Multiplex Communication System (RHD)	248

* These are the page numbers of the first page on which the related system is shown.

J POWER SOURCE (Current Flow Chart)

Fuse		System	Page
7.5A	PANEL	Rear Fog Light (LHD)	202
		Rear Fog Light (RHD)	206
		Theft Deterrent (RHD)	306
7.5A	STARTER	ECT and A/T Indicator	352
		Engine Control (LHD)	158
		Engine Control (RHD)	170
		LEXUS Navigation System (LHD)	414
		LEXUS Navigation System (RHD)	418
		Starting	148
10A	A/C	Automatic Air Conditioner (LHD)	452
		Automatic Air Conditioner (RHD)	458
10A	ECU-IG	ABS and Traction Control	366
		Automatic Air Conditioner (LHD)	452
		Automatic Air Conditioner (RHD)	458
		Automatic Light Control (RHD)	274
		Door Lock Control (LHD)	278
		Door Lock Control (RHD)	284
		Double Locking (RHD)	312
		Headlight (LHD w/ Daytime Running Light)	186
		Interior Light (LHD)	262
		Interior Light (RHD)	268
		Light Reminder (LHD)	338
		Light Reminder (RHD)	342
		Moon Roof	404
		Multiplex Communication System (LHD)	232
		Multiplex Communication System (RHD)	248
		Power Window (LHD)	318
		Power Window (RHD)	324
		Radiator Fan and Condenser Fan	448
		Seat Belt Warning (LHD)	330
		Seat Belt Warning (RHD)	334
		Shift Lock	400
		Theft Deterrent (RHD)	306
		Wireless Door Lock Control (LHD)	290
		Wireless Door Lock Control (RHD)	298
10A	GAUGE	ABS and Traction Control	366
		Back-Up Light	226
		Cellular Mobile Telephone	422
		Charging	154
		Combination Meter	442
		Cruise Control	360
		ECT and A/T Indicator	352
		Engine Control (LHD)	158
		Engine Control (RHD)	170

* These are the page numbers of the first page on which the related system is shown.

Fuse		System	Page
10A	GAUGE	Front Window Deicer	408
		LEXUS Navigation System (LHD)	414
		LEXUS Navigation System (RHD)	418
		Light Reminder (LHD)	338
		Light Reminder (RHD)	342
		Multiplex Communication System (LHD)	232
		Multiplex Communication System (RHD)	248
		Power Window (LHD)	318
		Power Window (RHD)	324
		Rear Window Defogger and Mirror Heater	410
		Seat Belt Warning (LHD)	330
		Seat Belt Warning (RHD)	334
		Shift Lock	400
		Stop Light	228
		Taillight	210
		Turn Signal and Hazard Warning Light (LHD)	222
		Turn Signal and Hazard Warning Light (RHD)	224
10A	RADIO NO.2	Automatic Air Conditioner (LHD)	452
		Automatic Air Conditioner (RHD)	458
		Clock	380
		Door Lock Control (LHD)	278
		Door Lock Control (RHD)	284
		Double Locking (RHD)	312
		Interior Light (LHD)	262
		Interior Light (RHD)	268
		LEXUS Navigation System (LHD)	414
		LEXUS Navigation System (RHD)	418
		Light Reminder (LHD)	338
		Light Reminder (RHD)	342
		Multiplex Communication System (LHD)	232
		Multiplex Communication System (RHD)	248
		Power Window (LHD)	318
		Power Window (RHD)	324
		Radio and Player (LHD 6 Speaker)	426
		Radio and Player (RHD 6 Speaker)	430
		Radio and Player (LHD 8 Speaker)	434
		Radio and Player (RHD 8 Speaker)	438
		Remote Control Mirror (LHD)	346
		Remote Control Mirror (RHD)	348
		Seat Belt Warning (LHD)	330
		Seat Belt Warning (RHD)	334
		Shift Lock	400
		Theft Deterrent (RHD)	306
		Wireless Door Lock Control (LHD)	290

* These are the page numbers of the first page on which the related system is shown.

J POWER SOURCE (Current Flow Chart)

Fuse		System	Page
10A	RADIO NO.2	Wireless Door Lock Control (RHD)	298
10A	SRS-ACC	SRS	373
10A	TAIL	Front Fog Light (LHD)	198
		Front Fog Light (RHD)	200
		Taillight	210
15A	CIG	Cigarette Lighter	378
15A	SEAT HTR	Seat Heater	390
15A	STOP	ABS and Traction Control	366
		Cruise Control	360
		ECT and A/T Indicator	352
		Engine Control (LHD)	158
		Engine Control (RHD)	170
		Shift Lock	400
		Stop Light	228
15A	WASHER	Headlight Cleaner	384
		Wiper and Washer (LHD)	392
		Wiper and Washer (RHD)	396
20A	D FR P/W	Multiplex Communication System (LHD)	232
		Multiplex Communication System (RHD)	248
		Power Window (LHD)	318
		Power Window (RHD)	324
20A	DOOR	Door Lock Control (LHD)	278
		Door Lock Control (RHD)	284
		Double Locking (RHD)	312
		Interior Light (LHD)	262
		Interior Light (RHD)	268
		Light Reminder (LHD)	338
		Light Reminder (RHD)	342
		Multiplex Communication System (LHD)	232
		Multiplex Communication System (RHD)	248
		Power Window (LHD)	318
		Power Window (RHD)	324
		Seat Belt Warning (LHD)	330
		Seat Belt Warning (RHD)	334
		Theft Deterrent (RHD)	306
		Wireless Door Lock Control (LHD)	290
		Wireless Door Lock Control (RHD)	298
20A	FR DEF	Front Window Deicer	408
25A	WIPER	Wiper and Washer (LHD)	392
		Wiper and Washer (RHD)	396
30A	D P/SEAT	Power Seat	350
30A	RR DEF	Rear Window Defogger and Mirror Heater	410

* These are the page numbers of the first page on which the related system is shown.

Passenger Side J/B (See Page 84 (LHD) or 90 (RHD))

Fuse		System	Page
30A	S/ROOF	Moon Roof	404
40A	RR DEF	Rear Window Defogger and Mirror Heater	410
7.5A	DOME	Interior Light (LHD)	262
		Interior Light (RHD)	268
		Multiplex Communication System (LHD)	232
		Multiplex Communication System (RHD)	248
		Wireless Door Lock Control (LHD)	290
		Wireless Door Lock Control (RHD)	298
7.5A	ECU-B2	Headlight (LHD w/ Daytime Running Light)	186
		Rear Fog Light (LHD)	202
		Rear Fog Light (RHD)	206
		Theft Deterrent (RHD)	306
7.5A	IGN	Cruise Control	360
		ECT and A/T Indicator	352
		Engine Control (LHD)	158
		Engine Control (RHD)	170
		SRS	373
7.5A	OBD	Engine Control (LHD)	158
		Engine Control (RHD)	170
		SRS	373
7.5A	SRS-B	Combination Meter	442
		Interior Light (LHD)	262
		Interior Light (RHD)	268
		Multiplex Communication System (LHD)	232
		Multiplex Communication System (RHD)	248
		SRS	373
7.5A	TV	LEXUS Navigation System (LHD)	414
		LEXUS Navigation System (RHD)	418
10A	MPX-B	Automatic Air Conditioner (LHD)	452
		Automatic Air Conditioner (RHD)	458
		Automatic Light Control (RHD)	274
		Clock	380
		Combination Meter	442
		Door Lock Control (LHD)	278
		Door Lock Control (RHD)	284
		Double Locking (RHD)	312
		Interior Light (LHD)	262
		Interior Light (RHD)	268
		Light Reminder (LHD)	338
		Light Reminder (RHD)	342
		Multiplex Communication System (LHD)	232
		Multiplex Communication System (RHD)	248

* These are the page numbers of the first page on which the related system is shown.

J POWER SOURCE (Current Flow Chart)

Fuse		System	Page
10A	MPX-B	Power Window (LHD)	318
		Power Window (RHD)	324
		Seat Belt Warning (LHD)	330
		Seat Belt Warning (RHD)	334
		Theft Deterrent (RHD)	306
		Wireless Door Lock Control (LHD)	290
		Wireless Door Lock Control (RHD)	298
15A	DOOR DL	Double Locking (RHD)	312
15A	FR FOG	Front Fog Light (LHD)	198
		Front Fog Light (RHD)	200
15A	MIR HTR	Rear Window Defogger and Mirror Heater	410
20A	D RR P/W	Multiplex Communication System (LHD)	232
		Multiplex Communication System (RHD)	248
		Power Window (LHD)	318
		Power Window (RHD)	324
20A	P FR P/W	Multiplex Communication System (LHD)	232
		Multiplex Communication System (RHD)	248
		Power Window (LHD)	318
		Power Window (RHD)	324
40A	HEATER	Automatic Air Conditioner (LHD)	452
		Automatic Air Conditioner (RHD)	458

* These are the page numbers of the first page on which the related system is shown.